



GE Fanuc Automation

Computer Numerical Control Products

*Series 16 / 18 / 20 / 21
Macro Compiler / Macro Executor*

Programming Manual

GFZ-61803E-1/07

August 1997

Warnings, Cautions, and Notes as Used in this Publication

Warning

Warning notices are used in this publication to emphasize that hazardous voltages, currents, temperatures, or other conditions that could cause personal injury exist in this equipment or may be associated with its use.

In situations where inattention could cause either personal injury or damage to equipment, a Warning notice is used.

Caution

Caution notices are used where equipment might be damaged if care is not taken.

Note

Notes merely call attention to information that is especially significant to understanding and operating the equipment.

This document is based on information available at the time of its publication. While efforts have been made to be accurate, the information contained herein does not purport to cover all details or variations in hardware or software, nor to provide for every possible contingency in connection with installation, operation, or maintenance. Features may be described herein which are not present in all hardware and software systems. GE Fanuc Automation assumes no obligation of notice to holders of this document with respect to changes subsequently made.

GE Fanuc Automation makes no representation or warranty, expressed, implied, or statutory with respect to, and assumes no responsibility for the accuracy, completeness, sufficiency, or usefulness of the information contained herein. No warranties of merchantability or fitness for purpose shall apply.

PROGRAMMING

1. OUTLINE	3
2. MACRO COMPILER AND MACRO EXECUTOR	7
2.1 MACRO COMPILER	8
2.1.1 Equipment Needed for Compile	8
2.1.2 Equipment Connection	9
2.1.3 Compiling Procedure (Main Flow)	10
2.1.4 Compiling Procedure Using System P Series (Details)	10
2.1.5 Table for Editing by P-G Mate	12
2.1.6 P-CODE Loader Function	13
2.1.6.1 Operation	14
2.1.6.2 Notes	19
2.1.6.3 Parameters	20
2.1.6.4 Alarms	22
2.2 MACRO EXECUTOR CONTROLS	23
3. EXECUTION MACRO	24
3.1 CALL CODE AND PROGRAM NO.	25
3.1.1 Calling Subprogram O9000 by T code	26
3.1.2 Calling subprograms O9001-9003 by M code	26
3.1.3 Calling a Subprogram Using Specified Codes	26
3.1.4 Calling Macros O9010-9019 by G Code	27
3.1.5 Modal Call Using G Code	27
3.1.6 Calling Macros O9020-9029 by M Code	27
3.1.7 Calling a Macro Using a T Code	28
3.1.8 M Code Subprogram Call with Range Specified	28
3.1.9 Calling Macros with a G Code by Specifying the Range	29
3.1.10 Function for Calling Macros with an Axis Address	29
3.2 ARGUMENT DESIGNATION	31
3.3 LIMITATION FOR EXECUTION MACRO	32
4. CONVERSATIONAL MACRO FUNCTION AND AUXILIARY MACRO FUNCTION	34
4.1 CONVERSATIONAL MACRO	35
4.2 AUXILIARY MACRO FUNCTION	38
4.3 EXECUTION CONTROL CODE	39
4.4 CONVERSATIONAL MACRO EXECUTION CONTROL VARIABLE #8500, #8550, #8551	40
4.5 NOTES	41
5. MACRO VARIABLES	42
5.1 MACRO VARIABLES	43
5.2 LOCAL VARIABLES (#1 TO #33 OR FOR REFERENCING THE P-CODE VARIABLES OF ARRAY TYPE, #1 TO #99)	43
5.3 COMMON VARIABLES (#100 TO #149 AND #500 TO #531)	43
5.4 P-CODE VARIABLES #10000-	44
5.5 VARIABLES OF EXPANDED P-CODE (#20000 -)	45
5.6 DISPLAYING VARIABLES	46

6. FUNCTIONS OF THE MACRO EXECUTOR	47
6.1 SCREEN DISPLAY FUNCTION	51
6.1.1 Coordinates System of Screen	51
6.1.2 Screen Display Control Code	53
6.1.3 Graphic Painting Function	59
6.1.4 Graphic Cursor Function	61
6.1.5 Rectangular Display Function	61
6.1.6 Intensity Modulation Mode Display of 9" Monochrome CRT	63
6.1.7 Displaying Seven Soft Keys Data on the Twelve Soft Keys Type	64
6.1.8 Function Screen Control Function	65
6.1.9 Function for Masking the Status Display on the Conventional Macro Screen	65
6.1.10 Shift Function for Adjusting the Graphic Screen	65
6.2 ADDRESS FUNCTIONS	66
6.3 READING AND WRITING A PMC ADDRESS	67
6.4 READER PUNCHER INTERFACE CONTROL BY CONVERSATIONAL MACRO	69
6.4.1 Outline	69
6.4.2 Function Details	70
6.4.3 Inputting and Outputting Macro Variables	72
6.4.4 Extending the Function for Inputting and Outputting a Macro Variable	75
6.4.5 FANUC Floppy Cassette Control	77
6.4.6 End Code (#8539)	80
6.5 REFERENCING AND READING NC PROGRAM WITH CONVERSATIONAL MACRO	81
6.5.1 Outline	81
6.5.2 Recording of a New Program	82
6.5.3 Deleting a Program	82
6.5.4 Reading a Specified Block	82
6.5.5 Block Writing	84
6.5.6 Block Deletion	86
6.5.7 Condensation of Program	87
6.5.8 End Code (#8529)	87
6.5.9 Notes	87
6.5.10 Address Code Table	87
6.6 CONTINUOUS INPUT BY CURSOR AND PAGE KEY	89
6.7 MASKING OF O, N NUMBER APPEARANCE	90
6.8 READING AND PRESETTING CUTTING TIME AND CUTTING DISTANCE BY CONVERSATIONAL MACRO	90
6.8.1 Reading and Presetting Cutting Time (#8553)	90
6.8.2 Reading and Presetting Cutting Distance (#8554)	90
6.9 READING AND PRESETTING RELATIVE COORDINATES BY CONVERSATIONAL MACRO	91
6.9.1 Reading Relative Coordinates	91
6.9.2 Presetting Relative Coordinates	91
6.10 KEY-INPUT AND DATA-INPUT CONTROL	92
6.11 CURSOR CONTROL	94
6.12 PROCESSING ARRAY TYPE P-CODE VARIABLES	95
6.13 TORQUE LIMIT CONTROL	98
6.14 DATA READING OF A/D CONVERTER (Series 16/18)	99
6.15 KEY-IN LINE CONTROL	100
6.16 READING THE BACKGROUND EDITING STATUS	101
6.17 READING THE NUMBER OF CATALOGED PROGRAMS	101
6.18 READING THE SIZE OF THE FREE SPACE IN THE CNC PROGRAM MEMORY	101

6.19	READING THE REMAINING TRAVELING DISTANCE	101
6.20	OFFSET MEMORY C AND EXTENDED SYSTEM VARIABLE OF THE WORKPIECE COORDINATE SYSTEM (Series 16/18)	101
6.21	PMC AXIS CONTROL	102
6.21.1	PMC Axis Control by the G Code	102
6.21.2	PMC axis Control by Variables	104
6.22	INTERLOCK FUNCTION FOR AXIS DIRECTION	106
6.23	FUNCTION FOR SEPARATING UI FROM UO OF THE P-CODE PROGRAM	107
6.24	REFERENCING COMMON VARIABLES OF CUSTOM MACROS	108
6.25	DISPLAYING THE CONVERSATIONAL MACRO SCREEN WHEN THE POWER IS TURNED ON	108
6.26	LEAVING THE SCREEN UNCHANGED WHEN THE  KEY IS PRESSED	108
6.27	FUNCTION FOR FINDING A P-CODE WORK NUMBER	109
6.28	FUNCTION FOR CALLING A USER PROGRAM BY AN EXECUTION MACRO	110
6.28.1	Function	110
6.28.2	Calling Format	110
6.28.3	Multiple Calls	110
6.29	OPERATION FUNCTIONS (LOGARITHM, EXPONENT, ARCSINE, ARCCOSINE)	113
6.29.1	Overview	113
6.29.2	Operation	113
6.30	FUNCTION FOR IDENTIFYING THE PRESSED MDI KEY USING A CONVERSATIONAL MACRO	114
6.30.1	Overview	114
6.30.2	Function	114
6.30.3	Key Number List	114
6.31	WINDOW FUNCTION	117
6.31.1	Overview	117
6.31.2	Referenced System Information	118
6.31.3	Detailed Description of Reference System Information	122
6.32	EXTERNAL CHARACTER REGISTRATION/DISPLAY FUNCTION (Series 20)	136
6.33	EXECUTION MACRO CALL MASK FUNCTION	139
6.33.1	Function	139
6.33.2	Macro Variables	140
7.	Series 16/18 2-PATH DEDICATED CONTROL FUNCTION	141
7.1	COMMON CONVERSATIONAL MACRO SCREEN	142
7.2	COMMON CONVERSATIONAL MACRO VARIABLE	143
8.	FUNCTIONS FOR STOPPING A CONVERSATIONAL MACRO	144

APPENDIX

A.	MACRO PROGRAM EXAMPLE	147
A.1	EXAMPLE-1:CIRCULAR CUTTING INPUT AND EXECUTION	148
A.1.1	Source Program for Main Program	148
A.1.2	Source Program for Input Control	150
A.1.3	Source Program for Cursor Control	151
A.1.4	Source Program for Character Display	152
A.1.5	Source Program for Address Variables	156

A.1.6	Source Program for Graphic Display and Circle Cutting	158
A.1.7	Execution Macro	161
A.1.8	Flow Chart	162
A.1.9	Explanation of Program	168
A.1.10	Program Example for PMC Sequence	171
A.2	EXAMPLE-2 EXAMPLE FOR KEY INPUT AND CURSOR CONTROL	185
A.2.1	Source program List	185
A.2.2	Specification	190
A.2.2.1	Type of Screen	190
A.2.2.2	Variable Data	191
A.2.3	Program Structure	193
A.2.4	Flow Chart	194
A.2.5	Coding	195
A.3	STANDARD MACRO PROGRAM	200
A.3.1	Standard Routine List	200
A.3.2	Area of Variable Used	200
A.3.3	Explanation of Variable Area	200
A.3.4	Standard Routine	204
A.3.5	List for Source Program	208
A.3.6	Explanation of Program	212
A.4	SCREEN LAYOUT	216
B.	MACRO COMPLIER OPERATION (Series 16-A/18-A)	217
B.1	OPERATION ON P-G	218
B.1.1	Special Notes	218
B.1.2	Basic Operations	218
B.1.2.1	Connectiing to FA writer	218
B.1.3	Inputting Macro Program from Keyboard	218
B.1.4	Correcting Macro Program (Screen edit)	219
B.1.5	Correcting Macro Program (Command edit)	220
B.1.6	Outputting Files to Floppy Disk	220
B.1.7	Inputting Files to P-G from Floppy Disk	221
B.1.8	Handling Floppy Disk	221
C.	DATA ON MACRO COMPILER	223
C.1	ARGUMENT TRANSFER	224
C.2	SUMMARY OF SYSTEM VARIABLES (REFER TO OPERATOR'S MANUAL FOR DETAILS)	226
D.	MACRO COMPILER/MACRO EXECUTOR WITH CAP I (Series 16/18)	229
D.1	OUTLINE	230
D.2	EQUIPMENT NEEDED FOR COMPILING	231
D.3	COMPILING PROCEDURE USING SYSTEM P-G	233
D.4	ROM MODULE	241
D.5	ADDITION OF OPTIONS	241
D.6	LIMITATION ON THE USER'S PROGRAM	241
E.	FANUC SUPER CAP T/CAP II T MACRO COMPILER/EXECUTOR (Series 16/18)	242
E.1	GENERAL	243
E.2	EQUIPMENT REQUIRED FOR DEVELOPMENT	244

E.3	TYPE OF USER PROGRAMS	246
E.4	DETAILS OF NEW USER PROGRAMS	247
E.5	USER PROGRAM SIZE	250
E.6	SOFTWARE PACKAGE FOR USER PROGRAM DEVELOPMENT	251
E.6.1	Software Package Associated with Tool Data and Cutting Condition Data	251
E.6.1.1	Overview	251
E.6.1.2	Details of the Software Package Associated with Tool Data	251
E.6.1.3	Details of the Software Package Associated with the Cutting Condition Data	257
E.6.2	Software Package Associated with Process Data	295
E.6.2.1	Overview	295
E.6.2.2	Specifications	295
E.6.3	Software Package Associated with the Interface Between User Programs and the System	343
E.6.3.1	Overview	343
E.6.3.2	Interface Between the Conversational Programming Menu and User Programs	343
E.6.3.3	Display Character Specification	348
E.6.3.4	Executable Macro Program Numbers	353
E.6.3.5	System Variable for Conversational Programming Menu Indication	353
E.6.3.6	System Variable for Window ON/OFF State Indication	353
E.6.3.7	System Variable for Conversational Mode/NC Mode Indication	353
E.6.3.8	System Variable for Execution Mode Indication	354
E.6.3.9	Conversational Macro Program Executed Immediately Before Execution	354
E.6.3.10	Parameters and System Variables	354
E.6.3.11	Program Numbers Usable with User Programs	354
E.6.4	Data Which Can Be Referred to by Macro Programs	355
E.6.4.1	Outline	355
E.6.4.2	Description	355
E.6.5	Displaying the Basic Menu Screen by a User Program (Not Supported by Ver.1.)	370
E.6.5.1	Overview	370
E.6.5.2	Setting a parameter	370
E.6.5.3	Details	370
E.6.6	Display of a Window by a User Program, Depending on the Cursor Position (Not Supported by Ver.1.)	371
E.6.6.1	Overview	371
E.6.6.2	Details	371
E.6.7	Using a User Program to Display Guidance on the Detailed Program Data Screen (Not Supported by Ver.1.)	396
E.6.7.1	Overview	396
E.6.7.2	Details	396
E.6.8	Displaying a Window by Using a User Program and Pressing a Soft Key on the Program Process Data Screen (Not Supported by Ver.1.)	398
E.6.8.1	Overview	398
E.6.8.2	Details	398
E.6.9	Displaying a Window by Using a Soft Key on the Tooling Data Screen (Not Supported by Ver.1.) ..	399
E.6.9.1	Overview	399
E.6.9.2	Setting a parameter	399
E.6.9.3	Details	400
E.6.10	Starting the Chuck/Tailstock Barrier Setting Screen (Not Supported by Ver.1.)	401
E.6.10.1	Overview	401
E.6.10.2	Details	401

E.7	SETTING PARAMETERS USED FOR COMPILER	403
E.7.1	Overview	403
E.7.2	Setting Parameters Used for Compiling	403
E.8	COMMAND USED IN THE DYNAMIC GRAPHIC FUNCTION	405
E.8.1	Outline	405
E.8.2	Description	405
E.8.3	Example	413
E.8.4	Transferring a Workpiece in Animated Simulation	414
E.9	COMMANDS FOR READING/WRITING VARIABLES STORED IN THE REMOTE HEAD ...	416
E.9.1	Outline	416
E.9.2	Description	416
E.10	FUNCTION FOR CONVERTING PROGRAMS USED FOR THE AUXILIARY AND TRANSFER PROCESSES TO NC STATEMENTS	417
E.10.1	Outline	417
E.10.2	Setting Parameters	417
E.10.3	Format Used for NC Statements Only for Calling Sub-programs	418
E.10.4	Note	418
E.11	IMPROVEMENTS FEATURED BY VERSION 4	419
E.11.1	Modifications Made to the Link File	420
E.12	IMPROVEMENTS FEATURED BY FANUC SUPER CAP II T	421
E.12.1	Software Package Related to Process Data	421
E.12.1.1	Specifications	421
E.12.2	Software Package Related to the Interface Between the System and User Programs	423
E.12.2.1	Interface Between the Conversational Program Screen and User Programs	423
E.12.2.2	Specification of Display Characters	424
E.12.3	Modifications Made to the Link File	426
F.	MACRO VARIABLES USED IN THE MACRO EXECUTOR FUNCTIONS	427
G.	DIFFERENCES BETWEEN SERIES 0 AND Series 16/18 (CONVERSION FROM FS0 TO FS16/18)	430
G.1	CHARACTER DISPLAY (G243)	431
G.2	DISPLAY COLOR SPECIFICATION (G240)	431
G.3	KEY INPUT VARIABLE (#8501)	431
G.4	CONTROLLING CONVERSATIONAL MACRO FUNCTION SCREENS (#8510)	432
G.5	PMC WRITE CONTROL CODE	432
G.6	PMC READ CONTROL CODE	432
G.7	CALLING A SUBPROGRAM WITH AN AXIS ADDRESS	433
G.8	CALLING A MACRO WITH A T CODE	434
G.9	A BIT CANNOT BE SPECIFIED TO READ A PARAMETER.	435
G.10	THE ROM SIZE IS SPECIFIED DIFFERENTLY.	435
G.11	THE USE OF P-CODE DEDICATED VARIABLES HAS BEEN EXTENDED.	436
G.12	THE METHOD FOR DISPLAYING P-CODE VARIABLES #10000 OR LARGER HAS BEEN CHANGED.	437
H.	G CODES THAT CAN BE USED BY THE CONVERSATIONAL AND AUXILIARY MACROS	438
I.	INTERNAL CODE	440

J. PARAMETERS	445
J.1 COMPILE PARAMERTES	446
J.2 EXECUTOR PARAMETER	453
K. ERROR CODES	455
K.1 COMPLIER ERROR CODES (SYSTEM P)	456
K.2 EXECUTOR ERROR CODE	459
L. CHARACTER COORDINATE SYSTEM	460
M. SCREEN DISPLAY ON A VGA GRAPHICS DISPLAY UNIT (SUPPORTED BY SUPER CAP EXECUTOR ONLY)	463
M.1 DISPLAY COLOR SPECIFICATION EXTENSION	464
M.1.1 Overview	464
M.2 SCREEN ERASURE EXTENSION	466
M.2.1 Overview	466
M.3 EXTENSION OF NUMBER OF DISPLAY LINES	467
M.3.1 Overview	467
M.3.2 Compile Parameters	468
M.4 GRAPHICS COORDINATE SYSTEM	469
M.4.1 Overview	469
N. DISPLAY WITH A BACKGROUND COLOR ON THE CUSTOM SCREEN	470
N.1 OVERVIEW	471
N.2 COMMAND FOR DISPLAY WITH A BACKGROUND COLOR	471
N.3 ITEMS OF THE COMMAND FOR DISPLAY WITH A BACKGROUND COLOR (P_)	472
N.4 DETAILS OF ITEMS OF THE COMMAND FOR DISPLAY WITH A BACKGROUND COLOR (P_)	473
N.5 COMPILE PARAMETERS	479
N.6 RELATED ITEMS	480
N.6.1 Related Compile Parameters	480
N.6.2 Conversational/Auxiliary Macro Alarms	481
N.6.3 Graphics Display Screen Erasure	481
N.6.4 Color Palette Difference between Character Display and Graphics Display	481

PROGRAMMING

1

OUTLINE

NC programs include those which are prepared by custom macro and very seldom altered and those which may differ from one another according to relevant machining such as part programs. A batch handling of these programs of different characters may cause 1 quicker battery consumption, or spoil the custom macro in case of misoperation.

To solve a problem, this function will convert the custom macro prepared by a machine tool builders into an execution format, register it to the ROM module, and enables it to be executed.

- (1) Since the custom macro is converted into an execution format and registered, the execution speed is high. This will shorten the machining time and improve the machining accuracy.
- (2) The registration to the ROM eliminates battery consumption and prevents custom macro damage through misoperation. This will improve the reliability.
- (3) Since the registered program is not indicated on the program display, the machine tool builder's knowhow can be protected.
- (4) Since the custom macro is registered in the ROM, the program edit memory can effectively be used.
- (5) The user can call the macro with an easy call procedure without being conscious of the registered program. On the program edit memory, custom macros can be prepared and executed in the standard manner.
- (6) The user can confirm the operation using RAM module before making a ROM. (excluding Series 21-B)
- (7) Conversational macro function can compile machine tool builders original screen.

The models covered by this manual, and their abbreviations are :

Model name	Abbreviation		
FANUC Series 16-TA	16-TA	Series 16-A	Series 16
FANUC Series 16-MA	16-MA		
FANUC Series 16-TTA	16-TTA		
FANUC Series 16-GCA	16-GCA		
FANUC Series 16-GSA	16-GSA		
FANUC Series 16-PA	16-PA		
FANUC Series 16-LA	16-LA		
FANUC Series 16-TB	16-TB	Series 16-B	
FANUC Series 16-MB	16-MB		
FANUC Series 16-PB	16-PB		
FANUC Series 16-LB	16-LB		
FANUC Series 160-TB	160-TB		
FANUC Series 160-MB	160-MB		
FANUC Series 160-PB	160-PB		
FANUC Series 160-LB	160-LB		
FANUC Series 16-TC	16-TC	Series 16-C	
FANUC Series 16-MC	16-MC		
FANUC Series 16-PC	16-PC		
FANUC Series 160-TC	160-TC		
FANUC Series 160-MC	160-MC		
FANUC Series 160-PC	160-PC		
FANUC Series 16i-TA	16i-TA	Series 16i-A	
FANUC Series 16i-MA	16i-MA		
FANUC Series 16i-PA	16i-PA		
FANUC Series 16i-LA	16i-LA		
FANUC Series 160i-TA	160i-TA		
FANUC Series 160i-MA	160i-MA		
FANUC Series 160i-PA	160i-PA		
FANUC Series 160i-LA	160i-LA		
FANUC Series 18-TA	18-TA	Series 18-A	Series 18
FANUC Series 18-MA	18-MA		
FANUC Series 18-TTA	18-TTA		
FANUC Series 18-GCA	18-GCA		
FANUC Series 18-GSA	18-GSA		
FANUC Series 18-PA	18-PA		
FANUC Series 18-TB	18-TB	Series 18-B	
FANUC Series 18-MB	18-MB		
FANUC Series 18-PB	18-PB		
FANUC Series 180-TB	180-TB		
FANUC Series 180-MB	180-MB		
FANUC Series 180-PB	180-PB		

Model name	Abbreviation		
FANUC Series 18-TC	18-TC	Series 18-C	Series 18
FANUC Series 18-MC	18-MC		
FANUC Series 18-PC	18-PC		
FANUC Series 180-TC	180-TC		
FANUC Series 180-MC	180-MC		
FANUC Series 180-PC	180-PC		
FANUC Series 18i-TA	18i-TA	Series 18i-A	
FANUC Series 18i-MA	18i-MA		
FANUC Series 18i-PA	18i-PA		
FANUC Series 180i-TA	180i-TA		
FANUC Series 180i-MA	180i-MA		
FANUC Series 180i-PA	180i-PA		
FANUC Series 20-FA	20-FA	Series 20-A	Series 20
FANUC Series 20-TA	20-TA		
FANUC Series 21-TB	21-TB	Series 21-B	Series 21
FANUC Series 21-MB	21-MB		
FANUC Series 210-TB	210-TB		
FANUC Series 210-MB	210-MB		
FANUC Series 21i-TA	21i-TA	Series 21i-A	
FANUC Series 21i-MA	21i-MA		
FANUC Series 210i-TA	210i-TA		
FANUC Series 210i-MA	210i-MA		

The 21-TB model is available in two types: control unit type A and control unit type B. The two types may also be referred to as the 21-TB (control unit A) and the 21-TB (control unit B) when the descriptions of the types differ.

In this manual, the models may be classified as indicated below.

System		Model name
Lathe system	T series	16-TA, 16-TTA, 16-GCA, 16-TB, 160-TB, 16-TC, 160-TC, 16i-TA, 160i-TA, 18-TA, 18-TTA, 18-GCA, 18-TB, 180-TB, 18-TC, 180-TC, 18i-TA, 180i-TA, 20-TA, 21-TB, 210-TB, 21i-TA, 210i-TA
Machining center system	M series	16-MA, 16-GSA, 16-PA, 16-LA, 16-MB, 16-PB, 16-LB, 160-MB, 160-PB, 160-LB, 16-MC, 16-PC, 160-MC, 160-PC, 16i-MA, 16i-PA, 16i-LA, 160i-MA, 160i-PA, 160i-LA, 18-MA, 18-GSA, 18-PA, 18-MB, 18-PB, 180-TB, 180-MB, 180-PB, 18-MC, 18-PC, 180-MC, 180-PC, 18i-MA, 18i-PA, 180i-MA, 180i-PA, 20-FA, 21-MB, 210-MB, 21i-TA, 210i-TA

The words used in the explanation are defined as follows.

”P-CODE program” :

Execution type macro program prepared by a machine tool builder, being compiled and registered to ROM.

”Execution macro” :

Program to operate machine in P-CODE program.

”Auxiliary macro” :

Program to make an auxiliary operation for the execution macro and the conversational macro in P-CODE program.

"Conversational macro" :


Program to operate screen in P-CODE program.

"User program" :

Program prepared by end-user for program edit memory.

2

MACRO COMPILER AND MACRO EXECUTOR




2.1 MACRO COMPILER

NOTE


For the macro compiler for other than Series 16/18-A, refer to the "FAPT MACRO COMPILER (For Personal Computer) PROGRAMMING MANUAL (B-66102E)." (When reading the manual, skip Section 2.1.)

The NC program is converted into an execution form (P-CODE program), output to the ROM module, and registered into a ROM. Mount the prepared ROM module on the Series 16-A or Series 18 to execute the registered P-CODE program to be called from the user program by means of G, M and T codes or specified code set by parameter.



2.1.1 Equipment Needed for Compile

MACRO Compiler Developing Equipment (When SYSTEM P series is used)




NOTE

Refer to Appendix D for macro executor with graphic conversation.

2.1.2 Equipment Connection


Connect FA writer to CN2 or CN3 for SYSTEM P series.



NOTE

Use CN1 normally for PPR.

2.1.3 Compiling Procedure (Main Flow)



2.1.4 Compiling Procedure Using System P Series (Details)

- (1) Equipment connection
Connect FA writer to CN2 or CN3 of SYSTEM P series.
Generally, connect FANUC PPR to CN1.
- (2) Turning on power of SYSTEM P series
Turn SYSTEM P series power ON.
- (3) Loading system
 1. Load the FAPT MACRO compiler system disk to either drive unit.
 2. Keep pressing the "LOAD" key on the left upper side of the keyboard for a few seconds.
 3. When the menu is displayed, loading operation is completed.
- (4) Source program input and correction
For detailed operation method, refer to APPENDIX B.
 1. "R2" (Display and edit)
 2. No. "1" (Custom MACRO program display and edit) <NL>
 - (a) Input from keyboard
 - "<F0> = OFF, <F1> = OFF, <F2> = OFF"
 - PROGRAM = "IN" <NL>
 - INPUT = "Oxxxx" <NL>,"
Date <NL> , , , ,
only "<NL>" at the last
 - (b) Reading from floppy disk
 - "<F0> = OFF, <F1> = OFF, <F2> = OFF"

- PROGRAM = "IN" <NL>
 - FD = "OK_ @File Name <NL>
or "OK : File No. <NL>
" " : Space
_
- (c) Program correction within memory
- "<F0> = ON, <F1> = OFF, <F2> = OFF"
 - PROGRAM = "Oxxxx" <NL>
 - Correct a program, using a screen editor.
- (5) Setting Compile parameter
- Not required when the compile parameter is already set.
1. For no initial screen, press <NL> a few times.
 2. "R1" (setting)
NO.= "1" (Parameter) <NL>
 3. No. = "1" (parameter setting) <NL>
 4. Set the parameter, using the screen editor with "CHG".
 5. "R0" (End) when the setting of all parameters is completed
 6. Only <NL> (End of program)
- (6) Test compile
1. For no initial screen, press <NL> a few times.
 2. "R0" (Start)
 3. "<F3> = ON " : Displays a source program during compile.
"<F3> = OFF" : Displays o[NL]y program No. during compile.
 4. No. = "1" (Test compile) <NL>
 5. If an error occurs during compiling, correct the error and compile a program.
- (7) Setting FA writer Channel
1. "R1" (setting)
 2. No. = "2 " (ROM writer) <NL>
 3. The current ROM writer channel setting conditions are displayed on the CRT screen.
 4. CN1 = : "ON" <NL> : The channel is used.
: "OFF" <NL> : The channel is not used.
: only <NL> : No setting is changed.
 5. CN2 = : Same as above.
 6. CN3 = : Same as above.
 7. BUILT-IN ROM WRITER =
: Same as above (only P-G mate)
 8. No. = <NL> (End)
- (8) Preparations for FA writer
1. Install the erased ROM module to the FA writer.
 2. Turn the FA writer power ON.
 3. Set the FA writer to the remote mode.
- (9) ROM writing

Job		Command	Keyboard input (enter NL at end of command)	Notes
Major classification	Minor classification			
Deletion	Deletion n whole lines	DELETE	Line number1 [,line number2]	Delete the data from line number1 to line number2
	Delete string	DELETE	D \square (d) character (d), { ALL } ⁿ	
	Delete address data	ADELETE	AD \square address character	
	Delete lines containing a particular string	BDELETE	BD \square atring	The string can be an address character
Scaling to require values	Multiple of a pecific address	SCALE	S \square address character / n	n is the scaling factor
	Multiple of incremental NC data	ASCALE	AS \square address character / n	n is the scaling factor
Adding and sorting sequence numbers		SEQNO	SEQ \square initial value [, increment [, n]]	If n is given, add a sequence number every n blocks
Copy paper tape		COPY	COPY	Copies any sort of data on paper tape.
Modification support	Renumber lines	RENUMBER	REN[\square initial value [, increment]]	
	Change character used to display EOB	EOB	EOB \square Character	
	Display list of commands	HELP	H	
	NC data TH, TV check	THTV	THTV	Read in NC data from tape reader, and check TH, TV'
	Advance pointer	FIND	F \square { (d) string (d) } [,n]	Advance pointer by n lines Advance to a line containing a particular string
	Move pointer back	RACK	Bn	Move pointer back n lines. If n is omitted, move pointer back to preceding line
	Comment	*	* comment string	Insert any commnet after *
Process control	Start editing	EDIT	ED \square { FAPT NC } [, { EIA ISO }]	
	Change data type and code system	MODE	M \square { FAPT NC } [, { EIA ISO }]	
	End editing	END	E	
Special conversion	Change from integer NVC data to floating point NC data	POINT	PO \square X ₁ / n ₁ [, X _i / n _i] ⁵ _{i=2}	
	Change from floating point NC data to integer NC data	INTEGER	INT \square X ₁ / n ₁ [, X _i / n _i] ⁵ _{i=2}	
	ADD a specified amount	ADD	ADD \square X ₁ / n ₁ [, X _i / n _i] ⁵ _{i=2}	

2.1.6 P-CODE Loader Function

The P-CODE loader function transfers files in Motorola format S, which is a ROM format, to the RAM module installed in the Series 16/18-A or the Series 16-TTA (tool posts 1 and 2). The files are created by the macro compiler for the FANUC SYSTEM P-MODEL G (referred to hereafter as the P-G) or a personal computer (referred to hereafter as the PC). The P-CODE loader function also operates the macro executor in the RAM.

The RS-232C interface is used to connect the Series 16/18-A to the P-G or PC.

The communication parameters for transferring the file in the ROM format (referred to below as loading) depend on the parameters of the Series 16/18-A. The parameters must be set before loading.

If the  and  keys are pressed simultaneously on the MDI, and the power to the Series 16/18-A is turned off, this function displays the data transfer screen (loading screen). For the Series 16/18-TTA, the function displays the data transfer selection screen. When tool post 1 or 2 is selected on the selection screen, the loading screen is displayed. Data can only be transferred while the loading screen is displayed.

Issue a data transfer command in the P-G or PC. For a description of the transfer commands and other details, refer to the specifications of the FAPT Macro Compiler.

The function eliminates the need to store data on a ROM chip when developing a macro program.

The P-CODE loader function is executed while a power-on sequence is suspended. The functions of the CNC are disabled while the data transfer selection screen or loading screen is displayed. The P-CODE loader function requires an executor option and reader/punch control option.

2.1.6.1 Operation

- (1) The communication parameters for loading depend on the parameters of the Series 16/18-A. Specify parameters such as the channels to be used and the baud rate before loading.
- (2) Turn off the power to the Series 16 and install a RAM module instead of the ROM module for custom macros. In Series 16/18-TTA, install the RAM module(s) in tool post 1 and/or tool post 2. Connect the Series 16/18 to the P-G or PC via the RS-232C interface.
- (3) Turn on the power to the Series 16/18 while simultaneously pressing the  and  keys on the MDI. Hold down the CAN and PROG keys until the title, MACRO COMPILER/EXECUTOR P-CODE LOADER is displayed.

- (4) On the Series 16/18-TTA, however, the following data transfer selection screen is displayed instead of the above title. Pressing address key M on the screen selects tool post 1 and pressing address key S selects tool post 2. Pressing numeric key 0 starts the Series 16/18-TTA and enables the executor to execute the macros loaded in the RAM.

```

MACRO COMPILER/EXECUTOR P-CODE LOADER

(I/O PARAMETERS)                (DATA TRANSFER)

I/O CHANNEL    = 0                (MAPPING - 1MB)
I/O UNIT       = 0
BAUDRATE       =11
STOP BIT       = 1
INPUT CODE     = 1

LOADING PATH 1 : YES (PUSH M KEY)
LOADING PATH 2 : YES (PUSH S KEY)
LOADING END    : YES (PUSH 0 KEY)

```

For the Series 16/18-TTA only

- (5) On CNCs other than the Series 16/18-TTA, performing the operation in step (3) displays the following screen. On the Series 16/18-TTA, selecting a tool post displays the following screen and initializes the RAM.

The following screen remains displayed while the RAM is being initialized. If the RAM has low capacity, the screen in step (6) may be displayed instead of the following screen.

The selected tool post, HEAD 1 or HEAD 2, is displayed on the second line of the screen for the Series 16/18-TTA.

```

MACRO COMPILER/EXECUTOR P-CODE LOADER
HEAD 1/HEAD 2
(I/O PARAMETERS)                (DATA TRANSFER)

I/O CHANNEL    = 0                (MAPPING - 1MB)
I/O UNIT       = 0
BAUDRATE       =11
STOP BIT       = 1
INPUT CODE     = 1

OMM RAM MODULE INITIALIZE

```

Screen for the Series 16/18-TTA
(The screens shown in subsequent steps are for the same CNC series.)

- (6) When the RAM module has been initialized, the following loading screen is displayed:

```

MACRO COMPILER/EXECUTOR P-CODE LOADER

(I/O PARAMETERS)                (DATA TRANSFER)

I/O CHANNEL    = 0                (MAPPING - 1MB)
I/O UNIT       = 0
BAUDRATE       =11
STOP BIT       = 1
INPUT CODE     = 1

LOADING READY ? : YES (PUSH 1 KEY)
    
```

- (7) When the P-G or PC is ready for data transmission, press numeric key 1. Then, the system waits for loading. When this screen is displayed, execute a data transfer command on the P-G or PC to start data transmission.

```

MACRO COMPILER/EXECUTOR P-CODE LOADER

(I/O PARAMETERS)                (DATA TRANSFER)
                                   ADR000000H:00
I/O CHANNEL    = 0                (MAPPING - 1MB)
I/O UNIT       = 0                _____
BAUDRATE       =11                _____
STOP BIT       = 1                _____
INPUT CODE     = 1                _____
                                   _____
                                   _____
                                   _____
    
```

(8) When the Series 16/18-A receives data, the following data reception state is displayed.

The transmitted data and its address are displayed.

Mapping is merely a term indicating how much RAM the created P-CODE program and executor occupy.

A single asterisk (*) refers to 16K bytes when a 2MB RAM module is installed and 8K bytes when a RAM module of 1MB or less is installed.

- When a RAM module of 1MB or less is installed

```

MACRO COMPILER/EXECUTOR P-CODE LOADER

(I/O PARAMETERS)                (DATA TRANSFER)
                                  ADRxxxxxxxxH:xx
I/O CHANNEL      = 0              (MAPPING - 1MB)
I/O UNIT         = 0              ****
BAUDRATE         =11              _____
STOP BIT         = 1              _____
INPUT CODE       = 1              _____
                                  _____
                                  _____
                                  _____
                                  _____

```

- When a 2MB RAM module is installed

```

MACRO COMPILER/EXECUTOR P-CODE LOADER

(I/O PARAMETERS)                (DATA TRANSFER)
                                  ADRxxxxxxxxH:xx
I/O CHANNEL      = 0              (MAPPING - 2MB)
I/O UNIT         = 0              ****
BAUDRATE         =11              _____
STOP BIT         = 1              _____
INPUT CODE       = 1              _____
                                  _____
                                  _____
                                  _____
                                  _____

```

- (9) When loading terminates normally, the following message is displayed. Pressing numeric key 1 starts the Series 16/18-A and enables the executor to execute the macros loaded in the RAM.

```

MACRO COMPILER/EXECUTOR P-CODE LOADER

(I/O PARAMETERS)          (DATA TRANSFER)
                           ADRxxxxxxxxH:xx
I/O CHANNEL = 0           (MAPPING - 1MB)
I/O UNIT    = 0           ****
BAUDRATE    =11           ****
STOP BIT    = 1           _____
INPUT CODE  = 1           _____

LOADING END   : TOTAL xxxxxxxxBYTES
PUSH 1 KEY    : CNC START WITH executor
    
```

When loading terminates normally for the Series 16/18-TTA, the following message is displayed. Pressing numeric key 1 returns to the screen in step (4). Select the next tool post on the screen.

```

MACRO COMPILER/EXECUTOR P-CODE LOADER
HEAD 1
(I/O PARAMETERS)          (DATA TRANSFER)
                           ADRxxxxxxxxH:xx
I/O CHANNEL = 0           (MAPPING - 1MB)
I/O UNIT    = 0           ****
BAUDRATE    =11           ****
STOP BIT    = 1           _____
INPUT CODE  = 1           _____

LOADING END   : TOTAL xxxxxxxxBYTES
PUSH 1 KEY    : RETURN TO HEAD SELECTION
    
```

- (10) If an error occurs during loading, the following message is displayed. To perform loading again, press the CAN key to retry from the beginning, that is, initializing the RAM in step (5). If an error such as a parameter setting error occurs in the Series 16/18-A, turn the power to the Series 16/18-A off then on again.

```

MACRO COMPILER/EXECUTOR P-CODE LOADER

(I/O PARAMETERS)                (DATA TRANSFER)
                                ADRxxxxxxxxH:xx
I/O CHANNEL   = 0                (MAPPING - 1MB)
I/O UNIT      = 0                *****
BAUDRATE      =11                _____
STOP BIT      = 1                _____
INPUT CODE    = 1                _____

(ERROR OCCURED)                  _____
ILLEGAL CHARACTER                  _____

LOADING RESTART ?   : YES (PUSH CAN KEY)
                   : NO  (TURN OFF POWER)

```

- (11) When an executor option or reader/punch control option is not selected, the following message is displayed. In this case, loading cannot be performed. Turn off the power.

```

MACRO COMPILER/EXECUTOR P-CODE LOADER

(I/O PARAMETERS)                (DATA TRANSFER)

I/O CHANNEL   = 0                (MAPPING - 1MB)
I/O UNIT      = 0
BAUDRATE      =11
STOP BIT      = 1
INPUT CODE    = 1

executor OPTION NOTHING
I/O OPTION NOTHING
I/O OPTION (CH2) NOTHING

PLEASE TURN OFF POWER

```

2.1.6.2

Notes

- (1) Either channel 1 or 2 is used for I/O for the Series 16 during loading. Data cannot be loaded using other channels.
- (2) Either ASCII or ISO code is used to transmit data. EIA codes cannot be used.
The setting of parameter ASI (bit 3 of parameter 101, 111, or 121) determines whether ASCII or ISO code is used to transmit data.
- (3) The settings of RS-232C parameters described in items (1) and (2) are displayed in the fields of I/O parameters on the loading screen. However, the parameters cannot be set on the screen.

- (4) Whether P-code data is transmitted together with the executor depends on the operation of the macro compiler even when parameter PCODE for loading by overwriting (bit 1 of parameter 8701) is 1.
- (5) When data is transferred for the first time after the RAM module is installed, set parameter PCODE (bit 1 of parameter 8701) to 0, so that the P-code data is transferred together with the macro executor.

2.1.6.3 Parameters

No.	
0020	Selection of an I/O device: I/O CHANNEL

Input setting enabled

Data type : Bytes

Valid range : 0 to 3

Selects an I/O device to be used.

- 0 : The device for channel 1 is selected.
(I/O device connected to JD5A of the main CPU board)
- 1 : The device for channel 1 is selected.
(I/O device connected to JD5A of the main CPU board)
- 2 : The device for channel 1 is selected.
(I/O device connected to JD5B of the main CPU board)

Either channel 1 or 2 can be used for I/O for the P-code loader.

No.	#7	#6	#5	#4	#3	#2	#1	#0
0101					ASI			SB2

Data type: Bits

SB2 : The number of stop bits is:

- 0 : 1
1 : 2

ASI : The following code is used for the data to be input.

- 0 : ISO code
1 : ASCII code

NOTE

The P-code loader cannot use EIA code.

No.	
0102	Specification number of the I/O device (when I/O CHANNEL = 0)

Data type: Bytes

Specify the number of the I/O device when I/O CHANNEL = 0 as follows:

Table 1

Setting	I/O device
0	RS-232C
1	FANUC CASSETTE ADAPTOR 1 (FANUC CASSETTE B1/B2)
2	FANUC CASSETTE ADAPTOR 3 (FANUC CASSETTE F1)
3	FANUC PROGRAM FILE MATE FANUC FA CARD ADAPTOR FANUC FLOOPY CASSETTE ADAPTOR FANUC SYSTEM P MODEL H
4	Not used
5	Portable tape reader
6	FANUC PPR FANUC SYSTEM P MODEL G FANUC SYSTEM P MODEL H

Specify 0 to use the P-code loader.

No.

Data type: Bytes

Specify the baud rate for the I/O device when I/O CHANNEL = 0 according to Table 2:

Table 2

Setting	Baud rate	Setting	Baud rate	Setting	Baud rate
1	50	5	200	9	2400
2	100	6	300	10	4800
3	110	7	600	11	9600
4	150	8	1200	12	19200

Specify the same baud rate for the P-code loader as that for the PC or P-G.

No.

#7	#6	#5	#4	#3	#2	#1	#0
				ASI			SB2

Data type: Bits

This parameter must be set when I/O CHANNEL = 1. The meanings of the bits correspond to those of the bits in parameter 101.

No.

Data type: Bytes

Specify the number of the I/O device when I/O CHANNEL = 1 according to Table 1.

No.

Data type: Bytes

Specify the baud rate for the I/O device when I/O CHANNEL = 1 according to Table 2.

No.	#7	#6	#5	#4	#3	#2	#1	#0
0121					ASI			SB2

Data type: Bits

This parameter must be set when I/O CHANNEL = 2. The meanings of the bits correspond to those of the bits in parameter 101.

No.	
0122	Number of the I/O device (when I/O CHANNEL = 2)

Data type: Bytes

Specify the number of the I/O device when I/O CHANNEL = 2 according to Table 1.

No.	
0123	Baud rate (when I/O CHANNEL = 2)

Data type: Bytes

Specify the baud rate for the I/O device when I/O CHANNEL = 2 according to Table 2.

No.	#7	#6	#5	#4	#3	#2	#1	#0
8701							PLD	

Data type: Bits

PLD In the P-code loader for the macro compiler or executor, the RAM is:

0 : Cleared with OMM and rewritten.

1 : Not cleared with OMM, but overwritten.

2.1.6.4 Alarms

Message	Explanation
EXECUTOR OPTION NOTHING	A macro executor option is not yet selected.
I/O OPTION NOTHING	Reader/punch control 1 option is not yet selected.
I/O OPTION (CH2) NOTHING	Reader/punch control 2 option is not yet selected.
ILLEGAL CHANNEL	A channel other than channel 1 or 2 is selected.
ILLEGAL CHARACTER	The transmitted data is not correct.
OVERRUN	Overrun error
FRAMING ERROR	Framing error
DSR SIGNAL OFF	Communication error
PARITY ERROR	Data without parity was transmitted.
CHECK SUM ERROR	Checksum error

2.2 MACRO EXECUTOR CONTROLS

The macro executor controls the execution of the P-CODE program created by the macro compiler.


The P-CODE program (execution macro) stored in the ROM can be called and executed by specifying G, M, T or original code set by parameter during compilation in the user program.

Custom macros can be created and executed in the user program, independently of P-CODE program.

3 EXECUTION MACRO

Only a registered P-CODE program cannot be executed. It is called from the user program by G, M, T code, or specified code by parameter setting, and executed. In case of macro call, argument designation is possible, and it is compared as a local variable at the P-CODE (execution macro) side.

Moreover, if a minus value is set to a parameter for macro call by G code, modal call of P-CODE program can be done by corresponding G code. Refer to 3.1.5 for details.



- (2) Difference between Subprogram Call (T, M) and Macro Call (G, M)
- Argument designation can be made in macro call. In subprogram call, however, argument designation is not possible without T code, special code and call code.
 - In subprogram call, after execution of another command than T- or M-code, it will branch to a subprogram. In macro call, however, it will branch off without doing anything.
 - In subprogram call, single block stop is made when another command than T- or M-code is commanded. In macro call, however, no stop is made.

3.1.1 Calling Subprogram O9000 by T code

The P-CODE program 09000 registered to the ROM can be called by a T code.

The commanded T code is stored as an argument in the common variable #149.

All the local variables will become <Vacant>.

N_ G_ X_ Y _ T < tttt >;

3.1.2 Calling subprograms O9001–9003 by M code


By commanding M codes which is designated by compilation parameter, the programs O9001, O9002, O9003” registered to the ROM can be called for subprograms. All the local variables are <Blank>.

N_ G_ X_ Y _ M<mm> ;

3.1.3 Calling a Subprogram Using Specified Codes

By setting character codes (decimal notation of ASCII codes) to the parameters (No. 6090, 6091) of CNC, the P-CODE program (09004, 09005) corresponding to the address can be called as a subprogram. The defined integer will be stored as a parameter to the macro variable (#146, #147). The actual use of this function is decided by specifying the appropriate compilation parameter (No. 9002#1, 9002#2, ACL1, ACL2).

Example) Compiler parameter (No. 9002#1, ACL=1)
When parameter No. 6090 = 66 at execution



Definable addresses for 16-TB/16-TA/GCA, 18-TB/18-TA/GCA, 20-TA, 21-TB: A, B, D, F, H, I, J, K, M, Q, R, S, T

Definable addresses for 16-MB/16-MA/GSA, 18-MB/18-MA/GSA, 20-FA, 21-MB: A, B, F, H, I, K, M, Q, R, S, T

3.1.4 Calling Macros O9010-9019 by G Code

By commanding G codes which is designated by compilation parameter (No. 9013 to 9022), the macro programs "O9010-O9019" registered to the ROM can be called.

Local variables without argument designation are <Vacant>.

N_ G<gg>< Argument designation>;

3.1.5 Modal Call Using G Code


A modal call can be used to call a macro when using G code.

When calling a G code is specified with a compilation parameter, continuous-state calling can be specified using a negative number.

Continuous-state calling is canceled with G167 or the G code specified by compilation parameter 9034.

During continuous-state calling, the values of address of each block for the user program are all arguments.

Example) When compilation parameter 9013 = -100



Multiple modal calls is not permitted.

3.1.6 Calling Macros O9020-9029 by M Code

By commanding M codes which is designated by compilation parameter (No. 9023 to 9032). the programs "O9020 - O9029" registered to the ROM can be called.

Local variables without argument designation will become <Vacant> .

N_ M<mm>< Argument designation>;

3.1.7 Calling a Macro Using a T Code

By setting compile parameter TMACC(No.9005#7) to 1, program of No.9008 registered to ROM can be called macros by specifying a T code in a user program.

All addresses specified in this block are used as arguments except that the T code is transferred to #27, values for address P and L are transferred to #16 and #12, respectively. Also G codes are transferred to variables #28 to #32 for each group.

Be sure that addresses shall be those available for CNC and the significant digits are those specified by the CNC.

Variable	Data to be transferred
#1-#26	Address data for each variable
#27	T code
#28	G code
#29	G code
#30	G code
#31	G code
#32	G code

NOTE

G codes are assigned to variables #28 to #32 in ascending order, starting with the lowest G code group number. When a G code of G code group 01 exists, G80 may be generated and assigned to #28 to #32.

Example) G91G28X123.45678T5678:
 #24=123.456
 #27=5678.0
 #28=28.0
 #29=91.0
 Other variables = < vacant >

3.1.8 M Code Subprogram Call with Range Specified

ROM-resident program 09009 can be called as a subprogram by using compilation parameters No. 9042 and No. 9043.

Specify the following codes in compilation parameters No. 9042 and No. 9043:

No. 9042 = M code indicating the lower limit

No. 9043 = M code indicating the upper limit

Examples are given below:

No. 9042 = 100

No. 9043 = 110

If the above codes are specified in the parameters upon compilation, specifying an M code within the range from M100 to M110 calls ROM-resident program O9009 as a subprogram.

3.1.9 Calling Macros with a G Code by Specifying the Range

The code specified by compilation parameters 9045 to 9047 can be used to call the programs registered in ROM.

Specifying call arguments is the same as calling macros with G code (3.1.4).

Specify the following for parameters 9045 to 9047:

Parameter 9045 : G code to start calling

Parameter 9046 : Number of P-CODE programs

Parameter 9047 : Number of the program to be called first

For example, suppose programs are compiled with 200 specified for parameter 9045, 100 specified for parameter 9046, and 1000 specified for parameter 9047. When G200 to G299 are specified, 100 programs from O1000 to O1099 compiled on the ROM can be called.

NOTE

- 1 Specifying call arguments is the same as calling macros with the G code specified by compilation parameters 9013 to 9022.
- 2 Continuous-state calling cannot be specified.
- 3 When the G code specified with compilation parameters 9013 to 9022 is specified, the specified parameters 9013 to 9022 are effective.

Parameter 9013 = 250

Parameter 9045 = 200

Parameter 9046 = 100

Parameter 9047 = 1000

When G250 is issued with the settings above, program O9010 is called.

3.1.10 Function for Calling Macros with an Axis Address

Axis address commands enable calling macros.

When AX1CL to AC8CL of compilation parameter 9005#0 to #3, 9008#0 to #3 are set to 1, the programs registered to ROM can be called by the axis address command.

The program number to be called is selected by compile parameter AXCLS (No. 9005#4) as follows:

AXCLS 1 : The program number to be called depends on a specified axis:

Program O9031 is called when 1st axis is specified.

Program O9032 is called when 2nd axis is specified.

: :

Program O9038 is called when 8th axis is specified.

0: Always program O9009 is called irrespective of specified axes.

In this case, all the addresses in the block specified axis address are passed for use as arguments. However, the specified axis address is passed to variable 27. Addresses P and L are passed to variable 16 and 12, respectively, for use as arguments. Up to five G codes in each G code group are passed to variables 28 to 32 starting from the group with the lowest number. When a G code of G code group 01 exists, G80 may be generated and assigned to #28 to #32.

When G code system A is used in the lathe system (T/TT), whether the axis addresses are called with an absolute or incremental command are informed to variable 33.

Variable No.	Address
#1 to #26	Usual argument address
#27	Specified axis address (1st to 8th)
#28	Specified G code
#29	Specified G code
#30	Specified G code
#31	Specified G code
#32	Specified G code
#33	Vacant for absolute address 1.0 for incremental address

If the following are specified when a 4th-axis address is B, for example:
G91G28B1.234567X123.4567;

The settings are passed to variables as follows:

123.456 to variable #24

1.234 to variable #27

28.0 to variable #28

91.0 to variable #29

Other variables: Null

The addresses transferred as arguments specified in a block used to call a macro make changes modal information of the CNC when calling the macro. In the above example, the CNC model of absolute/incremental command changes to G91 (incremental command) when a macro is called.

In the lathe system, for G code system A, and when a 2nd-axis address is Z (absolute) or W (incremental), the settings are passed to variables as follows:

Variable #27 = 100.0, variable #33 = <null> for Z100.;

Variable #27 = 100.0, variable #33 = 1.0 for W100.;

NOTE

The addresses those can be used and the range of the values specified to those addresses are the same as those allowed to each CNC model concerned.

3.2 ARGUMENT DESIGNATION

Argument designation is possible when calling a call. It can be referred to as a local variable at the P-CODE program side. Argument specification I and argument specification II are possible.

For arguments designation, negative symbol and decimal point can be used irrespective of the address.

Table 3.2(a) Argument specification I at P-CODE program call

Address of argument specification I	Local variable No.	Address of argument specification I	Local variable No.
A	#1	N (NOTE)	#14
B	#2	P (NOTE)	#16
C	#3	Q	#17
I	#4	R	#18
J	#5	S	#19
K	#6	T	#20
D	#7	U	#21
E	#8	V	#22
F	#9	W	#23
G (NOTE)	#10	X	#24
H	#11	Y	#25
L (NOTE)	#12	Z	#26
M	#13		

NOTE

It is available when compilation parameter bit5 of No.9008 is 1.

Table 3.2(b) Argument specification II at P-CODE program call

Address of argument specification II	Local variable No.	Address of argument specification II	Local variable No.
A	#1	K1	#6
B	#2	.	.
C	#3	I10	#31
I1	#4	J10	#32
J1	#5	K10	#33

3.3 LIMITATION FOR EXECUTION MACRO

Source program of execution macro should be programmed in the same way as for custom macro. But, there are some limits for execution.

(1) Macro call

Macro call from an execution macro is executed with "G65" as the custom macro. In the execution macro, since it is a macro program itself to be called from the user program with G (M, T) code or specified code, it is impossible to use a G CODE call, etc. from execution macro.

G65 P (Program No.) L (Number of repetition) <Argument specification>;

(2) Argument specification

Argument specification is the same as the custom macro.

(3) Variable

Expression, argument, etc. of variables are the same as those of the Custom macro.

NOTE

Common variables referred by a P-CODE program and Common variables referred by user program are completely different.
Refer to "5.3 Common variable".

(a) P-CODE variable (#10000 –)

Any number of 100 unit of P-CODE exclusive variables starting from #10000 can be used.

Since it can be used from execution, it is considered as extension of common variable #500.

However, execution macro cannot refer to P-CODE variable in arrangement type.

For details, refer to "5.4 P-CODE exclusive variable".

(4) Operation command

Operation commands can be used as with the custom macro.

(5) Control command

Both divergence and repetition commands can be used.

IF <Conditional expression> GOTO n;

WHILE <Conditional expression> DO m;

END m;(m=1,2,3)

(6) Modal call from execution macro

Modal call cannot be made.

(7) Macro and subprogram multiplexity in execution macro.

Separately from the user program multiplexity, 4-stack nesting of macro program, and 4-stack nesting of subprogram are possible on the execution macro.

(8) Cautions


(a) Separate registration of a program cannot be made. Max. 400 programs can be registered to the ROM.

(b) In one program, limit the sequence number used for branch destination (GOTO) to 200. In one program, the same sequence No. cannot be designated for others.

- (c) One block can accept designation of only one sequence number. Except the program No. "0" and the optional block skip "/", designate a sequence No. at the block head.
- (d) In T series multiple repetitive canned cycle cannot be executed in the P-CODE program. In case a program including a multiple repetitive canned cycle is registered and executed, the function cannot be guaranteed.
- (e) In T series programming through direct drawing dimensions programming cannot be made in the P-CODE program.
In case a program made through direct drawing dimension input is registered and executed the function cannot be guaranteed.

4

CONVERSATIONAL MACRO FUNCTION AND AUXILIARY MACRO FUNCTION



4.1 CONVERSATIONAL MACRO

The conversational macro function executes a program compiled by the macro compiler independently of the normal NC part program. This function basically is not affected by operation modes of NC . Accordingly, it works concurrently with the NC part program under execution independently even during the memory operation.

NOTE

The execution of the conversational macro function is processed at a lower level than that of the CNC operation internally. Therefore, the execution of the conversational macro function will not affect the processing speed of the CNC operation, but the processing speed of the conversational macro function may become slow while the CNC operation is ON.




Fig.4.1 Conversational macro function conceptual diagram

The conversational macro function is executed only when the conversational screen is selected with the function key  .

The conversational macro function executes its macro program whose program No. is the value of the conversational macro execution control variable #8500. The value of the conversational macro execution control variable #8500 is to be set with the parameter No. 9038 at compiling. The conversational macro function will not be executed when there is not a conversational macro program compiled whose program No. is the value of the conversational macro execution control variable #8500.


The conversational macro program, as well as NC part program, consists of macro sentences and NC sentences (specific G code commands).

The conversational macro program can describe all the macro statements used for the custom macro. And all the system variables and common variables which can be referred to in the P-CODE program can be read and written. But the conversational macro program has no local variables except for #1 to #99. They are used to refer an array type P-CODE variables #10000 's. Also, P-CODE variables are prepared for the conversational macro control.

It is impossible to execute the NC part program statement with the NC statement of the conversational macro program. They will be ignored though commnded. It is impossible to use any codes except the screen display codes and the execution control codes described in the following sections. And be sure that the NC statement of the conversational macro program have the addresses whose meanings and usage are different from those of the NC part program statement.

The CUSTOM screen started by the conversational macro program is under the same control as the other screens (POS screen, etc.). Therefore, finishing of the CUSTOM screen is necessary for changing over from one screen to another. Decide the timing to finish when executing M99 of the main program. Be careful about the condition of the conversational macro program, because if it is of a bad program example as shown below, it will be impossible to change the screen to another and HANG-UP STATE will be held. When another function key is pressed mistake, press

 again.



Program the conversational program so that it will be a cyclic like the PMC ladder program. That is, execute M99 without fail and it will return to the head of the main program or to the sequence No. specified with M99Pp.

Thus, avoid the programming that the divergence destination by GOTO will reverse direction.

NOTE

To select a conversational macro screen, press function key



To change the screen from the conversational macro screen to another screen such as current position screen or program screen, press the correspondence function key



If the Series 20 is your NC, press both right most and left most soft keys at the same time and the screen changes from the conversational macro screen to the current position display screen.

4.2 AUXILIARY MACRO FUNCTION

The auxiliary macro is always executed regardless of the selection screen while the conversational macro function is executed only when the conversational macro screen is selected in the function  .

The auxiliary macro function executes the auxiliary macro program with the program number set by parameter 9030 on compiling.

If parameter 9039 is equal to 0 or the auxiliary macro with a set program number has not been compiled, no auxiliary macro function is executed.

Major differences between the conversation macro and auxiliary macro functions are as in the following:

- 1) Auxiliary macro function is always executed regardless of the screen being displayed.
- 2) No screen display control code can be used in the auxiliary macro function. G202, G240, G242, G243, G01, G02, G03
- 3) No variables for controlling and cursor can be used in the auxiliary macro function.
#8501-#8509
- 4) The conversational macro function can control the program number executed by conversational macro execution control variable #8500. On the other hand, the auxiliary macro function always executes the program of the program number set by parameter 9039 on compiling.

NOTE

- 1 Switching to another screen is disabled while an auxiliary macro is controlling the reader/punch interface.
- 2 A larger auxiliary macro (requiring a longer time to execute) causes screen drawing to become slower.

The conversation macro function and auxiliary macro function are executed at the same execution level (lower level).

The execution processing is as shown in the following when both the conversation macro function and auxiliary macro function are specified.

- 1) CUSTOM screen selected
The auxiliary macro execution and conversation macro executed are repeated in this order.
- 2) Screen other than CUSTOM screen
A compilation parameter makes it possible to display CUSTOM screen at power on.

4.3 EXECUTION CONTROL CODE

The following control codes are prepared for execution control.

M98 : Subprogram call

M99 : Subprogram end

(1) Subprogram call (M98)

M98 Pp ;

A macro subprogram specified by address P is called. Frequency of calling the macro subprogram shall be up to quadruple.

(2) Subprogram end (M99)

M99 Pp ;

When command is done in the called subprogram, the calling program will be restored. When the address P is specified, the block of the sequence No. specified at P of the calling program will be restored.

Command M99 without fail at the end of the main program. The command of M99 in the main program is explained below.

When M99 is commanded in the main program, execution of the conversational macro function is finished once.

Once execution of the conversational macro function is started, the screen will not change over to another though the function key is depressed until execution of the conversational macro function ends at M99. Accordingly, it is necessary to command M99 at the end of the main program.

When the function key is depressed during the execution of the conversational macro program, both character display and graphic display will be erased after the conversational macro program ends, and a corresponding screen will take place. When the function key  is depressed again, the execution of the conversational macro program will be started according to the value of the conversational macro execution control variable #8500. At this time, the program will be executed from the beginning regardless of the command of the address P in block of M99.

When M99 is executed, the value of the conversational macro execution control variable #8500 will be checked. When the value of #8500 is rewritten, both character display and graphic display will be erased and the control will be transferred to a new conversational macro program. If not, neither the character display nor the graphic display will be erased, and execution of the same conversational macro program will be repeated. In this case, when the address P is commanded, execution will be started at the block of the sequence No. specified at P.

Once M99 is executed, the graphic display will not be output on the screen until the graphic screen is erased next. Consequently, when the same conversational macro program is still executed, the second and the following graphic displays will not be output on the screen. When you want to redisplay the graphic display in 1 conversational macro program, command the graphic screen to be erased once.

4.4 CONVERSATIONAL MACRO EXECUTION CONTROL VARIABLE #8500, #8550, #8551

Three screens are available for execution of the conversational macro. These screens are selected by pressing the function key CUSTOM. The three screens correspond with those for the FANUC Series 0 as follows;

Screen for Series 16/18/20	Screen for Series 0	Conversational macro execution control variable
CUSTOM screen 1	AUX	#8500
CUSTOM screen 2	MENU	#8550
CUSTOM screen 3	MACRO	#8551

When the function key  is pressed, a conversational macro whose program number is specified by a value of the conversational macro execution control variable is executed.

Compile parameters (No.9038, No.9040, No.9041) set values of the conversational macro execution control variable effected at power on. When the value of the conversational macro execution control variable is re-written, another conversational macro is controlled. When the value is re-written, characters and graphics are erased after completion of M99 of the currently executed conversational macro program(main) and the new conversational macro is controlled.

If the value of the conversational macro execution control variable is not re-written, the same conversational macros are repeatedly executed. In this case, no characters and graphics are erased.

4.5 NOTES

The conversational macro and auxiliary macro must be programmed so that M99 of the main program is executed.


The conversational macro, auxiliary macro and standard CNC display (POS screen, etc.) are executed on the same level. If a wait is programmed in any macro not having M99, the following occurs:

- If the wait is executed by the conversational macro, the auxiliary macro is not executed.
- If the wait is executed by the auxiliary macro, the conversational macro is not executed. The CNC display (POS screen, etc.) is not updated.

When common variables are used by an auxiliary macro (or conversational macro) and execution macro, the same variable must not be written to as a flag. An execution macro has higher priority than an auxiliary macro (or conversational macro). So, while an auxiliary macro (conversational macro) is writing to a variable, an execution macro may interrupt and write to that variable.

In such a case, once writing to the variable by the execution macro ends, the remaining write processing by the auxiliary macro (or conversational macro) is completed. So, the value written by the execution macro may be overwritten by the auxiliary macro (or conversational macro).

Example: Bit 0 of the #100 value is used as an execution macro flag, while bit 1 of #100 is used as an auxiliary macro flag



The value of #100, read at the start of auxiliary macro processing, is written to #100 after auxiliary macro processing ends. So, a value written by execution macro processing may be lost.

5

MACRO VARIABLES



5.1 MACRO VARIABLES

Variable	No.	User program	Conversational macro	Auxiliary macro	Executable macro
Local variable	#1 to #33 (#99)	○	△ (NOTE 1)		○
Common variable	#100 and up #500 and up	○	○ (Common variable)		
P-CODE variable Extended P-CODE variable	#10000 and up #20000 and up	×	○ (Common variable)		
Control variable	#8500 and up	×	○	△ (NOTE 2)	×

○ : Usable △ : Partially usable × : Unusable

NOTE

- 1 To be used when the P-CODE variables of array type are referenced.
- 2 The variables for controlling screen display and key input cannot be used.

5.2 LOCAL VARIABLES (#1 TO #33 OR FOR REFERENCING THE P-CODE VARIABLES OF ARRAY TYPE, #1 TO #99)

The local variables can be used for executable macros.

These local variables are different from those used for the user programs.

The local variables can be used for auxiliary and conversational macros to reference the P-CODE variables of array type.

5.3 COMMON VARIABLES (#100 TO #149 AND #500 TO #531)

The common variables can be used for conversational macros, auxiliary macros, and executable macros.

The common variables are common to the conversational, auxiliary, and executable macros.

However, they are different from those used for the user programs.

5.4 P-CODE VARIABLES #10000-

It is possible to use optional quantity of the P-CODE variables starting with #10000 on 100-pc. basis.

A 100 times as many as the numerical value preset on the compiling parameter No. 9037 will be the usable quantity of P-CODE variables. When the value on the parameter No. 9037 is 0, P-CODE exclusive variables are not usable.

The upper limit of the P-CODE variables is as follows.

$$10000 + (\text{Value of Compiling Parameter No. 9037}) \times 100 - 1$$

The lower limit of the P-CODE variables is 10000. For example, the P-CODE variables can be used as follows:

#10000 to #10099 when the value of parameter No. 9037 is 1

#10000 to #10199 when the value of Parameter No. 9037 is 2

NOTE

- 1 For P-CODE variables, about 1.63 meter of part program memory is consumed per 100 pieces of variables when part program storage is 20 to 80m. The more P-CODE are used, the more part program memory decreases. The maximum no. of the usable P-CODE variables depends on the capacity of the part program memory.

Part program storage memory 10 m:

Parameter on compiling No. 9037 = 6

Part program storage memory 20 m:

Parameter on compiling No. 9037 = 12

Part program storage memory 40 m:

Parameter on compiling No. 9037 = 25

Part program storage memory 80 m:

Parameter on compiling No. 9037 = 51

Part program storage memory 160 m - 1280 m:

Parameter on compiling No. 9037 = 60

- In Series 16-B/18-B, part program storage memory is not used. (Parameter no. 9037 needs to be set).

When compilation parameter no. 9007#7 EXT=1, the no. of P-CODE variables is the above value-1.

- For the 21-TB, approximately 1.63 meters of tape is required to store each 100 P-CODE variables, even when the tape length is 160 meters.

- For the 21-MB, whether part program memory is used varies with the CNC system software series.

- DDA1 series : Part program memory is not used.

- D201 series : Part program memory is used.

- 2 The P-CODE variables still maintain their values after the power is turned off.

- 3 Before executing the conversational macro with the compiled ROM module loaded, erase all the programs in the part program storage memory once.

(Turn on the power while pushing  key with the setting (PWE = 1).)

With this operation all the conversational macro functions will be initialized to be "blank".

Array type variables for P-CODE in conversational macro #10000 - can be referred to in 2 to 3 dimensional array type. (See 6.12 (1))

5.5 VARIABLES OF EXPANDED P-CODE (#20000 –)

The variables of the expanded P-CODE which start from #20000 can be used for the optional number, if the capacity of tape memory is 160m to 1280m. This variable can be selected for numbers with floating decimal points, the same as the usual common variable or for numbers with the integer type by parameter (parameter No. 9002#3 EVF) specification.

Parameter No. 9002#3

EVF= 0: floating decimal point type

EVF= 1: the integer type

N times the number set parameter No.9044 is the number of the usable variables for the P-CODE the same as the exclusive variables for the P-CODE (#10000 ---). The P-CODE variables cannot be used, if parameter No. 9044 is 0.

The number of n is 12 with the floating decimal point type, and is 30 with the integer type.

EVF=0: in the case of the floating decimal point type

#20000 to #20011 if parameter No. 9044 equals 1

#20000 to #20023 if parameter No. 9044 equals 2

EVF=1: in the case of the integer type

#20000 to #20029 if parameter No.9044 equals 1

#20000 to #20059 if parameter No.9044 equals 2

In the case of the integer type, one of -32768 to 32767 can be set. Digits under the decimal point are rounded off when a value is substituted to the left side of the substitution statement.

Furthermore, this variables is evaluated after converted into the floatingdecimal point type, if this variables occurs in expression.

About a 0.21 meter of part program memory is used per set (number of parameter No. 9044) of the variables of the expanded P-CODE.

The part program memory being used is displayed on the program library screen. The maximum number of P-CODE variables depends on the capacity of the part program memory.

Part program memory 160m: Parameter No. 9044=819

Part program memory 320m: Parameter No. 9044=1638

Part program memory 640m (EVF=0): Parameter No. 9044=3276

Part program memory 640m (EVF=1): Parameter No. 9044=2184

Part program memory 1280m (EVF=0): Parameter No. 9044=5461

Part program memory 1280m (EVF=1): Parameter No. 9044=2184

NOTE

For Series 20, Series 21, expanded P-CODE (#2000 -) cannot be used.

5.6 DISPLAYING VARIABLES

The variables used for P-CODE programs, such as local variables, common variables, P-CODE variables, and extended P-CODE variables, can be displayed by pressing the function key  several times.

The values of these variables can be specified using the MDI keys.

P-CODE VARIABLE			
No.	DATA	No.	DATA
0	123.45678	0	123.45678
1	123.45678	1	123.45678
2	123.45678	2	123.45678
3	123.45678	3	123.45678
4	123.45678	4	123.45678
5	123.45678	5	123.45678
6	123.45678	6	123.45678
7	123.45678	7	123.45678
8	123.45678	8	123.45678
9	123.45678	9	123.45678

NUM. _____
[] [] [] [] [NO-SEL]

The desired screen can be selected using page keys, cursor key, and [NO-SEL] key.

Pressing the  page key returns the current screen to the previous screen. Pressing the  page key displays the next screen.

A desired variable can be displayed with the numeric key and [NO-SEL] key.

The desired value can be entered for the variable at the cursor position using the numeric keys and the  key. However, no values can be entered in local variables or write-inhibited system variables.

NOTE

- 1 The setting of NDP, bit 1 in parameter 9000, for the executor depends on whether variables to be used for P-CODE programs are displayed. To display the variables, set bit 1 of parameter 9000 to 1.
- 2 The specified values of the variables are displayed when the screen is displayed. In other words, if the values of the variables are changed while the screen is displayed, the changed values are not displayed.
- 3 To change the screen from the P-CODE VARIABLE screen to another screen such as current position screen or conversational macro screen, press the correspondence function key such as

 and  .

If the 20-FA or 20-TA is your NC, press both right most and left most soft keys at the same time and the screen changes from the P-CODE screen to the current position display screen.

6

FUNCTIONS OF THE MACRO EXECUTOR

Table 6 (a) Functions (1/2)

No.	Function	Outline	Conversational	Auxiliary	Executable
6.1	Screen display function 1 Screen display control 2 Function screen control 3 Masking conversational macro screen status display 4 Shift for adjusting the graphic screen	Controls the display of the conversational macro screen.	○ ○ ○ ○ (NOTE 1)	× ○ × × (NOTE 1)	× × × ×
6.2	Address function	Reads data at PMC addresses.	○	○	○
6.3	Writing at PMC addresses	Writes data at PMC addresses.	○	○	○ (NOTE 2)
6.4	Reader/punch interface control	Controls the RS-232C interface.	○	○	×
6.5	Reading and writing an NC program	Reads NC programs from and writes them onto the CNC tape.	○	○	×
6.6	Continuous input with the cursor and page keys	Continuously inputs data with the cursor and page keys.	○	×	×
6.7	Masking the display of O and N numbers	Clears the display of O and N numbers on the CUSTOM screen.	○	×	×
6.8	Reading and presetting the cutting time and cutting distance	Reads and presets the cutting time and the cutting distance.	○	○	×
6.9	Reading and presetting the relative coordinates	Reads and presets the relative coordinates.	○	○	×
6.10	Key/data input control	Reads the states of MDI keys and the values of entered data.	○	×	×
6.11	Cursor control	Displays the cursor at any position on the conversational macro display screen.	○	○	×
6.12	Processing of P-CODE variables of array type	References P-CODE variables of two- or three-dimensional array type.	○	○	×
6.13	Torque limit control	Specifies the override values of the torque limits for each servo axis.	○	○	○
6.14	Reading A/D converter data	Reads A/D converter data.	○ (NOTE 3)	○ (NOTE 3)	×
6.15	Key-in line function	Specifies a desired display position and color of the key-in line for conversational macros.	○	×	×
6.16	Reading the status indicating editing in the background	Reads the status indicating whether editing is currently performed in the background.	○	○	×
6.17	Reading the number of registered programs	Reads the number of the programs registered in CNC program memory.	○	○	×
6.18	Reading the unused capacity of CNC program memory	Reads the capacity of unused areas in CNC program memory.	○	○	×
6.19	Reading the remaining travel distance	Reads the remaining travel distances for each servo axis.	○	○	×

○ : Usable △ : Partially usable × : Unusable

Table 6 (a) Functions (2/2)

No.	Function	Outline	Conversational	Auxiliary	Executable
6.20	Use of offset memory and extended system variables in the workpiece coordinate system	Reference data in offset memory and the values of extended system variables in the workpiece coordinate system using macro variables from 100000 to 199999.	○ (NOTE 3)	○ (NOTE 3)	○ (NOTE 3)
6.21	PMC axis control	Controls the PMC control axes.	○ (NOTE 4)	○ (NOTE 4)	×
6.22	Interlock along each axis	Applies interlocks along each axis and reads the travel axis and the direction of movement along the axis when the skip signal goes high.	○ (NOTE 5)	○ (NOTE 5)	×
6.23	Separation of P-CODE program UI/UO	Separates the system variables for macro DI/DO into the signals for user programs and those for P-CODE programs.	○	○	○
6.24	Referencing the common variables for custom macros	Reads the common variables for the user program from and writes them to the P-CODE program.	○	○	○
6.25	Displaying the conversational macro screen when power is turned on	Displays the conversational macro screen in the emergency stop state of the CNC or in the external reset state.	○	×	×
6.26	Masking of screen switching with the CUSTOM key	Inhibits the conversational macro program from being executed again from the beginning when the CUSTOM key is pressed on the conversational macro screen.	○	×	×
6.27	Searching for a P-CODE workpiece number	Directly executes the P-CODE program registered in an executable macro variable.	×	×	○
6.28	Function for calling a user program with an executable macro	Calls a user program from the P-CODE programs for executable macros.	×	×	○
6.29	Arithmetic function	Logarithmic function, Exponential function Arc sine function and Arc cosine function can be used.	○	○	○ (NOTE 6)
6.30	MDI key image read function by conversational macro	MDI key image that reflects MDI key status (pressed/or released) can be read from the conversational macro.	○	×	×
6.31	Window function	Various CNC system information can be referred to through window.	○	○	×
6.32	Special character registration and display function	Maximum 40 special characters can be registered and displayed.	○ (NOTE 7)	×	×
6.33	Execution macro call mask function	An execution macro call can be masked by using an executor parameter or macro variable.	○	○	○

○ : Usable △ : Partially usable × : Unusable

NOTE

- 1 Since the Series 21 do not support the graphic display feature, they cannot use the drawing, painting, or other functions based on the graphic coordinate system.
- 2 This function can be used only for Series 16-B.
- 3 This function can not be used for Series 20 and for Series 21.
- 4 This function can not be used for Series 20-TA.
- 5 This function can not be used for Series 20.
- 6 To use the arithmetic function in the execution macro, custom macro B option must be combined in the CNC.
- 7 This function can be used only for Series 20.

Table 6 (b) Functions of the Macro Executor and the Associated G Codes and Macro Variables (1/2)

No.	Function	Associated G code	Associated macro variable	Conversational	Auxiliary	Executable
6.1	Screen display function	G01, G02, G03, G202, G204, G206, G240, G242, G243, G244, G249	#8509	○ (NOTE 1)	△ (NOTE 1)	×
6.2	Address function	———	———	○	○	○
6.3	Writing at PMC addresses	G310		○	○	○ (NOTE 2)
6.4	Reader/punch interface control	G330, G331, G335, G336, G337, G338, G339	#8539	○	○	×
6.5	Reading and writing of an NC program	G320, G321, G325, G326, G327, G328, G329	#8520, #8521, #8522, #8523, #8529	○	○	×
6.6	Continuous input with the cursor and page keys	———	#8501	○	×	×
6.7	Masking the display of O and N numbers	———	———	○	×	×
6.8	Reading and presetting the cutting time and cutting distance	———	#8553, #8554	○	○	×
6.9	Reading and presetting the relative coordinates	———	#8998, #8999	○	○	×
6.10	Key/data input control	———	#8501, #8502, #8503, #8504, #8552	○	×	×
6.11	Cursor control	———	#8505, #8506, #8507	○	○	×
6.12	Processing of P-CODE variables of array type	G315	#8511, #8512, #8513, #8514, #8515, #8516, #8517, #8519	○	○	×
6.13	Torque limit control	———	#8621, #8622, #8623, #8624	○	○	○
6.14	Reading of A/D converter data	———	#8631, #8632, #8633, #8634	○ (NOTE 3)	○ (NOTE 3)	×
6.15	Key-in line function	———	#8561, #8562, #8563, #8564, #8565	○	×	×
6.16	Reading the status indicating editing in the background	———	#8526	○	○	×
6.17	Reading the number of registered programs	———	#8527	○	○	×
6.18	Reading the unused capacity of CNC program memory	———	#8528	○	○	×
6.19	Reading the remaining travel distance	———	#5181 to #5188	○	○	×
6.20	Use of offset memory and extended system variables in the workpiece coordinate system	———	#100000 and up	○ (NOTE 3)	○ (NOTE 3)	○
6.21	PMC axis control	G340, G341, G344, G345, G346, G348, G349	#8602, #8700, #8710 to #8713, #8715, #8720 to #8723, #8725, #8730 to #8733, #8735, #8740 to #8743, #8745	○ (NOTE 4)	○ (NOTE 4)	×

○ : Usable △ : Partially usable × : Unusable

Table 6 (b) Functions of the Macro Executor and the Associated G Codes and Macro Variables (2/2)

No.	Function	Associated G code	Associated macro variable	Conversational	Auxiliary	Executable
6.22	Interlock along each axis	—	#8600, #8601	○ (NOTE 5)	○ (NOTE 5)	×
6.23	Separation of P-CODE program UI/UO	—	—	○	○	○
6.24	Referencing the common variables for custom macros	—	#99000	○	○	○
6.25	Displaying the conversational macro screen when power is turned on	—	—	○	×	×
6.26	Masking screen switching with the CUSTOM key	—	—	○	×	×
6.27	Searching for a P-CODE workpiece number	—	—	×	×	○
6.28	Function for calling a user program with an executable macro	—	—	×	×	○
6.29	Arithmetic function	—	—	○	○	○ (NOTE 6)
6.30	MDI key image read function by conversational macro	—	#8549	○	×	×
6.31	Window function	—	#8998, #8999	○	○	×
6.32	Special character registration and display function	—	—	○ (NOTE 7)	×	×
6.33	Execution macro call mask function	—	#8690, #8691	○	○	○

○ : Usable △ : Partially usable × : Unusable

NOTE

- 1 Since the Series 21 do not support the graphic display feature, they cannot use the drawing, painting, or other functions based on the graphic coordinate system.
- 2 This function can be used only for Series 16-B.
- 3 This function can not be used for Series 20 and for Series 21.
- 4 This function can not be used for Series 20-TA.
- 5 This function can not be used for Series 20.
- 6 To use the arithmetic function in the execution macro, custom macro B option must be combined in the CNC.
- 7 This function can be used only for Series 20.

6.1 SCREEN DISPLAY FUNCTION

In this section, the terms twelve-soft-key type and seven-soft-key type represent the following display units:

Twelve-soft-key type: Those display units with twelve (10 + 2) soft keys (such as the 14" CRT, 10" LCD, 9.5" LCD, and 10.4" LCD units)

Seven-soft-key type: Those display units with seven (5 + 2) soft keys (such as the 9" CRT, 8.4" LCD, 9" PDP, and 7.2" LCD units)

6.1.1 Coordinates System of Screen

The coordinates system used for character display and cursor display in the conversational macro program is called the character coordinates system.

The coordinate system used for graphic display in the conversational macro program is called the graphic coordinate system.

(1) Display unit with seven soft keys

The graphic coordinate system can be selected from the standard mode and the high resolution mode. Select one of these by the parameter HRGR (No.9003#2) in compiling. Select high-resolution mode for Series 16 and Series 18.

As for the character coordinates system, the horizontal direction is X coordinate and the vertical direction is Y coordinate. Specify the X coordinates from 0 to 39 from left to right and the Y coordinates from 0 to 15 from top to bottom. Any command of display exceeding the above range will be ignored. 1 unit is 1 character.

Since the 13th is used for the input section and the 14th is used for the state display section, they cannot be specified. Furthermore, the soft key frame section cannot be specified either.




Fig.6.1.1(a) Character Coordinate System (In Case of Seven Soft Keys)

The coordinates system used for graphic display in the conversational macro function is called the graphic coordinates system.

As for the graphic coordinates system, too, the horizontal direction is the X coordinate and the vertical direction is the Y coordinate. Specify the X coordinates from -160 to 159(-320 to 319) from left to right and the Y coordinates from -112 to 112(-200 to 199) from bottom to top.(Value in parenthesis is for high resolution mode.) Any command of display outreaching the above range will be ignored. 1 unit is 1 dot.

The center of the screen will be $(X, Y) = (0, 0)$.




Fig.6.1.1(b) Graphic Coordinate System

(a) Standard mode

Use the same coordinate system as that of the series 0 standard seven soft keys.

Center of screen

$(X \text{ coordinates, } Y \text{ coordinates}) = (0, 0)$

Left and right of screen

$(X \text{ coordinates}) = (-160 - 159)$

Top and bottom of screen

$(Y \text{ coordinates}) = (-112 - 112)$

(b) High resolution mode

Use the high resolution coordinate system.

Center of screen

$(X \text{ coordinates, } Y \text{ coordinates}) = (0, 0)$

Left and right of screen

$(X \text{ coordinates}) = (-320 - 319)$

Top and bottom of screen

$(Y \text{ coordinates}) = (-200 - 199)$

Graphic display macro prepared in the series 0 standard seven soft keys can almost be used unchanged in standard mode. The high resolution graphic mode allows highly accurate display that was not possible in standard mode.

(2) Display unit with twelve soft keys

(a) Character coordinates line, graphic coordinates line

Character coordinate system instructs in the range of 0-79 for the left and right directions (X coordinates), and 0-24 for the up and down directions (Y coordinates). The 20th line is used for input and the 21st line is used by the system for status display and can not be satisfied. The space for the software key also cannot be satisfied.

- X coordinate of the graphic coordinates system
- Y : Y coordinate of the character coordinates system, Y coordinate of the graphic coordinates system
- I : X coordinate at the center of the circular graph of the graphic coordinates system
- J : Y coordinate at the center of the circular graphic of the graphic coordinates system
- A : Character size (Character display)
- B : Flash specification (Character display)
- F : Format of numeric display (Character display)
- Z : Zero suppress specification of numeric display (Character display)
- Q : Circular graph (Graphic display), PC address write data

NOTE

Since the Series 21 do not support the graphic display feature, they cannot use G01, G02, G03, G242, or G244. Only character deletion is possible when using G202 (screen deletion).

(1) Character display (G243)

G243 Xx Yy Aa Bb Cc (c..) (*hhh..*) Kk Ff.e Zz Dd Pp ;

There are 2 ways of commanding the character string to display.

- a) Command to display a character string by enclosing it with parentheses:
G243 (FANUC 16-SERIES) ; "FANUC 16-SERIES" will be displayed.

Those which you can command by enclosing with parentheses are the alphabet, numbers, minus marks, and decimal points only.

- b) Command to display a character string by bounding with "(" and ")" by internal codes:

G243 (*46 41 4E 55 43*) ; "FANUC" will be displayed.

G243 (*4E 43 4175 4356*) ; "NC system" will be displayed.

Command with hexadecimal number. Divide the internal codes with blanks. Take a space for 2 characters aside for hiragana and kanji. The coordinates will be renewed when a character string is displayed.

For the character string, it is possible to specify up to maximum total 255 characters in 1 block. Count hiragana and kanji as 2 characters respectively.

Also, it is possible to command the character code to display directly at the address C by decimal number. The commandable codes are 32 - 95 (20 - 5F with hexadecimal number) or 160 - 223 (A0 - DF with hexadecimal number).

C40 → * C61 → =

Command the display positions of the character strings at the addresses X and Y with the character coordinates.

Command character size at the address A.

A1 = Normal size

A2 = Full size

A3 = Triple size (3 × 2 size)

A4 = 2 × 2 size

The following characters and symbols can be displayed at full size:

Alphabetic characters, numeric characters, kana characters, blanks, the plus sign (+), minus sign (−), period (.), equal sign (=), comma (,), asterisk (*), slash (/), parentheses (()), square brackets ([]), inequality signs (< and >), and the sharp (#)

The triple size is 3 times as wide as and 2 times as long as the normal size. The characters which can be displayed with the triple size characters are the alphabet, numbers, minus marks, decimal points and blanks. No other characters can be displayed with the triple size.

A 2-by-2 character is two times taller and two times wider than a standard character. Fifteen types of 2-by-2 characters can be displayed: numbers (0 to 9), plus sign, minus sign, decimal point, asterisk, and slash. Note, however, that the Greek character ϕ is displayed for a slash.

NOTE

Only the Series 20 allows 2-by-2 character display. With the Series 16/18/21, 2-by-2 characters cannot be displayed; A4 cannot be specified.

1. Standard character

G243 Xx Yy A1 (8)




2. Full-size character

G243 Xx Yy A2 (8)




3. Triple-size character (3-by-2 character)

G243 Xx Yy A3 (8)



4. 2-by-2 character

G243 Xx Yy A4 (8)



Blink control is commanded by the address B.

B0 = Does not blink.

B1 = Blinks slowly. (Energized for about 1/2 sec. and deenergized for about 1/4 sec..)

B2 = Blinks quickly. (Energized for about 1/4 sec. and deenergized for about 1/8 sec..)

NOTE

When a blink is specified, the display is energized or deenergized according to the timer condition when the display is commanded. Therefore, when the display is not repeated, it will be kept energized or deenergized.

Command the number of blanks at the address K. The blanks as many as commanded at K will be displayed. When the blanks are displayed, the coordinates will be renewed.

Command the format to display the numeric values at the address F. Command the number of display figures on the left of the point and the number of figures under the point on the right of the point.

Command at the address Z whether you do "leading zero suppress" or not when displaying the numeric values.

Z = 0 .. leading zero suppress will take place.

= 1 .. leading zero suppress will not take place.

The mark will not be displayed when Z is 0.

Command the numeric values to display at the address D.

Command the sequence No. that the character string is cataloged at the address P. The character displayed will be the character string in one block of the sequence No. commanded with P in the program set at the character string registered program control variable #8509. The variable for controlling character-string registration programs (#8509) is defined as the number of the first program in the character-string registration program group. Use the five digits for address P to select the desired character-string registration program in the group.

G243 Xxx Yyy Pnnnn;

o : A number from 0 to 8 to select a program in the character-string registration program group

nnnn : Sequence number 0001 to 9999

Example 1) #8509 = 1000 ;

G243 P10 ; ⇒ Displays the character string with sequence number N10 in program O1000

G243 P80010 ; ⇒ Displays the character string with sequence number N10 in program O1008.

Up to nine character-string registration programs can be selected as desired in the above way.

Example 2)

O9000; : #8509=8000; X0Y0; G243(ABC)P20;	O8000; : N10(IJK); N20(XYZ);
--	---

In this case, one block of the sequence No. 20 in the program No. 8000 will be executed.

In the above example, "ABCXYZ" will be executed.

And address P executes the specified block after the process of the corresponding block is finished. Consequently, "ABCXYZ" will be displayed though command is done as follows with the above example.

G243 P20 (ABC) ;

Nothing but the character string will be described at the block specified by P.

When #8509 is 0, the block of the sequence No. specified in the current program will be executed.

NOTE

Process sequence of modal address

Program is processed by block in the normal NC program, but it is processed in sequence of address command in the conversation macro program.

(Example)

```
1 F8.3 ;
  G243 F5.1 D#100 ;
2 F8.3 ;
  G243 D#100 F5.1 ;
```

In 1 #100 is displayed with F5.1, but in 2 it is displayed with F8.3.

(2) Screen erase (G202)

G202 XxYyliJjPp;

X= Start point of X coordinate in character coordinate

Y= Start point of Y coordinate in character coordinate

I = Number of characters to be erased from the start point (X coordinate) for partial erasing.

J = Number of characters to be erased from the start point (Y coordinate) for partial erasing.

P = 1 ... Erasing graphic screen

= 2 ... Erasing character screen

= 3 ... Erasing graphic and character screens

Also to make partial erasing, all X, Y, I and J addresses must be specified. If any address is omitted, all the screen is erased.

(3) Displayed color specification (G240)

G240 Pp L₁ ;

Colors of segments and character strings specified by conversational program can be designated.

P = 0 .. Black

= 1 .. Red =-1 Red (highlights)

= 2 .. Green =-2 Green (highlights)

= 3 .. Yellow =-3 Yellow (highlights)

= 4 .. Blue =-4 Blue (highlights)

= 5 .. Purple =-5 Purple (highlights)

= 6 .. Blueish green =-6 Bluish green(highlights)

= 7 .. White =-7 White (highlights)

L = 0 .. not blink

= 1 .. blink

If no designation is made, a segment and a character string are white without blink.

(4) Graphic line specification (G244)

G244 Pp ;

P = 0 .. Full line

= 1 .. Broken line

= 2 .. 1-dot line

= 3 .. 2-dot line

= 4 .. Erase

The graphic line is full line at power ON.

(5) Setting of graph start point (G242)

G242 Xx Yy ;

Command the display start point with the absolute coordinates at the addresses X and Y.

Next display will start at this point.

(6) Straight line graph (G01)

G01 Xx Yy ;

Command the coordinate of the end of the straight line with the absolute coordinate at the addresses X and Y.

A straight line will be made with the line commanded with G244 from the current position to the commanded coordinate. The coordinates will be renewed.


(7) Circular display (G02, G03)

G02 Xx Yy Ii Jj Qq ;

G03 Xx Yy Ii Jj Qq ;

G02 display the arc clockwise and G03 counter-clockwise.

Command the end of the arc with the absolute coordinate at the addresses X and Y.



Command the center coordinate of the arc with the absolute coordinate at the address I and J.

Command the number of quadrant (0 - 4) of the arc at the address Q. The arc will be graphed with the line commanded with G244 from the current position to the coordinate of the commanded end.

The coordinate will be renewed.

6.1.3 Graphic Painting Function

The graphic function for conversational macros enables painting the specified field.

NOTE

The graphic painting function cannot be used for Series 21.

(1) Description

The field to be painted is drawn using a solid line with the graphic function. Then the paint command is used together with control code G206 to specify any point inside the field and the boundary color. The field is filled with the color which is used as standard when G206 is issued.

G206PpXxYy;

Painting boundary color (P)

p = 0: Same as the fill color

p = 1: Red

p = 2: Green

p = 3: Yellow


p = 4: Blue

- p = 5: Purple
- p = 6: Blue-green
- p = 7: White
- p = 8: Specified two or more colors other than black

Arbitrary point inside the field to be painted (X, Y)

NOTE

The field to be painted must have a closed boundary.



NOTE

To use the painting command on the high-resolution 9" monochrome CRT, set HRGC of compilation parameter 9004 to 1 to make the CRT enter the intensity modulation mode.


(2) Examples

- (a) When p = 8 is specified
The innermost field is painted.

```

G240P1;
G244P0;
G242X0Y0;
G01X100;
Y100;
X0;
Y0;
G240P4;
G242X50Y50;
G01X150;
Y150;
X50;
Y50;
G206P8X110Y110;
        
```

- (b) When the same color is specified for the fill and the boundary (p = 0)
A line with another color in the field to be painted is painted.



**6.1.4
Graphic Cursor Function**

Graphic cursor can be displayed in the conversational macro.

(Command Format)

G249 Pp Xxx Yyyy:

p : Control code

=0 : Display on (lit)

=1 : Display on (Blinks at low speed)

=2 : Display on (Blinks at high speed)

=3 : Display off

xxx/yyy : Graphic cursor display position
(Graphic coordinate)


(When display off is specified, this specification is ignored. It can be omitted).

**6.1.5
Rectangular Display Function**


In a conversational macro, a rectangular figure can be displayed.

(1) Function

In rectangular display, a rectangle in which addresses X and Y, I and J become diagonal positions is displayed.



Addresses X and Y, I and J are any position that can create a rectangle.



(Command format)

G204 X_ Y_ I_ J_ [P];

X: X coordinate of the start of a rectangle

Y: Y coordinate of the start of a rectangle

I : X coordinate of the end of a rectangle

J : Y coordinate of the end of a rectangle

P : Painting control= 1 : Painting in rectangle (red)
 = 2 : Painting in rectangle (green)
 = 3 : Painting in rectangle (yellow)
 = 4 : Painting in rectangle (blue)
 = 5 : Painting in rectangle (purple)
 = 6 : Painting in rectangle (bluish green)
 = 7 : Painting in rectangle (white)

Command in parentheses can be omitted.

The color of boundary of a rectangle is of specified by G240P_ and painted color in rectangle is of specified by address P.

When address P is omitted, only boundary of a rectangle is displayed.

After the painted color is specified by P, the color remains the following movement. That is, the color specified by P changes the P value of G240P_.


Type of line of rectangle is of a type specified by the line type specification command (G244P_).

(2) Example

G244 P1;

G240 P1;

G204 X-200 Y150 I0 J10;




6.1.7 Displaying Seven Soft Keys Data on the Twelve Soft Keys Type

Data for a twelve soft keys can be displayed on the user-1 screen for a conversational macro screen on the twelve soft keys by setting US19W of compilation parameter (bit 5 of parameter 9006). (This screen is equivalent to the AUX screen in Series 0.)

The whole of user screens 2 and 3 can be used as macro screens while they are displayed. (The absolute coordinates are always displayed on the position screen.)

US19W = 1: Displays seven soft keys data on the twelve soft keys type


<<USER1 screen when seven soft keys data is displayed>>



NOTE

Upper left corner of the macro screen is X=40 and Y=7.

<<USER2 and USER3 screens>>



6.1.8 Function Screen Control Function

Writing a desired value in parameter 8510 enables displaying any function screen. Reading the value of parameter 8510 enables checking which function screen is currently displayed.

The following table shows the correspondence between function screens and the values of parameter 8510.

Function screen for a small keyboard	Value of parameter 8510	Function screen for a standard/FAPT keyboard	Value of parameter 8510
 : Current value display screen	0	 : Current value display screen	0
 : Program display screen	1	 : Program display screen	1
 : Offset/setting screen	2	 : Offset/setting screen	2
 : Parameter/diagnosis and suchlike	3	 : Parameter/diagnosis and suchlike	3
 : Alarm/message screen	4	 : Alarm/message screen	4
 : Graphic/user screen	5	 : Graphic screen	5
 : User screen	6	 : User screen	6
		 : FAPT screen (FAPT key)	7

6.1.9 Function for Masking the Status Display on the Conventional Macro Screen

The mode and status display can be masked on the user-1, -2, and -3 screens for displaying the conversational macro screen by specifying compilation parameter STDM (bit 2 of parameter 9006).

The 14th line on the seven soft keys and 21st line on the twelve soft keys can therefore be controlled with conventional macros.

6.1.10 Shift Function for Adjusting the Graphic Screen

The graphic coordinate system can be shifted in units of dots on the conversational macro screen by specifying compilation parameters 9048 and 9049.

Compilation parameter 9048:
Shift value along the X-axis in the graphic coordinate system on the conversational macro screen

Compilation parameter 9049:
Shift value along the Y-axis in the graphic coordinate system on the conversational macro screen

6.2 ADDRESS FUNCTIONS

The address functions are the functions to return the address of PMC or the contents of the parameter as the function values. However, as the address functions cannot be written, it is impossible to describe them on the left side of an operation. Control code G310 is prepared for PMC address writing.

The format of the address functions is as follows.

<Address><Address No.> or <Address><Address No.>.<Bit position>
(parameter cannot be used) or <Address><Address No.>.<Axis No.>

Address P indicates the parameter and the other addresses indicate PMC addresses.

P100 returns the contents of the parameter No. 100 as function values respectively.

Since the bit position cannot be specified for parameters, if it is required, take the bit data using AND instruction.

Also, G100.1 returns the contents of the bit 1 of PMC address G100, and G105 returns the contents of PMC address G105 as function values respectively.

It is possible to describe <Address No.> and <Bit position> or <Axis No.> with variables or # [<Expression>] or [<Expression>], instead of numbering them with numerical values directly.

For example, it is possible to describe as follows.

```
P#100
P#100.#101
G# [#100+1]
G [#100+1] .[[#100-1]/2]
```

The usable addresses are "P" for parameter and X, Y, F, G, R, D, T, C, K and A of PMC addresses.

Format conforms to that used for ladder diagram.

Refer to the operator's manual for the detail of parameters and to the PMC programming manual for details of the PMC addresses.

NOTE

Refer to the section titled "PMC Address Write Control Code (G310)" for writing data to the PMC addresses R, D, C, and K.

6.3 READING AND WRITING A PMC ADDRESS

(1) PMC address write control

Data of one, two, or four bytes can be written when address L is specified with control code G310.

G310 Dd Qq Lx;

G310 Rr Qq Lx;

G310 Cr Qq Lx;

G310 Kr Qq Lx;

These commands write the data indicated by address Q at the PMC address indicated by address D, R, C, or K, a number of bytes at a time as indicated by address L. The data cannot be specified in bits.

The write data indicated by address Q is rounded as follows: Decimal places of 0.5 and over are counted as a whole number and the rest are discarded. Then the data is expressed in binary form and written. When the data is a negative value, it is handled and converted as two's complement.

When the following is specified, the data is written in the PMC data area (D300 to D303) as shown in the table below:

#100 = -500.0;

G310 D300 Q#100 L4;

Bit	7	6	5	4	3	2	1	0
D300	0	0	0	0	1	1	0	0
D301	1	1	1	1	1	1	1	0
D302	1	1	1	1	1	1	1	1
D303	1	1	1	1	1	1	1	1

In two's complement, the decimal number -500 becomes FFFFFFFE0CH in hexadecimal.)

When the specified data contains more bytes than that indicated by address L, only the data of the length specified by address L is written. This will not cause an error. (If L1 is specified in the example above, the identical data is written only in D300.)

(2) PMC address read control

When a variable is indicated by address P with control code G310, the PMC data can be read. Address L indicates that the data of one, two, or four bytes is read at a time.

G310 Dd Pp Lx;

G310 Rr Pp Lx;

G310 Cr Pp Lx;

G310 Kr Pp Lx;

These commands read the data which starts from the PMC address indicated by address D, R, C, K or A and whose length is indicated in bytes by address L into the variable indicated by address P. The read data is handled as binary data consisting of the specified number of bytes, converted, and assigned to the variable.

If G310 D400 P101 L2; is specified when the PMC data area (D400 to D401) has the data shown below, -500.0 is input in #101.

Bit	7	6	5	4	3	2	1	0
D400	0	0	0	0	1	1	0	0
D401	1	1	1	1	1	1	1	0

The address function can read data the specified number of bytes at a time. However, the following must be noted: As the address function handles and converts the read data as a signed value (in two's complement), the read data may be changed.

If the following is specified with the example shown above, -2.0 and 254.0 are read into #102 and #103 respectively.

G310 D401 P102 L1;

#103 = D401;

NOTE

- 1 When address Q is specified, write control is executed. When address P is specified, read control is executed. If both addresses Q and P are specified, write control is executed.
- 2 Addresses other than D, R, C, K (X, Y, G, F...) cannot be specified.
- 3 With address L, 1, 2, or 4 can be specified. If another value is specified, or if address L is omitted, the data is written or read the specified number of bytes at a time.
- 4 For details of the PMC address, refer to the PMC programming manual.

6.4 READER PUNCHER INTERFACE CONTROL BY CONVERSATIONAL MACRO

6.4.1 Outline

The conversation macro function allows the reader/puncher interface to be controlled.

The control is performed by combining the following four control codes. When this function is used, always set the expansion function validity (No. 9002.7, EXT1) to 1 in the parameter on compiling.

- G330 → reader puncher interface open
- G331 → reader puncher interface close
- G335 → 1 byte read
- G336 → Data transmit
- G337 → input of macro variable
- G338 → output of macro variable

Select either channel 1 or channel 2 as a circuit to be used by specification on opening.

Channels 1 and 2 cannot be controlled simultaneously.

In addition, when the normal I/O function is commanded on the channel which is being used in this function, operation is not proper if the channel, where the input of NC program is being executed by the I/O function, is opened.

Select one control method out of the three methods shown in the following by specification on opening a circuit.

(1) User macro control

The reader puncher interface is opened in the bidirectional mode and no output control of control codes (DC1 to DC4) can be carried out by the macro executor.

Use the macro executor when creating your own protocol.

When overflow of the reception buffer is detected, send the transmission stop/restart message to the target device by switching ON/OFF the control signal "RS".

(2) Read control (DC1/DC3 automatic control)

The "DC1" code is automatically sent on opening, thus requesting the target device to transmit data.

The "DC3" code is transmitted on closing.

In addition, when overflow of the reception buffer is detected, the output of "DC3" and "DC1" is automatically controlled.

No control of data transmission (G336) can be performed when the reader/puncher interface circuit is opened in the read control mode. (End code = 8)

(3) Transmission control (DC2/DC4 automatic control)

The "DC2" code is automatically on opening, thus requesting the target device to transmit data.

The "DC4" code is transmitted on closing.

The interruption and restart processing of transmission by the target device using the "DC3" and "DC1" are also automatically carried out.

No control of 1 byte reading (G335) can be carried out when the reader/puncher interface circuit is opened in the transmission control mode (End code = 8). There is an end code to check to see if the commanded control code has been properly executed or not. Check the end code after executing G330 to G338.

#8539 : End code (only for reading)

However, the circuit closing processing always ends normally.

6.4.2

Function Details

(1) Circuit open (G330)

G330 Pp Bb Ss Cc ;

The reader puncher interface of the specified channel is opened according to the control method and control conditions to enable it to be used.

Select the channel and control method used by the specification of address "P".

- 1: Channel 1 User macro control
- 2: Channel 2 User macro control
- 11 : Channel 1 Reading control (DC1/DC3 automatic control)
- 12 : Channel 2 Reading control (DC1/DC3 automatic control)
- 21 : Channel 1 Transmission control (DC2/DC4 automatic control)
- 22 : Channel 2 Transmission control (DC2/DC4 automatic control)

NOTE

In case of 21-TB, only channel 1 is used.

Specify the baud rate by the specification of address "B".

- 1 : 50b/s 2 : 100b/s 3 : 110b/s
- 4 : 150b/s 5 : 200b/s 6 : 300b/s
- 7 : 600b/s 8 : 1200b/s 9 : 2400b/s
- 10 : 4800b/s 11 : 9600b/s

Specify the stop bit and parity by the specification of address "S".

- 1 : 1 stop bit, No parity
- 2 : 2 stop bits, No parity
- 11 : 1 stop bit, Odd parity
- 12 : 2 stop bits, Odd parity
- 21 : 1 stop bit, Even parity
- 22 : 2 stop bits, Even parity

Specify the output code on transmitting data by the specification of address "C".

- 1 : Output code (ASCII)
- 2 : Output code (ISO)

Example) Device and transmission control of channel 2
(DC2/DC4 automatic control)

Baud rate = 4800 b/s, Stop bit = 2, Even parity, ISO code output
G330 P22 B10 S22 C2 ;

IF [#8539 NE 0] GOTO 900 ;

Open processing end

N900 error processing :

(2) Circuit closing (G331)

G331 ;

The circuit, which is currently open, is closed.

There is no end code for the circuit closing processing.

It always ends normally.

(3) 1 byte reading (G335)

G335 Pp ; p : Reading variable number

Data 1 byte received through circuit is read into the variable area specified.

The received data is stored in the reception buffer (128 bytes) temporarily and is read one byte at a time by this control code.

When there is no reception data, end code 255 is sent.

If the reception buffer is nearly overflowing due to delay of reading processing for the reception data, either of the following processing is carried out according to the opening specification of control method.

(a) In the case of user macro control

When overflow of the reception buffer is detected, the transmission stop is requested to the target by the turning OFF of control signal "RS".

Then, when there is an empty reception buffer area by reading, the signal (RS) is turned ON, thus requesting the target device to continue transmission.

(b) In the case of reading control (DC1/DC3 automatic control)

When overflow of the reception buffer is detected, the "DC3" code is output automatically, thus requesting the target device to stop transmission.

Then, when there is an empty reception buffer area by reading, the DC1" code is output, thus requesting the target device to continue transmission.

(c) In the case of transmission control (DC2/DC4 automatic control)

When the circuit is opened in the transmission control mode, no control of 1 byte reading is carried out (end code = 8).

Example)

N100 G335 P100;

IF [#8539 EQ 255] GOTO100;

IF [#8539 NE 0] GOTO900;

Reading processing ended

(#100: Received data)

N900 error processing

(4) Data transmission (G336)

G336 transmission data;

The following commands of transmission data are available:

(c...)	→ String command 1
(*hh..*)	→ String command 2
Ff	→ Data format command
Zz	→ Zero suppress command
Dd	→ Data command
Pp	→ Block number command
Kk	→ Null code command
Cc	→ 1-character command

See screen display control code G243 (character display) for string commands 1 and 2 and address F, Z, D, P, and K commands since they are similar.

The commanded string is converted into either ASCII or ISO code and is transmitted by the specification on opening.

However, the code output by address K is not the space but the null code (no punching).

In the one-character command by address C, no code conversion processing is carried out.

Use it when the code is output other than the control code (DC1 - DC4) or ASCII/ISO code.

Example)

```
G336 C18 K20 (FANUC) K20 C20;
IF [#8539 NE 0] GOTO900;
Transmission processing ended
N900 error processing;
```

The following data is transmitted in the circuit by this command:

C18	→ DC2 (12hex)
K20	→ Null code 20 (Feed)
(FANUC)	→ "FANUC" (ASCII/ISO)
K20	→ Null code 20 (Feed)
C20	→ DC4 (14hex)

When the circuit is opened in the reading control mode, no control of data transmission is carried out (End code = 8).

6.4.3 Inputting and Outputting Macro Variables

Macro variable data input and output can be conducted simply by an instruction via reader puncher interface. Instruct the control with the following G code.

G337	→ macro variable data input
G338	→ macro variable data output

An end code #8539 is provided to check that input and output processing runs correctly or not. Check the end code #8539 after running G337, G338.

#8539	→ end code (read only)
-------	------------------------


(1) Macro Variable Data Input (G337)

G337 Pp ;

p : the head variable number which mounts the macro variable (omissible)

A macro variable data, which is input from reader puncher interface that opened with the read control mode, is read and set it to the correspondenting variable.

The tape format of macro variable data is as follows;




Information before "LF" which appears on the tape at first is all disregarded.

The tape to the end ("EOR") from the first "LF" is analyzed as significant information.

A section which is spaced with "LF" and "LF" into significant information segments called a block, and one block shows one macro variable data.

Address "N" can be omitted. In this case, the variable number is interpreted to be (the variable number of the preceding block) +1. If "N" is omitted at the head block, the variable number is assumed to be the one specified by address "P" with instruction G337. Therefore, a tape without "N" is made out, and arbitrary variables are read by the instruction of "337" "Pp".

Address "P" on the tape indicates the value of the variable and cannot be omitted. "LF" is specified after "P" for value zero (#0) without specifying the value.



"LSK" or "EDIT" goes on and off under the right of the screen if the data is being read. If the data is being read, the screen cannot be changed.

NOTE

- 1 G337 is a one shot G code.
- 2 Address "O" data and every "CR", space, "DEL" code is disregarded within the significant information section.
- 3 Only ISO or ASCII code can be used for input code.
- 4 TV, TH check does not run.

(2) Outputting Macro Variable Values(G338)

G338 Pp Qq Ff Zz ;

A specified macro variable is changed into a prescribed tape format and output from reader puncher interface which opened with the transmit control mode.

Output code is selected between ISO and ASCII code by the open command.

- p : Specify the head of output macro variable
- q : Specify the number of output macro variable data
- f : Specify the output format of macro variable data (modal value when omitted)
- z : Specify the zero-suppress of macro variable data (modal value when omitted)

For output tape format, same as the input format, the head variable number address "N" and variable values with address "P" at the head block, then variable values are continuously output with P in the following blocks and finally, the tape end ("EOR") code is output.

"CR" code of every block can be output by the compile parameter PTCR(No.9003#6) . Use this code to make carriage return of a printer, etc.

PTCR=0: "CR" is not output after "LF", when outputting macro variable values.

%	LF	N10000P1234	LF	P5678	LF	%
---	----	-------------	----	-------	----	---

PTCR=1: "CR" is output twice after "LF", when outputting macro variable values.

%	LF	CR	CR	N10000P1234	LF	CR	CR	P1234	LF	CR	CR	%
---	----	----	----	-------------	----	----	----	-------	----	----	----	---

Control of the feed part does not act at output. Conduct with "G336Kk" data transmission to feed with a paper tape puncher, etc.

"EDIT" goes on and off at the lower right of the screen if a data is outputting. Screen cannot change if data is outputting.

NOTE

- 1 G338 is a one-shot G code.
- 2 Only ISO code or ASCII code can be used for output.
- 3 An end code is communicated by 115 when an invalid data is specified to a variable number, and the outputting stops.

6.4.4 Extending the Function for Inputting and Outputting a Macro Variable

The conversational macro can input and output a macro variable via the reader/punch interface. This function can be extended so that two or more variable groups can be output at a time and the output data can be read into another variable.

(1) Outputting macro variables

By adding address R to G338 described in (2) of Section 6.4.3, the tape format of the variable data to be output can be controlled.

(Command format)

G338 Pp Qq Ff Zz Rr;

R0 : Standard format (Same as when R is not specified)

R1 : Variable numbers are not output.

R10 : At the end of the tape, % (EOR) is not output.

R11 : Variable numbers are not output. At the end of the tape, % (EOR) is not output.

R20 : At the beginning of the tape, % (EOR) is not output.

R21 : Variable numbers are not output. At the beginning of the tape, % (EOR) is not output.

R30 : At the beginning and end of the tape, % (EOR) is not output.

R31 : Variable numbers are not output. At the beginning and end of the tape, % (EOR) is not output.

- (a) When variable numbers are not output, the function for inputting a macro variable (G337) can read the output variable data into a variable indicated by address P.
- (b) When % (EOR) is not output at the beginning and/or end of a tape, two or more variable groups can be output to form a single tape format.

(Example)

G330 Pp Bb ... ;

G338 P10000 Q10 F8.3 Z1 At the beginning, % (EOR) is output. Then the data of R11;⇒ #10000 to #10009 is output without variable numbers. IF[#8539NE0]GOTO999; At the end, % (EOR) is not output.

G338 P11000 Q20 F8.3 Z1 At the beginning and end, % (EOR) is not output. The R31;⇒ data follows the data output above to form a single tape format. IF[#8539NE0]GOTO999;

G338 P12000 Q10 F8.3 Z1 At the end, % (EOR) is output. R21;⇒ The tape format is closed. IF[#8539NE0]GOTO999;

G331;

6.4.5 FANUC Floppy Cassette Control

File data on the FANUC FLOPPY CASSETTE, FA CARD or FANUC PROGRAM FILE Mate can be read, prepared and deleted, by an opening command and the instruction of control code "G339".

Read file data	(G330)
Make file and write data	(G330)
Read directory information	(G330/G339 P1)
Delete file	(G330/G339 P2)
Change file data	(G330/G339 P3)

(1) Reading File Data (G330)

G330 Pp Bb Ss Cc Ll/Ff/Aa ;

Specify one of the address "L/F/A" at the time when the line is open by read control mode. At the result of this action, the head of specified file and file data reading is conducted. Refer to Section 6.4.2(1) "Circuit open" about address "P/B/S/C". However, specify reading control (11/12) for address "P" and ISO(2) for address (C).

Select one of addresses L,F, or A depending on the process.

(a) Head call by file name

Head call by file name is possible if the head variable number of the variable string which is housed in the file name is specified by address "L".

Set the file name by decimalized ASCII code to the variable string of 17 variables, and specify the head variable number by address "L".

(Example)

When calling the file name "ABCD", set 65(A), 66(B), 67(C), 68(D), 32...32(space) to 17 variables of common variables #100-116.

G330 P11 B10 S2 C2 L100 ;

NOTE

- 1 A file name is fixed to 17 characters. Be sure to use 17 characters.
- 2 Specify the file name with alphanumerics and space. Alarm 8 will be generated if code 32(space) is specified at the head of file name.

(b) Head call by the file number

Head call can be conducted with a file number, if the file number (1-9999) is specified with address "F".

(Example)

When making a head call of file number 3

G330 P11 B10 S2 C2 F3 ;

(c) Head call of next file

Next file's head call, which already exists can be conducted by the specification of address "A". Use this function to read files continuously. Be sure to specify "A1" for address A". End code (=8) is the other specification.

(Example)

When making a head call of the next file which is being called now

G330 P11 B10 S2 C2 A1 ;

(2) Making Files and Writing Data (G330)

G330 PpB_b Ss Cc (Ll/Ff) ;

New files are made and data can be written on a FANUC cassette by specifying one of address L or F when the communication line is opened with transmission control mode.

Refer to 6.4.2(1) "Circuit open" for the specification of address "P/B/S/C". Be sure to specify transmission control (21/22) for address "P", and ISO (2) for address "C".

Select one of address L or F by processing.

(a) Making files by file name

A new file can be made and data can be written on a FANUC cassette with a specified file name, if you specify the head variable number of a variable string describing a file name by address "L".

Set the file name by decimalized ASCII code to a variable string of 17 variables. Set the head variable number with address "L".

(Example)

If you make a file of file name "ABCD";

65(A), 66(B), 67(C), 68(D), 32...32(space) shall be set to the 17 common variables of #100-116

G330 P21 B10 S2 C2 L100 ;

NOTE

- 1 A file name is fixed to 17 characters. Be sure to fill spaces(code 32), if the file name is less than 17 characters.
- 2 Specify a file name with alphanumeric and spaces. Alarm 8 will be generated if the 32(space) code is specified at the head of the file name.
- 3 A new file is added to the end of recorded files.

(b) Making files by file number

A new file can be made and data can be written to a specified file number by specifying the file number (1-9999) after address "F".

(Example)

To make file No.3, specify as follows:

G330 P21 B10 S2 C2 F3 ;

NOTE

- 1 If you make a file with the file number, be careful that every file which was previously input in the specified file number, and all subsequent file numbers are deleted.
- 2 Preparation of files by file number can only be conducted for the existing files. Files can be added only by file name specification.

(3) Control of Directory Information (G330/G339)

The control of directory information is possible with control code "G339".

Read directory information (G339 P1)

Delete file (G339 P2)

Change file name (G339 P3)

The control mode at line opening shall be of directory information to use this function. Instruct P=31/32 at the opening time for specification of directory information.

G330 Pp Bb Ss Cc ;

P31 : Channel 1 Directory information control

P32 : Channel 2 Directory information control

Refer to the section on line opening for address "B/S/C". Be sure to specify ISO (2) for address "C".

Do not instruct several functions continuously in one opening time for every function of directory reading, file deleting, file name changing if you open with the control mode of directory information.

For instance, close the line once to delete the file after reading and checking directory information, as follows;

1. Open with the control mode of directory information
2. Read directory information
3. Close the line
4. Open with the control mode of directory information
5. Delete a file
6. Close the line

The same function can be instructed several times in one opening.

(a) Reading directory information

G339 P1 Ff Ll Ss ;

File directory information can be read to a specified variable by specifying "G339 P1".

Specify the file number(1-9999) for which the directory information is to be read by address "F".

Address "L" specifies the head variable number of a continuous 17 variables which houses the read file name. The file name is read with decimalized ASCII code every character.

Address "S" specifies the variable number which houses the read file size.

If you have specified (F specification) the file number once, the next directory information can be read by instructing "G339 P1" without F specification.

End code =11 reports that the directory of the specified file number does not exist.

(b) Deleting a file (G339 P2)

G339 P2 Ll/Ff ;

The relevant file can be deleted by the specification of "G339 P2".

Specify the head variable number of the variable string which houses the file name (ASCII code) you wish to delete by address "L", or specify the file number of the file you want to delete by address "F".

Be carefull when deleting with the file number because subsequent file numbers will change after deletion.

(c) Changing the file name (G339 P3)

G339 P3 Ff L1 ;

The recorded file name can be changed by the specification of "G339 P3".

Specify the file number (1-9999) of the file name you wish to change, by address "F".

Specify the head variable number of the variable string that houses the file name (ASCII code) to be changed, with address "L".

6.4.6 End Code (#8539)

Check the end code when G330-G339, has been instructed. There is no end code for line closing processing. It is always a normal end.

#8539	Contents
0	Normal end
1	Line doesn't open
2	Line trouble ,DSR signal OFF
3	Line trouble, Over run
4	Line trouble, Receive buffer over flow
5	Line trouble, Framing error, parity error
6	No option for line function
7	Line use
8	Error in parameter G335 instructed with transmit control mode G336 instructed with read control mode
9	Data format error
10	Error on file number
11	File of file number specified to read directory information does not exist
115	Undefined variable number specified
255	Receive data does not exist

6.5 REFERENCING AND READING NC PROGRAM WITH CONVERSATIONAL MACRO

6.5.1 Outline

Recording, deleting and changing of NC part program is possible by the conversational macro function. Control the NC program with program number and block number. The block numbers are counted on each EOB regarding the block with address "O" being the No.1 block. For NC programs in the conversational macro, one word is expressed by 2 variables of an address code and a number, and several words construct a block.

Set extension function valid (Parameter EXT1(No. 9002#7)) to "1" at compiling when using this function.

Make the control instruction using G codes (G320-G329) in the conversational macro.

There is an end code #8529 to check that the instructed function run correctly or not. Check end code after running G320-G329.

The end is normal when the end code #8529 is 0, and in the cases other than 0, the same number as the P/S alarm in the usual editing process will be notified.

Control variable

#8520 Specification of program number

#8521 Specification of block number

#8522 Specification of housed variable number

#8523 Variable number of a variable that specifies the number of digits under a decimal point.

#8529 End code(for reading only)

Control codes

G320 Record a new block

G321 Delete block

G322 Condensation of program

G325 Read specified block

G326 Write block

G327 Delete block

G328 Read a specified block coded in characters

G329 Write a specified block coded in characters

Background editing function as NC function is necessary for this function.

6.5.2

Recording of a New Program

G320 ;

Specify the program number to #8520 and instruct G320 to record a new program.

(Example)

```
To record O0002,  
#8520=2 ;  
G320 ;  
IF[#8529 NE 0] GOTO 900 ;  
Recording end  
N900 ;  
Error
```

Conduct similar processing as the edit "Oxxxx"+"INSERT" when recording a new program. EOB is not inserted.

```
O0002  
%
```

6.5.3

Deleting a Program

G321 ;

Specify the program number and instruct G321 to delete a program.

(Example)

```
To delete O0003  
#8520=3 ;  
G321 ;  
IF[#8529 NE 0] GOTO900 ;  
End of deletion  
N900 ;  
Error
```

6.5.4

Reading a Specified Block

(1) Reading a specified block coded in words (G325)

When issuing this command, specify a program number, block number, and the number of the variable into which the block is to be read. From the corresponding NC program coded in words, the corresponding block is read into the specified variable area. Each word contains two variables: an address code and numerical value.

(Example)

```
O0004 ;  
G92 X0. M08 ;  
G90 G00 X10.5 M05 ;  
#8520=4 ;
```

```
#8521=3 ;
#8522=100 ;
G325 ;
IF[#8529 NE 0] GOTO900 ;
End of reading
N900 ;
Error
```

The following program data is loaded from #100 which is specified by variable number #8522, when the above instruction is executed.;

```
#100=7      Address "G"
#101=90     Number
#102=7      Address "G"
#103=0      Number
#104=24     Address "X"
#105=10.5   Number
#106=13     Address "M"
#107=5      Number
#108=27     Address "EOB"
```

EOR (28) is housed as an address, if EOB is not at the end block of the program or EOR position is specified with block number.

Reading is not conducted as the end code becomes "255", if a block No. exceeding the block of EOR is specified.

(Example)

```
O0004 ;
G92 X0. M08 ;
M02
%
#100=13     Address "M"
#101=2      Number
#102=28     Address "EOR"
```

(Example)

```
If
O0004 ;
G92 X0. M08 ;
%
#100=28     Address "EOR"
```

If the function for reading a specified block coded in words (G325) reads a block which is not coded in words, completion code #8529 is set to 253 to indicate the fact.

When the completion code is set to 253, use the function for reading a specified block coded in characters (G328) to read the same block.

```
#8520 = program-number ;
#8521 = block-number ;
```

```
#8522 = number-of-the-variable-into-which-the-block-is-read ;
G325 ;
IF[#8529 EQ 253]GOTO100 ; Conventional processing
N100 G328 ;
Character-type analysis
```

(2) Reading a specified block coded in characters (G328)

When entering this command, specify a program number and block number. From an NC program which is not coded in words, the corresponding block can be read in units of characters into a specified variable area. The block is read in the form of decimal ASCII codes. Each control command (WHILE/IF/...) or function (SIN/COS/FUP/...) is represented as a single data item consisting of special code.

```
#8520 = program-number ;
#8521 = block-number ;
#8522 = 100 ;
          (Number of the variable into which the block is read)
G328 ;
IF[#8529 NE 0]GOTO900 ; ← Error check
```

When the corresponding block is "#1 = SIN [#2];"

```
#100 : 35 (23H) "#"
#101 : 49 (31H) "1"   The data is input as shown on the left.
#102 : 61 (3Dh) "="
#103 : 276 (114H) "SIN"
#104 : 91 (5BH) "["
#105 : 35 (23H) "#"
#106 : 50 (32H) "2"
#107 : 93 (5DH) "]"
#108 : 59 (3BH) ";," ← "EOB" code
```

6.5.5

Block Writing

(a) Writing a block coded in words (G326Pp)

Prepared program data can be written in the variable area after the block specified by the program number and block number. Specify the maximum number of variable data by address P. If address "EOB" is present within the specified data, program is written up to "EOB"; if "EOR" is present, program is written up to the EOR; and if neither "EOB" nor "EOR" is present, program is written by the number of data specified by address "P".

(Example)

```
O0004 ;
G92 X0. M08 ;
G90 G00 X10.5 M05 ;
#8520=4 ;
#8521=2 ;
#8522=100 ;
#100=7 ;
```

```
#101=1 ;
#102=24 ;
#103=20.5 ;
#104=6 ;
#105=1000 ;
#106=20.7 ;
G326 P7 ;
IF[#8529 NE 0] GOTO900 ;
End of writing
N900 ;
Error
```

If the above instruction is executed, a block is input as follows;

```
O0004 ;
G92 X0. M08 ;
G1 X20.5 F1000. ;
G90 GO X10.5 M05 ;
```

End code becomes "255" and it is impossible to conduct writing, if the specification of block number is EOR block only or higher numbers.

(1) Decimal point specification of every address in block writing

The number of digits after the decimal point of every address can be specified. With this specification, the contents of the variable number which was specified to #8523 becomes the number of digits after the decimal point of address A, and it is possible to determine the number of digits after the decimal point of every address, as shown below.

```
#8523=501 ;
#501 is the number of digits after the decimal point of address A
#502 is the number of digits after the decimal point of address B
:
:
#525 is the number of digits after the decimal point of address Y
#526 is the number of digits after the decimal point of address Z
```

Specify <vacant> or 0 - 7 for the number of digits after the decimal point. In the case of <vacant>, it is considered that no decimal point exists in the address.

(Example)

If address code=A, number=1.2345678

```
Decimal point specification
= <blank>  A1
= 0        A1.
= 1        A1.2
= 2        A1.23
= 3        A1.235  *
= 4        A1.2346 *
= 5        A1.23457 *
= 6        A1.234568 *
= 7        A1.2345678
```

* The data less than the specified digits is rounded off.

When #8523 is 0, auto setting is conducted by the system conditions (mm input/inch input, 0.1 μ m instruction) and specified address. #8520 - #8523 is set to 0 when the power is turned on.

(2) Writing a block coded in characters (G329Pp)

Use this command to write a program whose data is not coded in words. This command writes the program data coded in units of characters in a variable area.

The block to be written must be defined beforehand in ASCII code in a macro variable area. This command writes the data after the block specified by the program number and block number.

The maximum number of variable data items is indicated by address P. If EOB or EOR is detected while the specified variable data is being written, data writing ends at the EOB or EOR. When neither EOB nor EOR is found, the complete data indicated by address P is written.

(ASCII string definition)

#8520 = program-number

#8521 = block-number

#8522 = number-of-variable-at-the-beginning-of-the-ASCII-string

G329 P20 ;

IF[#8529 NE 0]GOTO900 ; ← Error check

NOTE

This command cannot catalog a program. If an attempt is made to catalog a program with this command (if the data to be written begins with O), an error code is indicated and #8529 is set to 202.

6.5.6

Block Deletion

G327 ;

A block specified by a program number and a block number can be deleted.

#8520=4 ;

#8521=3 ;

G327 ;

IF[#8529 NE 0] GOTO900 ;

End of deletion

N900 ;

Error

The block of block No.3 of program O0004 is deleted by the above instruction.

6.5.7 Condensation of Program

When writing an NC program prepared by a conversational macro onto the NC's tape memory, the program can be condensed to extend memory area.

Set a program number of a program to be condensed to the variable #8520 and specify G322. Then the program is condensed.

The result of condensation is informed to the end code #8529.

(Example) To condense O1234

```
#8520=1234;
G322;
IF [#8529 NE 0] GOTO Error;
```

6.5.8 End Code (#8529)

Check the end code after running every processing.

The end is normal when the end code is 0, and when the end code is a number other than 0, the same number as with the P/S alarm in the usual edition processing and the following codes are informed.

#8529	Contents
140	Processing of the program being selected in the foreground cannot be conducted.
200	The specified character code is not found. (G329)
202	The data to be written begins with O. (G329)
253	The specified block is not coded in words.
254	Program editing is prohibited by setting the memory protection key [when compilation parameter bit 1 of No. 9006 (KEYC) is set to 0].
255	Need the option for background editing function. It is impossible to instruct the statement during background editing. Parameter for the extension function effective (No.9002#7 EXT1) must be set to "1" at compiling.

6.5.9 Notes

Selection processing by work number search etc. is required when foreground operation is executed for a program which has been prepared and edited under background.

6.5.10 Address Code Table

Address	Code	Address	Code	Address	Code
A	1	B	2	C	3
D	4	E	5	F	6
G	7	H	8	I	9
J	10	K	11	L	12
M	13	N	14	O	15
P	16	Q	17	R	18
S	19	T	20	U	21
V	22	W	23	X	24
Y	25	Z	26		
EOB	27	EOR	28	/	29


Statement	Decimal	Hexadecimal	Statement	Decimal	Hexadecimal
IF	258	102H	SIN	276	114H
WHILE	259	103H	COS	277	115H
GOTO	260	104H	TAN	278	116H
DO	261	105H	ATAN	279	117H
END	262	106H	SQRT	280	118H
GE	264	108H	ABS	281	119H
GT	265	109H	BCD	282	11AH
LE	266	10AH	BIN	283	11BH
LT	267	10BH	FIX	284	11CH
NE	268	10CH	FUP	285	11DH
EQ	269	10DH	ROUND	286	11EH
XOR	272	110H	POPEN	291	123H
OR	273	111H	PCLOS	292	124H
AND	274	112H	DPRNT	293	125H
			BPRINT	294	126H
			SETVN	295	127H

6.6 CONTINUOUS INPUT BY CURSOR AND PAGE KEY

Continuous input by cursor and page key is possible with the conversational macro key input control (#8501).

(Address code table)

#8501 can be read with the following timing if the cursor and page key, are continuously pressed.



NOTE

The value of #8501 remains as is until read by a macro statement. Once the value has been read, all key entries are ignored.

6.7 MASKING OF O, N NUMBER APPEARANCE

O, N number appearance can be erased on the CUSTOM screen.

O, N numbers does not appear when compile parameter "ONMSK=1" (No.9003#0).

6.8 READING AND PRESETTING CUTTING TIME AND CUTTING DISTANCE BY CONVERSATIONAL MACRO

Cutting distance and cutting time can be read and preset with the macro variable of the conversational macro.

Use it for the control of a tool life.

#8553, #8554 does not become 0 at power on.

6.8.1 Reading and Presetting Cutting Time (#8553)

The time only for instruction of G01 (linear interpolation) and G02,G03 (circular interpolation) can be counted by #8553.

The unit is the same as the macro variable (#3002).

6.8.2 Reading and Presetting Cutting Distance (#8554)

The distance only for instruction of G01(linear interpolation), and G02, G03 (circular interpolation) can be counted by #8554.

It is valid also for helical instruction.

Parameters (No.9002#7 / EXT1) and (No.9004#7 / CUTLG) have to be on at compiling to use this function.

The unit is

... 0.001(mm) for the mm input system.

... 0.0001(inch) for the inch input system.

As the tool movement distance is added to #8554 at the time of starting the cutting block, the distance of block movement is added even when cutting stops during a block due to resetting, etc.

6.9 READING AND PRESETTING RELATIVE COORDINATES BY CONVERSATIONAL MACRO

Relative coordinates can be read and preset with the conversational macro.

6.9.1 Reading Relative Coordinates

Reading of relative coordinates can be informed by the window function.

Set ID No.110-115 to #8993, and relative coordinates can be read by #8999.

ID No. 110 1st axis coordinates
 111 2nd axis coordinates
 112 3rd axis coordinates
 113 4th axis coordinates
 114 5th axis coordinates
 115 6th axis coordinates
 116 7th axis coordinates
 117 8th axis coordinates

(Example)

If the relative coordinates value of the 1st axis is -123.456
 #8998=110; ((Include the contents of ID No.110)
 #500=#8999;
 Contents of #500 is -123456.

6.9.2 Presetting Relative Coordinates

Relative coordinate values can be freely preset by G310AaQq.

Set the ID No. shown above to address A.

A110 - 115

Set the coordinates values to be preset to address Q.

Q -99999999 to 99999999

Relative coordinate values can be preset freely by execution of this control.

(Example)

To preset the relative coordinates value of 1st axis to -123.45;
 G310 A110 Q-123450

Be sure that this function does not change the increment system.

6.10 KEY-INPUT AND DATA-INPUT CONTROL

(1) Key-input control variable #8501

You can read out the key input with #8501. The following is the correspondence of the key input and #8501.

Display unit with seven soft keys

Key input	Value	Key input	Value
PAGE.DOWN	1	SOFT FUNCTION KEY LEFT	11
PAGE UP	2	SOFT FUNCTION KEY 1	12
CURSOR DOWN	3	SOFT FUNCTION KEY 2	13
CURSOR UP	4	SOFT FUNCTION KEY 3	14
ALTER	5	SOFT FUNCTION KEY 4	15
INSERT	6	SOFT FUNCTION KEY 5	16
DELETE	7	SOFT FUNCTION KEY RIGHT	17
INPUT	8		
RESET	10		
CURSOR RIGHT	18		
CURSOR LEFT	19		

Display unit with twelve soft keys

The soft function keys follows:

The other keys are the same as seven softy keys.

Key input	Value	Key input	Value
SOFT FUNCTION KEY LEFT	20	SOFT FUNCTION KEY 1	21
SOFT FUNCTION KEY 2	22	SOFT FUNCTION KEY 3	23
SOFT FUNCTION KEY 4	24	SOFT FUNCTION KEY 5	25
SOFT FUNCTION KEY 6	26	SOFT FUNCTION KEY 7	27
SOFT FUNCTION KEY 8	28	SOFT FUNCTION KEY 9	29
SOFT FUNCTION KEY 10	30	SOFT FUNCTION KEY RIGHT	31

When there is no key input, the #8501 value is 0.

Once there is a key input, #8501 holds its value till it is input with the macro statement, and the following key inputs will be ignored. When #8501 is input, the status gets ready to accept the key input and #8501 will be 0.

It is impossible to write a value into #8501.

(2) Data input control variable #8502, numerical data variable #8503, address data variable #8504

Control the input of numeric data and address data by setting the following values to #8502.

- #8502 = 0 ...No data input
- = 1 ... Input of numeric data
- = 2 ...Input of address data and numeric data
- = 3... Expanded data input control

When #8502 is 0, nothing will be displayed on the data input line and it will be impossible to input data, either.

When #8502 is 1, NUM will be displayed on the data input line and input of numeric data will be possible. When #8502 is 2, ADRS will be displayed on the data input line. After address data is input, NUM is displayed and it is possible to input the numeric data. #8502 value is 0 at switching on the power.

When the key-input control variable #8501 is key-input to the value other than 0, the data input line will return to the initial state. It is possible to read out the input numeric value and address with the numeric data variable #8503 and the address data variable #8504 respectively. The following is the correspondence of the input address and #8504.

```
A  ...1  B  ...2  C  ...3  D...4  E  ...5
F  ...6  G  ...7  H  ...8  I  ...9  J  ..10
K  ..11  L  ...1  M  ..13  N..14  O  ..15
P  ..16  Q  ..17  R  ..18  S  ..19  T  ..20
U  ..21  V  ..22  W  ..23  X..24  Y  ..25
Z  ..26
```

#8503 and #8504 values will be held till the input control variable #8501 is key-input to the value other than 0.

When numerical data and address data are not input, #8503 and #8504 will be "vacant" respectively.

It is impossible to write any values to #8503 and #8504.

Conversational Macro Extended Data Input Control Function

If you set 3 to #8502, and a variable number to #8552, the character string input mode is entered, and < appears on the input line, and it is possible to input addresses and number data.

The data input line changes to the initial state when key input status variable #8501 changes to other than 0. 32 variables from a variable number which is set to variable #8552 can read the input numbers and addresses for as ASCII codes.

<blank> input a 32 number series if there is no input data.

(Example)

Set for

```
#8502=3 ;
```

```
#8552=500 ;
```

and input

```
0123456ABCD<
```

and press return key, then the following values are set to the variables.

```
#500=48, #501=49, #502=50, #503=51, #504=52, #505=53,
#506=54, #507=65, #508=66, #509=67, #510=68,
#511=<blank> to #531=<blank>, #8501=8
```

The values of #8503, #8504 are not guaranteed.

6.11 CURSOR CONTROL

It will be possible to display the cursor by setting the value at the cursor control variable #8505.

#8505 = 0 .. Cursor erase

= 1 .. Cursor display

#8505 value is 0 at power ON.

It will be possible to display the cursor at any optional position by setting the values for the cursor X position control variable #8506 and the cursor Y position control variable #8507. Specify the cursor position with the character coordinates system.

6.12 PROCESSING ARRAY TYPE P-CODE VARIABLES

- (1) Reference of array type P-CODE variables for conversational macro

In conversational macro, two or three-dimensional array type P-CODE variables (#10000...) can be referred. Set a proper value to the following array control variables beforehand and an array element of P-CODE variables is referred to corresponding to the variable number (#1 - #99).

NOTE

Variables #1 to #99 for conversational macro are different from local variables #1 to #33 for execution macro.

Array control variable:

- #8512 Two-dimensional array number
- #8513 Three-dimensional array number
- #8516 Maximum value of one-dimensional array number
- #8517 Maximum value of two-dimensional array number
- #8519 Array top variable number

Specify an array type by the array control variables #8516 to #8519 and specify the array number referred to by the #8512 and #8513. Variables #1 to #99 are used to refer the values.

The correspondence between the P-CODE variables and array elements is as shown below:

P-CODE variable number

$$= \#8519 + ((\#8516 \times \#8517) \times (\#8513 \times 1)) + (\#8516 \times (\#8512 - 1))$$

(Specified variable number-1)

Example)

When the #8516, #8517, and #8519 are set to 10, 5, and 10100, respectively:

- 1) When both of #8512 and #8513 are set to 1, the value for #1 corresponds to that for #10100.
- 2) When the #8512 and #8513 are set to 3 and 2, respectively, the value for #10 corresponds to that for #10179.

Each variable of #8512 to #8517 and #8519 are set to 1 and 10000, respectively when the power is turned on.

Thus, the #8513 and #8517 can be used in the case of use as the two-dimensional array. No check is carried out on minimum value of each variable P-CODE variable number after calculation.

Use the macro program when needed.

NOTE

This function can be used in the conversation macro program and auxiliary macro program.

In the execution macro, the #1 to #33 are local variables and the #34 to #99 are variables which cannot be used and would result in an alarm.

(2) Processing array type P-CODE variables

This is a function which controls processing of array type variable or of variable string when P-CODE variables are used in the conversational macro.

- 1) clearing array type number, variable string (continuous writing of specified data)
- 2) transferring to variable string from array type variables or variable string

Every processing commands control code "G315" after defining an array or variable string or data to the following control numbers.

- #8511 : data to be transferred
- #8512 : 2 dimensional array number or the head variable of a variables string to be transferred
- #8513 : 3 dimensional array number to be transferred
- #8514 : transferred 2 dimensional array number or the head variable of a variable string
- #8515 : transferred 3 dimensional array number

Control code

G315 P (Processing code) K (a number of processing data) ;

Processing code specifies the type of processing with a 3-digit number. High-order "0s" can be suppressed.

- P001 (P1) : Loads data of #8511 to K continuous numbers from the number which was specified at #8514.
- P002 (P2) : Transfers K continuous data which was specified at #8512 to K continuous variables from the variable which was specified at #8514 (ascending order).
- P003 (P3) : Transfers K continuous data which was specified at #8512 to K continuous numbers from the number which was specified at #8514 (descending order).
- P101 : Loads data of #8511 to K continuous array numbers of array number #1 which was specified at #8514, #8515.
- P102 : Transfers K continuous array variables starting with variable #1 which was specified at #8512 and #8513, to the continuous array variable which was specified at #8514 and #8515 (ascending order).
- P103 : Transfers K continuous array ariables starting with variable #1 which was specified at #8512 and #8513, to the continuous array variable which was specified at #8514 and #8515 (dscending order).

The difference of P2 and P3, or P102 and P103 results from whether transfer processing is conducted from a small number or from a large number.

(Example)

If #8512=10000, #8514=10010,

G315 P2 K3 ; has the following disposition.

- #10010=#10000 ;
- #10011=#10001 ;

#10012=#10002 ;

G315 P3 K3 ; has the following disposition

#10012=#10002 ;

#10011=#10001 ;

#10010=#10000 ;

6.13 TORQUE LIMIT CONTROL

The torque limit override can be modified to the specified value by setting values to the #8621 to #8628.

#8621	1st axis	#8625	5th axis
#8622	2nd axis	#8626	6th axis
#8623	3rd axis	#8627	7th axis
#8624	4th axis	#8628	8th axis

The relation of setting value and torque limit override are shown as below:

Setting	Torque override
0	0%
:	:
128	50%
255	100%

The values on power on are 100%.

NOTE

When a value other 0 to 255 is set:
In an execution---P/S alarm 110
In conversational/auxiliary macro---Ignored

6.14 DATA READING OF A/D CONVERTER (Series 16/18)

Data from the A/D converter can be read by the conversational macro.

The A/D converted data from channels 1 to 4 corresponds to macro variables #8631 to #8634.

When reading operation is performed in the conversational macro program, the A/D converted data of each channel at that timing is input.

#8631 A/D converted data of channel 1

#8632 A/D converted data of channel 2

#8633 A/D converted data of channel 3

#8634 A/D converted data of channel 4

The input data is calculated in proportion to the following:

-10V = 0

0V = 128

+10V = 255

NOTE

- 1 The A/D converted data variables #8631 to #8634 can be used for read only.No data can be written in them.

Correct #100 = #8631
IF [#8631 GT 1000] GOTO 100 ;
#101 = #8634/200 ;

Incorrect #8631 = 2000 ;

- 2 The PCB "Option 2 board (analog I/O)" (A16B - 1211 - 0960) is required when this function is used.

6.15 KEY-IN LINE CONTROL

On the conversational macro screen, a key-in line is displayed at a point whose X and Y coordinates are 0 and 20 respectively. Up to 32 characters (20 lines when CNC parameter no. 3105#2 = 1) can be input. The prompt and key-in lines are displayed in light blue. The conversational macro can control the display position, number, and color. When the screen is switched from the POS screen to the conversational macro screen, the setting is initialized. When switching the screen, create a P-CODE program to set control variables.

- (1) #8561, #8562 (X and Y coordinates of the point where the key-in line is displayed)

#8561 : X coordinate

#8562 : Y coordinate

The display position is changed when #8562 is written.

The macro program must be created so that #8561 and #8562 are set in that order. The previous key-in line is not automatically erased after the display position is changed. If required, erase the previous key-in line with a macro routine.

- (2) #8563 (Number of input keys)

#8563 : Number of input keys

Previous key-in lines are not automatically erased after the number of input keys is reduced. If required, erase the previous key-in lines with a macro routine.

- (3) #8564, #8565 (Display of prompt and key-in line)

To change the display of the prompt, set #8564 as listed below.

To change the display of the key-in line, set #8565 as listed below. The set values are listed below.

	Standard	Blinking	Reversed	Blinking and reversed
White	224	232	240	250
Light blue	192	200	208	216
Purple	160	168	176	184
Blue	128	136	144	152
Yellow	96	104	112	120
Green	64	76	80	88
Red	32	40	48	56

6.16 READING THE BACKGROUND EDITING STATUS

The conversational and auxiliary macros can read the CNC background editing status with a variable.

#8526: Background editing status
 0 : The background editing is halted.
 1 : The background editing is in progress.

NOTE

Variable #8526 cannot be written.

6.17 READING THE NUMBER OF CATALOGED PROGRAMS

The conversational and auxiliary macros can read the number of programs cataloged in the CNC program memory with a variable.

#8527 : Number of cataloged programs

NOTE

Variable #8527 cannot be written.

6.18 READING THE SIZE OF THE FREE SPACE IN THE CNC PROGRAM MEMORY

The conversational and auxiliary macros can read the size of the free space remained in the CNC program memory with a variable.

#8528: Size of free space in CNC program memory
 (Unit: Characters)

NOTE

Variables #8528 cannot be written.

6.19 READING THE REMAINING TRAVELING DISTANCE

The conversational and auxiliary macros can read the remaining traveling distance of each CNC control axis with a variable.

#5181: Remaining traveling distance of the first axis
 #5182: Remaining traveling distance of the second axis
 : :
 #5188: Remaining traveling distance of the eighth axis

NOTE

Variable #5181 to #5188 cannot be written.

6.20 OFFSET MEMORY C AND EXTENDED SYSTEM VARIABLE OF THE WORKPIECE COORDINATE SYSTEM (Series 16/18)

When the execution, conversational, or auxiliary macro references offset memory C or an extended system variable of the workpiece coordinate system, 100000 is added to the corresponding variable number used by the custom macro function of the system.

(Example) Reading and writing the compensation data of the offset memory (C) by the execution, conversational, or auxiliary macro

#100 = #110001;
 #110002 = 1.5;

6.21 PMC AXIS CONTROL

NOTE

PMC axis control is not available for 20-TA/21-TA.

6.21.1 PMC Axis Control by the G Code

The conversational macro can control the PMC control axis through the PMC axis control interface. The seven control codes listed below are used for this purpose. The PMC control axis to be controlled is specified by the PMC control axis selection variable, #8602.

- G340 → Rapid traverse command
- G341 → Cutting feed command
- G344 → Dwell command
- G345 → Reference position return command
- G346 → Miscellaneous function command
- G348 → Status signal read command
- G349 → Command signal write command
- #8602 → PMC control axis selection variable

#8602	Area	Series 16	Series 18	20-FA	Series 21
0	Area A	1st to 8th axis	1st to 4th axis	1st to 3rd axis	1st to 4th axis
1	Area B	1st to 8th axis	1st to 4th axis	1st to 3rd axis	1st to 4th axis
2	Area C	1st to 8th axis	1st to 4th axis	1st to 3rd axis	1st to 4th axis
3	Area D	1st to 8th axis	1st to 4th axis	1st to 3rd axis	1st to 4th axis

NOTE

- 1 For information about the PMC axis control interface, refer to the corresponding connection manual for each machine.
- 2 A control axis is selected by setting bits of the input signal parameter G136. Use the PMC to set the bits of G136.

For details, refer to the CONNECTION MANUAL for each Series.

If a value other than 0 to 3 is specified in #8602, the control command is ignored.

(1) Control codes

(a) Rapid traverse command (G340)

G340 Xxxx;

The rapid traverse command is issued to the PMC control axis. Specify the incremental traveling distance after address X.

(b) Cutting feed command (G341)

G341 Xxxx Ffff;

The cutting feed command is issued to the PMC control axis. Specify the incremental traveling distance after address X. Specify the feedrate after address F.

(c) Dwell command (G344)

G344 Pxxx;

The dwell command is issued to the PMC control axis. Specify the dwell time after address P.

(d) Reference position return command (G345)

G345;

The reference position return command is issued to the PMC control axis.

(e) Miscellaneous function command (G346)

G346 Mmm;

The miscellaneous function command is issued to the PC control interface. Specify the miscellaneous function code after address M.

(f) Status signal read command (G348)

G348 Pppp;

The status signals (F130, F133, F136, F139) of the corresponding PMC axis control interface are read into the variable indicated by address P. A one-byte signal is expressed in decimal and input to the variable. The EBSY signal is always input as 0.

7	6	5	4	3	2	1	0
EBSY	EOTN	EOTP	EGEN	EDEN	EIAL	ECKZ	EINP

For details of the signals, refer to the CONNECTION MANUAL for each Series.

(Example) When both EOTN and EIAL are 1

G348 P100;

This G code causes #100 to be set to 68.

(g) Command signal write command (G349)

G349 Pppp;

A numeric value indicated by address P is written into the command signals (G142, G154, G166, G178) of the corresponding PMC axis control interface. The EBUF and EFIN signals cannot be written.

7	6	5	4	3	2	1	0
EBUF	ECLR	ESTP	ESOF	ESBK			EFIN

For details of the signals, refer to the CONNECTION MANUAL for each Series.

(Example) ECLR can be set to 1 by the following G code:

G349 P64; (64 = 01000000b)

(2) Notes

(a) Buffering a command

The PMC axis control function buffers command blocks in the CNC unit so that it can execute two or more commands sequentially. While a block is being executed, the next block can be specified if the CNC buffer has sufficient free space. If the CNC buffer has no free space, the next command is in the wait state until the previous command block is executed and space in the buffer becomes free. Meanwhile, the display level is locked.

(b) Miscellaneous function command

A miscellaneous function command can be issued by G346. The conversational macro, however, cannot control the miscellaneous function completion signal, EFIN. Use the PMC to control it.

(c) Contention for the PMC axis control function

The situation in which both the PMC and this function issue commands to an identical PMC control axis must be avoided. When this function is used for a PMC control axis, the PMC can control only the following two signals for the same control axis: Miscellaneous function completion signal (EFIN) and axis selection signal (G136).

For details, refer to the CONNECTION MANUAL for each Series.

**6.21.2
PMC axis Control by
Variables**

The conversational macro can control the PMC control axis with variables through the PMC axis control interface.

The macro uses the following variables for PMC axis control:

#8700 → PMC control axis selection variable

Name of variable	Variable area			
	Area A	Area B	Area C	Area D
PMC command signal variable	#8710	#8720	#8730	#8740
PMC control command variable	#8711	#8721	#8731	#8741
PMC cutting feedrate variable	#8712	#8722	#8732	#8742
PMC controlled travelling distance variable	#8713	#8723	#8733	#8743
PMC status signal read variable	#8715	#8725	#8735	#8745

Variable	Series 16	Series 18	20-FA	Series 21
Area A	1st to 8th axis	1st to 4th axis	1st to 3rd axis	1st to 4th axis
Area B	1st to 8th axis	1st to 4th axis	1st to 3rd axis	1st to 4th axis
Area C	1st to 8th axis	1st to 4th axis	1st to 3rd axis	1st to 4th axis
Area D	1st to 8th axis	1st to 4th axis	1st to 3rd axis	1st to 4th axis

NOTE

A control axis is selected by the PMC control axis selection variable, #8700.

For details, refer to the CONNECTION MANUAL for each Series.

(1) Variables

(a) PMC command signal variable
(#8710, #8720, #8730 and #8740)

When a numeric value is specified in #8710 or #8720, data is written into the command signals (G142, G154, G166, G178) of the corresponding PMC axis control interface. G142, G154, G166, and G178 cannot be read from the PMC. The EFIN signal cannot be written.

7	6	5	4	3	2	1	0
EBUF	ECLR	ESTP	ESOF	ESBK			EFIN

- (b) Control command variable
(#8711, #8721, #8731 and #8741)

When a control command is specified in #8711 or #8721, the axis control command is written into the corresponding axis control command signal (G143, G155, G167, G179). (G143, G155, G167, and G179 cannot be read from the PMC). The command can also be read.

7	6	5	4	3	2	1	0
	EC6	EC5	EC4	EC3	EC2	EC1	EC0

- (c) Cutting feedrate control variable
(#8712, #8722, #8732 and #8742)

When a numeric value is specified in #8712 or #8722, the cutting feedrate is written into the corresponding command data signal (G144, G145, G156, G157, G168, G169, G180, G181). The feedrate can also be read. (G144, G145, G156, G157, G168, G169, G180 and G181 cannot be read from the PMC).

7	6	5	4	3	2	1	0
EIF7	EIF6	EIF5	EIF4	EIF3	EIF2	EIF1	EIF0
EIF15	EIF14	EIF13	EIF12	EIF11	EIF10	EIF9	EIF8

- (d) Controlled traveling distance variable
(#8713, #8723, #8733 and #8743)

When a numeric value is specified in #8713 or #8723, the axis traveling distance, dwell time, or miscellaneous function code is written into the corresponding command data signal (G146 to G149, G158 to G161, G170 to G173, G182 to G185). The data can also be read. (G146 to G147, G158 to G161, G170 to G173 and G182 to G185 cannot be read from the PMC).

7	6	5	4	3	2	1	0
EID7	EID6	EID5	EID4	EID3	EID2	EID1	EID0
EIF15	EID14	EID13	EID12	EID11	EID10	EID9	EID8
EID23	EID22	EID21	EID20	EID19	EID18	EID17	EID16
EIF31	EID30	EID29	EID28	EID27	EID26	EID25	EID24

- (e) PMC status signal read variable
(#8715, #8725, #8735 and #8745)

The status signals (F130, F133, G136, G139) of the corresponding PMC axis control interface are written into the variable specified by #8715 or #8725. A one-byte signal is expressed in decimal and input into the variable.

7	6	5	4	3	2	1	0
EBSY	EOTN	EOTP	EGEN	EDEN	EIAL	ECKZ	EINP

For details of the signals, refer to the CONNECTION MANUAL for each Series.

6.22 INTERLOCK FUNCTION FOR AXIS DIRECTION

The interlock control variable for a single axis direction, #8600, determines the direction for which interlocks are provided. Variable #8601 indicates the axis and direction of a movement when the SKIP signal is set on.

This function is validated when compilation parameter XDIL (No. 9002, #4) is set to 1.

NOTE

- 1 This function cannot be used with the Series 20.
- 2 This function cannot be used when the manual linear or circular interpolation function is supported (Series 16 and 18).

The interlock function for a single axis direction is validated only when the following two conditions are satisfied: The system is in the mode in which an interlock is provided for a single axis direction, that is, the JOG or HNDL mode. The signal of the internal PMC relay (R area) which was specified by compilation parameters 9035 and 9036 is set on.

When the values of variables #8600 and #8601 are expressed in binary, each digit corresponds to a single axis direction as shown below:

	7	6	5	4	3	2	1	0
M Series	4-	4+	Z-	Z+	Y-	Y+	X-	X+
T Series	4-	4+	3-	3+	Z-	Z+	X-	X+

When the values of #8600 and #8601 are 00000001 in binary, for example, they indicate the positive direction along the X-axis. When they are 00000010 in binary, they indicate the negative direction along the X-axis.

- (1) Interlock control variable for a single axis direction, #8600

When the value of variable #8600 is 0, interlocks are provided for all axes whenever the SKIP signal is set on.

When the value of variable #8600 is other than 0, interlocks are provided for the axis direction indicated by the value.

When the power is turned on, the value of #8600 is set to 0.

- (2) Variable indicating the axis and direction of movement when the SKIP signal is set on, #8601

When the state of the SKIP signal changes from off to on, variable #8601 indicates the axis along which the last movement was made and the direction of movement.

The value of #8601 is retained until the state of the SKIP signal changes from off to on next time.

No value can be written in variable #8601.

6.23 FUNCTION FOR SEPARATING UI FROM UO OF THE P-CODE PROGRAM

This function allows the signals of the system variables of the P-CODE program (UI: #1000 to #1015, #1032, UO: #1100 to #1115, #1132) to be different from those of the user program.

When the program is compiled with parameter DIOC (No. 9006, #0) set to 1, UI and UO of the P-CODE program (execution, conversational, or auxiliary macro) correspond to the following interface signals. Even when this function is used, UI and UO of a user-created custom macro program correspond to ordinary interface signals.

Input signal	Output signal
#1000 : EUI00	#1100 : EUO00
#1001 : EUI01	#1101 : EUO01
#1002 : EUI02	#1102 : EUO02
:	:
#1015 : EUI15	#1115 : EUO15
#1032 : EUI00-EUI15	#1132 : EUO00-EUO15

PMC interface

Input signal

	7	6	5	4	3	2	1	0
G082	EUI07	EUI06	EUI05	EUI04	EUI03	EUI02	EUI01	EUI00
G083	EUI15	EUI14	EUI13	EUI12	EUI11	EUI10	EUI09	EUI08

Output signal

	7	6	5	4	3	2	1	0
F084	EUO07	EUO06	EUO05	EUO04	EUO03	EUO02	EUO01	EUO00
F085	EUO15	EUO14	EUO13	EUO12	EUO11	EUO10	EUO09	EUO08

6.24 REFERENCING COMMON VARIABLES OF CUSTOM MACROS

An execution, conversational, or auxiliary P-CODE program can reference and write common variables (#100 to #199, #500 to #999) used by a user program for custom macro B. With variables #99100 to #99199 and #99500 to #99999, the P-CODE program can reference and write common variables #100 to #199 and #500 to #999 of the user program.

#99100 → Corresponds to #100.

:

#99149 → Corresponds to #149.

:

#99500 → Corresponds to #500.

:

#99531 → Corresponds to #531.

NOTE

The common variables #100 to #149 and #500 to #531 can be referenced or written.

6.25 DISPLAYING THE CONVERSATIONAL MACRO SCREEN WHEN THE POWER IS TURNED ON

With the conventional compilation parameter, DAUX (No. 9002, #5), the screen of CNC series and edition is displayed while the CNC unit is in the emergency stop state or external reset state. If a new parameter, DAUXR (No. 9006, #3), is specified, the conversational macro screen can be immediately displayed even in the emergency stop state or external reset state.

DAUXR=1: The conversational macro screen is displayed when the power is turned on.

Parameter DAUX (No. 9002, #5) must also be set to 1.

6.26 LEAVING THE SCREEN UNCHANGED WHEN THE KEY IS PRESSED

If compilation parameter CNCHG (No. 9006, #4) is set to 1, the execution of a conversational macro can be continued when the  key is pressed while the conversational macro screen is displayed. If the parameter is set to 0, the system assumes that a request to change the screen is made and the screen is initialized. The current conversational macro is executed from the beginning.

CNCHG=1: The execution of the conversational macro is continued when the  key is pressed while the conversational macro screen is displayed.

6.27 FUNCTION FOR FINDING A P-CODE WORK NUMBER

When compilation parameter PWSR (No. 9002, #6) is set to 1, the function for finding a P-CODE work number can be used.

When an operation program created in the program editing memory makes a G-, M-, or T-code call, generally an execution macro (program) is called and executed as a subprogram or a macro program. If automatic operation is started with this function, an execution macro program cataloged in the ROM can be directly activated.

A conversational or auxiliary macro is used to write the number of the P-CODE program to be started in the P-CODE work number control variable (#8610).

If the value of #8610 is not null or 0 when the automatic operation is started in the automatic operation (MEM) mode while the CNC unit is in the reset state, the P-CODE program having the number indicated by the value of #8610 is found and executed from the beginning.

If the value of #8610 is null or zero, the user program currently selected by the CNC unit is executed as usual.

If the program started by this function ends with M99, the currently selected program is executed after M99.

When power is turned on, the value of #8610 is set to 0.


NOTE

When #8610 is a value other than zero, this function starts a P-CODE program regardless of the program currently selected by the CNC unit (the user program displayed on the CNC screen). When this function is used, measures to prevent an operator error must be taken. For example, an alarm lamp activated by an auxiliary macro or the PMC and interlock processing are helpful.

6.28 FUNCTION FOR CALLING A USER PROGRAM BY AN EXECUTION MACRO

6.28.1 Function

Using the M code specified by compilation parameter, a P-CODE program (execution macro program) called by a G, M, or T code from a user program can call another user program as a subprogram.



6.28.2 Calling Format

Mmm Ppppp:

mm : M code specified in compilation parameter No. 9033
 pppp : Number of the user program to be called
 (A variable or expression can be specified.)

6.28.3 Multiple Calls

- (1) Program call from a user program which was called by an execution macro


Other user program in the program editing memory can be called from a user program, which was called by an execution macro program, using M98, G65 and G66. However, other user program cannot be called by using G, M, T, or special code, etc.

Also an execution macro program can be called from a user program which was called by an execution macro.

Program to be called	Calling method	
	M98, G65, G66	M/S/T/Special code/etc
User program in program editing memory	Yes	No
Execution macro program	No	Yes

- (2) Calling from an execution macro

A user program can be called from an execution macro which was called by a user program. However, user program cannot be called doubly from an execution macro program.




(3) Multiple calls

- The number of multiple calls of user programs and execution macro programs are limited, respectively. The number of multiple calls of user programs called from execution macro programs is calculated independently of the number of multiple calls of execution macros.

Calling method	Program to be called	
	User program	Execution macro program
Subprogram call	4 holds	4 holds
Macro call	4 holds	4 holds

- When an execution macro calls a user program, the number of multiple calls of user program is added by one.
- When a user program calls an execution macro program, the number of multiple calls is not added for the first call but it is added by one from the 2nd call.



Direction of calling		Addition to the number of multiple calls
Calling user program from execution macro program	1st	Not added
	2nd	Added to the number of multiple calls of execution macro program
Calling user program from execution macro program		Added to the number of multiple calls of user program

NOTE

When the program execution returns from a user program to an execution macro program, it is not available to specify a sequence number as a return designation.

6.29 OPERATION FUNCTIONS (LOGARITHM, EXPONENT, ARCSINE, ARCCOSINE)

6.29.1 Overview

The following operation functions can be used:

Logarithm (LN)
Exponent (EXP)
Arcsine (ASIN) (Unit: Degrees)
Arccosine (ACOS) (Unit: Degrees)

The functions above have the same effect as the operation instructions of custom macro B. For the precision, data format, operation precision, and so forth of the functions, refer to the OPERATOR'S MANUAL of each Series.

The functions can be used with an conversational macro, auxiliary macro, or execution macro. When the functions are used with an execution macro, the option for custom macro B is required for the CNC.

6.29.2 Operation

To find the value assumed by a function for a given value, enter the given value in #101, then execute the corresponding instruction indicated below. Then, the result is substituted into #101.

Logarithmic function (LN)
#100 = LN[#101] ;
Exponential function (EXP)
#100 = EXP[#101] ;
Arcsine function (ASIN)
#100 = ASIN[#101] ;
Arccosine function (ACOS)
#100 = ACOS[#101] ;

6.30 FUNCTION FOR IDENTIFYING THE PRESSED MDI KEY USING A CONVERSATIONAL MACRO

6.30.1 Overview

A control variable has been added so that the MDI number corresponding to the MDI key being pressed can be read using a conversational macro. The control variable allows a conversational macro to identify the MDI key being pressed.

6.30.2 Function

By reading the value of control variable #8549, the MDI key being pressed can be identified. This variable holds an MDI number in decimal.

A key number is represented in binary, and is 8 bits long.

This function can also tell the operator whether the key has been pressed together with the SHIFT key or just alone. For detailed information, see section 6.30.3 below.

6.30.3 Key Number List

A key number is expressed in binary from 00 to FF.

For example, when the SPACE key is being pressed, the key number 20h is sent to control; variable #8549, which holds 32 in decimal.


For example, when the RESET key is being pressed, the key number 90h is sent to control variable #8549, which holds 144 in decimal.

NOTE


Handling of soft keys

In the key number table, numbers F0 to F9, FR, and FL correspond to soft keys. Numbers other than those above correspond to MDI keys as follows

(Seven soft keys) "F0" – "F4" and "FR", "FL"



(Twelve soft keys) "F0" – "F9" and "FR", "FL"



(00H – 7FH)

	0	1	2	3	4	5	6	7
0			Space	0	@	P		
1				1	A	Q		
2				2	B	R		
3			#	3	C	S		
4				4	D	T		
5				5	E	U		
6			&	6	F	V		
7				7	G	W		
8			(8	H	X		
9)	9	I	Y		
A	;		*		J	Z		
	(EOB)							
B			+		K	[
C			'		L			
D			-	=	M]		
E			.		N			
F			/	?	O			

(80H – FFH)

	8	9	A	B	C	D	E	F
0		Reset						F0
1								F1
2								F2
3								F3
4	Shift	Insert						F4
5		Delete						F5
6	CAN	Alter						F6
7								F7
8	Cur→	Input						F8
9	Cur←							F9
A	Cur↓	Help						
B	Cur↑							
C								
D								
E	Page↓							FR
F	Page↑							FL

6.31 WINDOW FUNCTION

6.31.1 Overview

The window function can now reference system information.

Conversational macro variable

No.8998: System information ID number

No.8999: System information


Method of using the function

By setting a desired value in the system information ID number variable (#8998), system information can be read into the system information variable (# 8999).

(Example) Display of system version and editions

```
O6000 ;
G243 X10 Y02 ('SYSTEM SERIES') ;
    #8998 = 8000 ;      /* Get the contents of ID No.8000
G243 X15 Y04 C#8999 ; /* Display the contents of ID No.8000
    #8998 = 8001 ;      /* Get the contents of ID No.8001
G243 X16 Y04 C#8999 ; /* Display the contents of ID No.8001
    #8998 = 8002 ;      /* Get the contents of ID No.8002
G243 X17 Y04 C#8999 ; /* Display the contents of ID No.8002
    #8998 = 8003 ;      /* Get the contents of ID No.8003
G243 X18 Y04 C#8999 ; /* Display the contents of ID No.8003
G243 X10 Y06 ('SYSTEM VERSION') ;
    #8998 = 8005 ;      /* Get the contents of ID No.8005
G243 X15 Y08 C#8999 ; /* Display the contents of ID No.8005
    #8998 = 8006 ;      /* Get the contents of ID No.8006
G243 X16 Y08 C#8999 ; /* Display the contents of ID No.8006
```

Above screen is displayed.



NOTE

System version and edition to be displayed differs depending on NC model.

6.31.2 Referenced System Information

Referenced System Information and ID No. List (1/4)

ID No.	Information	Contents of Information
1	Alarm Information	Alarm check flag
5		Overheat alarm
6		Spindle alarm No.750 to 763(767)
11		P/S Alarm number
12		P/S Alarm number (≥ 5000)
13		P/S Alarm number (User alarm)
20		Overtravel alarm No.500 (1st to 8th axis)
21		Overtravel alarm No.501 (1st to 8th axis)
22		Overtravel alarm No.502 (1st to 8th axis)
23		Overtravel alarm No.503 (1st to 8th axis)
24		Overtravel alarm No.504 (1st to 8th axis)
25		Overtravel alarm No.505 (1st to 8th axis)
26		Overtravel alarm No.506 (1st to 8th axis)
27		Overtravel alarm No.507 (1st to 8th axis)
30		Servo alarm No.400 to 407
31		Servo alarm Axis of servo alarm No.400 (1st to 8th axis)
32		Servo alarm Axis of servo alarm No.401 (1st to 8th axis)
33		Servo alarm Axis of servo alarm No.404 (1st to 8th axis)
35		Servo alarm Judgment of the axis of servo alarm No.401
36		Servo alarm Axis of servo alarm No.401 (1st to 8th axis)
41		Servo alarm 1st axis No.410 to 417
42		Servo alarm 2nd axis No.410 to 417
43		Servo alarm 3rd axis No.410 to 417
44		Servo alarm 4th axis No.410 to 417
45		Servo alarm 5th axis No.410 to 417
46		Servo alarm 6th axis No.410 to 417
47		Servo alarm 7th axis No.410 to 417
48		Servo alarm 8th axis No.410 to 417
55		Judgement of external alarm
56		External alarm 1
57		External alarm 2
58		External alarm 3
59		External alarm 4
70		Judgement of APC alarm display
71		1st axis of APC alarm No.300
72		2nd axis of APC alarm No.300
73		3rd axis of APC alarm No.300
74		4th axis of APC alarm No.300
75		5th axis of APC alarm No.300
76		6th axis of APC alarm No.300
77		7th axis of APC alarm No.300
78		8th axis of APC alarm No.300

Referenced System Information and ID No. List (2/4)

ID No.	Information	Contents of Information
81	Alarm Information	1st axis of APC alarm No.301 to 308
82		2nd axis of APC alarm No.301 to 308
83		3rd axis of APC alarm No.301 to 308
84		4th axis of APC alarm No.301 to 308
85		5th axis of APC alarm No.301 to 308
86		6th axis of APC alarm No.301 to 308
87		7th axis of APC alarm No.301 to 308
88		8th axis of APC alarm No.301 to 308
90		Judgement of SPC alarm No. 350 to 351
91		SPC alarm No.350 to 351 of 1st axis
92		SPC alarm No.350 to 351 of 2nd axis
93		SPC alarm No.350 to 351 of 3rd axis
94		SPC alarm No.350 to 351 of 4th axis
95		SPC alarm No.350 to 351 of 5th axis
96		SPC alarm No.350 to 351 of 6th axis
97		SPC alarm No.350 to 351 of 7th axis
98		SPC alarm No.350 to 351 of 8th axis
100		Axis, Coordinate and Positional information
101	No. of PMC controlled axes	
102	Sum of controlled axes	
110	1st axis relative coordinate value	
111	2nd axis relative coordinate value	
112	3rd axis relative coordinate value	
113	4th axis relative coordinate value	
114	5th axis relative coordinate value	
115	6th axis relative coordinate value	
116	7th axis relative coordinate value	
117	8th axis relative coordinate value	
200	No. of machined parts, etc.	Total no. of parts machined
201		No. of parts required
202		No. of parts machined
210		Power on time
220		Operation time (Hour, minute)
221		Operation time (second)
222		Cutting time (Hour, minute)
223		Cutting time (Second)
224		Timer (Hour, minute)
225		Timer (Second)
226		Cycle time (Hour, minute)
227	Cycle time (Second)	

Referenced System Information and ID No. List (3/4)

ID No.	Information	Contents of Information	
411	Servo motor load current value	1st axis servo motor load current value	
412		2nd axis servo motor load current value	
413		3rd axis servo motor load current value	
414		4th axis servo motor load current value	
415		5th axis servo motor load current value	
416		6th axis servo motor load current value	
417		7th axis servo motor load current value	
418		8th axis servo motor load current value	
700	Diagnosis Information	Diagnosis 000 to 006	
701		Diagnosis 010 to 015	
710		Diagnosis 030	
711		Diagnosis 031	
712		Diagnosis 020 to 025	
800		1st axis position error amount	
801		2nd axis position error amount	
802		3rd axis position error amount	
803		4th axis position error amount	
804		5th axis position error amount	
805		6th axis position error amount	
806		7th axis position error amount	
807		8th axis position error amount	
8000		System configuration	System version 4th digit Main
8001			System version 3rd digit Main
8002	System version 2nd digit Main		
8003	System version 1st digit Main		
8005	System edition 2nd digit Main		
8006	System edition 1st digit Main		
8010	System version 4th digit Sub (TT only)		
8011	System version 3rd digit Sub (TT only)		
8012	System version 2nd digit Sub (TT only)		
8013	System version 1st digit Sub (TT only)		
8015	System edition 2nd digit Sub (TT only)		
8016	System edition 1st digit Sub (TT only)		
8020	Servo series 4th digit		
8021	Servo series 3rd digit		
8022	Servo series 2nd digit		
8023	Servo series 1st digit		
8025	Servo edition 4th digit		
8026	Servo edition 3rd digit		
8030	PMC version 4th digit		
8031	PMC version 3rd digit		
8032	PMC version 2nd digit		
8033	PMC version 1st digit		

Referenced System Information and ID No. List (4/4)

ID No.	Information	Contents of Information	
8030	System configuration	PMC version 4th digit	
8031		PMC version 3rd digit	
8032		PMC version 2nd digit	
8033		PMC version 1st digit	
8035		PMC edition 2nd digit	
8036		PMC edition 3rd digit	
8040		Ladder version 4th digit	
8041		Ladder version 3rd digit	
8042		Ladder version 2nd digit	
8043		Ladder version 1st digit	
8045		Ladder edition 2nd digit	
8046		Ladder edition 1st digit	
8050		Order made macro version 4th digit	
8051		Order made macro version 3rd digit	
8052		Order made macro version 2nd digit	
8053		Order made macro version 1st digit	
8055		Order made macro edition 2nd digit	
8056		Order made macro edition 1st digit	
8200		Main board	CRTC information
8201		Optional board	CRTC information
8202		Graphic module 1 information	
8203		Graphic module 2 information	

6.31.3**Detailed Description of Reference System Information**

Alarm information

Axis/coordinate position information

Miscellaneous information including the total number of machined parts

Diagnosis information

System configuration information

(1) Alarm information

- | | |
|---------------------------------------|------------------|
| (a) Alarm check flag | ID No. 1 |
| (b) Overheat alarms | ID No. 5 |
| (c) Spindle alarms | ID No. 6 |
| (d) P/S alarms | ID Nos. 11 to 13 |
| (e) Overtravel alarms | ID Nos. 20 to 27 |
| (f) Servo alarms | ID Nos. 30 to 48 |
| (g) External alarms | ID Nos. 55 to 59 |
| (h) Absolute pulse coder (APC) alarms | ID Nos. 70 to 98 |

First check the information of ID No. 1, then proceed to the processing of each alarm.

(Example)

```

O6001 ;
    #501 = 1 ;
    #502 = 1 ;
    #8998 = 1 ;
N10 #500 = #8999 ;          /* Contents of ID No.1 is taken.
    #500 = #500 AND #501 ;
IF[#500 NE 0] GOTO [#502*100] ; /* Alarm ?
IF[#501 GE 32768] GOTO 900 ;
    #501 = #501*2 ;
    #502 = #502+1 ;
                GOTO 10 ;
N100 (Processing Bit 0001h )
    :      :
N200 (Processing Bit 0002h )
    :      :
N300 (Processing Bit 0004h )
    :      :
    :      :
    :      :
    :      :
    :      :
    :      :
N900 M99 ;

```

(a) Alarm check flag

The alarm check flag ID No. 1, is a one-word data representing a number from 0 to 65535.

This flag indicates which alarm was issued.

Example : When bit 3 is 1 (on), 8 is output.
When bit 9 is 1 (on), 512 is output.
When bit 4 and bit 9 are 1 (on), 528 is output.

	#f	#e	#d	#c	#b	#a	#9	#8	#7	#6	#5	#4	#3	#2	#1	#0	Output information
Bit (0001h)	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	1
Bit (0002h)	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	2
Bit (0004h)	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0	4
Bit (0008h)	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0	0	8
Bit (0010h)	0	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0	16
Bit (0020h)	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0	32
Bit (0050h)	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0	64
Bit (0080h)	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	128
Bit (0100h)	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0	256
Bit (0200h)	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0	0	512
Bit (0400h)	0	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0	1024
Bit (0800h)	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0	2048
Bit (1000h)	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0	0	4096
Bit (2000h)	0	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0	80192
Bit (4000h)	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	16384
Bit (8000h)	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	32768

For the meaning of each bit, see the alarm check flag table.

Alarm Check Flag

ID No.	Bit Information	Meaning
1	Bit (0001h)	PS alarm No.100. Parameter is write enable.
	Bit (0002h)	P/S alarm No.000. Turn on the power again.
	Bit (0004h)	P/S alarm No.101. Power was turned off during program editing. Press <PROG> key and <RESET> key.
	Bit (0008h)	P/S alarm
	Bit (0010h)	Overtravel alarm
	Bit (0020h)	Overheat alarm
	Bit (0040h)	Servo alarm
	Bit (0080h)	Memory alarm
	Bit (0100h)	APC alarm
	Bit (0200h)	Spindle alarm
	Bit (0400h)	P/S alarm (No.500 or more)
	Bit (0800h)	F-16 laser alarm
	Bit (1000h)	—————
	Bit (2000h)	—————
	Bit (4000h)	—————
Bit (8000h)	External alarm	

(b) Overheat alarms

A one-byte data, ID No. 5, representing a number from 0 to 255 indicates which overheat alarm was issued.

Example : When bit 3 is 1 (on), 8 is output.
 When bit 5 is 1 (on), 32 is output.
 When bit 3 and bit 5 are 1 (on), 40 is output.

	#7	#6	#5	#4	#3	#2	#1	#0	Output information
Bit (01h)	0	0	0	0	0	0	0	1	1
Bit (02h)	0	0	0	0	0	0	1	0	2
Bit (04h)	0	0	0	0	0	1	0	0	4
Bit (08h)	0	0	0	0	1	0	0	0	8
Bit (10h)	0	0	0	1	0	0	0	0	16
Bit (20h)	0	0	1	0	0	0	0	0	32
Bit (40h)	0	1	0	0	0	0	0	0	64
Bit (80h)	1	0	0	0	0	0	0	0	128

For the meaning of each bit, see the overheat alarms table.

Overheat Alarm Table

ID No.	Bit information	Alarm No.	Meaning
5	Bit (01h)	700	Overheat of master PCB
	Bit (02h)	-----	-----
	Bit (04h)	-----	-----
	Bit (08h)	704	Spindle overheat by spindle speed fluctuation detection
	Bit (10h)	701	FAN MOTER
	Bit (20h)	-----	-----
	Bit (40h)	-----	-----
	Bit (80h)	-----	-----

(c) Spindle alarms

A one-word data, ID No. 6, representing a number from 0 to 65535 indicates which spindle alarm was issued.

For one-word data, see Section 6.31.3.(1)(a).

For the meaning of each bit, see the spindle alarm table.

Spindle Alarm Table

ID No.	Bit information	Alarm No.	Meaning
6	Bit (0001h)	749	S-SPINDLE LSI ERROR
	Bit (0002h)	750	This alarm is issued if the spindle control unit of a system with serial spindles is not started normally when the power is turned on. Four causes can be considered: 1) The optical cable makes poor contact, or power to the main control unit is turned off. 2) Power to the NC is turned on when the LED display of the spindle control unit indicates SU-01 or when an alarm state other than AL-24 is present. 3) Other causes (such as an incorrect hardware combination) 4) The second spindle (when bit 4 (SP2) of parameter No. 3701 is set to 1) is in one of the states 1) to 3) above.
	Bit (0004h)	751	This alarm is output to the NC to indicate alarm generation on the spindle unit of a system with serial spindles. Alarm information is indicated by AL-xx (xx = number). For detailed alarm information, see the AC Spindle Servo Unit Maintenance Manual.
	Bit (0008h)	752	In serial spindle control, switching to the contouring mode, spindle positioning mode, rigid tapping mode, or spindle control mode is not terminated normally. (This alarm is issued when the spindle control unit reacts abnormally to a switching command from the NC).
	Bit (0010h)	753	SPD-1 DATA TRANSFER ERROR
	Bit (0020h)	_____	_____
	Bit (0040h)	_____	_____
	Bit (0080h)	_____	_____
	Bit (0100h)	_____	_____
	Bit (0200h)	761	Refer to Alarm No.751
	Bit (0400h)	762	Refer to alarm No.752
	Bit (0800h)	763	SPD-2 DATA TRANSFER ERROR
	Bit (1000h)	_____	_____
	Bit (2000h)	_____	_____
	Bit (4000h)	_____	_____
	Bit (8000h)	_____	_____

(d) Program/setting (P/S) alarms

The information of ID Nos. 11 and 12 directly indicates the P/S alarm number.

The information of ID No. 13 is valid only when ID No. 11 indicates 255. The information of ID No. 13 is added to 2500 to make a P/S alarm number.

P/S Alarm Table

ID No.	Meaning
11	P/S alarm No.
12	P/S alarm No. (5000 or more)
13	P/S alarm No. (user alarm)

(e) Overtravel alarms

Each of ID Nos. 20 to 27 corresponds to an alarm number. The Information of each ID number indicates the axis in which the alarm occurred.

For one-byte data, see Section 6.31.3.(1)(b).

For the meaning of each bit, see the overtravel alarm table.

Overtravel Alarm Table

ID No.	Alarm No.	Meaning
20	500	Stored stroke limit I of + side was passed.
21	501	Stored stroke limit I of – side was passed.
22	502	Stored stroke limit II of + side was passed.
23	503	Stored stroke limit II of – side was passed.
24	504	Stored stroke limit III of + side was passed.
25	505	Stored stroke limit III of – side was passed.
26	506	Hardware OT of + side was passed.
27	507	Hardware OT of – side was passed.

Overtravel Alarm Table

ID No.	Bit information	Meaning
20 - 27	Bit (01h)	Overtravel alarm of 1st axis
	Bit (02h)	Overtravel alarm of 2nd axis
	Bit (04h)	Overtravel alarm of 3rd axis
	Bit (08h)	Overtravel alarm of 4th axis
	Bit (10h)	Overtravel alarm of 5th axis
	Bit (20h)	Overtravel alarm of 6th axis
	Bit (40h)	Overtravel alarm of 7th axis
	Bit (80h)	Overtravel alarm of 8th axis

(f) Servo alarms

The information of ID No. 30 indicates servo alarm Nos. 400 to 407. ID No. 31 indicates the number of the axis in which alarm No. 400 occurred, ID No. 32 indicates the number of the axis in which alarm No. 401 occurred, and ID No. 33 indicates the number of the axis in which alarm No. 404 occurred.

Note, however, that the number of the axis in which alarm No. 401 occurred serves as the information of ID No. 36 when the logical product of the information of ID No. 32 and the information of ID No. 35 is 0.

Each of ID Nos. 41 to 48 corresponds to a servo alarm axis, and the information of each ID number indicates an alarm number.

All information consists of one-byte data. For one-byte data, see Section 6.31.3.(1)(b). For the bit configuration, see the servo alarm table.

Servo Alarm Table

ID No.	Bit information	Alarm No.	Meaning
30	Bit (01h)	400	Overload signal is turned on.
	Bit (02h)	401	Ready signal (DRDY) of servo amplifier turned off.
	Bit (04h)	————	————
	Bit (08h)	————	————
	Bit (10h)	404	The ready signal (MCON) is off but the ready signal (DRDY) of the servo amplifier is still on. Alternatively, when power is turned on, DRDY is on but MCON is still off.
	Bit (20h)	405	The position control system is abnormal. Reference position return may have failed due to an abnormality in the NC or servo system. Retry, starting with reference position return.
	Bit (40h)	————	————
	Bit (80h)	407	Difference of position error between synchronized axes exceeds the specified value.

Servo Alarm Table

ID No.	Bit Information	Meaning
31 – 33, 36	Bit (01h)	1st axis servo alarm
	Bit (02h)	2nd axis servo alarm
	Bit (04h)	3rd axis servo alarm
	Bit (08h)	4th axis servo alarm
	Bit (10h)	5th axis servo alarm
	Bit (20h)	6th axis servo alarm
	Bit (40h)	7th axis servo alarm
	Bit (80h)	8th axis servo alarm

ID No.	Meaning
35	Judgement to fix an of servo alarm No.401

ID No.	Meaning
41	Servo alarm 1st axis
42	Servo alarm 2nd axis
43	Servo alarm 3rd axis
44	Servo alarm 4th axis
45	Servo alarm 5th axis
46	Servo alarm 6th axis
47	Servo alarm 7th axis
48	Servo alarm 8th axis

Servo Alarm Table

ID No.	Bit information	Alarm No.	Meaning
41 - 48	Bit (01h)	411	Position error during movement is larger than set value.
	Bit (02h)	413	Error register contents exceeds $\pm 2 \times 31$.
	Bit (04h)	415	A speed larger than 511875 detection units/sec is to be specified.
	Bit (08h)	416	Position detection system of pulse coder is abnormal.
	Bit (10h)	412	_____
	Bit (20h)	410	Position error at stop is larger than set value.
	Bit (40h)	414	Digital servo system is abnormal.
	Bit (80h)	417	This alarm is issued if any of the following conditions occur: 1) A value beyond the specifiable range is set in parameter No. 2020 (motor type). 2) A correct value (111 or -111) is not set in parameter No. 2022 (motor rotation direction). 3) An incorrect value such as a negative value is set in parameter No. 2023 (number of speed feedback pulses per motor revolution). 4) An incorrect value such as a negative value is set in parameter No. 2024 (number of position feedback pulses per motor revolution). 5) Parameter Nos. 2084 and 2085 (flexible feed gear ratios) are not set. 6) A value beyond a range from 1 to the number of controlled axes, or a value not successive is set in parameter No. 1023 (servo axis number).

(g) External alarms

A one-byte data, ID No. 55, representing a number from 0 to 255 indicates which external alarm was issued.

The information of ID Nos. 56 to 59 directly indicates alarm numbers.

For one-byte data, see Section 6.31.3.(1)(b). For the meaning of each bit, see the external alarm table.

External Alarm Table

ID No.	Bit information	Meaning
55	Bit (01h)	External alarm 1
	Bit (02h)	External alarm 2
	Bit (04h)	External alarm 3
	Bit (08h)	External alarm 4
	Bit (10h)	_____
	Bit (20h)	_____
	Bit (40h)	_____
	Bit (80h)	_____

ID No.	Meaning
56	Alarm No. of external alarm 1
57	Alarm No. of external alarm 2
58	Alarm No. of external alarm 3
59	Alarm No. of external alarm 4

(h) Absolute pulse coder (APC) alarms

First check ID No. 70. If bit 0 is on, check the following:

ID No. 71 to 78

ID No. 81 to 88

ID No. 90 to 98

Each of ID No. 71 to 78 corresponds to an axis; bit 5, if on, indicates that alarm No. 300 has occurred.

Each of ID No. 81 to 88 corresponds to an axis; the information of each ID No. indicates an APC alarm number.

Check ID No. 90 to determine whether to read the information of ID No. 91 to 98 indicating serial pulse coder (SPC) alarm information. Correct information can be read if bit 2 is on. Each of ID No. 91 to 98 corresponds to an axis.

All information consists of one-byte data. For one-byte data, see Section 6.31.3.(1)(b). For the meaning of each bit, see the APC alarms table.

APC Alarm Table

ID No.	Bit information	Meaning
70	Bit (01h)	Displays APC alarm

ID No.	Meaning
71	1st axis alarm No.300
72	2nd axis alarm No.300
73	3rd axis alarm No.300
74	4th axis alarm No.300
75	5th axis alarm No.300
76	6th axis alarm No.300
77	7th axis alarm No.300
78	8th axis alarm No.300

APC Alarm Table

ID No.	Bit information	Meaning
71 – 78	Bit (01h)	_____
	:	: :
	Bit (10h)	_____
	Bit (20h)	Manual reference position return is required.
	Bit (40h)	_____
	Bit (80h)	_____

ID No.	Meaning
81	1st axis APC alarm
82	2nd axis APC alarm
83	3rd axis APC alarm
84	4th axis APC alarm
85	5th axis APC alarm
86	6th axis APC alarm
87	7th axis APC alarm
88	8th axis APC alarm

ID No.	Bit information	Alarm No.	Meaning
81 – 88	Bit (01h)	301	APC communication error (Data transmission fault)
	Bit (02h)	302	APC over time error (Data transmission fault)
	Bit (04h)	303	APC framing error (Data transmission fault)
	Bit (08h)	304	APC Parity error (Data transmission fault)
	Bit (10h)	305	APC Pulse missing alarm. (APC alarm)
	Bit (20h)	306	APC battery voltage has lowered below the level, in which no data is held. (APC alarm)
	Bit (40h)	307	APC battery voltage is a level that requires replacement. (APC alarm)
	Bit (80h)	308	APC battery voltage might become a level that requires battery replacement in the past (APC alarm).

APC Alarm Table

ID No.	Bit information	Meaning
90	Bit (04h)	Displays SPC alarm

ID No.	Meaning
91	1st axis SPC alarm
92	2nd axis SPC alarm
93	3rd axis SPC alarm
94	4th axis SPC alarm
95	5th axis SPC alarm
96	6th axis SPC alarm
97	7th axis SPC alarm
98	8th axis SPC alarm

APC Alarm Table

ID No.	Bit information	Alarm No.	Meaning
91 – 98	Bit (01h)	350	Abnormal serial pulse coder.
	Bit (02h)	351	Communication error of serial pulse coder (Data transmission fault)
	Bit (04h)	————	————
	Bit (08h)	————	————
	Bit (10h)	————	————
	Bit (20h)	————	————
	Bit (40h)	————	————
	Bit (80h)	————	————

(2) Detailed information of Axis and Coordinate

Axis and Coordinate Detailed Information

ID No.	Meaning
100	No. of CNC controlled axes
101	No. of PMC controlled axes
102	No. of axes
110	1st axis relative coordinate value
111	2nd axis relative coordinate value
112	3rd axis relative coordinate value
113	4th axis relative coordinate value
114	5th axis relative coordinate value
115	6th axis relative coordinate value
116	7th axis relative coordinate value
117	8th axis relative coordinate value

(3) Miscellaneous information including the total number of machined parts

The information of ID Nos. 210, 220, 222, 224, and 226 is given in minutes.

Example: When ID No. 220 indicates 360, this information means 6 hours.

When ID No. 220 indicates 369, this information means 6 hours and 9 minutes.

When ID No. 224 indicates 359, this information means 5 hours and 59 minutes.

The information of ID Nos. 221, 223, 225, and 227 is given in 1/1000 seconds.

Example: When ID No. 221 indicates 3000, this information means 3 seconds.

When ID No. 221 indicates 36000, this information means 36 seconds.

No. of Total Parts Machined, etc.

ID No.	Meaning
200	Total number of Parts machined
201	Number of parts required
202	Number of parts machined
210	Power on time
220	Operation time
221	Operation time
222	Cutting time
223	Cutting time
224	General purpose integrated time
225	General purpose integrated time
226	Cycle time
227	Cycle time

(4) Servo motor load current (Series 16/18)

A load current, digitized by the A/D converter, can be read. The read data is input as a value between -7282.0 and +7282.0 inclusive.

ID No.	Meaning
411	1st axis servo motor load current
412	2nd axis servo motor load current
413	3rd axis servo motor load current
414	4th axis servo motor load current
415	5th axis servo motor load current
416	6th axis servo motor load current
417	7th axis servo motor load current
418	8th axis servo motor load current

Details of read data

The actual load current is calculated as follows:

$$(AD \times N)/7282 = \text{Load current (A peak)}$$

AD: Input value (value of #8999)

N:

Motor type	N value	Motor type	N value
4-0S	4	5S/3000	80
3-0S		10S/3000	
1-0S	12	20S/3000	100
2-0S		30S/1200	
1-0S/3000		30/2000	
0S	40	20S/3000	130
5S		30S/3000	
10S		40S/2000	
20S/1500			

The load current calculated from the above formula is the value corresponding to the maximum current for the motor being used. The calculated load current, therefore, becomes smaller than the continuous rated current for the motor, as displayed on the servo adjustment screen.

(5) Diagnosis information

Each of one-byte data, ID Nos. 700, 701, and 712, representing a number from 0 to 255 indicates diagnosis information.

Example: When bit 3 is 1 (on), 8 is output.
 When bit 5 is 1 (on), 32 is output.
 When bit 3 and bit 5 are 1 (on), 40 is output.

	#7	#6	#5	#4	#3	#2	#1	#0	Output information
Bit (01h)	0	0	0	0	0	0	0	1	1
Bit (02h)	0	0	0	0	0	0	1	0	2
Bit (04h)	0	0	0	0	0	1	0	0	4
Bit (08h)	0	0	0	0	1	0	0	0	8
Bit (10h)	0	0	0	1	0	0	0	0	16
Bit (20h)	0	0	1	0	0	0	0	0	32
Bit (40h)	0	1	0	0	0	0	0	0	64
Bit (80h)	1	0	0	0	0	0	0	0	128

For the meaning of each bit, see the diagnosis information table.

Diagnose Detailed Information

ID No.	Bit Information	Meaning
700	Bit (01h)	M,S,T function is being executed.
	Bit (02h)	Move command is being executed in automatic operation.
	Bit (04h)	Dwell is being executed.
	Bit (08h)	Inposition check is being done.
	Bit (10h)	Feed rate override is 0%.
	Bit (20h)	Interlock is on.
	Bit (40h)	Waiting for spindle speed arrival signal becom on.
	Bit (80h)	_____
701	Bit (01h)	Data is being output via reader/puncher interface.
	Bit (02h)	Data is being input via reader/puncher interface.
	Bit (04h)	Waiting for index table clamping /unclamping befor/after B axis index table indexing.
	Bit (08h)	_____
	Bit (10h)	Jog override is 0 %.
	Bit (20h)	Emergency stop, external reset, reset & rewind or reset key on MDI panel is on.
	Bit (40h)	External program number is being searched.
	Bit (80h)	_____

Diagnose Detailed Information

ID No.	System information	Meaning
710	0 – 255	Displays the character that caused TH alarm by the number of characters from the top of the block.
711	0 – 255	Reading code of the character that caused TH alarm.

Diagnose Detailed Information

ID No.	Bit Information	Meaning
712	Bit (01h)	Emergency stop or servo alarm.
	Bit (02h)	_____
	Bit (04h)	_____
	Bit (08h)	Reset key is pressed.
	Bit (10h)	Reset & rewind turned on.
	Bit (20h)	Emergency stop
	Bit (40h)	External reset, emergency stop reset, or reset & rewind
	Bit (80h)	A flag to stop pulse distribution by any of the following actions: 1) External reset 2) Reset & rewind 3) Emergency stop 4) Feed hold 5) Reset key on MDI 6) Mode changed to a manual mode (JOG/HANDLE/INC) 7) An alarm is issued

ID No.	Meaning
800	1st axis position error
801	2nd axis position error
802	3rd axis position error
803	4th axis position error
804	5th axis position error
805	6th axis position error
806	7th axis position error
807	8th axis position error

(6) System configuration information

The system information of the following ID numbers is output as ASCII code information represented in decimal:

8000 - 8003, 8005 - 8006

8010 - 8013, 8015 - 8016

8020 - 8023, 8025 - 8026

8030 - 8033, 8035 - 8036

8040 - 8043, 8045 - 8046

8050 - 8053, 8055 - 8056

NOTE

ID Nos. 8010 to 8013, 8015m and 8016 are usable only with the TT system.

For the meanings of ID Nos. 8200 to 8211, see the system configuration information table.

(Series 16/18)

Con- tents	Hexa- decimal	Deci- mal	Con- tents	Hexa- decimal	Deci- mal	Con- tents	Hexa- decimal	Deci- mal
A	41	65	N	4e	78	0	30	48
B	42	66	O	4f	79	1	31	49
C	43	67	P	50	80	2	32	50
D	44	68	Q	51	81	3	33	51
E	45	69	R	52	82	4	34	52
F	46	70	S	53	83	5	35	53
G	47	71	T	54	84	6	36	54
H	48	72	U	55	85	7	37	55
I	49	73	V	56	86	8	38	56
J	4a	74	W	57	87	9	39	57
K	4b	75	X	58	88			
L	4c	76	Y	59	89			
M	4d	77	Z	5a	90			

System Configuration Information Table

ID No.	Bit information	Meaning
8200	0	14-inch CRT screen module is installed
	1	9-inch CRT screen module is installed
	2	10-inch CRT screen module is installed
	255	CRT screen module is not installed
8201	0	14-inch CRTC screen main module is installed
	1	9-inch CRTC screen main module is installed
	2	10-inch CRTC screen main module is installed
	4	14-inch CRTC screen graphic module is installed
	5	9-inch CRTC screen graphic module is installed
	6	10-inch CRTC screen graphic module is installed
8202	0	Graphic module is installed
	255	Graphic module is not installed
8203	0	Graphic module is installed
	255	Graphic module is not installed
8210	255	No CRT module is mounted.
	1	9" CRT module is mounted.
	2	9" color CRT module is mounted.
	3	14" color CRT module is mounted.
	4	LCD 14" color CRT module is mounted.
	5	LCD 9" CRT module is mounted.
	6	VGA 14" color CRT module is mounted.
	7	Undefined
	8	LCD 14" CRT module is mounted.
	9	LCD 9" color CRT module is mounted.
	12	VGA 9" CRT module is mounted.
10	VGA 9" color CRT module is mounted.	
11	VGA 14" CRT module is mounted.	
8211	255	No graphics module is mounted.
	1	standard graphics module is mounted.
	2	FAPT graphics module is mounted.
	3	MMC graphics module is mounted.
	4	Undefined
5	VGA graphics module is mounted.	

(2) Displaying external characters

By executing a G code in the format below, an external character stored in external character memory can be displayed.

<Command format>

G243 Xx Yy ("80qq") :

Xx, Yy: Specifies a display start position. X and Y represent an X coordinate and Y coordinate in the character coordinate system, respectively.

("80qq"): Specifies the external character number of an external character to be displayed. Note, however, that an external character number from 00 to 39 must be specified for qq in hexadecimal. 80qq must be enclosed in quotation marks inside of parentheses.

That is, 80qq must be specified in the format ("80qq").)

qq: 00h to 31h in hexadecimal (external character number from 00 to 49)

External character number	Command value (80qq)
00	8000
01	8001
02	8002
.	.
.	.
10	800A
11	800B
12	800C
13	800D
14	800E
15	800F
16	8010
17	8011
.	.
.	.
.	.
.	.
38	8026
39	8027

Example: Command for displaying the external character (20th character in external character memory) registered in Example (1) above

G243 X__ Y__ "8014" ;

NOTE

Be sure to specify a hexadecimal value from 00h to 27h for qq. Otherwise, the display function does not function normally.)

6.33 EXECUTION MACRO CALL MASK FUNCTION

6.33.1 Function

An execution macro call can be masked by using the executor parameter or macro variable.

The following execution macro calls can be masked:

- Axis address call
- T code macro call
- T code subprogram call

A masked call instruction is handled as either an axis move command or a T code output command.

Examples) When bit 0 (AX1CL) of compilation parameter No. 9005 is set to 1 and bit 0 (MA1) of executor parameter No. 9010 is set to 0:

```
User program
00001 ;
G00 X10 Z10; → Calls execution macro program O9009.
G00 X20 Z20; → Calls execution macro program O9009.
:
```

When bit 0 (AX1CL) of compilation parameter No. 9005 is set to 1 and bit 0 (MA1) of executor parameter No. 9010 is set to 1:

```
User program
00001 ;
G00 X10 Z10; → Moves to X10, Z10 in rapid traverse mode.
G00 X20 Z20; → Moves to X20, Z20 in rapid traverse mode.
:
```

When bit 0 (TCAL) of compilation parameter No. 9002 is set to 1 and macro variable #8691 is set to 1:

<User program>	<P-CODE program>
00001 ;	09000 ;
G00 X10 Z10 ;	G00 X...
T11 ; →Calls P-CODE program 09000	:
G00 X20 Z20 ;	#8691 = 1 ;
:	:
T12 ; →T12 code	M99 ;
:	

6.33.2 Macro Variables

Variable number	Function	Conversational	Auxiliary	Execution
#8690	Execution macro call mask function variable 1	R/W	R/W	R/W
#8691	Execution macro call mask function variable 2	R/W	R/W	R/W

R: Read enabled/W: Write enabled

#8690: Execution macro call mask function variable 1

- 1 = Masks a first axis address macro call.
- 2 = Masks a second axis address macro call.
- 4 = Masks a third axis address macro call.
- 8 = Masks a fourth axis address macro call.
- 16 = Masks a fifth axis address macro call.
- 32 = Masks a sixth axis address macro call.
- 64 = Masks a seventh axis address macro call.
- 128 = Masks an eighth axis address macro call.

#8691: Execution macro call mask function variable 2

- 1 = Masks a T code macro call.

One or more macro calls can be masked. For example, to mask the first and second axis address macro calls, specify variable #8690 as follows:

```
#8690 = 3 ;
```

NOTE

- 1 When data is written to variable #8690, the value of executor parameter No. 9010 also changes accordingly. When data is read from #8690, the value of executor parameter No. 9010 is also read. The same is true of variable #8691 and executor parameter No. 9011.
- 2 If data is written to variable #8690 or #8691 using a conversational macro (display macro) while an execution macro (machining macro) is executing, the write operation may be delayed.

7

Series 16/18 2-PATH DEDICATED CONTROL FUNCTION

The macro libraries for path 1 are shared as libraries for single-path control. The macro libraries for path 2 are dedicated. The macro libraries listed below are for the T series, and similar libraries are available for the M series.

Macro libraries for path 1

16-TA.EXEC/??	: FANUC P-G Mark II/Mate
18-TA.EXEC/??	: FANUC P-G Mark II/Mate
F16TA_?? .MEX	: 16-TA macro library for personal computers
F18TA_?? .MEX	: 18-TA macro library for personal computers
F16TB_?? .MEX	: 16-TB macro library for personal computers
F18TB_?? .MEX	: 18-TB macro library for personal computers
F16TC_?? .MEX	: 16-TC macro library for personal computers
F18TC_?? .MEX	: 18-TC macro library for personal computers
F16TI_?? .MEX	: 16i-TA macro library for personal computers
F18TI_?? .MEX	: 18i-TA macro library for personal computers

Macro libraries for path 2

16-TTA.SB.EXEC/??	: FANUC P-G Mark II/Mate
18-TTA.SB.EXEC/??	: FANUC P-G Mark II/Mate
F16TTS?? .MEX	: 16-TA macro library for personal computers
F18TTS?? .MEX	: 18-TA macro library for personal computers
F16TTB?? .MEX	: 16-TB macro library for personal computers
F18TTB?? .MEX	: 18-TB macro library for personal computers
F16TTC?? .MEX	: 16-TC macro library for personal computers
F18TTC?? .MEX	: 18-TC macro library for personal computers

Both path 1 and path 2 allow the coding of execution, conversational, and auxiliary macro programs.

With Series 16i/18i, common macro libraries are used for path 1 and path 2. The path to be selected is determined by making a selection with the keyword SYSTEM in the link control file. For details, refer to the "FAPT MACRO COMPILER (For Personal Computer) PROGRAMMING MANUAL (B-66102E)."

The special 2-path control functions are explained below.

7.1 COMMON CONVERSATIONAL MACRO SCREEN

When macro executor ROM are mounted on tool posts 1 and 2, the conversational macro of the macro executor of tool post 1 can be executed, regardless of which tool post selects the conversational macro screen.

Set compilation parameter TTDSP (No. 9007, #0) to 1 for the executor of tool post 2. Set parameters 9038, 9040, and 9041 to the same values as in tool post 1. The conversational macro program of tool post 1 is executed even when the  key is pressed while tool post 2 is being selected.

If the parameter is set to 0, the conversational macro programs selected by the heads of tool posts 1 and 2 are executed separately.

TTDSP=1 : The common conversational macro screen is validated.


NOTE

This function cannot be executed when the function for leaving the screen unchanged when the  key is pressed (Section 6.26) is executed.

7.2 COMMON CONVERSATIONAL MACRO VARIABLE

When the macro executor ROM are mounted on tool posts 1 and 2, the heads of tool posts 1 and 2 can share conversational macro variables (#10000 and on and #20000 and on). When this function is validated, the execution, auxiliary, and conversational macro programs of tool posts 1 and 2 can share the conversational macro variables.

If this function is not used, heads 1 and 2 can use different conversational macro variables.



8

FUNCTIONS FOR STOPPING A CONVERSATIONAL MACRO

The macro executor can stop the execution of a conversational macro program at a particular program and sequence specified by parameters.

Parameters of the macro executor

1) No. 9000, bit 2 (TSTP)

TSTP 1 : The execution of the conversational macro program is stopped.

0 : The conversational macro program is executed.

2) No. 9002 : Number of the program at which execution of the conversational macro program is stopped


3) No. 9003 : Number of the sequence at which execution of the conversational macro program is stopped

Specify the numbers of the program and sequence at which the conversational macro program is to be stopped and execute the conversational macro program on the  screen. When an attempt is made to execute the block corresponding to the specified program and sequence, TSTP is automatically turned on. The execution of the conversational macro is stopped. If parameter No. 9002 is set to 0, this function is invalidated. In usual operation, it must be set to 0.


When this function is used, compilation parameter SEQ must be set to 1 to output sequence numbers to the P-CODE program.

APPENDIX

A MACRO PROGRAM EXAMPLE



A.1 EXAMPLE-1: CIRCULAR CUTTING INPUT AND EXECUTION



Circular Cutting Display Layout:

The cursor is moved, using the cursor key , or soft keys "RADIUS", "FEED" or "OFSNUM". Key in data from MDI at the cursor position and press  to write data. Or after keying in data, press the soft key for direct input. After all data has been input, press the soft key "EXEC": the axis will move. By pushing the soft key "END", the display returns to the menu screen.

A.1.1 Source Program for Main Program

```

00010 O9999 ;
00020 N001 (00001 -- MAIN PROG -MENU          ) ;
00030 N002 (00010 -- KEY TEST                  ) ;
00040 N003 (00011 --      SUB SOFT KEY DISP    ) ;
00050 N004 (00020 -- CURSOR TEST               ) ;
00060 N005 (00030 -- DISPLAY TEST              ) ;
00070 N006 (00031 --      SUB TIMER            ) ;
00080 N007 (00032 --      SUB BLINK TEST       ) ;
00090 N008 (00033 --      SUB STRING DATA     ) ;
00100 N009 (00040 -- ADDRESS VARIABLE TEST     ) ;
00110 N010 (00041 --      SUB DATA TABLE     ) ;
00120 N011 (00050 -- CIRCLE TEST               ) ;
00130 N012 (00051 --      SUB DATA DISP       ) ;
00140 N013 (00052 --      SUB STRING DISP     ) ;
00150 N014 (00053 --      SUB GRAPHIC DISP    ) ;
00160 N015 (00054 --      SUB PMC WINDOW       ) ;
00170 N016 (09010 -- EXEC MACRO PROGRAM -G100- ) ;
00180 ;
00190 N101 (V140 --- PROGRAM NUMBER           ) ;

```

```
00200 N102 (V141 --- TIMER ) ;
00210 N103 (V142 --- KEY CONTROL DATA -V8501- ) ;
00220 N104 (V143 --- STRINGS DATA OFFSET ) ;
00230 N105 (V144 --- KEY INPUT DATA -V8503- ) ;
00240 N105 (V145 --- ADDRESS INPUT DATA -V8504- ) ;
00250 N107 (V146 --- CURSOR X POINTER ) ;
00260 N108 (V147 --- CURSOR Y POINTER ) ;
00270 N109 (V148 --- ) ;
00280 N110 (V149 --- ) ;
00290 ;
00300 ;
00310 ;
00320 ;
00330 ;
00340 ;
```

```
00010 O0001 ;
00020 N000 G202 P3 ;
00030 #8505=0 ;
00040 G243 X0 Y0 A1 B0 (SAMPLE PROGRAM) ;
00050 X2 Y3 (1 -- KEY TEST) ;
00060 X2 Y5 (2 -- CURSOR TEST) ;
00070 X2 Y7 (3 -- DISPLAY TEST) ;
00080 X2 Y9 (4 -- ADDRESS VARIABLE) ;
00090 X2 Y11 (5 -- CIRCLE) ;
00100 #8509=0033 ;
00110 #143=300 ;
00120 M98 P0011 ;
00130 N001 #142=#8501 ;
00140 IF [#142 EQ 0] GOTO 99 ;
00150 IF [#142 LT 12] GOTO 99 ;
00160 IF [#142 GT 16] GOTO 99 ;
00170 #8500=[#142-11] *10 ;
00180 M99
00190 N099 M99 P1 ;
00200 ;
00210 ;
00220 ;
00230 ;
00240 ;
```

A.1.2 Source Program for Input Control

```
00010  O0010 ;
00020      G202 P3 ;
00030      G243 X0 Y2 A1 B0 (KEY TEST  -- HIT ANY KEY --) ;
00040      #143=100 ;
00050          M98 P0011 ;
00060  N001 #8502=2 ;
00070      #142=#8501 ;
00080      IF [#142 EQ 0] GOTO 99 ;
00090      #101=#142 ;
00100      #102=#8503 ;
00110      #103=#8504 ;
00120      G243 X0 Y4 A1 B0 (CONTROL  ) F8.3 Z0 D#101 ;
00130      G243 X0 Y5 A1 B0 (ADDRESS  ) F8.3 Z0 D#103 ;
00140      G243 X0 Y6 A1 B0 (DATA     ) F8.3 Z0 D#102 ;
00150  N099 IF [#142 NE 16] GOTO 97 ;
00160  N098 #8500=1 ;
00170      M99 ;
00180  N097 M99 P1 ;
00190      ;
00200      ;
00210      ;
00220      ;
00230      ;
```

```
00010  O0011 ;
00020      #100=0 ;
00030      WHILE [#100 LT 5] DO 1 ;
00040          G243 X[#100*8+1] Y16 A1 B0 P[#143+#100] ;
00050          #100=#100+1 ;
00060      END 1 ;
00070      M99;
00080      ;
00090      ;
00100      ;
00110      ;
00120      ;
```

A.1.3

Source Program for Cursor Control

```
00010  O0020 ;
00020      G202 P3 ;
00030      #8505=0 ;
00040      #8502=0 ;
00050  N008 G243 X0 Y1 (CURSOR TEST -- MOVE CURSOR --) ;
00060      G243 X0 Y3 (A) ;
00070      G243 X0 Y4 (B) ;
00080      G243 X0 Y5 (C) ;
00090      G243 X0 Y6 (D) ;
00100      G243 X0 Y7 (E) ;
00110      G243 X0 Y8 (F) ;
00120      #143=100 ;
00130      M98 P0011 ;
00140      #100=0 ;
00150      #8506=2 ;
00160  N001 #142=#8501 ;
00170      IF [#142 EQ 0] GOTO 3 ;
00180      IF [#142 NE 3] GOTO 2 ;
00190      #100=#100+1 ;
00200  N002 IF [#142 NE 4] GOTO 3 ;
00210      #100=#100-1 ;
00220  N003 #100=#100+6 ;
00230      #100=#100-[FI×[#100/6]]*6 ;
00240      #8507=#100+3 ;
00250      #8505=1 ;
00260  N099 IF [#142 NE 16] GOTO 97 ;
00270  N098 #8500=1 ;
00280      M99 ;
00290  N097 M99 P1 ;
00300      ;
00310      ;
00320      ;
00330      ;
00340      ;
```

A.1.4 Source Program for Character Display

```
00010  O0030 ;
00020      G202 P3 ;
00030      #8502=0 ;
00040      #8505=0 ;
00050      #143=100 ;
00060          M98 P0011 ;
00070 N001 G243 X0 Y2 A1 B0 K200 ;
00080      X0 Y2 (DISPLAY TEST) ;
00090      G243 X0 Y4 A1 B0 K200 ;
00100      #141=100 ;
00110          M98 P0031 ;
00120      X0 Y4 (FANUC 0 SERIES MACRO COMPILER) ;
00130      #141=300 ;
00140          M98 P0031 ;
00150      G243 X0 Y4 A1 B0 K200 ;
00160      #141=100 ;
00170          M98 P0031 ;
00180      G243 X0 Y4 A1 B0 K200 ;
00190      X0 Y4 (*3441 2438 493D 3C28 00C3 00BD 00C4*) ;
00200      #141=300 ;
00210          M98 P0031 ;
00220      G243 X0 Y4 A1 B0 K200 ;
00230      #141=100 ;
00240          M98 P0031 ;
00250      G243 X0 Y4 A1 B0 K200 ;
00260      X0 Y4 (INT. CODE ) (*2F40 2F48 2F79 2F53*) ;
00270      #141=300 ;
00280          M98 P0031 ;
00290      G243 X0 Y4 A1 B0 K200 ;
00300      #141=100 ;
00310          M98 P0031 ;
00320      X0 Y4 A3 B0 (3 MULTI) ;
00330      #141=300 ;
00340          M98 P0031 ;
00350      G243 X0 Y4 A1 B0 K200 ;
00360      #141=100 ;
00370          M98 P0031 ;
00380          M98 P0032 ;
00390      #141=100 ;
```

```
00400          M98 P0031 ;
00410      G243 X0 Y4 A1 B0 K200 ;
00420      X0 Y4 (DATA DISPLAY TEST      1234.567) ;
00430      #100=1234.567 ;
00440      G243 X0 Y6 F8.3 Z0 K200 ;
00450      X0 Y6 (F8.3 ) D#100 ;
00460      #141=300 ;
00470          M98 P0031 ;
00480      G243 X0 Y6 F8.3 Z1 K200 ;
00490      #141=100 ;
00500          M98 P0031 ;
00510      X0 Y6 (F8.3 ) D#100 ( LEADING ZERO NEG.) ;
00520      #141=300 ;
00530          M98 P0031 ;
00540      G243 X0 Y6 F5.2 K200 ;
00550      #141=100 ;
00560          M98 P0031 ;
00570      X0 Y6 (F5.2 ) D#100 ;
00580      #141=300 ;
00590          M98 P0031 ;
00600      #8509=0033 ;
00610      G243 X0 Y4 A1 B0 K200 ;
00620      #141=100 ;
00630          M98 P0031 ;
00640      X0 Y4 (STRINGS DISPLAY TEST) ;
00650      G243 X0 Y6 K200 ;
00660      X0 Y6 P10 ;
00670      #141=300 ;
00680          M98 P0031 ;
00690      G243 X0 Y6 K200 ;
00700      #141=100 ;
00710          M98 P0031 ;
00720      X0 Y6 P20 ;
00730      #141=300 ;
00740          M98 P0031 ;
00750      #142=#8501 ;
00760 N099 IF [#142 NE 16] GOTO 97 ;
00770 N098 #8500=1 ;
00780      M99 ;
00790      M99 P1 ;
00800      ;
00810      ;
00820      ;
00830      ;
```

```
00840 ;

00010 O0031 ;
00020 N001 IF [#141 LT 0] GOTO 99 ;
00030     #141=#141-1 ;
00040     GOTO 1 ;
00050 N099 #142=#8501 ;
00060     IF [#142 EQ 16] GOTO 97 ;
00070     M99 ;
00080 N097 M99 P98 ;
00090 ;
00100 ;
00110 ;
00120 ;
00130 ;

00010 O0032 ;
00020     G243 X0 Y4 A1 B0 (BLINK TEST) ;
00030     #100=200 ;
00040         WHILE [#100 GT 0] DO 1 ;
00050             #100=#100-1 ;
00060 N001         G243 X0 Y6 A1 B1 (BLINK SLOW) ;
00070             END 1 ;
00080     G243 X0 Y6 A1 B0 K20 ;
00090     #141=100 ;
00100     M98 P0031 ;
00110     #100=200 ;
00120         WHILE [#100 GT 0] DO 2 ;
00130             #100=#100-1 ;
00140 N002         G243 X0 Y6 A1 B2 (BLINK FAST) ;
00150             END 2 ;
00160     G243 X0 Y4 A1 B0 K200 ;
00170     M99 ;
00180 ;
00190 ;
00200 ;
00210 ;
00220 ;
```

```
00010 O0033 ;
00020 N010 (ABCDEFGHIJKLMNPOQRSTUVWXYZ0123456789) ;
00030 N020 (FANUC TECHNICAL TRAINING CENTER) ;
00040 N100 ( ) ;
00050 N101 ( ) ;
00060 N102 ( ) ;
00070 N103 ( ) ;
00080 N104 ( END ) ;
00090 N200 (RADIUS) ;
00100 N201 ( FEED ) ;
00110 N202 (OFS NO) ;
00120 N203 ( EXEC ) ;
00130 N204 ( END ) ;
00140 N300 (TEST-1) ;
00150 N301 (TEST-2) ;
00160 N302 (TEST-3) ;
00170 N303 (TEST-4) ;
00180 N304 (TEST-5) ;
00190 N500 (INPOSITION WIDTH ) ;
00200 N504 (SERVO ERROR LIMIT ) ;
00210 N508 (GRID SHIFT VALUE ) ;
00220 N512 (LOOP GAIN MULTIPLY ) ;
00230 M99 ;
00240 ;
00250 ;
00260 ;
00270 ;
00280 ;
```

A.1.5

Source Program for Address Variables

```
00010  O0040 ;
00020      G202 P3 ;
00030      #143=100 ;
00040          M98 P0011 ;
00050  N008 G243 X0 Y2 A1 B0 K520 ;
00060      G243 X0 Y2 A1 B0 (ADDRESS VARIABLE TEST) ;
00070      #141 =100 ;
00080          M98 P0031 ;
00090      X0 Y4 (ADDRESS G READ TEST) ;
00100  N001 #101=G121.4 ;
00110      IF [#101 EQ 0] GOTO 2 ;
00120      X0 Y6 Z1 F1.0 (ESP STATUS -- ) D#101 ( PUSH ESP) ;
00130      #142=#8501 ;
00140      IF [#142 EQ 16] GOTO 98 ;
00150      M99 P1 ;
00160  N002 X0 Y6 Z1 F1.0 (ESP STATUS -- ) D#101 ( RESET ESP) ;
00170      #141=100 ;
00180          M98 P0031 ;
00190      X0 Y4 K200 ;
00200      #141=100 ;
00210          M98 P0031 ;
00220      X0 Y4 (ADDRESS D WRITE TEST) ;
00230          M98 P0041 ;
00240      G243 X0 Y4 A1 B0 K200 ;
00250      #141=100 ;
00260          M98 P0031 ;
00270      G243 X0 Y4 (PARAMETER READ) ;
00280      #102=0 ;
00290      #8509=0033 ;
00300          WHILE [#102 LE 3] DO 1 ;
00310              #103=P[#102*4+500] ;
00320              G243 X0 Y[#102+6] (NUM ) Z1 F3.0 D[#102*4+500] ;
00330              ( -- ) D#103 ;
00340              G243 ( ) P[#102*4+500] ;
00350              #102=#102+1 ;
00360          END 1 ;
00370      #141=500 ;
00380          M98 P0031 ;
00390      #142=#8501 ;
```

```
00400 N099 IF [#142 NE 16] GOTO 97 ;
00410 N098 #8500=1 ;
00420     M99 ;
00430 N097 M99 P8 ;
00440     ;
00450     ;
00460     ;
00470     ;
00480     ;

00010 O0041 ;
00020     #100=0 ;
00030         WHITE [#100 LT 5] DO 1 ;
00040             G310 D699 Q#100 ;
00050             #141=10 ;
00060             M98 P0031 ;
00070             #100=#100+1 ;
00080         END 1 ;
00090             #100=D699 ;
00100     G243 X0 Y6 (DATA TABLE -- ) F3.0 D#100 ;
00110     #141=300 ;
00120     M98 P0031 ;
00130     M99 ;
00140     ;
00150     ;
00160     ;
00170     ;
00180     ;
```

A.1.6

Source Program for Graphic Display and Circle Cutting

```
00010  O0050 ;
00020      G202 P3 ;
00030      #8506=13 ;
00040      #8507=2 ;
00050      #8505=1 ;
00060      #147=0 ;
00070      G202 P3 ;
00080          M98 P0052 ;
00090          M98 P0053 ;
00100          M98 P0051 ;
00110  N001 #8502=1 ;
00120      #142=#8501 ;
00130      #144=#8503 ;
00140      IF [#142 EQ 0] GOTO 99 ;
00150      IF [#142 NE 12] GOTO 3 ;
00160      #147=0 ;
00170      GOTO 9 ;
00180  N003 IF [#142 NE 13] GOTO 4 ;
00190      #147=1 ;
00200      GOTO 9 ;
00210  N004 IF [#142 NE 14] GOTO 5 ;
00220      #147=2 ;
00230      GOTO 9 ;
00240  N005 IF [#142 NE 4] GOTO 6 ;
00250      #147=#147-1 ;
00260      GOTO 9 ;
00270  N006 IF [#142 NE 3] GOTO 7 ;
00280      #147=#147+1 ;
00290      GOTO 9 ;
00300  N007 IF [#142 NE 15] GOTO 8 ;
00310      #140=1 ;
00320          M98 P0054 ;
00330      GOTO 10 ;
00340  N008 IF [#142 NE 8] GOTO 10 ;
00350  N009 #147=#147+3 ;
00360      #147=#147-FIX[#147/3]* 3 ;
00370      IF [#144 EQ #0] GOTO 10 ;
00380      #[500+#147]=#144 ;
00390      G243 X14 Y[#147+2] Z1 F4.0 D#[#147+500] ;
```

```
00400 N010 M98 P0051 ;
00410 N099 IF [#142 NE 16] GOTO 97 ;
00420 N098 #8500=1 ;
00430     M99 ;
00440 N097 M99 P1 ;
00450 ;
00460 ;
00470 ;
00480 ;
00490 ;

00010 O0051 ;
00020     #8507=#147+2 ;
00030     #100=0 ;
00040     WHILE [#100 LT 3] DO 1 ;
00050         G243 X14 Y[#100+2] Z1 F4.0 D#[500+#100] ;
00060         #100=#100+1 ;
00070     END 1 ;
00080     M99 ;
00090 ;
00100 ;
00110 ;
00120 ;
00130 ;

00010 O0052 ;
00020     G243 X0 Y0 A1 B0 (CIRCULAR CUTTING) ;
00030     X1 Y2 (I) ;
00040     C40 (PADIUS) C41 C61 ;
00050     X1 Y3 (F) ;
00060     C40 ( FEED ) C41 C61 ;
00070     X1 Y4 (D) ;
00080     C40 (OFS NO) C41 C61 ;
00090     #143=200 ;
00100     M98 P0011 ;
00110     M99 ;
00120 ;
00130 ;
00140 ;
00150 ;
00160 ;
```


```
00010 O0053 ;
00020     G244 P0 ;
00030     G242 X80 Y20 ;
00040     G01 X110 Y50 ;
00050     G02 X140 Y20 I110 J20 Q0 ;
00060     G02 X140 Y20 I80 J20 Q4 ;
00070     G02 X110 Y-10 I110 J20 Q0 ;
00080     G01 X80 Y20 ;
00090     G244 P2 ;
00100     G242 X80 Y20 ;
00110     G01 Y-70 ;
00120     G242 X20 Y20 ;
00130     G01 Y-70 ;
00140     G244 P1 ;
00150     G242 X80 Y-65 ;
00160     G01 X20 ;
00170     G243 X25 Y12 A1 B0 (I) ;
00180     M99 ;
00190 ;
00200 ;
00210 ;
00220 ;
00230 ;
```


```
00010 O0054 ;
00020     G310 D699 Q[#140+16] ;
00030     #141=5 ;
00040     M98 P0031 ;
00050     G310 D699 Q[#140+48] ;
00060     #141=5 ;
00070     M98 P0031 ;
00080     G310 D699 Q[#140+16] ;
00090     #141=5 ;
00100     M98 P0031 ;
00110     G310 D699 Q0 ;
00120     M99 ;
00130 ;
00140 ;
00150 ;
00160 ;
00170 ;
```


A.1.7 Execution Macro

```
00020      G40 G49 G80 ;
00030      #1=#500/2 ;
00040      G91 G42 G01 X#1 Y#1 D#502 F#501 ;
00050      G02 X#1 Y-#1 J-#1 ;
00060      I-#500 ;
00070      X-#1 Y-#1 I-#1 ;
00080      G40 G01 X-#1 Y#1 ;
00090      M99 ;
00100      ;
00110      ;
00120      ;
00130      ;
00140      ;
```


A.1.8 Flow Chart









O0041 (Data table write test)



O0050 (Circular cutting)





O0054 (Execution macro start up)


(START)

Program No. and
AUTO mode select-
ing signal output

Use external program No. search
function.
When AUTO mode is selected from
the macro, prepare PMC so that the
external program No. from machine
side becomes invalid.

Timer

Time chart



Further, start signal
is output

Timer



Only start signal
OFF

Timer

Program No. and
AUTO mode select-
ing signal OFF

Unless the AUTO mode signal
is turned OFF finally, and selec-
tion from the operator's panel is
invalid.

RET



A.1.9 Explanation of Program

```
(1) O0001
    0020 N000 G202 P3
        Screen erase
        P1: Character screen, P2: Graphic screen,
        P3: Character and graphics
    0030 #8505=0
        Cursor control
        #8505=0 : Cursor OFF, #8505=1 : Cursor ON
    0040 G243 X0 Y0 A1 B0 (SAMPLE PROGRAM)
        X2 Y3 (.....)
```

Displaying the characters on the screen
 G243 : Character display
 X0 : Position to start X-axis display
 Y0 : Position to start Y-axis display
 A1 : Size of the letter (A1 : 1 time, A3 : 3 times)

0, 0	39, 0
Character coordinate	
0, 15	39, 15

The character string in parenthesis is displayed on the screen.

* In NC programming, a set of parentheses () is a control IN/OUT function, which can be used as a comment, but in conversation macro, it means the display data, which cannot be used as a comment.

```
0100 #8509=0033
```

```
    #143=300
```

```
    M98 P0011
```

#8509 is a character string registration control variable.

The character string corresponding to a sequence No. can be displayed, using G243 XYP sequence No.

Set Program No. including Sequence No., using #8509.

#143 is a common variable, which is used as offset of Sequence No. here.

The menu corresponding to the soft key is displayed, using subprogram O0011.

```
0130 N001 #142=#8501
```

#8501 is a key input variable, which accepts the cursor key, page key, soft key, edit key and input key.

Once it is read, it is cleared to "0"; then, save the data in #142.

```
(2) O0011
```

```
    0030 WHILE [Conditional Expression] D01
```

```
        {
```

```
    END1
```

In a WHILE statement, while the conditional expression is established, processing between DO and END is carried out, and when it is not established, execution is started from the next block of the corresponding END statement.

0040 G243 X [] Y [] P [#143+#100]

#143 is a common variable, which is used for Sequence No. offset.

#100 is used as a counter, which counts 0 to 4.

Here set the head Sequence No. of the character string written in Program No. O0033, using #143, and loop it with #100 to make it correspond to soft key 1 to 5.

O0020

0220 N003 #100=#100+6

#100=#100-[FIX [#100/6]]*6

This calculation is made to find the cursor position.

Add 6 in advance so that cursor position does not become negative on the 220th line. "6" means that the cursor moves at 6 places.

"FIX" on the 230th line is a function which omits the figure below the decimal place of the answer for the quotient. Find the remainder divided by 6.

O0030

0090 G243 X0 Y2 A1 B0 K200

Write 200 blanks, using K200.

If a triple character is specified with A3, the blank of a triple character is written by the specified number.

0190 X0 Y4 (*3441 2438 493D.....*)

When internal codes, such as Chinese characters are used for the screen display, enclose them with "(*" and "*)".

For chinese characters, space for 2 letters are used.

0480 G243 X__Y__ F8.3

F8.3 specifies the digits when numerical data is displayed: total 8 digits and 3 digits below the decimal place.

0570 X6 Y6 (5.2)

#100=1234.567

When the display is made in 2 digits below the decimal place, using F5.2 format, the figure is half-adjusted to "1234.57".

0600 #8509=0033

Use the character string registration program variable #8509 that designates program No. including sequence No. specified by G243 P(Sequence No.).

Here, use Program No. 0033 character string.

O0032

G243.....B1(...)

For blink display, display instructions are given only once but repeated.

O0040

0101 #101=G121.4

G121.4 (emergency stop) condition is read to common variable #100.

0310 #103 =P [#102*4+1821].1

The contents of parameter specified by P [] is read to common variable #103.


Here, value of #102 changes from 0 to 2 and parameters 1821, 1825, 1829 are read.

- 1821.1 Reference counter
- 1825.1 Loop gain multiply
- 1829.1 Excessive error at stop

(3) O0054

Use data table No. 699 for data transfer with PMC, and write Program No.,

AUTO mode selection and cycle start signal.




In the PMC sequence program, the external Program No. from the machine side was made invalid and Program No. from the macro valid when the AUTO mode from the macro (MC.A) is received.


When MC.A signal is input, the mode on the operator's panel is changed to "AUTO" automatically.

When the timer preset time elapses after the mode selection, turn the cycle start signal ON.

Within PMC, this signal is "OR" with the cycle start signal on the operator's panel.



A.1.10 Program Example for PMC Sequence



```

00010  O0001 ; Main
00020  N000 G202 P3 ; Screen clear
00030      #8505=0 ; Cursor OFF
00040      G243 X0 Y0 A1 B0 (SAMPLE PROGRAM)
00050      X2 Y3 (1 -- KEY TEST) ;
00060      X2 Y5 (2 -- COUSOR TEST) ;
00070      X2 Y7 (3 -- DISPLAY TEST) ;
00080      X2 Y9 (4 -- ADDRESS VARIABLE) ;
00090      X2 Y11 (5 -- CIRCLE) ;
00100      #8509=0033 ; Character string registration program No.
00110      #143=300 ;
00120      M98 P0011 ; } Soft key display
00130  N001 #142=#8501 ; Input variable read
00140      IF [#142 EQ 0] GOTO 99 ; Loop for which no key is depressed (including M99)
00150      IF [#142 LT 12] GOTO 99 ;
00160      IF [#142 GT 16] GOTO 99 ;
00170      #8500=[#142-11] *10 ;
00180      M99
00190  N099 M99 P1 ;
00200 ;
00210 ;
00220 ;
00230 ;
00240 ;

```

} Menu display

} Separate to program per softkeys

```

00010 00010 ; Key test
00020      G202 P3 ; Screen clear
00030      G243 X0 Y2 A1 B0 (KEYTEST  -- HIT ANY KEY --) ; Title display
00040      #143=100 ;           } Soft key display: #143 is displayed at the
00050      M98 P0011 ;       } head of character sequence No.
00060 N001 #8502=2  Input an address and numeral
00070      #142=#8501 ; SAVE a key input variable
00080      IF [#142 EQ 0] GOTO 99 ;           }
00090      #101=#142 ;                       } Key input presence or absence judgement,
00100      #102=#8503 ;                       } loop for which key input is none.
00110      #103=#8504 ; Key input data read
00120      G243 X0 Y4 A1 B0 (CONTROL  ) F8.3 Z0 D#101 ; }
00130      G243 X0 Y5 A1 B0 (ADDRESS  ) F8.3 Z0 D#103 ; } Key input
00140      G243 X0 Y6 A1 B0 (DATA     ) F8.3 Z0 D#102 ; } data display
00150 N099 IF [#142 NE 16] GOTO 97 ; Shift to the menu after a push
00160 N098 #8500=1 ;           on the END key.
00170      M99 ;
00180 N098 M99 P1 ;
00190 ;
00200 ;
00210 ;
00220 ;
00230 ;

```

```

00010 00011 ;
00020      #100=0 ; Clear the counter      Top sequence No. of
                                         character for soft key
00030      WHILE [#100 LT 5] DO 1 ;
00040          G243 X[#100*8+1] Y16 A1 B0 P[#143+#100] ;
00050          #100=#100+1 ; Counter +1
00060      END 1 ;
00070      M99 ;
00080 ;
00090 ;
00100 ;
00110 ;
00120 ;

```

```

00010  O0020 ; Cursor test
00020      G202 P3 ;
00030      #8505=0 ; Cursor display none
00040      #8502=0 ; key input none
00050  N008 G243 X0 Y1 (CURSOR TEST -- MOVE CURSOR --) ; Title display
00060      G243 X0 Y3 (A) ;
00070      G243 X0 Y4 (B) ;
00080      G243 X0 Y5 (C) ;
00090      G243 X0 Y6 (D) ;
00100      G243 X0 Y7 (E) ;
00110      G243 X0 Y8 (F) ;
00120      #143=100
00130      M98 P0011 ;
00140      #100=0 ; Pointer for cursor display position
00150      #8506=2 ; Cursor position in X-axis direction
00160  N001 #142=#8501 ; SAVE key input control variable.
00170      IF [#142 EQ 0] GOTO 3 ; Key input presence or absence judgment
00180      IF [#142 NE 3] GOTO 2 ; Pointer +1 for cursor ↓
00190      #100=#100+1 ;
00200  N002 IF [#142 NE 4] GOTO 3 ; Pointer -1 for cursor ↑
00210      #100=#100-1 ;
00220  N003 #100=#100+6 ;
00230      #100=#100-[FIX [#100/6]]*6 ;
00240      #8507=#100+3 ; Actual Y-axis cursor position
00250      #8505=1 ; Cursor display ON
00260  N099 IF [#142 NE 16] GOTO 97 ; Return to the menu after a push on the END key.
00270  N098 #8500=1 ;
00280      M99 ;
00290  N097 M99 P1 ;
00300 ;
00310 ;
00320 ;
00330 ;
00340 ;

```

} The menu for cursor is displayed

} Soft key display

} Pointer position calculation

```

00010 00030 ; Character display test
00020     G202 P3 ; Screen clear
00030     #8502=0 ; Data input invalid
00040     #8505=0 ; Cursor display OFF
00050     #143=100 ;
00060         M98 P0011 ; } Soft key display
00070 N001 G243 X0 Y2 A1 B0 K200 ; Partial screen erase
00080     X0 Y2 (DISPLAY TEST) ;
00090     G243 X0 Y4 A1 B0 K200 ;
00100     #141=100 ;
00110         M98 P0031 ; } Timer
00120     X0 Y4 (FANUC 0 SERIES MACRO COMPILER) ;
00130     #141=300 ;           ↖Enclose the characters to be displayed
00140         M98 P0031 ;           with a parenthesis.
00150     G243 X0 Y4 A1 B0 K200 ;
00160     #141=100 ;
00170         M98 P0031 ;
00180     G243 X0 Y4 A1 B0 K200 ;
00190     X0 Y4 (*3441 2438 493D 3C28 00C3 00BD 00C4*) ;
00200     #141=300 ;           ↖Enclose the internal code with "("
00210         M98 P0031 ;           and "*"".
00220     G243 X0 Y4 A1 B0 K200 ;
00230     #141=100 ;
00240         M98 P0031 ;
00250     G243 X0 Y4 A1 B0 K200 ;
00260     X0 Y4 (INT.␣CODE␣)(*2F40␣2F48␣2F79 2F53*) ;
00270     #141=300 ;
00280         M98 P0031 ;
00290     G243 X0 Y4 A1 B0 K200 ;
00300     #141=100 ;
00310         M98 P0031 ;
00320     X0 Y4 A3 B0 (3 MULTI) ;
00330     #141=300 ;
00340         M98 P0031 ;
00350     G243 X0 Y4 A1 B0 K200 ;
00360     #141=100 ;
00370         M98 P0031 ;
00380         M98 P0032 ; Blink test sub program
00390     #141=100 ;
00400         M98 P0031 ;
00410     G243 X0 Y4 A1 B0 K200 ;
00420     X0 Y4 (DATA DISPLAY TEST      1234.567) ;
00430     #100=1234.567 ;
00440     G243 X0 Y6 F8.3 Z0 K200 ;

```

```
00450      X0 Y6 (F8.3 ) D#100 ;
00460      #141=300 ;
00470          M98 P0031 ;
00480      G243 X0 Y6 F8.3 Z1 K200 ;
00490      #141=100 ;
00500          M98 P0031 ;
00510      X0 Y6 (F8.3 ) D#100 ( LEADING ZERO NEG. ) ;
00520      #141=300 ;
00530          M98 P0031 ;
00540      G243 X0 Y6 F5.2 K200 ;
00550      #141=100 ;
00560          M98 P0031 ;
00570      X0 Y6 (F5.2 ) D#100 ;
00580      #141=300 ;          } Timer
00590          M98 P0031 ;   }
00600      #8509=0033 ; The character string is O0033.
00610      G243 X0 Y4 A1 B0 K200 ; Partial screen erase
00620      #141=100 ;          } Timer
00630          M98 P0031 ;   }
00640      X0 Y4 (STRINGS DISPLAY TEST) ; Display
00650      G243 X0 Y6 K200 ; Screen partially erased
00660      X0 Y6 P10 ; The character string of sequence No. 10 is displayed.
00670      #141=300 ;          } Timer
00680          M98 P0031 ;   }
00690      G243 X0 Y6 K200 ; Screen partially erased
00700      #141=100 ;          } Timer
00710          M98 P0031 ;   }
00720      X0 Y6 P20 ; The character string of sequence No. 20 is displayed.
00730      #141=300 ;          } Timer
00740          M98 P0031 ;   }
00750      #142=#8501 ; Key input variable is SAVED.
00760 N099 IF [#142 NE 16] GOTO 97 ; Return to the menu when the soft key is "END".
00770 N098 #8500=1 ;
00780 M99;
00790 N097 M99 P1;
00800
00810
00820
00830
00840
```

```

00010  O0031 ; Timer
00020  N001 IF [#141 LT 0] GOTO 99 ; } End when timer value is smaller than -10;
00030      #141=#141-1 ;
00040      GOTO 1 ;
00050  N099 #142=#8501 ;
00060      IF [#142 EQ 16] GOTO 97 ; } Return to the menu when the END key
00070      M99 ; } is depressed during timer operation
00080  N097 M99 P98 ;
00090  ;
00100  ;
00110  ;
00120  ;
00130  ;

```

```

00010  O0032 ; Brink test
00020      G243 X0 Y4 A1 B0 (BLINK TEST) ; Title display
00030      #100=200 ; Loop counter setting
00040      WHILE [#100 GT 0] DO 1 ;
00050          #100=#100-1 ;
00060  N001      G243 X0 Y6 A1 B1 (BLINK SLOW) ;  Loop for blinkig
00070      END 1 ;
00080      G243 X0 Y6 A1 B0 K20 ; Screen partially erased
00090      #141=100 ;
00100      M98 P0031 ; } Timer
00110      #100=200 ; Loop counter setting
00120      WHILE [#100 GT 0] DO 2 ;
00130          #100=#100-1 ;
00140  N002      G243 X0 Y6 A1 B2 (BLINK FAST) ;  Loop for blinking
00150      END 2 ;
00160      G243 X0 Y4 A1 B0 K200 ; Screen partially erased
00170      M99 ;
00180  ;
00190  ;
00200  ;
00210  ;
00220  ;

```

```
00010  O0033 ; Display character string data.
00020  N010 (ABCDEFGHIJKLMN0PQRSTUVWXYZ0123456789) ;
00030  N020 (FANUC TECHNICAL TRAINING CENTER) ;
00040  N100 (      ) ;                               \Enclose the display character string
00050  N101 (      ) ;                               with parentheses.
00060  N102 (      ) ;
00070  N103 (      ) ;
00080  N104 ( END  ) ;
00090  N200 (RADIUS) ;
00100  N201 ( FEED ) ;
00110  N202 (OFS NO) ;
00120  N203 ( EXEC ) ;
00130  N204 ( END  ) ;
00140  N300 (TEST-1) ;
00150  N301 (TEST-2) ;
00160  N302 (TEST-3) ;
00170  N303 (TEST-4) ;
00180  N304 (TEST-5) ;
00190  N500 (INPOSITION WIDTH  ) ;
00200  N504 (SERVO ERROR LIMIT ) ;
00210  N508 (GRID SHIFT VALUE  ) ;
00220  N512 (LOOP GAIN MULTPLY ) ;
00230  M99 ;
00240      ;
00250      ;
00260      ;
00270      ;
00280      ;
```

} Enclose the internal code with "(" and ")"

```

00010 00040 ; Address variable test
00020      G202 P3 ; Screen erase
00030      #143=100 ;      }
00040      M98 P0011 ;    } Soft key display
00050 N008 G243 X0 Y2 A1 B0 K520 ; Screen partially erased
00060      G243 X0 Y2 A1 B0 (ADDRESS VARIABLE TEST) ; Title display
00070      #141=100 ;      }
00080      M98 P0031 ;    } Timer
00090      X0 Y4 (ADDRESS G READ TEST) ; Display ;
00100 N001 #101=G121.4 ; Emergency stop signal read
00110      IF [#101 EQ 0] GOTO 2 ;
00120      X0 Y6 Z1 F1.0 (ESP STATUS -- ) D#101 ( PUSH ESP) ;
00130      #142=#8501 ;      }
00140      IF [#142 EQ 16] GOTO 98 ; } Looped until the emergency stop signal is input,
00150      M99 P1 ;          } but a push on the END key returns the display to
                                } the menu.
00160 N002 X0 Y6 Z1 F1.0 (ESP STATUS -- ) D#101 ( RESET ESP) ;
00170      #141=100 ;      }
00180      M98 P0031 ;    } Timer
00190      X0 Y4 K200 ; Screen partialloy cleared
00200      #141=100 ;      }
00210      M98 P0031 ;    } Timer
00220      X0 Y4 (ADDRESS D WRITE TEST) ;
00230      M98 P0041 ; Subroutine of data table teat
00240      G243 X0 Y4 A1 B0 K200 ; Screen partially erased
00250      #141=100 ;      }
00260      M98 P0031 ;    } Timer
00270      G243 X0 Y4 (PARAMETER READ) ;
00280      #102=0 ; Counter
00290      #8509=0033 ; The character string for display is 00033
00300      WHILE [#102 LE 2] DO 1 ;
00310          #103=P[#102*4+1821].1;Calculate parameter No.(P:parameter)
00320          G243 X0 Y[#102+6] (NUM ) Z1 F3.0 D[#102*4+1821]
00330          ( -- ) D#103 ;
00340          G243 ( ) P[#102*4+1821] ; "P" is sequence No. of character string.
00350          #102=#102+1
00360      END 1 ;
00370      #141=500 ;      }
00380      M98 P0031 ;    } Timer
00390      #142=#8501 ;      }
00400 N099 IF [#142 NE 16] GOTO 97 ; } A push on the END key returns
00410 N098 #8500=1 ;          } the display to the menu.
00420      M99 ;
00430 N097 M99 P8 ;
00440      ;

```

Address G is
 PMC → NC input.

```
00450 ;
00460 ;
00470 ;
00480 ;
00010 O0041 ;
00020     #100=0 ; Counter
00030     WHILE [#100 LT 5] DO 1 ;
00040         G310 D699 Q#100 ; Write Q data on the data table specified by D.
00050         #141=10 ;
00060         M98 P0031 ; } Timer
00070         #100=#100+1 ; Counter +1
00080     END 1 ;
00090         #100=D699 ;
00100 G243 X0 Y6 (DATA TABLE -- ) F3.0 D#100 ; } Answer display
00110     #141=300 ;
00120     M98 P0031 ; } Timer
00130 M99 ;
00140 ;
00150 ;
00160 ;
00170 ;
00180 ;
```

```

00010 00050 ; Circular cutting
00020      G202 P3 ; Screen erased
00030      #8506=13 ; Cursor display X position
00040      #8507=2 ; Cursor display Y position
00050      #8505=1 ; Cursor display ON
00060      #147=0 ; Cursor pointer
00070      G202 P3 ;
00080          M98 P0052 ; Character string display subroutine for data
00090          M98 P0053 ; Graphic display subroutine
00100          M98 P0051 ; Data display subroutine
00110 N001 #8502=1 ; Data is input with numerals
00120      #142=#8501 ; SAVE key input variable.
00130      #144=#8503 ; Numeral data variable read
00140      IF [#142 EQ 0] GOTO 99 ; In the absence of key input, the loop M99 should
00150      IF [#142 NE 12] GOTO 3 ; } be included.
00160      #147=0 ; } When soft key 1 is depressed, the cursor
00170      GOTO 9 ; } pointer is 0.
00180 N003 IF [#142 NE 13] GOTO 4 ; }
00190      #147=1 ; } When soft key 2 is depressed, the cursor
00200      GOTO 9 ; } pointer is 1.
00210 N004 IF [#142 NE 14] GOTO 5 ; }
00220      #147=2 ; } When the soft key 3 is depressed, the cursor
00230      GOTO 9 ; } pointer is 2.
00240 N005 IF [#142 NE 4] GOTO 6 ; }
00250      #147=#147-1 ; } When the cursor is "↑", the pointer is -1.
00260      GOTO 9 ; }
00270 N006 IF [#142 NE 3] GOTO 7 ; }
00280      #147=#147+1 ; } When the cursor is "↓", the pointer is +1.
00290      GOTO 9 ; }
00300 N007 IF [#142 NE 15] GOTO 8 ; To N8 if soft key 4 is not "EXEC".
00310      #140=1 ; Select 00001 external program search No. → Select 00001 of NC memory.
00320          M98 P0054 ; Start NC via PMC.
00330      GOTO 10 ;
00340 N008 IF [#142 NE 8] GOTO 10 ; To N10 if "INPUT" is not depressed.
00350 N009 #147=#147+3
00360      #147=#147-FIX [#147/3]* 3 ; Cursor position calculation
00370      IF [#144 EQ #0] GOTO 10 ; To N10 if any numeric was keyed in.
00380      #[500+#147]=#144 ; Data written to common variable 500 -
00390      G243 X14 Y[#147+2] Z1 F4.0 D#[#147+500] ; } Data display
00400 N010 M98 P0051 ;
00410 N099 IF [#142 NE 16] GOTO 97 ; }
00420 N098 #8500=1 ; } To the menu when the END key is depressed.
00430      M99 ;
00440 N097 M99 P1 ;

```

```
0045 ;
0046 ;
0047 ;
0048 ;
0049 ;

00010 00051 ; Cursor and data display
00020     #8507=#147+2 ; Cusror and position
00030     #100=0 ; Counter
00040     WHILE {#100 LT 3} DO ! ;
00050         G243 X14 Y[#100+2] Z1 F4.0 D#[500+#100] ;
00060         #100=#100+1 ;
00070     END 1 ;
00080     M99 ;
00090 ;
00100 ;
00110 ;
00120 ;
00130 ;

00010 00052 ; Character string display for data
00020     G243 X0 Y0 A1 B0 (CIRCULAR CUTTING) ;
00030     X1 Y2 (I) ;
00040     C40 (RADIUS) C41 C61 ;
00050     X1 Y3 (F) ;
00060     C40 ( FEED ) C41 C61 ;
00070     X1 Y4 (D) ;
00080     C40 (OFS NUM) C41 C61 ;
00090     #143=200 ;
00100     M98 P0011 ;
00110     M99 ;
00120 ;
00130 ;
00140 ;
00150 ;
00160 ;
```

} Data is displayed, changing display position.

```

00010 00053 ; Graphic display
00020      G244 P0 ; Type of line (solid line)
00030      G242 X80 Y20 ; Drawing start posotion
00040      G01 X110 Y50 ;
00050      G02 X140 Y20 I110 J20 Q0 ;
00060      G02 X140 Y20 I80 J20 Q4 ;
00070      G02 X110 Y-10 I110 J20 Q0 ;
00080      G01 X80 Y20 ;          ↖Specify the number of quadrants.
00090      G244 P2 ;
00100      G242 X80 Y20 ;
00110      G01 Y-70 ;
00120      G242 X20 Y20 ;
00130      G01 Y-70 ;
00140      G244 P1 ;
00150      G242 X80 Y-65 ;
00160      G01 X20 ;
00170      G243 X25 Y12 A1 B0 (I) ;
00180      M99 ;
00190      ;
00200      ;
00210      ;
00220      ;
00230      ;

00010 00054 ; Data output to PMC
00020      G310 D699 Q[#140+16]; Select Program No. for #140 and AUTO mode with+16.
00030      #141=5 ;          }
00040      M98 P0031 ;      } Timer
00050      G310 D699 Q[#140+48] ;AUTO mode and cycle start are ON with+48
00060      #141=5 ;
00070      M98 P0031 ;
00080      G310 D699 Q[#140+16] ;Only AUTO mode is ON with+16. Cycle start is OFF.
00090      #141=5 ;
00100      M98 P0031 ; All data including program No. is OFF.
00110      G310 D699 Q0 ;
00120      M99 ;
00130      ;
00140      ;
00150      ;
00160      ;
00170      ;

```

```
00010 O9010 ; Execution macro for circular cutting
00020     G40 G49 G80 ;
00030     #1=#500/2 ;
00040     G91 G42 G01 X#1 Y#1 D#502 F#501 ;
00050     G02 X#1 Y-#1 J-#1 ;
00060     I-#500 ;
00070     X-#1 Y-#1 I-#1 ;
00080     G40 G01 X-#1 Y#1 ;
00090     M99 ;
00100 ;
00110 ;
00120 ;
00130 ;
00140 ;
```

Set 100 to compile parameter 9013, and call this program from program O0001 in NC memory, using G100. program O0001 is selected via PMC with external program No. search, from conversational macro O00054.

A.2

EXAMPLE-2

EXAMPLE FOR KEY

INPUT AND CURSOR

CONTROL

A.2.1

Source program List

```
00010 O8000 ;
00020 N1 M98 P8011 ;
00030 N9 M98 P9503 ;
00040 IF [#102 EQ 12] GOTO 100 ;
00050 IF [#102 EQ 13] GOTO 200 ;
00060 M99 P9 ;
00070 N100 M98 P8012 ;
00080 N19 M98 P9503 ;
00090 IF [#102 EQ 16] GOTO 199 ;
00100 IF [#102 NE 8] GOTO 190 ;
00110 IF [#104 EQ 1] GOTO 110 ;
00120 #10050 = #103 ;
00130 #140 = 4.0 ;
00140 #141 = 1 ;
00150 M98 P9501 ;
00160 M99 P19 ;
00170 N110 #[10051 + #105] = #103 ;
00180 #140 =5.2 ;
00190 #141 = 1 ;
00200 M98 P9501 ;
00210 N190 M99 P19 ;
00220 N199 M99 P1 ;
00230 N200 M98 P8013 ;
00240 N29 M98 P9503 ;
00250 IF [#102 EQ 16] GOTO 299 ;
00260 IF [#102 NE 8] GOTO 290 ;
00270 IF [#104 EQ 1] GOTO 210 ;
00280 #10060 = #103 ;
00290 #140 = 4.0 ;
00300 #141 = 0 ;
00310 M98 P9501 ;
00320 M99 P29 ;
00330 N210 #[10061 + #105] = #103 ;
00340 #140 = 4.0 ;
```

```
00350      #141 = 0 ;
00360          M98 P9501 ;
00370 N290 M99 P29 ;
00380 N299 M99 P1 ;
00390      ;
00400      ;
00410      ;
00420      ;
00430      ;

00010 O8001
00020      #10000 = 10010 ;
00030      #10001 = 2 ;
00040      #10002 = 10026 ;
00050      #10003 = 2 ;
00060      #10010 = 13 ;
00070      #10011 = 2 ;
00080      #10012 = 0 ;
00090      #10013 = 0 ;
00100      #10014 = 1 ;
00110      #10015 = 1 ;
00120      #10016 = 1 ;
00130      #10017 = 0 ;
00140      #10018 = 10 ;
00150      #10019 = 4 ;
00160      #10020 = 0 ;
00170      #10021 = 1 ;
00180      #10022 = 1 ;
00190      #10023 = 7 ;
00200      #10024 = 1 ;
00210      #10025 = 1 ;
00220      #10026 = 13 ;
00230      #10027 = 2 ;
00240      #10028 = 0 ;
00250      #10029 = 0 ;
00260      #10030 = 1 ;
00270      #10031 = 1 ;
00280      #10032 = 1 ;
00290      #10033 = 0 ;
00300      #10034 = 11 ;
00310      #10035 = 4 ;
00320      #10036 = 6 ;
00330      #10037 = 1 ;
00340      #10038 = 4 ;
```

```
00350      #10039 = 5 ;
00360      #10040 = 1 ;
00370      #10041 = 0 ;
00380      #8500 = 8000 ;
00390      M99 ;
00400      ;
00410      ;
00420      ;
00430      ;
00440      ;

00010 O8011 ;
00020      M98 P9506 ;
00030      G243 X0 Y1 A1 (MACRO EXAMPLE) ;
00040      X2 Y4 A1 (SOFTKEY SELECT) ;
00050      X3 Y6 (1 - EXAMPLE A) ;
00060      X3 Y7 (2 - EXAMPLE B) ;
00070      X3 Y8 (3 - EXAMPLE C) ;
00080      X3 Y9 (4 - EXAMPLE D) ;
00090      X3 Y10(5 - EXAMPLE E) ;
00100      X2 Y16(EX.A) ;
00110      X10(EX.B) ;
00120      X18(EX.C) ;
00130      X26(EX.D) ;
00140      X34(EX.E) ;
00150      #100 = 0 ;
00160      M99 ;
00170      ;
00180      ;
00190      ;
00200      ;
00210      ;

00010 O8012 ;
00020      M98 P9506 ;
00030      G243 X1 Y0 A1 (EXAMPLE A) ;
00040      X3 Y2 ( PROG NO ) C61 ;
00050      X0 Y4 ( DATA 1 ) C61 ;
00060      X0 Y5 ( DATA 2 ) C61 ;
00070      X0 Y6 ( DATA 3 ) C61 ;
00080      X0 Y7 ( DATA 4 ) C61 ;
00090      X0 Y8 ( DATA 5 ) C61 ;
00100      X0 Y9 ( DATA 6 ) C61 ;
00110      X0 Y10( DATA 7 ) C61 ;
```

```
00120      X34 Y16 (END) ;
00130      G243 X14 Y2 F4.0 Z0 D#10050 ;
00140      #140 = 5.2 ;
00150      #141 = 1 ;
00160      #142 = 11 ;
00170      #143 = 4 ;
00180      #144 = 10051 ;
00190      #145 = 7 ;
00200      #146 = -9999 ;
00210      #147 = 1 ;
00220      M98 P9505 ;
00230      #100 = 1 ;
00240      #104 = 0 ;
00250      #105 = 0 ;
00260      #140 = 0 ;
00270      M98 P9502 ;
00280      M99 ;
00290      ;
00300      ;
00310      ;
00320      ;
00330      ;


00010      O8013 ;
00020      M98 P9506 ;
00030      G243 X1 Y0 A1 (EXAMPLE B) ;
00040      X3 Y2 (PROG NO) (* 3D *) ;
00050      X0 Y4 (DATA SET1) ;
00060      X0 Y5 (DATA SET2) ;
00070      X0 Y6 (DATA SET3) ;
00080      X0 Y7 (DATA SET4) ;
00090      X0 Y8 (DATA SET5) ;
00100      X34 Y16 (END) ;
00110      G243 X14 Y2 F4.0 Z0 D#10060 ;
00120      #110 = 0 ;
00130      WHILE [#110 LE 4] DO 1 ;
00140          #140 = 4.0 ;
00150          #141 = 0 ;
00160          #142 = 12 ;
00170          #143 = #110 + 4 ;
00180          #144 = 10061 + #110 * 4 ;
00190          #145 = 4 ;
00200          #146 = -9999 ;
00210          #147 = 6 ;
```

```
00220             M98 P9504 ;
00230             #110 = #110 + 1 ;
00240     END 1 ;
00250     #100 = 2 ;
00260     #104 = 0 ;
00270     #105 = 0 ;
00280     #140 = 0 ;
00290             M98 P9502 ;
00300     M99 ;
00310 ;
00320 ;
00330 ;
00340 ;
00350 ;
00360 ;
```

A.2.2 Specification

A.2.2.1 Type of Screen

(1) Initial screen




Press  key: this screen will be displayed.

On this screen, select a menu.

However, in this example, EX.C, EX.D, and EX.E menu screens are not prepared.

(2) Menu-1 (EX.A)




Press soft key **END** : the display will return to the initial screen.

”_” indicates the cursor position.

Actually, the cursor is displayed always at one place.

(3) Menu-2 (EX.B)



Press soft key END : the display will return to the initial screen.
 ”_” indicates the cursor position.
 Acutally, the cursor is displayed always at one place.

A.2.2.2
Variable Data


(1) Cursor control data

P-CODE variable		
#100	CSNO	Cursor control No.
1		
2	KCONT	Key input control data (#8501 value)
3	KDATA	Key input numerical data (#8503 value)
4	CPNT	Cursor pointer
5	SUBP	Cursor subpointer


(2) Cursor data

#10000	10010	#10010	13
	2	1	2
	10026	2	0
	2	3	0
		4	1
		5	1
		6	1
		7	0
		8	10
		9	4
		20	0
		1	1
		2	1
		3	7
		4	1
		5	1
		#10026	13
		7	2
		8	0
		9	0
		30	1
		1	1
		2	1
		3	0
		4	11
		5	4
		6	6
		7	1
		8	4
		9	5
		40	1
		1	0


(3) Variables used in menu



A.2.3
Program Structure



A.2.4 Flow Chart



A.2.5 Coding

(1) Main program

```

00010 O8000 ;
00020 N1 M98 P8011 ; _____ Initial screen display
00030 N9 M98 P9503 ; _____ KEY IN
00040 IF [#102 EQ 12] GOTO 100 ; }
00050 IF [#102 EQ 13] GOTO 200 ; } Soft key #1, #2 ?
00060 M99 P9 ;
00070 N100 M98 P8012 ; _____ Screen (EX. A) display
00080 N19 M98 P9503 ;
00090 IF [#102 EQ 16] GOTO 199 ; _____ Soft key #5 (END) ?
00100 IF [#102 NE 8] GOTO 190 ; _____ Input key judgment
00110 IF [#104 EQ 1] GOTO 110 ; _____ Cursor position ?
00120 #10050 = #103 ;
00130 #140 = 4.0 ;
00140 #141 = 0 ;
00150 M98 P9501 ;
00160 M99 P19 ;
00170 N110 #[10051 + #105] = #103 ;
00180 #140 = 5.2 ;
00190 #141 = 1 ;
00200 M98 P9501 ;
00210 N190 M99 P19 ;
00220 N199 M99 P1 ; _____
00230 N200 M98 P8013 ; _____ Screen (EX. B) display
00240 N29 M98 P9503 ; _____ Key IN
00250 IF [#102 EQ 16] GOTO 299 ; _____ Soft key (END) ?
00260 IF [#102 NE 8] GOTO 290 ; _____ Input key judgment
00270 IF [#104 EQ 1] GOTO 210 ; _____ Cursor position ?
00280 #10060 = #103 ;
00290 #140 = 4.0 ;
00300 #141 = 0 ;
00310 M98 P9501 ;
00320 M99 P29 ;
00330 N210 #[10061 + #105] = #103 ;
00340 #140 = 4.0 ;
00350 #141 = 0 ;
00360 M98 P9501 ;
00370 N290 M99 P29 ; _____
00380 N299 M99 P1 ;
00390 ;
00400 ;
00410 ;
00420 ;
00430 ;

```

Processing on EX. A screen
 Data setting
 Processing on EX. B screen
 Data setting

(2) Initial screen display (Subprogram)

```
00010  O8011 ;
00020  M98 P9506 ;
00030  G243 X0 Y1 A3 (MACRO EXAMPLE) ;
00040  X2 Y4 A1 (SOFTKEY SELECT) ;
00050  X3 Y6 (1 - EXAMPLE A) ;
00060  X3 Y7 (2 - EXAMPLE B) ;
00070  X3 Y8 (3 - EXAMPLE C) ;
00080  X3 Y9 (4 - EXAMPLE D) ;
00090  X3 Y10(5 - EXAMPLE E) ;
00100  X2 Y16(EX.A) ;
00110  X10(EX.B) ;
00120  X18(EX.C) ;
00130  X26(EX.D) ;
00140  X34(EX.E) ;
00150  #100= 0 ;
00160  M99 ;
00170  ;
00180  ;
00190  ;
00200  ;
00210  ;
```

(3) EX. A Screen display (Subprogram)

```
00010  O8012 ;
00020  M98 P9506 ;
00030  G243 X1 Y0 A1 (EXAMPLE A) ;
00040      X3 Y2 (PROG NO ) C61 ;
00050  X0 Y4 ( DATA 1 ) C61 ;
00060  X0 Y5 ( DATA 2 ) C61 ;
00070  X0 Y6 ( DATA 3 ) C61 ;
00080  X0 Y7 ( DATA 4 ) C61 ;
00090  X0 Y8 ( DATA 5 ) C61 ;
00100  X0 Y9 ( DATA 6 ) C61 ;
00110  X0 Y10( DATA 7 ) C61 ;
00120  X34 Y16 (END) ;
00130  G243 X14 Y2 F4.0 Z0 D#10050 ;
00140  #140 = 5.2 ;
00150  #141 = 1 ;
00160  #142 = 11 ;
00170  #143 = 4 ;
00180  #144 = 10051 ;
```

```
00190 #145 = 7 ;
00200 #146 = -9999 ;
00210 #147 = 1 ;
00220 M98 P9505 ;
00230 #100 = 1 ;
00240 #104 = 0 ;
00250 #105 = 0 ;
00260 #140 = 0 ;
00270 M98 P9502 ;
00280 M99 ;
00290 ;
00300 ;
00310 ;
00320 ;
00330 ;
```

(4) FX.B Screen program (Subprogram)

```
00010 O8013 ;
00020 M98 P9506 ;
00030 G243 X1 Y0 A1 (EXAMPLE B) ;
00040 X3 Y2 (PROG NO)(*3D*) ;
00050 X0 Y4 (DATA SET1) ;
00060 X0 Y5 (DATA SET2) ;
00070 X0 Y6 (DATA SET3) ;
00080 X0 Y7 (DATA SET4) ;
00090 X0 Y8 (DATA SET5) ;
00100 X34 Y16 (END) ;
00110 G243 X14 Y2 F4.0 Z0 D#10060 ;
00120 #110 = 0 ;
00130 WHILE [#110 LE 4] DO 1 ;
00140 #140 = 4.0 ;
00150 #141 = 0 ;
00160 #142 = 12 ;
00170 #143 = #110 + 4 ;
00180 #144 = 10061 + #110 * 4 ;
00190 #145 = 4 ;
00200 #146 = -9999 ;
00210 #147 = 6 ;
00220 #98 P9504 ;
00230 #110 = #110 + 1 ;
00240 END 1 ;
00250 #100 = 2 ;
```

```
00260 #104 = 0 ;
00270 #105 = 0 ;
00280 #140 = 0 ;
00290 M98 P9502 ;
00300 M99 ;
00310 ;
00320 ;
00330 ;
00340 ;
00350 ;
00360 ;
```

(5) Cursor control data preparation

```
00010 O8001 ;
00020 #10000 = 10010 ;
00030 #10001 = 2 ;
00040 #10002 = 10026
00050 #10003 = 2 ;
00060 #10010 = 13 ;
00070 #10011 = 2 ;
00080 #10012 = 0 ;
00090 #10013 = 0 ;
00100 #10014 = 1 ;
00110 #10015 = 1 ;
00120 #10016 = 1 ;
00130 #10017 = 0 ;
00140 #10018 = 10 ;
00150 #10019 = 4 ;
00160 #10020 = 0 ;
00170 #10021 = 1 ;
00180 #10022 = 1 ;
00190 #10023 = 7 ;
00200 #10024 = 1 ;
00210 #10025 = 1 ;
00220 #10026 = 13 ;
00230 #10027 = 2 ;
00240 #10028 = 0 ;
00250 #10029 = 0 ;
00260 #10030 = 1 ;
00270 #10031 = 1 ;
00280 #10032 = 1 ;
00290 #10033 = 0 ;
00300 #10034 = 11 ;
```

```
00310 #10035 = 4 ;
00320 #10036 = 6 ;
00330 #10037 = 1 ;
00340 #10038 = 4 ;
00350 #10039 = 5 ;
00360 #10040 = 1 ;
00370 #10041 = 0 ;
00380 #8500 = 8000 ;
00390 M99 ;
00400 ;
00410 ;
00420 ;
00430 ;
00440 ;
```

Make this program so that it is executed only once after power ON.

A.3 STANDARD MACRO PROGRAM

A.3.1 Standard Routine List

No	Routine Name	Program number	Explanation
1	DDPL	O9501	Data display to cursor position
2	CDPL	O9502	Cursor display
3	KEYIN	O9503	Key input control
4	VDPLX	O9504	One- row display of variable data
5	VDPLY	O9505	One- column display of variable data
6	DSPC	O9506	Screen CLEAR
7	VSET	O9507	Data setting to continuous variable area
8	VCOPY	O9508	Variable copy

A.3.2 Area of Variable Used

In standard routine, the following variable area is used.

In user's program, do not use this area for others purposes.


P-CODE variables	#100 - #109
	#139 - #148
Common variables	#10000 - (up to the variables required)

A.3.3 Explanation of Variable Area

(1) P-CODE variable

#100	CSNO	Cursor control No. of screen being now selected
1	Vacant	
2	KCONT	Key input control data (#8501 value)
3	KDATA	Key input numerical data (#8503 value)
4	CPNT	Cursor pointer (0,1, 2,)
5	SUBP	Cursor subpointer (0,1, 2,)
	Spare	
9	Spare	
#139 {	Work area	
#148 #149		For macro call using T code (RESERVE)

(2) Cursor control data



1. CSNO (Cursor control No.)
1, 2, 3...are assigned to screen No. requiring cursor control.
In a program, to control the cursor on a screen, set this number to #100 value.
When #100 is "0", the cursor is not displayed.
2. CADDRI
It is necessary to prepare cursor data corresponding to cursor control No., but set its top address to CADDRI.
3. KOSUI
Specify the number of cursor data required on one screen.

(3) Explanation of cursor data

CADRI	CPX	Cursor position X
	CPY	Cursor position Y
	CΔX	X increment for group: 0 for no group
	CΔY	Y increment for group: 0 for no group
	CNX	X number for group: 1 for no group
	CNY	Y number for group:1 for no group
	CINP	Data input relative position
	CXYF	Cursor moving direction for group 0: Move in X direction 1: Move in Y direction

1. Cursor data
One cursor data corresponds to one cursor.
However, when the cursors are arranged in line regularly, those cursors are regarded as one group, which corresponds to one cursor data.
2. Cursor position (X, Y)
Specify the cursor position, using the coordinate on the screen.
When the cursors form a group, specify the position of a cursor at the head of the group.
3. X increment and Y increment (ΔX , ΔY)
When the cursors form a group, specify the spacing between the cursors in line.

When the cursors are arranged only in the X-direction, specify 0 for ΔY , and when the cursors are arranged only in the Y-direction, specify 0 for ΔX .
4. X number and Y number
When the cursors form a group, specify the number of cursors in X-direction and in Y-direction.
Specify 1 for Y and X number in case of X-direction only and Y-direction only arrangements respectively.
When the cursors does not form a group, specify 1 for the both.
5. Data input relative position (CINP)
When the key input numerical value is displayed at the cursor, this function displays it at the position deviated in X-direction by the specified figure.


9999.999

—

Cursor

In this case, "5" should be set for CINT.

(5) Cursor data



A.3.4 Standard Routine

To use the routines (O9501, O9502, O9503) with which the cursor position is associated among the following routines, the cursor data corresponding to the screen selected at that time should be selected. Specifically, set the following;

P-CODE variables

#100 = Cursor control No. of screen being selected at present

#104 = Cursor pointer (Initial value 0)

#105 = Cursor subpointer (Initial value 0)

#104 and #105 values are automatically changed each time the cursor key is pressed.

On the screen with no cursor, set #100 to "0"

(1) DDPL O9501

1. Function

This function displays the input data variable (KDATA value) in the position deviated in the X-direction by "CINT" from the cursor position.

2. Calling format

#140= f (F) : Total digits and digits under decimal point

#141= z (Z) : Reading zero

M98 P9501

f and z are the values commanded by G243.

3. Remark

When this routine is executed , the cursor display position advances by one.

#140 and #141 values are saved.

(2) CDPL O9502

1. Function

This function displays the cursor.

The cursor position is determined by #100 - #105 and #10000-values.

2. Calling format

#140=n

M98 P9502

n= 0 : No cursor pointer changes.

1 : The cursor pointer is advanced by one, displaying the cursor.

2 : The cursor pointer is retracted by one, displaying the cursor.

3. Remark

After this routine is executed, the #140 value is saved.

(3) KEYIN O9503

1. Function

This function accepts key input of numerical data, executing the following processing with its value.

(a) Cursor key

↓ : Moves the cursor forward by one.

↑ : Moves the cursor backward by one.

(b) Other than the cursor key

#8501 and #8503 values are saved.

#102(KCONT) ←#8501

#103(KDATA) ←#8503

2. Calling format

M98 P9503

(4) VDPLX O9504

1. Function

To display a continuous variable value, this function deviates it in the X-direction from the specified place on the CRT screen. (Within one line)

2. Calling format

#140=F (F)

#141=Z (Z)

#142=X } Display position on CRT

#143=Y }

#144=V Variable No.(head)

#145=N No. of display

#146=E End code

#147= Δ X Deviation in the X-direction on the CRT

M98 P9504

E: END code

The display ends when the data which coincides with the end code is reached even within the number of displays.

3. Remark

After this routine is executed, #140 - #147 values are saved.

(5) VDPLY O9505

1. Function

To display a continuous variable value, this function deviates it in the Y-direction from the specified place on the CRT screen. (within one column)

2. Calling format

#140=F

#141=Z

#142=X) Display position on CRT

#143=Y)

#144=V Variables No. (head)

#145=N No. of displays

#146=E End code

#147= Δ Y Deviation in Y-direction on the CRT

M98 P9505

E: End code

The display ends when the data which coincides with the end code is reached even within the number of displays.

3. Remark

After this routine is executed, #140 - #147 values are saved.

(6) DSPC O9506

1. Function

This function clears the screen, including the soft key.

2. Calling format

M98 P9506

3. Remark
The soft key is not cleared with G202.

(7) VSET O9507


1. Function
This function sets the specified data to a continuous variable area.
2. Calling format
#140 = V Variable No. (head number)
#141 = D Data to be set
#142 = N No. of variables

M98 P9507
3. Remark
After this routine is executed, #140 - #142 are saved.

(8) VCOPY O9508

1. Function
This function copies the data in a continuous variable area to another area.
2. Calling format
#140=ADDR_S Address of original data to be copied
#141=ADDR_O Address of data to be copied
#142=N No. of variables

M98 P9508



3. Remark
After this routine is executed, the #140 - #142 values are saved.

A.3.5

List for Source Program

```
00010 O9501 ;
00020 IF [#100 EQ 0] GOTO 900 ;
00030 #145 = #[10000 + [#100 - 1] * 2] ;
00040 IF [#145 EQ 0] GOTO 900 ;
00050 #145 = #104 * 8 + #145 ;
00060 IF [#[#145+7] EQ 1] GOTO 10 ;
00070 #139 = FIX [#105 / [#145 + 4]] ;
00080 #148 = #105 - #139 * [#145 + 4] ;
00090 GOTO 20 ;
00100 N10 #148 = FIX [#105 / [#145 + 5]] ;
00110 #139 = #105 - #148 * [#145 + 5] ;
00120 N20 G243 F#140 Z#141 ;
00130 X[#[#145]+#[#145+2]*#148+#[#145+6]] Y[#[#145+1]+#[#145+3]*#139]
      D#103
00140 #147 = #140 ;
00150 #140 = 1 ;
00160 M98 P9502 ;
00170 #140 = #147 ;
00180 N900 M99 ;
00190 ;
00200 ;
00210 ;
00220 ;
00230 ;

00010 O9502 ;
00020 IF [#100 EQ 0] GOTO 900 ;
00030 #145 = #[10000 + [#100-1] * 2] ;
00040 IF [#145 EQ 0] GOTO 900 ;
00050 #145 = #104 * 8 + #145 ;
00060 #146 = [#145 + 4] * [#145+5] ;
00070 #147 =#[10001 + [#100-1] * 2] ;
00080 IF [#140 EQ 0] GOTO 200 ;
00090 IF [#140 EQ 2] GOTO 100 ;
00100 #105 = #105 + 1 ;
```

```
00110 IF [#105 LT #146] GOTO 200 ;
00120 #105 = 0 ;
00130 #104 = #104 +1 ;
00140 #145 = #145 + 8 ;
00150 IF [#104 LT #147] GOTO 200 ;
00160 #104 = 0 ;
00170 #145 = #[10000 + [#100 -1] * 2] + #104 * 8 ;
00180 GOTO 200 ;
00190 N100 #105 = #105 - 1 ;
00200 IF [#105 GE 0] GOTO 200 ;
00210 #104 = #104 - 1 ;
00220 IF [#104 GE 0] GOTO 120 ;
00230 #104 = #147 - 1 ;
00240 N120 #145 = #[10000 + [#100 -1] * 2] + #104 * 8 ;
00250 #105 = #[#145 + 4] * #[#145 + 5] - 1 ;
00260 N200 IF [#145 + 7] EQ 1] GOTO 210 ;
00270 #139 = FIX [#105 / #[#145 + 4]] ;
00280 #148 = #105 - #139 * #[#145 + 4] ;
00290 GOTO 220 ;
00300 N210 #148 = FIX [#105 / #[#145 + 5]] ;
00310 #139 = #105 - #148 * #[#145 + 5] ;
00320 N220 #8505 = 1 ;
00330 #8506 = #[#145] + #[#145 + 2] * #148 ;
00340 #8507 = #[#145 + 1] + #[#145 + 3] * #139 ;
00350 N900 M99 ;
00360 ;
00370 ;
00380 ;
00390 ;
00400 ;
```

```
00010 O9503 ;
00020 #8502 = 1 ;
00030 #102 = #8501 ;
00040 #103 = #8503 ;
00050 #140 = 1 ;
00060 IF [#102 EQ 3] GOTO 10 ;
00070 IF [#102 NE 4] GOTO 20 ;
00080 #140 = 2 ;
00090 N10 M98 P9502 ;
00100 N20 M99 ;
00110 ;
```

```
00120 ;
00130 ;
00140 ;
00150 ;
00010 O9504 ;
00020 G243 F#140 Z#141 ;
00030 #139 = 0 ;
00040 WHILE [#139 LT #145] DO 1 ;
00050 IF [#[#144 + #139] EQ #146] GOTO 90 ;
00060 X[#142 + #147 * #139] Y#143 D#[#144 + #139]
00070 #139 = #139 + 1 ;
00080 END 1 ;
00090 N90 M99 ;
00100 ;
00110 ;
00120 ;
00130 ;
00140 ;

00010 O9505 ;
00020 G243 F#140 Z#141 ;
00030 #139 = 0 ;
00040 WHILE [#139 LT #145] DO 1 ;
00050 IF [#[#144 + #139] EQ #146] GOTO 90 ;
00060 X#142 Y[#143 + #147 * #139] D#[#144 + #139] ;
00070 #139 = #139 + 1 ;
00080 END 1 ;
00090 N90 M99 ;
00100 ;
00110 ;
00120 ;
00130 ;
00140 :

00010 O9506 ;
00020 G243 X0 Y0 K560 ;
00030 #8505 = 0 ;
00040 X1 Y16 K6 ;
00050 X9 K6 ;
00060 X17 K6 ;
00070 X25 K6 ;
00080 X33 K6 ;
```

```
00090 M99 ;
00100 ;
00110 ;
00120 ;
00130 ;
00140 ;
```

```
00010 O9507 ;
00020 #139 = 0 ;
00030 WHILE [#139 LT #142] DO 1 ;
00040 #[#140 + #139] = #141 ;
00050 #139 = #139 + 1 ;
00060 END 1 ;
00070 M99 ;
00080 ;
00090 ;
00100 ;
00110 ;
00120 ;
```

```
00010 O9508 ;
00020 #139 = 0 ;
00030 WHILE [#139 LT #142] DO 1 ;
00040 #[#141 + #139] = #[#140 + #139] ;
00050 #139 = #139 + 1 ;
00060 END 1 ;
00070 M99 ;
```

A.3.6

Explanation of Program

```
00010  O9501 ; Display of data in cursor position
00020  IF [#100 EQ 0] GOTO 900 ; #100: Cursor control No.
00030  #145 = #[10000 + [#100 - 1] * 2] ; #145: Cursor data head address
00040  IF [#145 EQ 0] GOTO 900 ;
00050  #145 = #104 * 8 + #145 ; #104: Cursor pointer/display cursor address calculation
00060  IF [#[#145+7] EQ 1] GOTO 10 ; Display direction?
00070  #139 = FIX [#105 / [#145 + 4]] ; When displaying the data in the X-direction
00080  #148 = #105 - #139 * [#145 + 4] ;
00090  GOTO 20 ;
00100  N10 #148 = FIX [#105 / [#145 + 5]] ; When displaying the data in the Y-direction
00110  #139 = #105 - #148 * [#145 + 5] ;
00120  N20 G243 F#140 Z#141 ; Format setting for data display
00130  X[#[#145]+#[#145+2]*#148+#[#145+6]] Y[#[#145+1]+#[#145+3]*#139]
      D#103
00140  #147 = #140 ;      } Stack #140. #140=1
00150  #140 = 1 ;      }
00160  M98 P9502 ; Cursor display subroutine
00170  #140 = #147 ; Return #140 to this intial state.
00180  N900 M99 ;
00190  ;
00200  ;
00210  ;
00220  ;
00230  ;
```

```

00010 09502 ; Cursor display
00020 IF [#100 EQ 0] GOTO 900 ;
00030 #145 = #[10000 + [#100-1] * 2] ;
00040 IF [#145 EQ 0] GOTO 900 ; #145: Cursor data head address
00050 #145 = #104 * 8 + #145 ;
00060 #146 = #[#145 + 4] * #[#145+5] ; No. of displays in group
00070 #147 =#[10001 + [#100-1] * 2] ; No. of cursor pointers
00080 IF [#140 EQ 0] GOTO 200 ; No cursor pointer changes
00090 IF [#140 EQ 2] GOTO 100 ; ___
00100 #105 = #105 + 1 ;           ↓ cursor pointer advances
00110 IF [#105 LT #146] GOTO 200 ;
00120 #105 = 0 ; #105 is pointer No. in group
00130 #104 = #104 + 1 ;           }
00140 #145 = #145 + 8 ;           } Next group           } When in the last pointer is reached
00150 IF [#104 LT #147] GOTO 200 ; } Return to the begining when coming to the
00160 #104 = 0 ;                 } cursor pointer group end
00170 #145 = #[10000 + [#100 -1] * 2] + #104 * 8 ;
00180 GOTO 200 ;—————
00190 N100 #105 = #105 - 1 ;           ↓Cursor pointer moves backward
00200 IF [#105 GE 0] GOTO 200 ;
00210 #104 = #104 - 1 ;
00220 IF [#104 GE 0] GOTO 120 ;
00230 #104 = #147 - 1 ;
00240 N120 #145 = #[10000 + [#100 -1] * 2] + #104 * 8 ;
00250 #105 = #[#145 + 4] * #[#145 + 5] - 1 ;___
00260 N200 IF [#[#145 + 7] EQ 1] GOTO 210 ; ↓ When the cursor does not change.
00270 #139 = FIX [#105 / #[#145 + 4]] ; }
00280 #148 = #105 - #139 * #[#145 + 4] ; } The cursor pointer moves in the X-direction
                                           } in a gruop: #148: X #149: Y
00290 GOTO 220 ;
00300 N210 #148 = FIX [#105 / #[#145 + 5]] ; }
00310 #139 = #105 - #148 * #[#145 + 5] ; } The cursor pointer moves in the Y-
                                           } direction in a group.
00320 N220 #8505 = 1 ; Cursor display ON
00330 #8506 = #[#145] + #[#145 + 2] * #148 ; Cursor X position
00340 #8507 = #[#145 + 1] + #[#145 + 3] * #139 ; Cursor Y position
00350 N900 M99 ;
00360 ; #140=0 : No cursor pointer changes           #100 Cursor controll No.
00370 ; #140=1 : The cursor pointer moves forward by one. #101
00380 ; #140=2 : The cursor pointer moves backward by one.) #102 Key input control data
00390 ;                                           #103 key input numerical data
00400 ;                                           #104 Cursor pointer
                                           #105 Cursor subpointer

```

```

00010 O9503 ; Key input control
00020 #8502 = 1 ; Numerical data input
00030 #102 = #8501 ; Key input variable read
00040 #103 = #8503 ; Numerical data read
00050 #140 = 1 ; Advance the cursor.
00060 IF [#102 EQ 3] GOTO 10 ; 3:For cursor↓, advance the cursor pointer.
00070 IF [#102 NE 4] GOTO 20 ; 4:For cursor↑, reaturn the cursor pointer.
00080 #140 = 2 ; Cursor moves backward
00090 N10 M98 P9502 ; Cursor diaplsy sub
00100 N20 M99 ;
00110 ;
00120 ;
00130 ;
00140 ;
00150 ;

```

```

00010 O9504 ; One-line display of variable data (X axis direction)
00020 G243 F#140 Z#141 ; Display format setting
00030 #139 = 0 ; Counter
00040 WHILE [#139 LT #145] DO 1 ; #145 in No. of displays.
00050 IF [#[#144 + #139] EQ #146] GOTO 90 ;
00060 X[#142 + #147 * #139] Y#143 D#[#144 + #139] ;
00070 #139 = #139 + 1 ; #144 Head of variable No.
00080 END 1 ; #146 END code → If the display data is the same as
00090 N90 M99 ; END code, the cursor RETURNS with no display.
00100 ;
00110 ; #147 Deviation in X direction
00120 ;
00130 ;
00140 ;

```

```

00010 O9505 ; One-row display of variable data (Y direction) Difference from O09504
00020 G243 F#140 Z#141 ; Display format setting is that #147 is the
00030 #139 = 0 ;Counter deviation in Y direction
00040 WHILE [#139 LT #145] DO 1 ;
00050 IF [#[#144 + #139] EQ #146] GOTO 90 ;
00060 X#142 Y[#143 + #147 * #139] D#[#144 + #139] ;
00070 #139 = #139 + 1 ;
00080 END 1 ;
00090 N90 M99 ;
00100 ;
00110 ; '

```

```
00120 ;
00130 ;
00140 ;
```

```
00010 O9506 ; Screen clear
00020 G243 X0 Y0 K560 ; Blank of 560 value
00030 #8505 = 0 ; Cursor off
00040 X1 Y16 K6 ;
00050 X9 K6 ;
00060 X17 K6 ;
00070 X25 K6 ;
00080 X33 K6 ;
00090 M99 ;
00100 ;
00110 ;
00120 ;
00130 ;
00140 ;
```


} Erase the soft key

} Leaving the "frame" of the soft key, erase the other part.

```
00010 O9507 ; Set data in continued data area.
00020 #139 = 0 ;
00030 WHILE [#139 LT #142] DO 1 ;
00040 #[#140 + #139] = #141 ;
00050 #139 = #139 + 1 ;
00060 END 1 ;
00070 M99 ;
00080 ;
00090 ;
00100 ;
00110 ;
00120 ;
```

```
00010 O9508 ; Variable copy
00020 #139 = 0 ;
00030 WHILE [#139 LT #142] DO 1 ;
00040 #[#141 + #139] = #[#140 + #139] ;
00050 #139 = #139 + 1 ;
00060 END 1 ;
00070 M99 ;
```

A.4 SCREEN LAYOUT



B MACRO COMPLIER OPERATION (Series 16-A/18-A)

**NOTE**

For operation of macro compiler of Series 20/21, refer to FAPT MACRO COMPILER (For personal computer) Programming Manual (B-66102E).

B.1 OPERATION ON P-G

B.1.1 Special Notes

First, special notes on operation are described below.

- (1) When coming to a deadlock, press **<NL>** key.
Press **<NL>** key several times. The display returns to the initial screen.
Next, checking what should be operated, proceed with operation.
When "FD0 = □" is displayed at the lower left part of the screen, **<F2>** or **<F7>** may be ON.
At that time, to return the display to the initial screen, turn **<F2>** or **<F7>** OFF, and key in NO <NL>.
(2) Remember to switch!
Do not leave F key (**<F0>** - **<F7>**) ON. Before pressing R key, be sure to check F key ON/OFF.
(3) Numeric 1 and alphabet I
Numeric 0 and alphabets O, Comma, and point.
Most of input errors result from these figures, characters and symbols.
(4) Do not forget the minus (-) symbol.

B.1.2 Basic Operations

B.1.2.1 Connectiing to FA writer

Connect FA writer to CN2 or CN3 of P-G. P-G operation is as follows.
(Return to) Initial Screen and press "R1"

Answer the inquiry on the screen with NO = 2_ <NL>

B.1.3 Inputting Macro Program from Keyboard

(Return to) Initial Screen, **<F0>** - **<F7>** OFF and press "R2"

NO = 1 <NL>

PROGRAM = IN <NL>

INPUT = O Program No. **<NL>** (First register Program No. only)

INPUT = <NL> only

PROGRAM = O Program No. **<NL>** (Previously input number)

EDIT = K □ OLD <NL> (□ Space key)

Line No. at the lower left part of the screen is from O0020 on.

- (1) Input each line **<NL>**.
- (2) Before keying in **<NL>**, if a key-in error is found, use BS/CAN keys to correct it.
- (3) Note that program input ends for **<NL>** only.
- (4) After one line **<NL>**, if a key operation error is found, press the "CHG" key. (Check that F15 key lights up.)

Skip the cursor at the left upper part of the screen and move it to the place to be corrected, using the CURSOR key.

1. "CHG" screen edit switching (F15 key lights up)
2. "INS" insertion: the line is spaced out by a push on this key when the cursor is located in Line No.
3. "DEL" deletion: the line is deleted by a push on this key when the cursor is located in Line No.
4. "R1" Correction/cancellation: the current data is corrected and canceled on the screen.

The cursor is moved to the upper left part of the screen.

5. "R2" Page shift backward , "R3" Page shift forward
- (5) After correction, press the "CHG" key once again. (Check that F15 key goes off.)

The cursor returns to the lower left part of the screen. (The left lower screen indicates Line No.) : so input data successively.

- (6) To space out a line, input space **<NL>**.
- (7) After keying in the last line, this operation ends by a push on **<NL>** only. "EDIT =" is displayed at the left lower part of the screen.
- (8) Further, when it is desired to input the next program, press **<NL>** once again:
"PROGRAM =" is displayed at the left lower part of the screen. Operate this with IN **<NL>** .
- (9) Press **<NL>** several times : the display returns to the initial screen.

B.1.4 Correcting Macro Program (Screen edit)

(Return to) Initial Screen **<F0>** - **<F2>** OFF and press "R2"

NO=1 **<NL>**

PROGRAM= O program No. **<NL>** (Number to be corrected)

EDIT=

(1) Screen Edit

- Press the "CHG" key. (Check that F15 key lights up)

Skip the cursor at the upper left part of the screen, and move it to the place to be corrected, using the CURSOR key. After completion of correction, return the "CHG" key to the lower left part of the screen again.

"CHG": Screen edit switching (F15 key ON)

"INS": Insertion: the line is spaced out by a push on this key when the cursor is located in Line No.

"DEL": Deletion: the line is deleted by a push on this key when the cursor is located in Line No. (Do this most carefully.)

"R1": Correction/cancellation: the current data is corrected and canceled on that screen.

The cursor is moved to the upper left part of the screen.

"R2": Page shift backward

"R3": Page shift forward

- 71 files can be registered by INT and 175 files can be registered by I2 for the first time. Consequently, 695 files can be registered for I7. (incremented by 104)
- In the file with same name, no substituting processing is carried out, so that no output is possible.
- The file name consists of up to 17 character, "," comma cannot be used.
- A longer file name is preferable for easier identification.
- At input, File No. can be used for access.

B.1.7 Inputting Files to P-G from Floppy Disk

(Return to) Initial Screen only <F2> ON and press "R2"

NO = 1 <NL>

PROGRAM = IN <NL>

FD0 = OK $\left\{ \begin{array}{l} 0 \\ 1 \end{array} \right\} \left\{ \begin{array}{l} @ \text{ File name} \\ : \text{ File No.} \end{array} \right\} <NL>$

Upon completion, turn <F2> OFF.

B.1.8 Handling Floppy Disk

(1) File name directory

(Return to) Initial Screen and turn <F5> ON as needed and press R3.

REQUEST = FD LIST $\left\{ \begin{array}{l} 0 \\ 1 \end{array} \right\} <NL>$

1 sector = 256 characters

Converted to No. of characters if the size is multiplied by 256.

Upon completion, turn <F5> OFF as needed. " _ " is omissible

(2) File delete

(Return to) Initial Screen and press "R3"

REQUEST = SCRATCH $\left\{ \begin{array}{l} 1 \\ 0 \end{array} \right\} \left\{ \begin{array}{l} @ \text{ File name} \\ : \text{ File No.} \end{array} \right\} <NL>$

FD0 = OK <NL> In error FD0 = NO <NL>

(3) File delete area open

(Return to) Initial Screen and press "R3"

REQUEST = CONDENCE $\left\{ \begin{array}{l} 0 \\ 1 \end{array} \right\} <NL>$

(4) File delete area open

(Return to) Initial Screen and press "R3."

REQUEST = RENAME $\left\{ \begin{array}{l} 0 \\ 1 \end{array} \right\} \left\{ \begin{array}{l} @ \text{ File name} \\ : \text{ File No.} \end{array} \right\} , \left\{ \begin{array}{l} NP \\ P \end{array} \right\} . / \text{Date} . @ \text{ New File name} <NL>$

(5) File attribute change

(Return to) Initial Screen and press "R3"

REQUEST = REMOVE <NL>

FD0 = OK \square $\left\{ \begin{array}{c} M \\ A \end{array} \right\}$, Input driveNo. $\left\{ \begin{array}{c} 0 \\ 1 \end{array} \right\}$ $\left\{ \begin{array}{l} @ \text{ File name} \\ : \text{ File No.} \end{array} \right\}$ <NL>


"A : automatically"

"M : Ask for each time"

FD1 = OK \square $\left\{ \begin{array}{c} I7 \\ INT \end{array} \right\}$,output drive No. $\left\{ \begin{array}{c} 1 \\ 0 \end{array} \right\}$ <NL> (For the first time)

FD1 = OK \square Output drive No. $\left\{ \begin{array}{c} 1 \\ 0 \end{array} \right\}$ <NL>

C DATA ON MACRO COMPILER



C.1 ARGUMENT TRANSFER

It is possible to specify parameters for macro calls that can be referred to as local variables by the P-CODE program. In the parameter specification method for the custom macro of the custom macro B type, the parameter specification I and parameter specification II can be specified separately or mixed in one label.

Signs, decimal points, and other symbols not related to the address can be used in the parameters.

Table C.1 (a) Argument specification I for P-CODE program call

Address of argument specification I	Local variable No.
A	#1
B	#2
C	#3
I	#4
J	#5
K	#6
D	#7
E	#8
F	#9
G (Note)	#10
H	#11
L (Note)	#12
M	#13
N (Note)	#14
P (Note)	#16
Q	#17
R	#18
S	#19
T	#20
U	#21
V	#22
W	#23
X	#24
Y	#25
Z	#26

NOTE

It is available when compilation parameter bit 5 of No.9008 is 1.

Table C.1 (b) Argument specification II for P-CODE program call

Address of argument specification II	Local variable No.
A	# 1
B	# 2
C	# 3
I1	# 4
J1	# 5
K1	# 6
⋮	⋮
⋮	⋮
I10	# 31
J10	# 32
K10	# 33

C.2
SUMMARY OF
SYSTEM VARIABLES
(Refer to Operator's
Manual for details)

(1) Series 16-MB/16-MA/18-MB/18-MA/20-FA/21-MB

Tool compensation

#2001	Tool compensation value	1
#2002	" "	2
}	}	
#2200	" "	200

Work offset

#2500	X. External work OFFSET	
#2501	G54 " "	
}	}	
#2506	G59 " "	
#2600	Y. External work OFFSET	
#2601	G54 " "	
}	}	
#2606	G59 " "	
#2700	Z. External work OFFSET	
#2701	G54 " "	
}	}	
#2706	G59 " "	
#2800	4. External work OFFSET	
#2801	G54 " "	
}	}	
#2806	G59 " "	

G code

#4001	G00, 01, 02, 03, 33
#4002	G17, 18, 19
#4003	G90, 91
#4004	*
#4005	G94, 95
#4006	G20, 21
#4007	G40, 41, 42
#4008	G43, 44, 49
#4009	G73, 74, 76, 80-89
#4010	G98, 99
#4011	G50, 51
#4012	G65, 66, 67
#4013	*
#4014	G54-59
#4015	G61-64
#4016	G68, 69
#4017	*
}	}
#4022	*

* :Reserved

Code

#4102	B code
#4109	F code
#4111	H code
#4113	M code
#4114	Sequence Number
#4115	Program Number
#4119	S code
#4120	T code

Position data

#5001	X. Block end position
#5002	Y. "
#5003	Z. "
#5004	4. "
#5021	X. Machine coordinates
#5022	Y. "
#5023	Z. "
#5024	4. "
#5025	5. "
#5026	6. "
#5041	X. Work coordinates
#5042	Y. "
#5043	Z. "
#5044	4. "
#5045	5. "
#5046	6. "
#5061	X. Skip signal position
#5062	Y. "
#5063	Z. "
#5064	4. "
#5081	X. Tool compensation value
#5082	Y. "
#5083	Z. "
#5101	X. Servo variation value
#5102	Y. "
#5103	Z. "
#5104	4. "

Control variables

#3000	Macro ALARM n<99
#3001	Clock (msec)
#3002	Clock (Hour)
#3003	Single block
#3004	Feed hold
#3005	Setting
#3011	Clock (mm dd yy)
#3012	Clock (hour minute second)
#3901	Number of processed parts
#3902	Number of required parts

#3003

n	SBK	FIN
0	○	w
1	×	w
2	○	×
3	×	×

○ : No control

× : Control

W : Waiting for auxiliary function end signal

#3004

n	FH	OR	ES
0	○	○	○
1	×	○	○
2	○	×	○
3	×	×	○
4	○	○	×
5	×	○	×
6	○	×	×
7	×	×	×

FH : Feed hold

OR : Overwrite

ES : Exact stop check

Parameter instructions

		#0
A	A	#1
B	B	#2
C	C	#3
I	I1	#4
J	J1	#5
K	K1	#6
D	I2	#7
E	J2	#8
F	K2	#9
	I3	#10
H	J3	#11
	K3	#12
M	I4	#13
	J4	#14
	K4	#15
	I5	#16
Q	J5	#17
R	K5	#18
S	I6	#19
T	J6	#20
U	K6	#21
V	I7	#22
W	J7	#23
X	K7	#24
Y	I8	#25
Z	J8	#26
	K8	#27
	I9	#28
	}	}
	K10	#33

Common variables

#100
#101
}
#149

Common variables (Maintenance type)

#500
#501
}
#999

Data input

#1000
#1001
}
#1015
#1032

Data output

#1100
#1101
}
#1115
#1132
#1133

(2) Series 16-TB/16-TA/18-TB/18-TA/20-TA/21-TB

Tool compensation quantity

#2001/2701 } } #2032/2732	X. Offset } "	1 32
#2101/2801 } } #2132/2832	Z. Offset } "	1 32
#2201/2901 } } #2232/2932	Tool nose compensation value " } "	
#2301 } #2332	Hypothetical cutter tip T postion " } "	
#2401 } #2432	Y. Tool position OFFSET " } "	32

* left : Wear compensation
right : Geometry compensation

Work coordinates shift quantity

#2501	X. Work coordinate
#2601	Y. Work coordinate

G code (G code system A)

#4001	G00-03,32,34,90
#4002	G96,97
#4003	*
#4004	G68,69
#4005	G98,99
#4006	G20,21
#4007	G40,41,42
#4008	G25,26
#4009	G22,23
#4010	G80A89
#4011	*
#4012	G66,67
#4013	*
#4014	*
}	}
#4021	*

* : Reserved

Code

#4109	F code
#4113	M code
#4114	Sequence number
#4115	Program number
#4119	S code
#4120	T code

Position data

#5001	X. Block end position
#5002	Z. "
#5003	3. "
#5004	4. "
#5021	X. Machine coordinates
#5022	Z. "
#5023	3. "
#5024	4. "
#5025	5. "
#5026	6. "
#5041	X. Work coordinates
#5042	Z. "
#5043	3. "
#5044	4. "
#5045	5. "
#5046	6. "
#5061	X. Skip signal position
#5062	Z. "
#5063	3. "
#5064	4. "
#5081	X. Tool compensation value
#5082	Z. "
#5101	X. Servo variation value
#5102	Z. "
#5103	3. "
#5104	4. "

Control variables

#3000	Macro ALARM n<99
#3001	Clock (msec)
#3002	Clock (hour)
#3003	Single block
#3004	Feed hold
#3005	Setting
#3011	Clock (mm dd yy)
#3012	Clock (hour minute second)
#3901	Number of processed parts
#3902	Number of required parts

#3003

n	SBK	FIN
0	○	w
1	×	w
2	○	×
3	×	×

○ : No control
× : Control
W : Waiting for help
function end signal

#3004

n	FH	OR	ES
0	○	○	○
1	×	○	○
2	○	×	○
3	×	×	○
4	○	○	×
5	×	○	×
6	○	×	×
7	×	×	×

FH : Feed hold
OR : Overwrite
ES : Exact stop check

Parameter instructions

		#0
A	A	#1
B	B	#2
C	C	#3
I	I1	#4
J	J1	#5
K	K1	#6
D	I2	#7
E	J2	#8
F	K2	#9
	I3	#10
H	J3	#11
	K3	#12
M	I4	#13
	J4	#14
	K4	#15
	I5	#16
Q	J5	#17
R	K5	#18
S	I6	#19
T	J6	#20
U	K6	#21
V	I7	#22
W	J7	#23
X	K7	#24
Y	I8	#25
Z	J8	#26
	K8	#27
	I9	#28
	}	}
	K 10	#33

Common variables

#100
#101
}
#149

Common variables
(Maintenance type)

#500
#501
}
#999

Data input

#1000
#1001
}
#1015
#1032

Data output

#1100
#1101
}
#1115
#1132
#1133

D

MACRO COMPILER/MACRO EXECUTOR WITH CAP I (Series 16/18)



D.1 OUTLINE

When an option conversational automatic programming function I (CAP I) is selected, the macro program must be loaded in the same ROM module as that in which a custom macro prepared by MTB is loaded.

The display screen and operating processes related to conversational automatic programming cannot be changed by the user's program prepared by the machine tool builder.

In order to store the user's program prepared by the machine tool builder and the CAP I in the same ROM module, the same procedure as making a ROM module shall be performed by compiling the standard format macro-executor program and user's program. However, the dedicated macro executor floppy disk must be used. Specific details are described hereinafter.

NOTE

Optional conversational automatic programming function I is not available with Series 20/21.

D.2 EQUIPMENT NEEDED FOR COMPILING

In order to produce the ROM for the ROM module in which both the user's program (custom macro) and the CAP I are to be stored, either the P-G Mark II or the P-G Mate are required.

In addition, a dedicated macro compiler system floppy disk is also needed. As the specific system floppy disk to be used depends on the language appearing in the conversational programming displays and corresponding CRT, select the appropriate floppy disk from the table below.

Table 2 (a) Specifications of FAPT MACRO COMPILER (MACRO EXECUTOR) with CAP I (For Lathe)

NC model	P-G model	Name of function	Number of floppy disk File name
FS16-TA	P-G Mark-II P-G Mate	FAPT MACRO COMPILER (MACRO EXECUTOR) 9" High resolution monochrome /color CRT English, Japanese, German, French, Italian, Spanish	A08B-0036-J764#BH01 16-TA, BH01, EXC1/** 16-TA, BH01, EXC2/** 16-TA, CAP, PROG/**
		FAPT MACRO COMPILER (MACRO EXECUTOR) 9" High resolution monochrome /color CRT English, Japanese, Chinese, Korean	A08B-0036-J764#BB02 16-TA, BB02, EXC1/** 16-TA, BB02, EXC2/** 16-TA, CAP, PROG/**
FS18-TA	P-G Mark-II P-G Mate	FAPT MACRO COMPILER (MACRO EXECUTOR) 9" High resolution monochrome /color CRT English, Japanese, German, French, Italian, Spanish	A08B-0036-J744#BH51 18-TA, BH51, EXC1/** 18-TA, BH51, EXC2/** 18-TA, CAP, PROG/**

NOTE

The /** at the end of the file name in the table indicates the version number of that system's software.

As differences exist depending on the version number, at the time of actual use, check the file name in the floppy disc and input the appended number.

The 1st file stores files 16-TA.BB**.EXC1 and 16 TA. CAP PROG and 2nd file stores files 16-TA.BB**.EXC2.

Table 2 (b) Specifications of FAPT MACRO COMPILER (MACRO EXECUTOR) with CAP I (For machining center)

NC model	P-G model	Name of function	Number of floppy disk File name
FS16-MA	P-G Mark-II P-G Mate	FAPT MACRO COMPILER (MACRO EXECUTOR) 9" High resolution monochrome /color CRT English, Japanese, German, French, Italian, Spanish, Chinese, Korea	A08B-0036-J765#BA21 16MA, BA21, EXC1/** 16MA, BA21, EXC2/** 16MA, CAP, PROG/**
FS18-MA	P-G Mark-II P-G Mate	FAPT MACRO COMPILER (MACRO EXECUTOR) 9" High resolution monochrome /color CRT English, Japanese, German, French, Italian, Spanish, Chinese, Korea	A08B-0036-J745#BJ51 18MA, BA51, EXC1/** 18MA, BA51, EXC2/** 18MA, CAP, PROG/**

NOTE

The symbol /** appearing at the end of the file name in the table indicates the version number of the system software. As differences exist depending on the version, when putting these to actual use, check the file name in the floppy disk, then input the attached number.

The 1st file stores files 16-MA.BA**.EXC1 and 16MA.CAP PROG and 2nd file stores files 16MA.BA**.EXC2.

In addition to the above, the following development devices or software are required.

(1) Macro compiler system floppy disk

P-G Mark-II : A08B-035-J760

P-G Mate : A08B-036-J760

(2) FA writer : A13B-0157-B001


(3) Adapter : A13B-0157-H010

(4) ROM module (having a memory capacity of 1M byte)
: A02B-0120-K513

D.3 COMPILING PROCEDURE USING SYSTEM P-G


(1) Outline

CAP I consists of a system section and a dedicated custom macro section. The user's program is compiled with this dedicated custom macro section, then stored in the ROM module.



(2) Connection of devices

Connect the FA writer to CN2 or CN3 of P-G. In general, connect CN1 to PPR.



(3) P-G Power Supply ON

Switch the P-G power supply ON.

(4) System loading

1. Insert the FAPT MACRO COMPILER system floppy disk into the disc drive (either one can be used).
2. Depress the [LOAD] button on the upper left of the keyboard for several seconds.
3. Loading is ended when the menu is displayed.

(5) Input of macro executor 1 having CAP

1. Press the R3 key in the initial screen.
2. Key in 'MEXEC IN <NL>' from 'REQUEST='.
3. After the message "Set FD (DATA) and key in 'OK' or 'NO'" is displayed, insert the floppy disc containing macro compiler having CAP into disk drive 0, then key in 'OK @***.***.EXC1/**<NL>'.

However, as 'OK @***.***.EXC1/**<NL>' is different depending on the macro executor used, refer to the Specifications of FAPT MACRO COMPILER (MACRO EXECUTOR) with CAP in Section 2, then input the file name of the macro executor to be used.

Example)

The file name when using the FS-16MA 9" monochrome high resolution CRT is "16MA.BA21.EXC1/02".

Completion of the above-described procedure ends input of macro executor 1 having CAP.

The display returns to the initial screen when <NL> is pressed once.

(6) Input of CAP custom macro program and user's program.

1. Press the R2 key in the initial screen.
2. With the F2 key in ON status, key in '3<NL>' from 'NO.= '.
3. After the message "Set FD (DATA) and key in 'OK' or 'NO'" is displayed, insert the floppy disc containing macro executor having CAP into disk drive 0, then key in 'OK @***.CAP.PROG / ** <NL>'.

However, as ***.CAP.PROG / ** is different depending on the macro executor used, refer to the Table of Specifications of FAPT MACRO COMPILER (MACRO EXECUTOR) with CAP in Section 2, then input the file name of the macro executor to be used.

Example)

The file name when using the FS-16MA 9" monochrome high resolution CRT is "16MA.CAP.PROG/02".

4. In the case when the program is not completely input to internal memory, external extension is performed. When a message instructing that the floppy disk be set is displayed, insert a blank data floppy disk into disk drive 1, then key in 'OK<NL>'. This allows input to continue. Do not remove the floppy disk from disk drive 1 during program editing or compiling.
5. When all the dedicated custom macro program input has ended, 'NO.= ' is displayed. Therefore, if '3<NL>' is keyed in, the same message as in step 3 will be displayed. After inserting the floppy disk containing the user's program into disk drive 0, key in 'OK@ file name <NL>'. Specify the file name stored in the user's program.
6. When all the custom macro program input has ended, 'NO.= ' is displayed. Pressing <NL> twice will return the display to the initial screen.

(7) Setting compiling parameters

1. Press the R1 key in the initial screen.
2. Key in '1<NL>' from 'NO.= '.
3. If the <CHG> key is pressed, screen editor will begin, hence the necessary parameters must be set.
4. Setting parameters for FS-16TA.

8000 00000000

bit 0 = 1: The program of the block containing M99 ends
 = 0: The program of the block containing M99 does not end (Be sure to set 0)

- bit 1 = 1: The program of the block containing M02 ends
= 0: The program of the block containing M99 does not end (Be sure to set 0)
- bit 2 = 1: The program of the block containing M30 ends
= 0: The program of the block containing M30 does not end (Be sure to set 0)
- bit 7 = 1: The ROM module is used. (For the FS16)
= 0: The ROM cassette is used.
(Always specify 1.)
- 8010 0000001
- bit 0 = 1: Corresponds to macro executor having CAP
= 0: Corresponds to the standard macro executor
(Be sure to set 1)
- 8011 16-TA, ****. EXC2/**
- Specifies the file name of macro executor 2.
However, as '16-TA.****.EXC2/** <NL>' is different depending on the macro executor used, refer to the Table of Specifications of FAPT MACRO COMPILER (MACRO EXECUTOR) with CAP in Section 2, then input the file name of the macro executor to be used.
- Example)
The file name when using the FS16-TA 9" monochrome high resolution CRT, English, Japanese, German, French, Italian, Spanish version is "16-TA.BB01.EXC2/07".
- 9000 10010000
- bit 4 = 1: Allows use of a macro cassette of 1M byte capacity
= 0: Allows use of a macro cassette of other than 1M byte capacity (Be sure to set 1)
- bit 7 = 1: Compiles a macro program with custom macro B format
= 0: Compiles a macro program with custom macro A format (Be sure to set 1)
- 9001 10000001
- bit 0 = 1: Outputs sequence number in the P-CODE program at ROM writing
= 0: Does not output sequence number in the P-CODE program at ROM writing (Be sure to set 1)
- bit 7 = 1: Can refer to variables at the #10000 level by RAM program
= 0: Cannot refer to variables at the #10000 level by RAM program (Be sure to set 1)
- 9002 11000000
- bit 7 = 1: Macro executor expansion function valid
= 0: Macro executor expansion function not valid
(Be sure to set 1)
- bit 6 = 1: Automatic work number search valid
= 0: Automatic work number search not valid
(Be sure to set 1)
- bit 3 = 1: Expanded conversational macro exclusive variables at the #20000 level have non-floating decimal point format

- = 0: Expanded conversational macro exclusive variables at the #20000 level have floating decimal point format (Be sure to set 0)
- 9003 10000000
bit 7 = 1: Special function for CAP valid
= 0: Special function for CAP not valid (Be sure to set 1)
bit 3 = 1: 14" color CRT
= 0: 9" monochrome/color CRT
- 9007 0100000
bit 6 = 1: FS16-TA CAP I is valid
= 0: FS16-TA CAP I is invalid
- 9033 97
Dedicated data for CAP
- 9037 7
Dedicated data for CAP
- 9044 2044
Dedicated data for CAP Set this value unconditionally for either case of part program memory of 120 m or 320 m.
5. Setting parameters for FS16-MA
- 8000 10000000
bit 0 = 1: The program of the block containing M99 ends
= 0: The program of the block containing M99 does not end (Be sure to set 0)
bit 1 = 1: The program of the block containing M02 ends
= 0: The program of the block containing M02 does not end (Be sure to set 0)
bit 2 = 1: The program of the block containing M30 ends
= 0: The program of the block containing M30 does not end (Be sure to set 0)
- 8010 00000001
bit 0 = 1: Corresponds to macro executor having CAP
= 0: Corresponds to the standard macro executor (Be sure to set 1)
- 8011 16MA, ***, EXC2/**
Specifies the file name of macro executor 2.
However, as '16MA.***.EXC2/**' is different depending on the macro executor used, refer to the Table of Specifications of FAPT MACRO COMPILER (MACRO EXECUTOR) with CAP in Section 2, then input the file name of the macro executor to be used.
Example)
The file name when using the FS16-MA monochrome high resolution CRT is "16MA.BA21.EXC2/02".
- 9000 10010000
bit 4 = 1: Allows use of a macro cassette of 1M Kbyte capacity
= 0: Allows use of a macro cassette of other than 1M Kbyte capacity (Be sure to set 1)

	bit 7 = 1: Compiles a macro program with custom macro B format
	= 0: Compiles a macro program with custom macro A format (Be sure to set 1)
9001	10000001
	bit 0 = 1: Outputs sequence number in the P-CODE program at ROM writing
	= 0: Does not output sequence number in the P-CODE program at ROM writing (Be sure to set 1)
	bit 7 = 1: Can refer to variables at the #10000 level by RAM program
	= 0: Cannot refer to variables at the #10000 level by RAM program (Be sure to set 1)
9002	10000000
	bit 7 = 1: Macro executor expansion function valid
	= 0: Macro executor expansion function not valid (Be sure to set 1)
	bit 6 = 1: Automatic work number search valid
	= 0: Automatic work number search not valid
	bit 3 = 1: Expanded P-CODE exclusive variables at the #20000 level havenon-floating decimal point format
	= 0: Expanded P-CODE exclusive variables at the #20000 level have floating decimal point format
9003	10000000
	bit 7 = 1: Special function for CAP valid
	= 0: Special function for CAP not valid (Be sure to set 1)
	bit 3 = 1: Corresponds to 14" color CRT
	= 0: Corresponds to 9" monochrome high resolution CRT
9007	1000000
	bit 7 = 1: FS16-MA CAP I is valid
	= 0: FS16-MA CAP I is invalid (Always set to 1)
9013	0
9014	0
9015	0
9013 - 9022	0
	Be sure to set 0
9033	97
	Dedicated data for CAP
9037	10
	Dedicated data for CAP
9044	?
	Determine the setting values with reference to the Note) given below.
9045	100
	Dedicated data for CAP

9046 900
Dedicated data for CAP
9047 8100
Dedicated data for CAP

NOTE

Concerning expanded P-CODE exclusive variables (#2000 -)

If the length of the part program memory is Min. 160m, an arbitrary number of exclusive variables starting from #20000 can be used. Bit 3 of parameter number 9002 allows selection of either floating decimal point format or non-floating decimal point format like regular common variables of these variables.

Parameter No. 9002

bit 3 = 0: Floating decimal point format

 = 1: Non-floating decimal point format

The nth value of the number set by parameter number 9044 is the number of expanded P-CODE exclusive variables that can be used.

When the setting value of parameter number 9044 is 0, the expanded P-CODE exclusive variables cannot be used.

When using the floating decimal point format, n=12, and when using the integer format,

n=30.

Example)

Floating decimal point format

#20000 to #20011 can be used when parameter No. 9044=1

#20000 to #20023 can be used when parameter No. 9044=2

Integer format

#20000 to #20029 can be used when parameter No. 9044=1

#20000 to #20059 can be used when parameter No. 9044=2

When using the non-floating decimal point format, values in the range -32768 to 32767 can be set. In the case that assignment is performed at the left side of the assigned statement, settings are made by rounding off to the nearest whole number. In the case that the variable appears in an expression, evaluation is performed after conversion to a floating decimal point format.

Approximately 0.21m of part program memory is used per set of expanded conversational macro exclusive variables (those of parameter no. 9044). Be careful of decrease in the capacity of available tape memory when using a large number of expanded conversational macro exclusive variables. The available part program memory capacity during use in accordance with the number of specified variables is displayed on the program library screen.

The maximum number of variables that can be set to parameter No. 9044 varies, as shown below, in accordance with the part program memory capacity.

Example)

Part program memory 160 m: Parameter No. 9044 = 819

Part program memory 320 m: Parameter No. 9044 = 1638

6. When setting of all necessary parameters is completed, press the R0 key, then press the <NL> key twice to return to the initial screen.
- (8) Test Compiling
1. Press the R0 key in the initial screen.
 2. To display the source program during compiling, put the F3 key into ON status, and to display only the program number, put the F3 key into OFF status.
 3. Key in '1<NL>' from 'NO.= '.
 4. As the dedicated custom macro program for CAP and the user's program are compiled simultaneously, check for the absence of errors.
- (9) Setting the FA writer channel
1. Press the R1 key in the initial screen.
 2. By keying in '2<NL>' from 'NO.= ', the current FA writer channel setting status is displayed.
 3. Concerning CN=1
 - 'ON<NL>' :Uses the channel
 - 'OFF<NL>' :Does not use the channel
 - '<NL>' :Setting is unchanged
 4. The same as above applies to CN=2
 5. The same as above applies to CN=3
 6. By only pressing '<NL>' in response to 'NO=', the display returns to the initial screen.
- (10)Preparation of the FA writer
1. Install a ROM module with the previous contents erased in the FA writer
 2. Switch ON the power supply of the FA writer
 3. Set FA writer to the Remote mode.
- (11)ROM writing
1. Press the R0 key in the initial screen.
 2. Put the F7 into OFF and the F9 key into ON status. (FA writer selection)
 3. When you want to display the source program during compiling, put the F3 key into ON status, and when you want to display only the program number, put the F3 key into OFF status.
 4. Key in '2<NL>' from 'NO='.
 5. If the floppy disk containing macro executor 2 is already inserted in floppy disk drive 0, the data will be read automatically from the second floppy disk and simultaneously written into the ROM module. If the floppy disk has not been inserted in the disk drive,

D.4 ROM MODULE

The capacity of the memory area provided for the user's program in combination with the system section of macro executor in the ROM module is 192 Kbyte.

D.5 ADDITION OF OPTIONS

When the CAP and macro executor function exist in combination as described, procure the options listed below.

- (1) FS16-TA CAPI
→ Macro executor provided with CAP I (A02B-0120-J560)
- (2) FS16-MA CAP I
→ Macro executor provided with CAP (A02B-0121-J560)

D.6 LIMITATION ON THE USER'S PROGRAM

Take note that the following limitations exist on the user's program prepared by the machine tool manufacturer (custom macro format).


- (1) FS16-TA CAP I
 1. Program numbers of 8999 and below cannot be used in the macro program.
 2. The only alarm numbers that can be set by the macro program are P/S515 - 519.
 3. The only expanded conversational macro variables that can be used are in the range of #10050 - #10399
- (2) FS16-MA CAP I
 1. Program numbers in the range of 8100 - 8255 as well as 9900 and above cannot be used in the macro program.
 2. The only alarm numbers that can be set by the macro program are P/S3000 - 3049.
 3. The only expanded conversational macro variables that can be used are #20000 and above.
 4. Only G256 to G999 can be used for G-code macro calling, in which a user program calls a P-CODE program. G256 to G999 call programs O8256 to O8999 respectively.
 5. When custom macro B is added, G01 to G99 except G65 to G67 (parameters 6050 to 6059) can be used for G-code macro calling.

NOTE

- 1 Conversational programming-related screens cannot be changed by the user's program.
- 2 Some functions which can be used with the standard macro executor cannot be used with macro executor provided with CAP.

E

**FANUC Super CAP T/CAP II T MACRO COMPILER/EXECUTOR
(Series 16/18)**



E.1 GENERAL

FANUC Super Cap T versions 1, 2, and 3 enable machine tool builders to create their own systems. This is done by combining a user program, created by the machine tool builder, and the system program, provided by FANUC, in a single file and storing that file into a custom-built ROM module (versions 1 and 2) or flash ROM (version 3). In other words, some of screens and operations associated with Super CAP T versions 1, 2, and 3 can be created and modified in the user program developed by the machine tool builder.

The user program provided by the machine tool builder and the FANUC system program are both stored into a single ROM module or flash ROM in almost the same way as the standard macro executor system, user program being compiled and stored into a ROM module or flash ROM. Differences between the two methods include the former requiring a special macro executor floppy disk. In comparison with the standard macro executor system, Super CAP T has unique functions and limitations. These are detailed in the subsequent sections.

NOTE

- 1 Whether a function can be used varies from version to version. For details, see the relevant section of this manual.
- 2 The Series 20/21 does not support a macro compiler/executor with Super CAP T.

E.2 EQUIPMENT REQUIRED FOR DEVELOPMENT

To develop a user program for use with the macro executor, the equipment listed below needs to be prepared beforehand.

- (1) Personal computer (supported by a FAPT macro compiler (for personal computer use))
 - Main memory: 640K bytes or more
 - OS: MS-DOS (Version 3.1 and later)
 - Hard disk with a capacity of about 20M bytes or more (Note 1)
 - 5-inch floppy disk drive (Note 2)
 - Serial interface
 - General-purpose screen editor
 - GP-IB interface (Note 3)

NOTE

- 1 The macro compiler utility software and macro executor, when used, need to be stored on hard disk. A macro program to be developed, compile-time list file/object file, link-time ROM-format file, and so forth are output as files onto hard disk.
- 2 The macro compiler utility software and FANUC Super CAP macro executor system are provided on 5-inch (2HD) floppy disks. A 5-inch floppy disk drive is needed to incorporate the system and executor system.
- 3 With the FANUC FA-Writer, high-speed ROM write/check operation can be performed via the GP-IB interface.

- (2) Peripheral equipment
 - FANUC FA Writer (with control software version C or later) (Note 4)
 - Memory Card adapter (Note 5)
 - Memory Card (greater than 2M bytes) (Note 5)

NOTE

- 1 Required for versions 1 and 2 (FANUC Series 16-T/16-TTA/18-T/18-TTA)
- 2 Required for version 3 (FANUC Series 16-TB)

- (3) FAPT macro compiler (for personal computer use)
(A08B-9001-J500#EN03)

NOTE

Version 3.1 or later is required for version 3 (FANUC Series 16-TB).

(4) FANUC Super CAP macro executor (Table 1)

Table 1

	NC model	Name of floppy disk, File name
Ver. 1	FS16-TA	A08B-9001-J621 BH0C_**.EX1, BH0C_**.EX2, BH0C_**.EX3, BH0C_**.SRC
	FS16-TTA	A08B-9001-J622 BH13_**.EX1, BH13_**.EX2, BH13_**.EX3, BH13_**.SRC BH23_**.EX1, BH23_**.EX2, BH23_**.EX3, BH23_**.SRC
	FS18-TA	A08B-9001-J623 BH5C_**.EX1, BH5C_**.EX2, BH5C_**.EX3, BH5C_**.SRC
Ver. 2	FS16-TA	A08B-9001-J626 BH0D_**.EX1, BH0D_**.EX2, BH0D_**.EX3, BH0D_**.SRC, CAPS_**.SRC
	FS16-TTA	A08B-9001-J627 BH14_**.EX1, BH14_**.EX2, BH14_**.EX3, BH14_**.SRC BH24_**.EX1, BH24_**.EX2, BH24_**.EX3, BH24_**.SRC, CAPS_**.SRC
	FS18-TA	A08B-9001-J628 BH5D_**.EX1, BH5D_**.EX2, BH5D_**.EX3, BH5D_**.SRC, CAPS_**.SRC
	FS18-TTA	A08B-9001-J629 BH64_**.EX1, BH64_**.EX2, BH64_**.EX3, BH64_**.SRC BH74_**.EX1, BH74_**.EX2, BH74_**.EX3, BH74_**.SRC, CAPS_**.SRC
Ver. 3	FS16-TB	A08B-9001-J680 BH0F_**.EX1, BH0F_**.EX2, BH0F_**.EX3, BH0F_**.SRC, CAPS_**.SRC
	FS16-TB (Two paths)	A08B-9001-J681 BH16_**.EX1, BH16_**.EX2, BH16_**.EX3, BH16_**.SRC BH26_**.EX1, BH26_**.EX2, BH26_**.EX3, BH26_**.SRC, CAPS_**.SRC
Ver. 4	16/18-TC	A08B-9001-J684 BH0G_**.EX1, BH0G_**.EX2, BH0G_**.EX3, BH0G_**.SRC
	16/18-TC (Two paths)	A08B-9001-J685 BH17_**.EX1, BH17_**.EX2, BH17_**.EX3, BH17_**.SRC, BH27_**.EX1, BH27_**.EX2, BH27_**.EX3, BH27_**.SRC
Super CAP II T	16/18-TC	A08B-9001-J730 BH0H_**.EX1, BH0H_**.EX2, BH0H_**.EX3, BH0H_**.SRC
	16/18-TC (Two paths)	A08B-9001-J731 BH18_**.EX1, BH18_**.EX2, BH18_**.EX3, BH18_**.SRC, BH28_**.EX1, BH28_**.EX2, BH28_**.EX3, BH28_**.SRC

NOTE

A pair of asterisks (**) appearing at the end of a file name in the table above indicates the version number of that system's software.

(5) Operator's manual of the FAPT macro compiler for personal computer use (B-66102E)

(6) Debug NC unit

E.3

TYPE OF USER PROGRAMS

With the macro compiler/executor, machine tool builders can generate the types of user programs listed below.

- (1) Programs for auxiliary process/transfer process display on the conversational programming menu

For detailed information, see each relevant section that follows.

- (2) Programs for auxiliary process/transfer process operation

The program format is the same as for an ordinary macro program. For detailed information, see each relevant section that follows.

- (3) Programs equivalent to user programs for use with the 0 Series macro compiler/executor

E.4 DETAILS OF NEW USER PROGRAMS

(1) Programs for auxiliary process/transfer process display on the conversational programming menu

Auxiliary process screen:

PREP A NEW PROCESS PROGRAM

NO. =1234 NAME=DEMONSTRATION

INITIAL	SET MATERIAL	SHAPE	OUT-DIA	IN-DIA	WORK-LNG	MAX-S	COOLANT
	FC25	BAR	100.000		154.000	2000	ON
	FINISH X	FINISH Z	E-REMOVL	PROD-LNG			
	0.200	0.100	2.000	150.000			
PROC (01)	TYPE	HEAD	*****1	*****2	*****3	*****4	*****5
AUX	#####1						
	*****6	*****7	*****8	*****9	*****10	*****11	*****12

WINDOW

SOFTKEY

TYPE

<	#####1	#####2	#####3	#####4	#####5	MCHN-C	TOOL-D	DETAILED DATA	PLOT	GUIDE
---	--------	--------	--------	--------	--------	--------	--------	------------------	------	-------

For an auxiliary process, programs for directing auxiliary operations such as bar feed, cutting-off, loader operation can be generated in the conversational mode.

Desired types of auxiliary operation can be selected using the soft keys displayed when the cursor is placed in the data item "TYPE"; up to 20 types of operations can be generated. In this case, no more than five soft keys are displayed at a time. So several groups of soft keys are displayed, group by group, for type selection.

For each type, up to 12 data items (*****1 to *****12 in the figure above) can be displayed. For each data item, five soft keys (#####1 to #####5 in the figure above) can be displayed for operation such as menu selection.

For each data item, detailed menu information including a figure and characters can be displayed in the window (shaded part in the figure above).

The conversational system automatically displays data item names and soft key names if the data item names and soft key names are just stored together with their data identification sequence numbers in a program with a particular program number for the macro executor.


Example of transfer process screen:

PREP A NEW PROCESS PROGRAM

NO. =1234 NAME=DEMONSTRATION

INITIAL SET	MATERIAL	SHAPE	OUT-DIA	IN-DIA	WORK-LNG	MAX-S	COOLANT
	FC25	BAR	100.000		154.000	2000	ON
FINISH X	FINIFSH Z	E-REMOVL	PROD-LNG				
0.200	0.100	2.000	150.000				

PROD (01)	AREA	HEAD					
BAR (R)	OUT-END	HEAD-L					
PROD (01)	AREA	HEAD					
BAR (F)	OUT-END	HEAD-L					
START	X=	20.000	Z=	0			
↗	X=	35.000	Z=	20			
←	X=	35.000	Z=	25			
↑	X=	50.000	Z=	25			
←	X=	50.000	Z=	35			
↖	X=	60.000	Z=	50			
PROD (02)	TYPE	HEAD	Z POINT				
TRANS.	SYNCRO	L→R	<input style="width: 50px; height: 15px;" type="text"/>				



SFTKEY
TYPE


<	REED COORD.				MCHN-C	TOOL-D	DETAIL DATA	PLOT	GUIDE	+
---	----------------	--	--	--	--------	--------	----------------	------	-------	---

A transfer process is used with a lathe having facing spindles to transfer a workpiece from spindle 1 to spindle 2 or vice versa.

For a transfer process, a user program can display up to 20 types of operations, up to 12 data items for each type, and five soft keys for each data item as in the case of an auxiliary process.

The example above shows the screen for reading, from the machine coordinates, the Z-axis coordinate for transferring a workpiece from spindle 1 to spindle 2.

Example of transferring a workpiece: Workpiece transferred between spindles



The following user programs for auxiliary process/transfer process display are available:

- (a) Program for displaying a detailed data screen when the [DETAIL DATA] soft key is pressed

NOTE

A detailed data screen displays such data that cannot be displayed on a tabular programming screen as shown in the example above.

- (b) Program for displaying process data

NOTE

This program displays a window in multi-window mode, displays soft keys, and controls the cursor.

- (c) Program for automatically initializing each data item of a process when the process is to be newly developed
- (d) Program executed in moving to another screen

NOTE

This program is called when the current screen is changed to to another screen such as a current position screen forcibly, for example, by pressing a function key.

E.5 USER PROGRAM SIZE

An area of 512K bytes is available for the user program used with the macro executor (including the execution macro program of the system).

NOTE

For the system's execution macro program, 192K bytes are reserved.

E.6 SOFTWARE PACKAGE FOR USER PROGRAM DEVELOPMENT

E.6.1 Software Package Associated with Tool Data and Cutting Condition Data

E.6.1.1 Overview

FANUC Super CAP T versions 1, 2, and 3 can read the tool data, held in a tool data file, into system variables #9900 to #9942. FANUC Super CAP T can also search through the data in the tool data file for a tool ID number.

FANUC Super CAP T versions 2 and 3 can read cutting condition data, held in the cutting condition file, into system variables #9992 to #9996 if ID numbers are already set in system variables #9990 and #9991. (To read the chuck/tailstock data, different variables are used.)

E.6.1.2 Details of the Software Package Associated with Tool Data

The contents of a tool data file can be determined by setting an ID number, such as the tool ID number of a desired tool, in variable #9999 and reading #9900 to #9942. Tools can also be searched for.

(1) Variables

To macro variables #9900 to 9941, the data (described later) corresponding to each variable is read. The data set in each variable depends on the type of tool. This means that the same variable number may represent different data, depending on the type of tool.

#9999 – An ID number is to be set.

(Tool ID number) :

To read the data of a tool directly by tool ID number, the ID number of the tool is to be set.

(Tool type number) :

To determine the tool ID number of a tool by tool type number, the tool type number of the tool is to be set.

- = 100: Outer surface machining
- = 150: Inner surface machining
- = 200: End facing
- = 250: External threading
- = 300: Inner threading
- = 400: Inner bottom end facing
- = 450: Outer surface grooving
- = 500: Inner surface grooving
- = 550: End face grooving
- = 600: Drilling
- = 650: Tapping
- = 700: Center drilling
- = 750: End milling

- = 800: Side cutting
- = 850: Chamfering
- = 900: Reaming
- = 950: Boring

(Control symbol number) :

When a tool ID number is determined using tool data, a control symbol number is to be set in order to specify a range of tool data used.

- = 11: (Tool file data) < (reference data)
- = 12: (Tool file data) \leq (reference data)
- = 13: (Tool file data) = (reference data)
- = 14: (Tool file data) \geq (reference data)
- = 15: (Tool file data) > (reference data)

- 1 : To be set when the data of the tool immediately after the currently selected tool (whose tool ID number is set in #9998) in the tool data list is to be obtained
- 2 : To be set when the data of the tool immediately before the currently selected tool (whose tool ID number is set in #9998) in the tool data list is to be obtained
- 3 : To be set when the data of the first tool in the tool data list is to be obtained
- 1 : To be set upon completion of reference data input when a tool ID number is to be searched for from tool type information and tool data.

#9998 –

The tool ID number of the currently selected tool (selected using this function immediately before) or the error code "99" is set. (This variable allows read operation only.)

#9900 – Tool type

- = 1 : Outer surface machining
- = 2 : Inner surface machining
- = 3 : End facing
- = 4 : External threading
- = 5 : Inner threading

- = 7 : Inner bottom end facing
- = 8 : Outer surface grooving
- = 9 : Inner surface grooving
- = 10 : End face grooving
- = 11 : Drilling
- = 12 : Tapping
- = 13 : Center drilling
- = 14 : End milling
- = 15 : Side cutting
- = 16 : Chamfering
- = 17 : Reaming
- = 18 : Boring

#9901 – Tool direction

- = 1 Outer surface or inner surface machining: Right hand
- = 2 Outer surface or inner surface machining: Left hand
- = 3 End facing: + direction
- = 4 End facing: – direction
- = 5 Outer or inner surface grooving: Left-reference
- = 6 Outer or inner surface grooving: Right-reference
- = 7 End face grooving: Down-reference
- = 8 End face grooving: Up-reference

- = 9 Drilling, tapping, center drilling, end milling, chamfering:
 End face
- = 10 Drilling, tapping, center drilling, end milling, chamfering:
 Side face
- = 11 Outer surface, inner surface, or end face machining:
 Round nose

#9902 – Rough/finish machining (turning tool)
 = 0 : Common = 1 : Rough = 2 : Finish
 Rotation/turning (drilling tool)
 = 0 : Common = 1 : Rotation = 2 : Turning

#9903 – Specified T code

#9904 – Spindle rotation direction
 = 1 : Normal = 2 : Reverse

#9905 – Radius of tool tip, radius of tool

	General-purpose	Threading	Grooving	Drilling	Tapping	Center drilling
#9906	Cutting edge angle	–	Tool length	Tool length	Tool length	Depth of cut
#9907	Tool angle	Tool angle	Cutting edge angle	Point angle	Pitch	Point angle
#9908	Tool width	Tool width	Cutting edge width	Nominal diameter	Nominal diameter	Nominal diameter

	End milling	Side cutting	Chamfering	Reaming	Boring
#9906	Tool length	Tool length	Edge clearance	Tool length	Tool length
#9907	Number of teeth	Number of teeth	Tool angle	–	–
#9908	–	Tool width	Small diameter	Nominal diameter	Tool width

#9909 – Virtual tool tip direction

#9910 – Tool material
 = 1 : Cemented carbide
 = 2 : High-speed tool
 = 3 : Special

#9911 – Tool life

#9912 – Spare tool

#9920 - #9927 – Tool tip figure

#9920:X1, #9921:Z1, #9922:X2, #9923:Z2
 #9924:X3, #9925:Z3, #9926:X4, #9927:Z4

#9930 - #9941 – Tool shank figure

#9930:X1, #9931:Z1, #9932:X2, #9933:Z2, #9934:X3, #9935:Z3
 #9936:X4, #9937:Z4, #9938:X5, #9939:Z5, #9940:X6, #9941:Z6

#9942 – Tool post

= 0 or 1: Tool post 1, = 2: Tool post 2
 (Tool post 1 for FANUC Series 16-TA/18-TA)

NOTE

System variable #9942 can be used with versions 2 and 3 only.

A user program can use P-CODE variables #10000 to #10699 as desired. With the standard macro compiler/executor (having no conversational functions), the value set in compile parameter 9037 determines the number of P-CODE variables from #10000. In a system that supports the conversational function, however, the parameter is always set to 7.

NOTE

The P-CODE variables can be extended to #10000 to #13999 by adding the optional 4000 P-CODE variables.

Extended P-CODE variables from #20000 are used by the system. The user program cannot access these variables.

(2) Examples of command format

(a) When the data of a tool is to be referenced based on its tool ID number

```
#9999 = (tool ID number)      ; - 1.
IF [#9998 EQ 99] GOTO 100    ; - 2.
#????? = #99??               ; - 3.
```

1. Sets the tool ID number of a tool whose data is to be referenced in #9999.
 2. Checks #9998 to see if the tool is registered in the tool file.
 3. Reads the variables corresponding to data to be referenced if the tool currently selected is registered in the file.
- If the specified tool ID number cannot be found, 99 is set in #9998.

(b) When the tool ID number and data of the next or previous tool in the tool data list are to be referenced based on the currently selected tool (whose tool ID number is set in #9998)

```
IF [#9998 EQ 99] GOTO 100    ; - 1.
#????? = #9998              ; - 2.
#9999 = 1 or 2               ; - 3.
#????? = #99??              ; - 4.
```

1. Checks #9998 to see if the currently selected tool is registered.
 2. Checks the tool ID number of the currently selected tool.
 3. Finds the tool ID number of the next or previous tool by setting 1 or 2 in #9999.
 4. Reads the variables corresponding to data to be referenced.
- If the currently selected tool cannot be found (as in the case of power-up), 99 is set in #9998.

(c) When the tool ID number and data of the first tool in the tool data list are to be referenced

```
#9999 = 3                    ; - 1.
IF [#9998 EQ 99] GOTO 100    ; - 2.
#????? = #99??              ; - 3.
```

1. Finds the first tool in the tool data list.
2. Checks if the tool is registered.

3. Reads the variables corresponding to data to be referenced if the tool is registered.

→ If the tool cannot be found, 99 is set in #9998.

(d) When a tool ID number is to be searched for using tool type number information and tool data

#9999 = (tool type number) ; -1.

#9999 = (control symbol number) ; -2.

#99?? = *.*.* ; -3.

#9999 = (control symbol number) ; -4.

#99?? = *.*.* ; -5.

#9999 = - 1 ; -6.

#????? = #9998 ; -7.

1. Sets the tool type number of a tool to be referenced.

2., 4. Writes control symbol numbers specifying an ordinal relationship in #9999.

3., 5. Writes search reference data to the corresponding macro variables.

6. Writes the setting completion code (- 1) to #9999 upon completion of the setting of search reference data.

7. Allows the desired tool ID number to be obtained by reading #9998.

→ If there is no tool that matches specified conditions, 99 is set in #9998.

Control symbol numbers and tool data need to be specified in pairs. Be sure to specify a control symbol number first, then specify tool data. Up to five pairs can be specified. If a control symbol number is missing and the next tool data is read, or tool data is missing and the next control symbol number is read, the error code (99) is set in #9998. When several tools match specified conditions, the tool that has the smallest tool ID number is searched for.

(e) Examples of execution

Assume that the following tools are registered:

101 Outer surface machining 451 Outer surface grooving

102 Outer surface machining 452 Outer surface grooving

103 Outer surface machining 453 Outer surface grooving

104 Outer surface machining 601 Drilling

151 Inner surface machining 651 Tapping

201 End facing 701 Center drilling

251 External threading

(i) When the data of a certain tool is to be referenced

[The cutting edge angle of the tool ID number 251 (external threading) is read into #10000.]

#9999 = 251 ;

Writes the tool ID number 251 to #9999.

#10000 = #9907 ;

Reads the macro variable, #9907, corresponding to the cutting edge angle of the external threading tool.

(ii) When the data of all tools of a type is to be read

[The tool length data of all outer surface grooving tools is sequentially set in macro variables starting with #10000.]

#9999 = 450 ;

References outer surface grooving tools.

#9999 = - 1 ;

Setting completion code

#10000 = 10000 ;

IF [#9999 EQ 99] GOTO 99 ;

Causes a jump to N99 if there is no outer surface grooving tool.

N10 # [#10000] = #9906 ;

Reads the tool length data of an outer surface grooving tool.

#10000 = #10000+1 ;

#9999 = 1 ;

Searches for the next tool.

IF [#9998 LT 500] GOTO 10 ;

Causes a jump to N10 if there is another outer surface grooving tool.

N99

(iii) When tools satisfying specified conditions are to be searched for

[Outer surface grooving tools that have a tool length of 50mm or more and a tool width of 5 mm or less are searched for.]

#9999 = 450 ; References outer surface grooving tools.

#9999 = 14 ; Control symbol number \geq (50 mm)

#9906 = 50000 ; Tool length: 50 mm
 (Least input increment: 0.001 mm)

#9999 = 12 ; Control symbol number \leq (5 mm)

#9908 = 5000 ; Tool width: 5 mm
 (Least input increment: 0.001 mm)

#9999 = - 1 ; Setting completion code

E.6.1.3 Details of the Software Package Associated with the Cutting Condition Data

If ID numbers are set in system variables #9990 and #9991, the cutting condition data can be read into #9992 to #9996, depending on the values set.

For example, in case (1) (a) shown below, if 18 is set in #9990 and 1 is set in #9991, the feed amount, cutting speed, and cutting depth for roughing material 1 with a general-purpose carbide tool are set in system variables #9992, #9993, and #9994.

NOTE

- 1 Variables #9990 to #9996 are not used to read the chuck/tailstock figure data. (See (10).)
- 2 This function is supported by versions 2 and 3 only.

(1) Cutting condition data screen for general-purpose tools
(a) Carbide tool

101	#L	OUTER		T0101	RN	0.400	AC	95	AN	80	TW	20.000
102	#R	OUTER		T0202	RN	0.400	AC	95	AN	55	TW	20.000
103	#L	OUTER		T0303	RN	0.400	AC	95	AN	55	TW	20.000
251	#L	OUTER	TH	T0404	RN	0.400	AN	60			TW	20.000
252	#R	OUTER	TH	T0505	RN	0.400	AN	60			TW	20.000

*** MACHINING CONDITION (GENERAL) ***

[#9990=x] ROUGHING CARBITE	[#9990=y] FINISHING CARBITE
MATERIAL	MATERIAL
FEED/REV. CUT SPD. CUT DPTH (MM/REV.) (M/MIN.) (MM)	FEED/REV. CUT SPD. (MM/REV.) (M/MIN.)
<#9991=1> #9992 #9993 #9994	<#9991=1> #9992 #9993
<#9991=2> #9992 #9993 #9994	<#9991=2> #9992 #9993
<#9991=3> #9992 #9993 #9994	<#9991=3> #9992 #9993
<#9991=4> #9992 #9993 #9994	<#9991=4> #9992 #9993
<#9991=5> #9992 #9993 #9994	<#9991=5> #9992 #9993
<#9991=6> #9992 #9993 #9994	<#9991=6> #9992 #9993
<#9991=7> #9992 #9993 #9994	<#9991=7> #9992 #9993
<#9991=8> #9992 #9993 #9994	<#9991=8> #9992 #9993

SET FEEDRATE AMOUNT BY MAX. VALUE.

WORK MATERL								MENU RETRN			
----------------	--	--	--	--	--	--	--	---------------	--	--	--

- Workpiece material 1 to 8 : x= 18, y= 19
- Workpiece material 9 to 16 : x=155, y=156
- Workpiece material 17 to 24 : x=161, y=162

NOTE

Workpiece materials 9 to 16 and 17 to 24 are available only when 99 tools can be registered.

(b) High-speed tool

101	#L	OUTER	↙	T0101	RN	0.400	AC	95	AN	80	TW	20.000
102	#R	OUTER	↘	T0202	RN	0.400	AC	95	AN	55	TW	20.000
103	#L	OUTER	↙	T0303	RN	0.400	AC	95	AN	55	TW	20.000
251	#L	OUTER	TH	T0404	RN	0.400	AN	60			TW	20.000
252	#R	OUTER	TH	T0505	RN	0.400	AN	60			TW	20.000

*** MACHINING CONDITION (GENERAL) ***

[#9990=x] ROUGHING				[#9990=y] FINISHING		
HI-SPD				HI-SPD		
MATERIAL	FEED/REV. (MM/REV.)	CUT SPD. (M/MIN.)	CUT DPTH (MM)	MATERIAL	FEED/REV. (MM/REV.)	CUT SPD. (M/MIN.)
<#9991=1>	#9992	#9993	#9994	<#9991=1>	#9992	#9993
<#9991=2>	#9992	#9993	#9994	<#9991=2>	#9992	#9993
<#9991=3>	#9992	#9993	#9994	<#9991=3>	#9992	#9993
<#9991=4>	#9992	#9993	#9994	<#9991=4>	#9992	#9993
<#9991=5>	#9992	#9993	#9994	<#9991=5>	#9992	#9993
<#9991=6>	#9992	#9993	#9994	<#9991=6>	#9992	#9993
<#9991=7>	#9992	#9993	#9994	<#9991=7>	#9992	#9993
<#9991=8>	#9992	#9993	#9994	<#9991=8>	#9992	#9993

SET FEEDRATE AMOUNT BY MAX. VALUE.

WORK MATERL						MENU RETRN			
----------------	--	--	--	--	--	---------------	--	--	--

- Workpiece material 1 to 8 : x= 16, y= 17
- Workpiece material 9 to 16 : x=157, y=158
- Workpiece material 17 to 24 : x=163, y=164

NOTE

Workpiece materials 9 to 16 and 17 to 24 are available only when 99 tools can be registered.

(c) Special tool

101	#L	OUTER	↙	T0101	RN	0.400	AC	95	AN	80	TW	20.000
102	#R	OUTER	↘	T0202	RN	0.400	AC	95	AN	55	TW	20.000
103	#L	OUTER	↙	T0303	RN	0.400	AC	95	AN	55	TW	20.000
251	#L	OUTER	TH	T0404	RN	0.400	AN	60			TW	20.000
252	#R	OUTER	TH	T0505	RN	0.400	AN	60			TW	20.000

*** MACHINING CONDITION (GENERAL) ***

[#9990=x] ROUGHING				[#9990=y] FINISHING		
SPECIAL				SPECIAL		
MATERIAL	FEED/REV. (MM/REV.)	CUT SPD. (M/MIN.)	CUT DPTH (MM)	MATERIAL	FEED/REV. (MM/REV.)	CUT SPD. (M/MIN.)
<#9991=1>	#9992	#9993	#9994	<#9991=1>	#9992	#9993
<#9991=2>	#9992	#9993	#9994	<#9991=2>	#9992	#9993
<#9991=3>	#9992	#9993	#9994	<#9991=3>	#9992	#9993
<#9991=4>	#9992	#9993	#9994	<#9991=4>	#9992	#9993
<#9991=5>	#9992	#9993	#9994	<#9991=5>	#9992	#9993
<#9991=6>	#9992	#9993	#9994	<#9991=6>	#9992	#9993
<#9991=7>	#9992	#9993	#9994	<#9991=7>	#9992	#9993
<#9991=8>	#9992	#9993	#9994	<#9991=8>	#9992	#9993

SET FEEDRATE AMOUNT BY MAX. VALUE.

WORK MATERL							MENU RETRN			
----------------	--	--	--	--	--	--	---------------	--	--	--

- Workpiece material 1 to 8 : x= 20, y= 21
- Workpiece material 9 to 16 : x=159, y=160
- Workpiece material 17 to 24 : x=165, y=166

NOTE
Workpiece materials 9 to 16 and 17 to 24 are available only when 99 tools can be registered.

(2) Cutting condition data screen for threading tools
 (a) Carbide tool

101	#L	OUTER	↙	T0101	RN	0.400	AC	95	AN	80	TW	20.000
102	#R	OUTER	↘	T0202	RN	0.400	AC	95	AN	55	TW	20.000
103	#L	OUTER	↙	T0303	RN	0.400	AC	95	AN	55	TW	20.000
251	#L	OUTER	TH	T0404	RN	0.400	AN	60			TW	20.000
252	#R	OUTER	TH	T0505	RN	0.400	AN	60			TW	20.000

*** MACHINING CONDITION (THRZAD) ***

[#9990=x]			
CARBITE			
MATERIAL	FEED/REV.	CUT SPD.	CUT DPTH
	(MM/REV.)	(M/MIN.)	(MM)
<#9991=1>	#9992	#9993	#9994
<#9991=2>	#9992	#9993	#9994
<#9991=3>	#9992	#9993	#9994
<#9991=4>	#9992	#9993	#9994
<#9991=5>	#9992	#9993	#9994
<#9991=6>	#9992	#9993	#9994
<#9991=7>	#9992	#9993	#9994
<#9991=8>	#9992	#9993	#9994

SET FEEDRATE AMOUNT BY MAX. VALUE.

WORK MATERL						MENU RETRN			
----------------	--	--	--	--	--	---------------	--	--	--

- Workpiece material 1 to 8 : x= 97
- Workpiece material 9 to 16 : x=198
- Workpiece material 17 to 24 : x=201

NOTE
 Workpiece materials 9 to 16 and 17 to 24 are available only when 99 tools can be registered.

(b) High-speed tool

101	#L	OUTER	↙	T0101	RN	0.400	AC	95	AN	80	TW	20.000
102	#R	OUTER	↘	T0202	RN	0.400	AC	95	AN	55	TW	20.000
103	#L	OUTER	↙	T0303	RN	0.400	AC	95	AN	55	TW	20.000
251	#L	OUTER	TH	T0404	RN	0.400	AN	60			TW	20.000
252	#R	OUTER	TH	T0505	RN	0.400	AN	60			TW	20.000

*** MACHINING CONDITION (THRZAD) ***

[#9990=x]
HI-SPD

MATERIAL	FEED/REV. (MM/REV.)	CUT SPD. (M/MIN.)	CUT DPTH (MM)
<#9991=1>	#9992	#9993	#9994
<#9991=2>	#9992	#9993	#9994
<#9991=3>	#9992	#9993	#9994
<#9991=4>	#9992	#9993	#9994
<#9991=5>	#9992	#9993	#9994
<#9991=6>	#9992	#9993	#9994
<#9991=7>	#9992	#9993	#9994
<#9991=8>	#9992	#9993	#9994

SET FEEDRATE AMOUNT BY MAX. VALUE.

WORK MATERL							MENU RETRN			
----------------	--	--	--	--	--	--	---------------	--	--	--

- Workpiece material 1 to 8 : x= 96
- Workpiece material 9 to 16 : x=197
- Workpiece material 17 to 24 : x=200

NOTE
Workpiece materials 9 to 16 and 17 to 24 are available only when 99 tools can be registered.

(c) Special tool

101	#L	OUTER	↙	T0101	RN	0.400	AC	95	AN	80	TW	20.000
102	#R	OUTER	↘	T0202	RN	0.400	AC	95	AN	55	TW	20.000
103	#L	OUTER	↙	T0303	RN	0.400	AC	95	AN	55	TW	20.000
251	#L	OUTER	TH	T0404	RN	0.400	AN	60			TW	20.000
252	#R	OUTER	TH	T0505	RN	0.400	AN	60			TW	20.000

*** MACHINING CONDITION (THRZAD) ***

[#9990=x]			
SPCIAL			
MATERIAL	FEED/REV.	CUT SPD.	CUT DPTH
	(MM/REV.)	(M/MIN.)	(MM)
<#9991=1>	#9992	#9993	#9994
<#9991=2>	#9992	#9993	#9994
<#9991=3>	#9992	#9993	#9994
<#9991=4>	#9992	#9993	#9994
<#9991=5>	#9992	#9993	#9994
<#9991=6>	#9992	#9993	#9994
<#9991=7>	#9992	#9993	#9994
<#9991=8>	#9992	#9993	#9994

SET FEEDRATE AMOUNT BY MAX. VALUE.

WORK MATERL								MENU RETRN				
----------------	--	--	--	--	--	--	--	---------------	--	--	--	--

- Workpiece material 1 to 8 : x= 98
- Workpiece material 9 to 16 : x=199
- Workpiece material 17 to 24 : x=202

NOTE

Workpiece materials 9 to 16 and 17 to 24 are available only when 99 tools can be registered.

(3) Cutting condition data screen for grooving tools

(a) Carbide tool

101	#L	OUTER	↙	T0101	RN	0.400	AC	95	AN	80	TW	20.000
102	#R	OUTER	↘	T0202	RN	0.400	AC	95	AN	55	TW	20.000
103	#L	OUTER	↙	T0303	RN	0.400	AC	95	AN	55	TW	20.000
251	#L	OUTER	TH	T0404	RN	0.400	AN	60			TW	20.000
252	#R	OUTER	TH	T0505	RN	0.400	AN	60			TW	20.000

*** MACHINING CONDITION (GROOVING) ***

[#9990=x]	[#9990=y]
ROUGHING	FINISHING
CARBITE	CARBITE
MATERIAL	MATERIAL
(S-WIDTH MM~	FEED/REV. CUT SPD.
MM)	(MM/REV.) (M/MIN.)
CUT DPTH	CUT SPD.
(MM)	(M/MIN.)
<#9991=1> #9992 #9993 #9994	<#9991=1> #9992 #9993
<#9991=2> #9992 #9993 #9994	<#9991=2> #9992 #9993
<#9991=3> #9992 #9993 #9994	<#9991=3> #9992 #9993
<#9991=4> #9992 #9993 #9994	<#9991=4> #9992 #9993
<#9991=5> #9992 #9993 #9994	<#9991=5> #9992 #9993
<#9991=6> #9992 #9993 #9994	<#9991=6> #9992 #9993
<#9991=7> #9992 #9993 #9994	<#9991=7> #9992 #9993
<#9991=8> #9992 #9993 #9994	<#9991=8> #9992 #9993

SET FEEDRATE AMOUNT BY MAX. VALUE.

WORK							MENU			
MATERL							RETRN			

- Workpiece material 1 to 8 : x= 24, y= 25
- Workpiece material 9 to 16 : x=169, y=170
- Workpiece material 17 to 24 : x=175, y=176

NOTE
Workpiece materials 9 to 16 and 17 to 24 are available only when 99 tools can be registered.

(b) High-speed tool

101	#L	OUTER	↙	T0101	RN	0.400	AC	95	AN	80	TW	20.000
102	#R	OUTER	↘	T0202	RN	0.400	AC	95	AN	55	TW	20.000
103	#L	OUTER	↙	T0303	RN	0.400	AC	95	AN	55	TW	20.000
251	#L	OUTER	TH	T0404	RN	0.400	AN	60			TW	20.000
252	#R	OUTER	TH	T0505	RN	0.400	AN	60			TW	20.000

*** MACHINING CONDITION (GROOVING) ***

[#9990=x] ROUGHING				[#9990=y] FINISHING		
HI-SPD	(S-WIDTH	MM~	MM)	HI-SPD		
MATERIAL	FEED/REV.	CUT SPD.	CUT DPTH	MATERIAL	FEED/REV.	CUT SPD.
	(MM/REV.)	(M/MIN.)	(MM)		(MM/REV.)	(M/MIN.)
<#9991=1>	#9992	#9993	#9994	<#9991=1>	#9992	#9993
<#9991=2>	#9992	#9993	#9994	<#9991=2>	#9992	#9993
<#9991=3>	#9992	#9993	#9994	<#9991=3>	#9992	#9993
<#9991=4>	#9992	#9993	#9994	<#9991=4>	#9992	#9993
<#9991=5>	#9992	#9993	#9994	<#9991=5>	#9992	#9993
<#9991=6>	#9992	#9993	#9994	<#9991=6>	#9992	#9993
<#9991=7>	#9992	#9993	#9994	<#9991=7>	#9992	#9993
<#9991=8>	#9992	#9993	#9994	<#9991=8>	#9992	#9993

SET FEEDRATE AMOUNT BY MAX. VALUE.

WORK MATERL								MENU RETRN			
----------------	--	--	--	--	--	--	--	---------------	--	--	--

- Workpiece material 1 to 8 : x= 22, y= 23
- Workpiece material 9 to 16 : x=167, y=168
- Workpiece material 17 to 24 : x=173, y=174

NOTE

Workpiece materials 9 to 16 and 17 to 24 are available only when 99 tools can be registered.

(c) Special tool

101	#L	OUTER	↙	T0101	RN	0.400	AC	95	AN	80	TW	20.000
102	#R	OUTER	↘	T0202	RN	0.400	AC	95	AN	55	TW	20.000
103	#L	OUTER	↙	T0303	RN	0.400	AC	95	AN	55	TW	20.000
251	#L	OUTER	TH	T0404	RN	0.400	AN	60			TW	20.000
252	#R	OUTER	TH	T0505	RN	0.400	AN	60			TW	20.000

*** MACHINING CONDITION (GROOVING) ***

[#9990=x] ROUGHING				[#9990=y] FINISHING		
SPCIAL	(S-WDTH	MM~	MM)	SPCIAL		
MATERIAL	FEED/REV.	CUT	SPD.	MATERIAL	FEED/REV.	CUT
	(MM/REV.)	(M/MIN.)	(MM)		(MM/REV.)	(M/MIN.)
<#9991=1>	#9992	#9993	#9994	<#9991=1>	#9992	#9993
<#9991=2>	#9992	#9993	#9994	<#9991=2>	#9992	#9993
<#9991=3>	#9992	#9993	#9994	<#9991=3>	#9992	#9993
<#9991=4>	#9992	#9993	#9994	<#9991=4>	#9992	#9993
<#9991=5>	#9992	#9993	#9994	<#9991=5>	#9992	#9993
<#9991=6>	#9992	#9993	#9994	<#9991=6>	#9992	#9993
<#9991=7>	#9992	#9993	#9994	<#9991=7>	#9992	#9993
<#9991=8>	#9992	#9993	#9994	<#9991=8>	#9992	#9993

SET FEEDRATE AMOUNT BY MAX. VALUE.

WORK MATERL								MENU RETRN			
----------------	--	--	--	--	--	--	--	---------------	--	--	--

- Workpiece material 1 to 8 : x= 26, y= 27
- Workpiece material 9 to 16 : x=171, y=172
- Workpiece material 17 to 24 : x=177, y=178

NOTE
Workpiece materials 9 to 16 and 17 to 24 are available only when 99 tools can be registered.

(4) Cutting condition data screen for drilling tools

(a) High-speed tool

101	#L	OUTER		↙ T0101	RN	0. 400	AC	95	AN	80	TW	20. 000
102	#R	OUTER		↘ T0202	RN	0. 400	AC	95	AN	55	TW	20. 000
103	#L	OUTER		↙ T0303	RN	0. 400	AC	95	AN	55	TW	20. 000
251	#L	OUTER	TH	T0404	RN	0. 400	AN	60			TW	20. 000
252	#R	OUTER	TH	T0505	RN	0. 400	AN	60			TW	20. 000

*** MACHINING CONDITION (DRILLING) ***

[#9990=x]
 HI-SPD DRIL (S-DIA. MM~ MM)
 MATERIAL FEED/REV. CUT SPD.
 (MM/REV.) (M/MIN.)

<#9991=1>	#9992	#9993
<#9991=2>	#9992	#9993
<#9991=3>	#9992	#9993
<#9991=4>	#9992	#9993
<#9991=5>	#9992	#9993
<#9991=6>	#9992	#9993
<#9991=7>	#9992	#9993
<#9991=8>	#9992	#9993

SET FEEDRATE AMOUNT BY MAX. VALUE.

WORK MATERL	DRILL	CENTER	REAMER	BORE			MENU RETRN		
----------------	-------	--------	--------	------	--	--	---------------	--	--

<DRILL>

- Workpiece material 1 to 8 : x=28
- Workpiece material 9 to 16 : x=179
- Workpiece material 17 to 24 : x=182

<CENTER>

- Workpiece material 1 to 8 : x=92
- Workpiece material 9 to 16 : x=185
- Workpiece material 17 to 24 : x=188

<REAMER>

- Workpiece material 1 to 8 : x=137
- Workpiece material 9 to 16 : x=140
- Workpiece material 17 to 24 : x=143

<BORE>

- Workpiece material 1 to 8 : x=146
- Workpiece material 9 to 16 : x=149
- Workpiece material 17 to 24 : x=152

NOTE

Workpiece materials 9 to 16 and 17 to 24 are available only when 99 tools can be registered.

(b) Carbide tool

101	#L	OUTER	↙	T0101	RN	0.400	AC	95	AN	80	TW	20.000
102	#R	OUTER	↘	T0202	RN	0.400	AC	95	AN	55	TW	20.000
103	#L	OUTER	↙	T0303	RN	0.400	AC	95	AN	55	TW	20.000
251	#L	OUTER	TH	T0404	RN	0.400	AN	60			TW	20.000
252	#R	OUTER	TH	T0505	RN	0.400	AN	60			TW	20.000

*** MACHINING CONDITION (DRILLING) ***

[#9990=x]
 CARBID DRIL (S-DIA. MM~ MM)
 MATERIAL FEED/REV. CUT SPD.
 (MM/REV.) (M/MIN.)

<#9991=1>	#9992	#9993
<#9991=2>	#9992	#9993
<#9991=3>	#9992	#9993
<#9991=4>	#9992	#9993
<#9991=5>	#9992	#9993
<#9991=6>	#9992	#9993
<#9991=7>	#9992	#9993
<#9991=8>	#9992	#9993

SET FEEDRATE AMOUNT BY MAX. VALUE.

	WORK MATERL	DRILL	CENTER	REAMER	BORE			MENU RETRN		
--	-------------	-------	--------	--------	------	--	--	------------	--	--

<DRILL>

- Workpiece material 1 to 8 : x= 29
- Workpiece material 9 to 16 : x=180
- Workpiece material 17 to 24 : x=183

<CENTER>

- Workpiece material 1 to 8 : x= 93
- Workpiece material 9 to 16 : x=186
- Workpiece material 17 to 24 : x=189

<REAMER>

- Workpiece material 1 to 8 : x=138
- Workpiece material 9 to 16 : x=141
- Workpiece material 17 to 24 : x=144

<BORE>

- Workpiece material 1 to 8 : x=147
- Workpiece material 9 to 16 : x=150
- Workpiece material 17 to 24 : x=153

NOTE

Workpiece materials 9 to 16 and 17 to 24 are available only when 99 tools can be registered.

(c) Special tool

101	#L	OUTER	↙	T0101	RN	0.400	AC	95	AN	80	TW	20.000
102	#R	OUTER	↘	T0202	RN	0.400	AC	95	AN	55	TW	20.000
103	#L	OUTER	↙	T0303	RN	0.400	AC	95	AN	55	TW	20.000
251	#L	OUTER	TH	T0404	RN	0.400	AN	60			TW	20.000
252	#R	OUTER	TH	T0505	RN	0.400	AN	60			TW	20.000

*** MACHINING_CONDITION (DRILLING) ***

[#9990=x]
 SPCIAL DRIL (S-DIA. MM~ MM)
 MATERIAL FEED/REV. CUT SPD.
 (MM/REV.) (M/MIN.)

<#9991=1>	#9992	#9993
<#9991=2>	#9992	#9993
<#9991=3>	#9992	#9993
<#9991=4>	#9992	#9993
<#9991=5>	#9992	#9993
<#9991=6>	#9992	#9993
<#9991=7>	#9992	#9993
<#9991=8>	#9992	#9993

SET FEEDRATE AMOUNT BY MAX. VALUE.

WORK MATERL	DRILL	CENTER	REAMER	BORE			MENU RETRN			
----------------	-------	--------	--------	------	--	--	---------------	--	--	--

<DRILL>

- Workpiece material 1 to 8 : x= 30
- Workpiece material 9 to 16 : x=181
- Workpiece material 17 to 24 : x=184

<CENTER>

- Workpiece material 1 to 8 : x= 94
- Workpiece material 9 to 16 : x=187
- Workpiece material 17 to 24 : x=190

<REAMER>

- Workpiece material 1 to 8 : x=139
- Workpiece material 9 to 16 : x=142
- Workpiece material 17 to 24 : x=145

<BORE>

- Workpiece material 1 to 8 : x=148
- Workpiece material 9 to 16 : x=151
- Workpiece material 17 to 24 : x=154

NOTE

Workpiece materials 9 to 16 and 17 to 24 are available only when 99 tools can be registered.

(5) Cutting condition data screen for taps

(a) High-speed tool

101	#L	OUTER	↙	T0101	RN	0.400	AC	95	AN	80	TW	20.000
102	#R	OUTER	↘	T0202	RN	0.400	AC	95	AN	55	TW	20.000
103	#L	OUTER	↙	T0303	RN	0.400	AC	95	AN	55	TW	20.000
251	#L	OUTER	TH	T0404	RN	0.400	AN	60			TW	20.000
252	#R	OUTER	TH	T0505	RN	0.400	AN	60			TW	20.000

*** MACHINING CONDITION (TAPPING) ***

[#9990=x]
 HI-SPD TAP (S-DIA. MM~ MM)
 MATERIAL CUT SPD.
 (M/MIN.)

<#9991=1> #9992
 <#9991=2> #9992
 <#9991=3> #9992
 <#9991=4> #9992
 <#9991=5> #9992
 <#9991=6> #9992
 <#9991=7> #9992
 <#9991=8> #9992

SET FEEDRATE AMOUNT BY MAX. VALUE.

WORK MATERL						MENU RETRN			
----------------	--	--	--	--	--	---------------	--	--	--

<TAP>

- Workpiece material 1 to 8 : x= 60
- Workpiece material 9 to 16 : x=191
- Workpiece material 17 to 24 : x=194

NOTE

Workpiece materials 9 to 16 and 17 to 24 are available only when 99 tools can be registered.

(b) Carbide tool

101	#L	OUTER	↙	T0101	RN	0.400	AC	95	AN	80	TW	20.000
102	#R	OUTER	↘	T0202	RN	0.400	AC	95	AN	55	TW	20.000
103	#L	OUTER	↙	T0303	RN	0.400	AC	95	AN	55	TW	20.000
251	#L	OUTER	TH	T0404	RN	0.400	AN	60			TW	20.000
252	#R	OUTER	TH	T0505	RN	0.400	AN	60			TW	20.000

*** MACHINING CONDITION (TAPPING) ***

[#9990=x]	
CARBID TAP	(S-DIA. MM~ MM)
MATERIAL	CUT SPD.
	(M/MIN.)
<#9991=1>	#9992
<#9991=2>	#9992
<#9991=3>	#9992
<#9991=4>	#9992
<#9991=5>	#9992
<#9991=6>	#9992
<#9991=7>	#9992
<#9991=8>	#9992

SET FEEDRATE AMOUNT BY MAX. VALUE.

WORK								MENU				
MATERL								RETRN				

<TAP>

- Workpiece material 1 to 8 : x= 61
- Workpiece material 9 to 16 : x=192
- Workpiece material 17 to 24 : x=195

NOTE

Workpiece materials 9 to 16 and 17 to 24 are available only when 99 tools can be registered.

(c) Special tool

101	#L	OUTER	↙	T0101	RN	0.400	AC	95	AN	80	TW	20.000
102	#R	OUTER	↘	T0202	RN	0.400	AC	95	AN	55	TW	20.000
103	#L	OUTER	↙	T0303	RN	0.400	AC	95	AN	55	TW	20.000
251	#L	OUTER	TH	T0404	RN	0.400	AN	60			TW	20.000
252	#R	OUTER	TH	T0505	RN	0.400	AN	60			TW	20.000

*** MACHINING CONDITION (TAPPING) ***

[#9990=x]
 SPECIAL TAP (S-DIA. MM~ MM)
 MATERIAL CUT SPD.
 (M/MIN.)

<#9991=1> #9992
 <#9991=2> #9992
 <#9991=3> #9992
 <#9991=4> #9992
 <#9991=5> #9992
 <#9991=6> #9992
 <#9991=7> #9992
 <#9991=8> #9992

SET FEEDRATE AMOUNT BY MAX. VALUE.

WORK MATERL							MENU RETRN			
----------------	--	--	--	--	--	--	---------------	--	--	--

<TAP>

- Workpiece material 1 to 8 : x= 62
- Workpiece material 9 to 16 : x=193
- Workpiece material 17 to 24 : x=196

NOTE

Workpiece materials 9 to 16 and 17 to 24 are available only when 99 tools can be registered.

(6) Cutting condition data screen for rotary tools

(a) End mill

(i) High-speed tool

101	#L	OUTER	↙	T0101	RN	0.400	AC	95	AN	80	TW	20.000
102	#R	OUTER	↘	T0202	RN	0.400	AC	95	AN	55	TW	20.000
103	#L	OUTER	↙	T0303	RN	0.400	AC	95	AN	55	TW	20.000
251	#L	OUTER	TH	T0404	RN	0.400	AN	60			TW	20.000
252	#R	OUTER	TH	T0505	RN	0.400	AN	60			TW	20.000

*** MACHINING CONDITION (ENDMILL) ***

[#9990=x] ROUGHING	[#9990=y] FINISHING
HI-SPDENDMIL (S-WDTH MM~ MM)	HI-SPDENDMIL
MATERIAL FEED QUT-H FEED QNT-A CUT SPD. (MM/EDG.) (M/EDG.) (M/MIN.)	MATERIAL FEED QUT-H FEED QNT-A CUT SPD. (MM/EDG.) (M/EDG.) (M/MIN.)
<#9991=1> #9992 #9993 #9994	<#9991=1> #9992 #9993 #9994
<#9991=2> #9992 #9993 #9994	<#9991=2> #9992 #9993 #9994
<#9991=3> #9992 #9993 #9994	<#9991=3> #9992 #9993 #9994
<#9991=4> #9992 #9993 #9994	<#9991=4> #9992 #9993 #9994
<#9991=5> #9992 #9993 #9994	<#9991=5> #9992 #9993 #9994
<#9991=6> #9992 #9993 #9994	<#9991=6> #9992 #9993 #9994
<#9991=7> #9992 #9993 #9994	<#9991=7> #9992 #9993 #9994
<#9991=8> #9992 #9993 #9994	<#9991=8> #9992 #9993 #9994

SET FEEDRATE AMOUNT BY MAX. VALUE.

WORK	ENDMIL	SIDCUT	CHAMFR			MENU			
MATERL						RETRN			

- Workpiece material 1 to 8 : x=9003, y=9004
- Workpiece material 9 to 16 : x=9057, y=9058
- Workpiece material 17 to 24 : x=9063, y=9064

NOTE

Workpiece materials 9 to 16 and 17 to 24 are available only when 99 tools can be registered.

(ii) Carbide tool

101	#L	OUTER	↙	T0101	RN	0.400	AC	95	AN	80	TW	20.000
102	#R	OUTER	↘	T0202	RN	0.400	AC	95	AN	55	TW	20.000
103	#L	OUTER	↙	T0303	RN	0.400	AC	95	AN	55	TW	20.000
251	#L	OUTER	TH	T0404	RN	0.400	AN	60			TW	20.000
252	#R	OUTER	TH	T0505	RN	0.400	AN	60			TW	20.000

*** MACHINING CONDITION (ENDMIL) ***

[#9990=x] ROUGHING	[#9990=y] FINISHING
CARBID ENDMIL (S-WIDTH MM~ MM)	CARBID ENDMIL
MATERIAL FEED QUT-H FEED QNT-A CUT SPD. (MM/EDG.) (M/EDG.) (M/MIN.)	MATERIAL FEED QUT-H FEED QNT-A CUT SPD. (MM/EDG.) (M/EDG.) (M/MIN.)
<#9991=1> #9992 #9993 #9994	<#9991=1> #9992 #9993 #9994
<#9991=2> #9992 #9993 #9994	<#9991=2> #9992 #9993 #9994
<#9991=3> #9992 #9993 #9994	<#9991=3> #9992 #9993 #9994
<#9991=4> #9992 #9993 #9994	<#9991=4> #9992 #9993 #9994
<#9991=5> #9992 #9993 #9994	<#9991=5> #9992 #9993 #9994
<#9991=6> #9992 #9993 #9994	<#9991=6> #9992 #9993 #9994
<#9991=7> #9992 #9993 #9994	<#9991=7> #9992 #9993 #9994
<#9991=8> #9992 #9993 #9994	<#9991=8> #9992 #9993 #9994

SET FEEDRATE AMOUNT BY MAX. VALUE.

WORK MATERL	ENDMIL	SIDCUT	CHAMFR			MENU RETRN			
-------------	--------	--------	--------	--	--	------------	--	--	--

- Workpiece material 1 to 8 : x=9001, y=9002
- Workpiece material 9 to 16 : x=9055, y=9056
- Workpiece material 17 to 24 : x=9061, y=9062

NOTE
Workpiece materials 9 to 16 and 17 to 24 are available only when 99 tools can be registered.

(iii) Special tool

101	#L	OUTER	↙	T0101	RN	0.400	AC	95	AN	80	TW	20.000
102	#R	OUTER	↘	T0202	RN	0.400	AC	95	AN	55	TW	20.000
103	#L	OUTER	↙	T0303	RN	0.400	AC	95	AN	55	TW	20.000
251	#L	OUTER	TH	T0404	RN	0.400	AN	60			TW	20.000
252	#R	OUTER	TH	T0505	RN	0.400	AN	60			TW	20.000

*** MACHINING CONDITION (ENDMILL) ***

[#9990=x] ROUGHING			
SPCIAL ENDMIL	(S-WIDTH	MM~	MM)
MATERIAL	FEED	QUT-H	FEED QNT-A
	(MM/EDG.)	(M/EDG.)	(M/MIN.)
<#9991=1>	#9992	#9993	#9994
<#9991=2>	#9992	#9993	#9994
<#9991=3>	#9992	#9993	#9994
<#9991=4>	#9992	#9993	#9994
<#9991=5>	#9992	#9993	#9994
<#9991=6>	#9992	#9993	#9994
<#9991=7>	#9992	#9993	#9994
<#9991=8>	#9992	#9993	#9994

[#9990=y] FINISHING			
SPCIAL ENDMIL			
MATERIAL	FEED	QUT-H	FEED QNT-A
	(MM/EDG.)	(M/EDG.)	(M/MIN.)
<#9991=1>	#9992	#9993	#9994
<#9991=2>	#9992	#9993	#9994
<#9991=3>	#9992	#9993	#9994
<#9991=4>	#9992	#9993	#9994
<#9991=5>	#9992	#9993	#9994
<#9991=6>	#9992	#9993	#9994
<#9991=7>	#9992	#9993	#9994
<#9991=8>	#9992	#9993	#9994

SET FEEDRATE AMOUNT BY MAX. VALUE.

	WORK MATERL	ENDMIL	SIDCUT	CHAMFR				MENU RETRN			
--	----------------	--------	--------	--------	--	--	--	---------------	--	--	--

- Workpiece material 1 to 8 : x=9005, y=9006
- Workpiece material 9 to 16 : x=9059, y=9060
- Workpiece material 17 to 24 : x=9065, y=9066

NOTE

Workpiece materials 9 to 16 and 17 to 24 are available only when 99 tools can be registered.

(b) Side cutter
(i) High-speed tool

101	#L	OUTER	↙	T0101	RN	0.400	AC	95	AN	80	TW	20.000
102	#R	OUTER	↘	T0202	RN	0.400	AC	95	AN	55	TW	20.000
103	#L	OUTER	↙	T0303	RN	0.400	AC	95	AN	55	TW	20.000
251	#L	OUTER	TH	T0404	RN	0.400	AN	60			TW	20.000
252	#R	OUTER	TH	T0505	RN	0.400	AN	60			TW	20.000

*** MACHINING CONDITION (SIDECUT) ***

<p>[#9990=x] ROUGHING</p> <p>HI-SPD SIDECUT (S-WIDTH MM~ MM)</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td>MATERIAL</td> <td>FEED/REV.</td> <td>CUT SPD.</td> </tr> <tr> <td></td> <td>(MM/EDG.)</td> <td>(M/MIN.)</td> </tr> <tr> <td><#9991=1></td> <td>#9992</td> <td>#9993</td> </tr> <tr> <td><#9991=2></td> <td>#9992</td> <td>#9993</td> </tr> <tr> <td><#9991=3></td> <td>#9992</td> <td>#9993</td> </tr> <tr> <td><#9991=4></td> <td>#9992</td> <td>#9993</td> </tr> <tr> <td><#9991=5></td> <td>#9992</td> <td>#9993</td> </tr> <tr> <td><#9991=6></td> <td>#9992</td> <td>#9993</td> </tr> <tr> <td><#9991=7></td> <td>#9992</td> <td>#9993</td> </tr> <tr> <td><#9991=8></td> <td>#9992</td> <td>#9993</td> </tr> </table>	MATERIAL	FEED/REV.	CUT SPD.		(MM/EDG.)	(M/MIN.)	<#9991=1>	#9992	#9993	<#9991=2>	#9992	#9993	<#9991=3>	#9992	#9993	<#9991=4>	#9992	#9993	<#9991=5>	#9992	#9993	<#9991=6>	#9992	#9993	<#9991=7>	#9992	#9993	<#9991=8>	#9992	#9993	<p>[#9990=y] FINISHING</p> <p>HI-SPD SIDECUT</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td>MATERIAL</td> <td>FEED/REV.</td> <td>CUT SPD.</td> </tr> <tr> <td></td> <td>(MM/EDG.)</td> <td>(M/MIN.)</td> </tr> <tr> <td><#9991=1></td> <td>#9992</td> <td>#9993</td> </tr> <tr> <td><#9991=2></td> <td>#9992</td> <td>#9993</td> </tr> <tr> <td><#9991=3></td> <td>#9992</td> <td>#9993</td> </tr> <tr> <td><#9991=4></td> <td>#9992</td> <td>#9993</td> </tr> <tr> <td><#9991=5></td> <td>#9992</td> <td>#9993</td> </tr> <tr> <td><#9991=6></td> <td>#9992</td> <td>#9993</td> </tr> <tr> <td><#9991=7></td> <td>#9992</td> <td>#9993</td> </tr> <tr> <td><#9991=8></td> <td>#9992</td> <td>#9993</td> </tr> </table>	MATERIAL	FEED/REV.	CUT SPD.		(MM/EDG.)	(M/MIN.)	<#9991=1>	#9992	#9993	<#9991=2>	#9992	#9993	<#9991=3>	#9992	#9993	<#9991=4>	#9992	#9993	<#9991=5>	#9992	#9993	<#9991=6>	#9992	#9993	<#9991=7>	#9992	#9993	<#9991=8>	#9992	#9993
MATERIAL	FEED/REV.	CUT SPD.																																																											
	(MM/EDG.)	(M/MIN.)																																																											
<#9991=1>	#9992	#9993																																																											
<#9991=2>	#9992	#9993																																																											
<#9991=3>	#9992	#9993																																																											
<#9991=4>	#9992	#9993																																																											
<#9991=5>	#9992	#9993																																																											
<#9991=6>	#9992	#9993																																																											
<#9991=7>	#9992	#9993																																																											
<#9991=8>	#9992	#9993																																																											
MATERIAL	FEED/REV.	CUT SPD.																																																											
	(MM/EDG.)	(M/MIN.)																																																											
<#9991=1>	#9992	#9993																																																											
<#9991=2>	#9992	#9993																																																											
<#9991=3>	#9992	#9993																																																											
<#9991=4>	#9992	#9993																																																											
<#9991=5>	#9992	#9993																																																											
<#9991=6>	#9992	#9993																																																											
<#9991=7>	#9992	#9993																																																											
<#9991=8>	#9992	#9993																																																											

SET FEEDRATE AMOUNT BY MAX. VALUE.

	WORK MATERL	ENDMIL	SIDECUT	CHAMFR			MENU RETRN		
--	-------------	--------	---------	--------	--	--	------------	--	--

- Workpiece material 1 to 8 : x=9009, y=9010
- Workpiece material 9 to 16 : x=9069, y=9070
- Workpiece material 17 to 24 : x=9075, y=9076

NOTE
Workpiece materials 9 to 16 and 17 to 24 are available only when 99 tools can be registered.

(ii) Carbide tool

101	#L	OUTER		↙ T0101	RN	0. 400	AC	95	AN	80	TW	20. 000
102	#R	OUTER		↘ T0202	RN	0. 400	AC	95	AN	55	TW	20. 000
103	#L	OUTER		↙ T0303	RN	0. 400	AC	95	AN	55	TW	20. 000
251	#L	OUTER	TH	T0404	RN	0. 400	AN	60			TW	20. 000
252	#R	OUTER	TH	T0505	RN	0. 400	AN	60			TW	20. 000

*** MACHINING CONDITION (SIDECUT) ***

<p>[#9990=x] ROUGHING</p> <p>CARBID SIDECUT (S-WDTH MM~ MM)</p> <table style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">MATERIAL</th> <th style="width: 20%;">FEED/REV. (MM/EDG.)</th> <th style="width: 20%;">CUT SPD. (M/MIN.)</th> </tr> </thead> <tbody> <tr><td><#9991=1></td><td>#9992</td><td>#9993</td></tr> <tr><td><#9991=2></td><td>#9992</td><td>#9993</td></tr> <tr><td><#9991=3></td><td>#9992</td><td>#9993</td></tr> <tr><td><#9991=4></td><td>#9992</td><td>#9993</td></tr> <tr><td><#9991=5></td><td>#9992</td><td>#9993</td></tr> <tr><td><#9991=6></td><td>#9992</td><td>#9993</td></tr> <tr><td><#9991=7></td><td>#9992</td><td>#9993</td></tr> <tr><td><#9991=8></td><td>#9992</td><td>#9993</td></tr> </tbody> </table>	MATERIAL	FEED/REV. (MM/EDG.)	CUT SPD. (M/MIN.)	<#9991=1>	#9992	#9993	<#9991=2>	#9992	#9993	<#9991=3>	#9992	#9993	<#9991=4>	#9992	#9993	<#9991=5>	#9992	#9993	<#9991=6>	#9992	#9993	<#9991=7>	#9992	#9993	<#9991=8>	#9992	#9993	<p>[#9990=y] FINISHING</p> <p>CARBID SIDECUT</p> <table style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">MATERIAL</th> <th style="width: 20%;">FEED/REV. (MM/EDG.)</th> <th style="width: 20%;">CUT SPD. (M/MIN.)</th> </tr> </thead> <tbody> <tr><td><#9991=1></td><td>#9992</td><td>#9993</td></tr> <tr><td><#9991=2></td><td>#9992</td><td>#9993</td></tr> <tr><td><#9991=3></td><td>#9992</td><td>#9993</td></tr> <tr><td><#9991=4></td><td>#9992</td><td>#9993</td></tr> <tr><td><#9991=5></td><td>#9992</td><td>#9993</td></tr> <tr><td><#9991=6></td><td>#9992</td><td>#9993</td></tr> <tr><td><#9991=7></td><td>#9992</td><td>#9993</td></tr> <tr><td><#9991=8></td><td>#9992</td><td>#9993</td></tr> </tbody> </table>	MATERIAL	FEED/REV. (MM/EDG.)	CUT SPD. (M/MIN.)	<#9991=1>	#9992	#9993	<#9991=2>	#9992	#9993	<#9991=3>	#9992	#9993	<#9991=4>	#9992	#9993	<#9991=5>	#9992	#9993	<#9991=6>	#9992	#9993	<#9991=7>	#9992	#9993	<#9991=8>	#9992	#9993
MATERIAL	FEED/REV. (MM/EDG.)	CUT SPD. (M/MIN.)																																																					
<#9991=1>	#9992	#9993																																																					
<#9991=2>	#9992	#9993																																																					
<#9991=3>	#9992	#9993																																																					
<#9991=4>	#9992	#9993																																																					
<#9991=5>	#9992	#9993																																																					
<#9991=6>	#9992	#9993																																																					
<#9991=7>	#9992	#9993																																																					
<#9991=8>	#9992	#9993																																																					
MATERIAL	FEED/REV. (MM/EDG.)	CUT SPD. (M/MIN.)																																																					
<#9991=1>	#9992	#9993																																																					
<#9991=2>	#9992	#9993																																																					
<#9991=3>	#9992	#9993																																																					
<#9991=4>	#9992	#9993																																																					
<#9991=5>	#9992	#9993																																																					
<#9991=6>	#9992	#9993																																																					
<#9991=7>	#9992	#9993																																																					
<#9991=8>	#9992	#9993																																																					

SET FEEDRATE AMOUNT BY MAX. VALUE.

	WORK MATERL	ENDMIL	SIDCUT	CHAMFR			MENU RETRN		
--	----------------	--------	--------	--------	--	--	---------------	--	--

- Workpiece material 1 to 8 : x=9007, y=9008
- Workpiece material 9 to 16 : x=9067, y=9068
- Workpiece material 17 to 24 : x=9073, y=9074

NOTE

Workpiece materials 9 to 16 and 17 to 24 are available only when 99 tools can be registered.

(iii) Special tool

101	#L	OUTER		↙ T0101	RN	0. 400	AC	95	AN	80	TW	20. 000
102	#R	OUTER		↘ T0202	RN	0. 400	AC	95	AN	55	TW	20. 000
103	#L	OUTER		↙ T0303	RN	0. 400	AC	95	AN	55	TW	20. 000
251	#L	OUTER	TH	T0404	RN	0. 400	AN	60			TW	20. 000
252	#R	OUTER	TH	T0505	RN	0. 400	AN	60			TW	20. 000

*** MACHINING CONDITION (SIDECUT) ***

[#9990=x] ROUGHING	[#9990=y] FINISHING
SPECIAL SIDECUT (S-WIDTH MM~ MM)	SPECIAL SIDECUT
MATERIAL FEED/REV. CUT SPD. (MM/EDG.) (M/MIN.)	MATERIAL FEED/REV. CUT SPD. (MM/EDG.) (M/MIN.)
<#9991=1> #9992 #9993	<#9991=1> #9992 #9993
<#9991=2> #9992 #9993	<#9991=2> #9992 #9993
<#9991=3> #9992 #9993	<#9991=3> #9992 #9993
<#9991=4> #9992 #9993	<#9991=4> #9992 #9993
<#9991=5> #9992 #9993	<#9991=5> #9992 #9993
<#9991=6> #9992 #9993	<#9991=6> #9992 #9993
<#9991=7> #9992 #9993	<#9991=7> #9992 #9993
<#9991=8> #9992 #9993	<#9991=8> #9992 #9993

SET FEEDRATE AMOUNT BY MAX. VALUE.

	WORK MATERL	ENDMIL	SIDCUT	CHAMFR			MENU RETRN		
--	-------------	--------	--------	--------	--	--	------------	--	--

- Workpiece material 1 to 8 : x=9011, y=9012
- Workpiece material 9 to 16 : x=9071, y=9072
- Workpiece material 17 to 24 : x=9077, y=9078

NOTE
Workpiece materials 9 to 16 and 17 to 24 are available only when 99 tools can be registered.

(c) Chamfering tool

(i) High speed tool

101	#L	OUTER	↙	T0101	RN	0.400	AC	95	AN	80	TW	20.000
102	#R	OUTER	↘	T0202	RN	0.400	AC	95	AN	55	TW	20.000
103	#L	OUTER	↙	T0303	RN	0.400	AC	95	AN	55	TW	20.000
251	#L	OUTER	TH	T0404	RN	0.400	AN	60			TW	20.000
252	#R	OUTER	TH	T0505	RN	0.400	AN	60			TW	20.000

*** MACHINING CONDITION (CHAMFER) ***

[#9990=x]

HI-SPD CHAMFR	(S-WIDTH	MM~	MM)
MATERIAL	FEED/REV.	CUT	SPD.
	(MM/EDG.)	(M/MIN.)	
<#9991=1>	#9992	#9993	
<#9991=2>	#9992	#9993	
<#9991=3>	#9992	#9993	
<#9991=4>	#9992	#9993	
<#9991=5>	#9992	#9993	
<#9991=6>	#9992	#9993	
<#9991=7>	#9992	#9993	
<#9991=8>	#9992	#9993	

SET FEEDRATE AMOUNT BY MAX. VALUE.

	WORK MATERL	ENDMIL	SIDCUT	CHAMFR			MENU RETRN			
--	----------------	--------	--------	--------	--	--	---------------	--	--	--

- Workpiece material 1 to 8 : x=9014
- Workpiece material 9 to 16 : x=9080
- Workpiece material 17 to 24 : x=9083

NOTE

Workpiece materials 9 to 16 and 17 to 24 are available only when 99 tools can be registered.

(ii) Carbide tool

101	#L	OUTER	↙	T0101	RN	0.400	AC	95	AN	80	TW	20.000
102	#R	OUTER	↘	T0202	RN	0.400	AC	95	AN	55	TW	20.000
103	#L	OUTER	↙	T0303	RN	0.400	AC	95	AN	55	TW	20.000
251	#L	OUTER	TH	T0404	RN	0.400	AN	60			TW	20.000
252	#R	OUTER	TH	T0505	RN	0.400	AN	60			TW	20.000

*** MACHINING CONDITION (CHAMFER) ***

[#9990=x]

CARBID CHAMFR (S-WIDTH MM~ MM)

MATERIAL FEED/REV. CUT SPD.
(MM/EDG.) (M/MIN.)

<#9991=1>	#9992	#9993
<#9991=2>	#9992	#9993
<#9991=3>	#9992	#9993
<#9991=4>	#9992	#9993
<#9991=5>	#9992	#9993
<#9991=6>	#9992	#9993
<#9991=7>	#9992	#9993
<#9991=8>	#9992	#9993

SET FEEDRATE AMOUNT BY MAX. VALUE.

WORK MATERL	ENDMIL	SIDCUT	CHAMFR			MENU RETRN			
----------------	--------	--------	--------	--	--	---------------	--	--	--

- Workpiece material 1 to 8 : x=9013
- Workpiece material 9 to 16 : x=9079
- Workpiece material 17 to 24 : x=9082

NOTE
Workpiece materials 9 to 16 and 17 to 24 are available only when 99 tools can be registered.

(iii) Special tool

101	#L	OUTER	↙	T0101	RN	0.400	AC	95	AN	80	TW	20.000
102	#R	OUTER	↘	T0202	RN	0.400	AC	95	AN	55	TW	20.000
103	#L	OUTER	↙	T0303	RN	0.400	AC	95	AN	55	TW	20.000
251	#L	OUTER	TH	T0404	RN	0.400	AN	60			TW	20.000
252	#R	OUTER	TH	T0505	RN	0.400	AN	60			TW	20.000

*** MACHINING CONDITION (CHAMFER) ***

```
[#9990=x]
SPECIAL CHAMFR(S-WDTH  MM~      MM)
MATERIAL      FEED/REV.  CUT SPD.
              (MM/EDG.) (M/MIN.)
<#9991=1>     #9992      #9993
<#9991=2>     #9992      #9993
<#9991=3>     #9992      #9993
<#9991=4>     #9992      #9993
<#9991=5>     #9992      #9993
<#9991=6>     #9992      #9993
<#9991=7>     #9992      #9993
<#9991=8>     #9992      #9993
```

SET FEEDRATE AMOUNT BY MAX. VALUE.

WORK MATERL	ENDMIL	SIDCUT	CHAMFR			MENU RETRN			
----------------	--------	--------	--------	--	--	---------------	--	--	--

- Workpiece material 1 to 8 : x=9015
- Workpiece material 9 to 16 : x=9081
- Workpiece material 17 to 24 : x=9084

NOTE

Workpiece materials 9 to 16 and 17 to 24 are available only when 99 tools can be registered.

(7) Coefficient setting data screen

(a) Coefficient setting data for general-purpose tools

101	#L	OUTER	↙	T0101	RN	0.400	AC	95	AN	80	TW	20.000
102	#R	OUTER	↘	T0202	RN	0.400	AC	95	AN	55	TW	20.000
103	#L	OUTER	↙	T0303	RN	0.400	AC	95	AN	55	TW	20.000
251	#L	OUTER	TH	T0404	RN	0.400	AN	60			TW	20.000
252	#R	OUTER	TH	T0505	RN	0.400	AN	60			TW	20.000

*** MACHINING CONDITION (COEFIC) ***

[#9990=x] FINISHING GENERAL

FEED/REV.
(MM/REV.) #9992 #9993 #9994 #9995 <#9991=1>

MATERIAL

<#9991=2>	#9992	#9993	#9994	#9995	#9996
<#9991=3>	#9992	#9993	#9994	#9995	#9996
<#9991=4>	#9992	#9993	#9994	#9995	#9996
<#9991=5>	#9992	#9993	#9994	#9995	#9996
<#9991=6>	#9992	#9993	#9994	#9995	#9996
<#9991=7>	#9992	#9993	#9994	#9995	#9996
<#9991=8>	#9992	#9993	#9994	#9995	#9996
<#9991=9>	#9992	#9993	#9994	#9995	#9996

(CUT SPD.)

WORK MATERL							MENU RETRN	GUIDE	
----------------	--	--	--	--	--	--	---------------	-------	--

- Workpiece material 1 to 8 : x= 31
- Workpiece material 9 to 16 : x=203
- Workpiece material 17 to 24 : x=204

NOTE
Workpiece materials 9 to 16 and 17 to 24 are available only when 99 tools can be registered.

(d) Coefficient setting data for drills

101	#L	OUTER	↙	T0101	RN	0.400	AC	95	AN	80	TW	20.000
102	#R	OUTER	↘	T0202	RN	0.400	AC	95	AN	55	TW	20.000
103	#L	OUTER	↙	T0303	RN	0.400	AC	95	AN	55	TW	20.000
251	#L	OUTER	TH	T0404	RN	0.400	AN	60			TW	20.000
252	#R	OUTER	TH	T0505	RN	0.400	AN	60			TW	20.000

*** MACHINING CONDITION (COEFIC) ***

```

[ #9990=33 ] DRIL
NOMINL-D #9992 #9993 #9994 #9995 <#9991=1>
(MM)
HI-SPD #9992 #9993 #9994 #9995 #9996 <#9991=3>
CARBID #9992 #9993 #9994 #9995 #9996 <#9991=2>
SPECIAL #9992 #9993 #9994 #9995 #9996 <#9991=4>

(FEED/REV.)
  
```

									MENU		GUIDE	
									RETRN			

(f) Coefficient setting data for reamers

101	#L	OUTER	↙	T0101	RN	0.400	AC	95	AN	80	TW	20.000
102	#R	OUTER	↘	T0202	RN	0.400	AC	95	AN	55	TW	20.000
103	#L	OUTER	↙	T0303	RN	0.400	AC	95	AN	55	TW	20.000
251	#L	OUTER	TH	T0404	RN	0.400	AN	60			TW	20.000
252	#R	OUTER	TH	T0505	RN	0.400	AN	60			TW	20.000

*** MACHINING CONDITION (COEFIC) ***

```

[ #9990=207 ] REAMER
BORE DIA. #9992 #9993 #9994 #9995 <#9991=1>
(MM)      |   |   |   |   |
HI-SPD   #9992 #9993 #9994 #9995 #9996 <#9991=3>
CARBID   #9992 #9993 #9994 #9995 #9996 <#9991=2>
SPECIAL  #9992 #9993 #9994 #9995 #9996 <#9991=4>

(FEED/REV.)
  
```

									MENU		GUIDE	
									RETRN			

(i) Coefficient setting data for end mills

101	#L	OUTER	↙	T0101	RN	0.400	AC	95	AN	80	TW	20.000
102	#R	OUTER	↘	T0202	RN	0.400	AC	95	AN	55	TW	20.000
103	#L	OUTER	↙	T0303	RN	0.400	AC	95	AN	55	TW	20.000
251	#L	OUTER	TH	T0404	RN	0.400	AN	60			TW	20.000
252	#R	OUTER	TH	T0505	RN	0.400	AN	60			TW	20.000

*** MACHINING CONDITION (COEFIC) ***

```
[#9990=9016]          ROUGHING          ENDMIL
NOMINL-D      #9992 #9993 #9994 #9995<#9991=1>
(MM)          |      |      |      |      |
CARBID        #9992 #9993 #9994 #9995 #9996<#9991=2>
HI-SPD        #9992 #9993 #9994 #9995 #9996<#9991=3>
SPECIAL       #9992 #9993 #9994 #9995 #9996<#9991=4>
```

```
[#9990=9017]          FINISHING
NOMINL-D      #9992 #9993 #9994 #9995<#9991=1>
(MM)
CARBID        #9992 #9993 #9994 #9995 #9996<#9991=2>
HI-SPD        #9992 #9993 #9994 #9995 #9996<#9991=3>
SPECIAL       #9992 #9993 #9994 #9995 #9996<#9991=4>
(FEED/REV.)
```

									MENU		GUIDE	
									RETRN			

(8) Surface roughness data screen

101	#L	OUTER	↙	T0101	RN	0.400	AC	95	AN	80	TW	20.000
102	#R	OUTER	↘	T0202	RN	0.400	AC	95	AN	55	TW	20.000
103	#L	OUTER	↙	T0303	RN	0.400	AC	95	AN	55	TW	20.000
251	#L	OUTER	TH	T0404	RN	0.400	AN	60			TW	20.000
252	#R	OUTER	TH	T0505	RN	0.400	AN	60			TW	20.000

*** MACHINING CONDITION (ROUGH) ***

[#9990=35]

RGH CODE	SURFACE ROUGHNESS (MM/100)
1 ▽	#9992<#9991=1>
2 ▽	#9992<#9991=2>
3 ▽▽	#9992<#9991=3>
4 ▽▽	#9992<#9991=4>
5 ▽▽▽	#9992<#9991=5>
6 ▽▽▽	#9992<#9991=6>
7 ▽▽▽	#9992<#9991=7>
8 ▽▽▽	#9992<#9991=8>
9 ▽▽▽	#9992<#9991=9>
10 ▽▽▽	#9992<#9991=10>

								MENU				
								RETRN				

(9) Pre-tool list

101	#L	OUTER		↙ T0101	RN	0. 400 AC	95 AN	80 TW	20. 000
102	#R	OUTER		↘ T0202	RN	0. 400 AC	95 AN	55 TW	20. 000
103	#L	OUTER		↙ T0303	RN	0. 400 AC	95 AN	55 TW	20. 000
251	#L	OUTER	TH	T0404	RN	0. 400 AN	60	TW	20. 000
252	#R	OUTER	TH	T0505	RN	0. 400 AN	60	TW	20. 000

*** PRE-TOOL LIST ***

	LAST TL		TOOL NO.		TL NAME
			#9992<#9991=1>		
PRE-TOOL	1		#9992<#9991=2>		
		2	#9992<#9991=3>		
		3	#9992<#9991=4>		
		4	#9992<#9991=5>		
		5	#9992<#9991=6>		

	WORK MATERL					SEARCH		MENU RETRN	TOOL LIST		
--	----------------	--	--	--	--	--------	--	---------------	--------------	--	--

- Pre-tool list 1 : x=101
- Pre-tool list 2 : x=102
- Pre-tool list 3 : x=103
- Pre-tool list 4 : x=104
- Pre-tool list 5 : x=105
- Pre-tool list 6 : x=106

(10) Chuck/tailstock figure data

(a) Chuck figure data

To read the data for a chuck, using system variables #9951 to #9955, set the corresponding chuck number in #9950.

101	#L	OUTER	↙	T0101	RN	0.400	AC	95	AN	80	TW	20.000
102	#R	OUTER	↘	T0202	RN	0.400	AC	95	AN	55	TW	20.000
103	#L	OUTER	↙	T0303	RN	0.400	AC	95	AN	55	TW	20.000
251	#L	OUTER	TH	T0404	RN	0.400	AN	60			TW	20.000
252	#R	OUTER	TH	T0505	RN	0.400	AN	60			TW	20.000

*** CHUCK FIGURE ***

NO.	TYPE	L	W	L1	W1	
1	#9951	#9952	#9953	#9954	#9955	[#9950= 1]
2	#9951	#9952	#9953	#9954	#9955	[#9950= 2]
3	#9951	#9952	#9953	#9954	#9955	[#9950= 3]
4	#9951	#9952	#9953	#9954	#9955	[#9950= 4]
5	#9951	#9952	#9953	#9954	#9955	[#9950= 5]
6	#9951	#9952	#9953	#9954	#9955	[#9950= 6]
7	#9951	#9952	#9953	#9954	#9955	[#9950= 7]
8	#9951	#9952	#9953	#9954	#9955	[#9950= 8]
9	#9951	#9952	#9953	#9954	#9955	[#9950= 9]
10	#9951	#9952	#9953	#9954	#9955	[#9950=10]

	EXT.	INT.	OUT-S	CHUCK	TAIL STOCK			MENU RETRN		
--	------	------	-------	-------	------------	--	--	------------	--	--

<TYPE>

- External jaw : #9951=1
- Internal jaw : #9952=2
- Special external jaw : #9953=3

NOTE

The OUT-S type is supported only when the optional 60-chuck function is provided. This function provides data on 60 different chucks.

(b) Tailstock figure data

To read the data for a tailstock, using system variables #9981 to #9986, set the desired tailstock number in #9980.

101	#L	OUTER	↙	T0101	RN	0.400	AC	95	AN	80	TW	20.000
102	#R	OUTER	↘	T0202	RN	0.400	AC	95	AN	55	TW	20.000
103	#L	OUTER	↙	T0303	RN	0.400	AC	95	AN	55	TW	20.000
251	#L	OUTER	TH	T0404	RN	0.400	AN	60			TW	20.000
252	#R	OUTER	TH	T0505	RN	0.400	AN	60			TW	20.000

*** TAIL STOCK FIGURE ***

NO.	1	2
	[#9980=1]	[#9980=1]
D0	#9981	#9981
L0	#9982	#9982
D1	#9983	#9983
L1	#9984	#9984
D2	#9985	#9985
L2	#9986	#9986

				CHUCK	TAIL STOCK			MENU				
								RETRN				

NOTE

Data for up to four tailstocks can be stored.

E.6.2 Software Package Associated with Process Data

E.6.2.1 Overview

With the FANUC Super CAP T Ver. 1, 2, 3 the first macro variable number of the process data of a process in a conversational program can be read into #9898 to reference the process data. In addition, a process can be searched for using the process data.

E.6.2.2 Specifications

The first macro variable number of a process to be searched for can be set in #9898 by setting reference process data used for search operation in #9892, setting the offset number of the macro variable containing data to be searched for in #9893, and setting the completion code in #9899. If search operation fails, the error code (99) is set in #9898.

In #9890, the first macro variable number of the process data of the currently indicated process is set. In addition, the initially set first macro variable number of the program currently selected is set in #9891.

(a) Macro variables and process numbers used with the function

(i) Details of macro variables

#9898 – When a process is searched for using process data, the first macro variable number of the process searched for is set. (This macro variable allows read operation only.)

#9899 – In process search operation, -1 is to be entered when reference process data for search operation and the offset number, from the beginning, of the macro variable containing data to be searched have been entered. (This macro variable allows write operation only.)

#9890 – The first macro variable number of the process data currently edited is set. (This macro variable allows read operation only.)

#9891 – The first macro variable number of the initially set data of the program currently edited is set. (This macro variable allows read operation only.)

#9880 – The first macro variable number of the process data currently executed is set. (This macro variable allows read operation only.)

#9881 – The first macro variable number of the initially set data of the program currently executed is set. (This macro variable allows read operation only.)

#9884 – The first macro variable number of the block of the initially set workpiece figure data of the current program is set. (This macro variable allows read operations only.)

#9892 – When a process is to be searched for, reference process data used for search operation is set. (This macro variable allows write operation only.)

#9893 – When a process is to be searched for, the offset number, from the beginning, of the macro variable containing data to be searched for is set. (This macro variable allows write operation only.)

#9894 – The first macro variable number of the block containing the initially set molding material figure data of the program currently edited is set. (This macro variable allows read operation only.)

#9895 = 1: Searches for the program currently executed.
0: Searches for the program currently edited.

P-code variables #10000 to #10699 can be freely used with a user program. With a general macro compiler/executor (with the FANUC Super CAP T Ver. 1 not incorporated), the number of P-code variables (#10000 and up) can be changed using compile parameter number 9037. With the system that has the conversational function, however, this parameter is always set to 7. The system uses extended P-code variables #20000 and up; these variables cannot be used with a user program.

(ii) Process numbers

Currently, up to 99 processes can be registered. When processes are generated, the same number is assigned to a rough machining process, finish machining process, and chamfering process. (After renumbering operation is executed, a different process number is assigned in ascending order to each of these processes.)

When a workpiece figure represents a molding material figure, 60 macro variables (initial setting - 2) are added to contain the data of each point of the workpiece figure at the time of initial setting. The first macro variable number of the block containing the molding material figure data is set in #9894. When a workpiece figure does not represent a molding material figure, #9894 is set to 0 or a null.

(b) Process data and offset

A conversational program consists of a block of 60 macro variables as a basic unit. So, except at the time of initial setting, any process data can be represented using the first macro variable number of the block containing the process and its offset from the first macro variable number.

However, the contents of a program depends on the type of process. Accordingly, the data represented by the same offset can vary from process to process.

(i) Details of offsets for each type of process

<Initial Setting – 1>

+ 0	Work material	+30	Finishing allowance X (*2)
+ 1	Work figure (1=Bar, 2=Molding)	+31	Finishing allowance Z (*2)
+ 2	Outside diameter D (Bar)	+32	End face cutting allowance E, CZ
+ 3	Inside diameter H (Bar)	+33	T code T (1)
+ 4	Length L (Bar)	+34	Workpiece shift amount SZ (1)
+ 5	Unused	+35	Chuck number C (1)
+ 6	Unused	+36	Chuck reference point X (1)
+ 7	T code T (2)	+37	Chuck reference point Z (1)
+ 8	Workpiece shift amount SZ (2)	+38	Tail stock number
+ 9	Chuck number C (2)	+39	
+10	Chuck reference point X (2)	+40	
+11	Chuck reference point Z (2)	+41	
+12	Product length PL	+42	Name of program ASCII code
+13	Coolant (1=ON, 2=OFF) (*1)	+43	
+14	●Trapezoidal groove figure editing flag (*22)	+44	Unused
+15	●Tail stock number (2)	+45	Unused
+16	●Tool change position X (1)	+46	Unused
+17	●Tool change position Z (1)	+47	System utilization area (*3)
+18	●Tool change position X (2)	+48	Run hour
+19	●Tool change position Z (2)	+49	Common safety point outer diameter X
+20	●Tail stock reference point Z (1)	+50	Common safety point outer diameter Z
+21	●Tail stock reference point Z (2)	+51	Common safety point internal diameter X
+22	●Face position	+52	Common safety point internal diameter Z
+23	Program prepared data (y, m, d)	+53	Unused
+24	Program prepared data (time)	+54	Unused
+25	Program update (y, m, d)	+55	First variable number of the 2nd initial setting block
+26	Program update (time)	+56	* Unused
+27	Common safety point X for drilling (turning)	+57	* Use status flag (0: Not used, 1: Used)
+28	Common safety point Z for drilling (turning)	+58	* Unused
+29	Maximum spindle speed	+59	* First variable number of the next block

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Some item names vary with the version.

[1]: First tool post [2]: Second tool post (*?): See the note below.

* : System management area –
Avoid data writing by a user program.

<Initial Setting – 2>

+ 0	Outside diameter X1 (Molding)	+30	Inside diameter X4 (Molding)
+ 1	Outside diameter Z1 (Molding)	+31	Inside diameter Z4 (Molding)
+ 2	Outside diameter X2 (Molding)	+32	Inside diameter X5 (Molding)
+ 3	Outside diameter Z2 (Molding)	+33	Inside diameter Z5 (Molding)
+ 4	Outside diameter X3 (Molding)	+34	Inside diameter X6 (Molding)
+ 5	Outside diameter Z3 (Molding)	+35	Inside diameter Z6 (Molding)
+ 6	Outside diameter X4 (Molding)	+36	Inside diameter X7 (Molding)
+ 7	Outside diameter Z4 (Molding)	+37	Inside diameter Z7 (Molding)
+ 8	Outside diameter X5 (Molding)	+38	Inside diameter X8 (Molding)
+ 9	Outside diameter Z5 (Molding)	+39	Inside diameter Z8 (Molding)
+10	Outside diameter X6 (Molding)	+40	Inside diameter X9 (Molding)
+11	Outside diameter Z6 (Molding)	+41	Inside diameter Z9 (Molding)
+12	Outside diameter X7 (Molding)	+42	Inside diameter X10 (Molding)
+13	Outside diameter Z7 (Molding)	+43	Inside diameter Z10 (Molding)
+14	Outside diameter X8 (Molding)	+44	Inside diameter X11 (Molding)
+15	Outside diameter Z8 (Molding)	+45	Inside diameter Z11 (Molding)
+16	Outside diameter X9 (Molding)	+46	Inside diameter X12 (Molding)
+17	Outside diameter Z9 (Molding)	+47	Inside diameter Z12 (Molding)
+18	Outside diameter X10 (Molding)	+48	Unused
+19	Outside diameter Z10 (Molding)	+49	Unused
+20	Outside diameter X11 (Molding)	+50	Unused
+21	Outside diameter Z11 (Molding)	+51	Unused
+22	Outside diameter X12 (Molding)	+52	Unused
+23	Outside diameter Z12 (Molding)	+53	Unused
+24	Inside diameter X1 (Molding)	+54	Unused
+25	Inside diameter Z1 (Molding)	+55	* Unused
+26	Inside diameter X2 (Molding)	+56	* Unused
+27	Inside diameter Z2 (Molding)	+57	* Use status flag (0: Not used, 1: Used)
+28	Inside diameter X3 (Molding)	+58	* Unused
+29	Inside diameter Z3 (Molding)	+59	* Unused

●: Ver.2 or later, ■: Ver.3 or later.

NOTE

Some item names vary with the version.

* : System management area –
Avoid data writing by a user program.

<Process Data>

● Bar (rough machining)

+ 0	Process number	+30	Speed <residual machining>
+ 1	Unused	+31	Surface reoughness <residual machining>
+ 2	System utilization area (*3)	+32	●Escape amount <residual machining>
+ 3	Machining type (*4)	+33	●Process movement (1=Standard, 2=High speed)<residual machining>
+ 4	Machining area (*5)	+34	Tool number <residual machining>
+ 5	Tool post (Spindle axis selection) (*6)	+35	T code <residual machining>
+ 6	Machining cycle (*7)	+36	●Program override
+ 7	Cutting start point X	+37	●Program override <residual machining>
+ 8	Cutting start point Z	+38	Cutting speed <residual machining>
+ 9	Unused	+39	Feed amount <residual machining>
+10	Unused	+40	Direction of rotation (1=CW, 2=CCW) <residual machining>
+11	Surface roughness	+41	Cut depth <residual machining>
+12	●Escape amount	+42	Spindle gear (*8) <residual machining>
+13	●Process movement (1=Standard, 2=High speed)	+43	Coolant (1=ON, 2=OFF)<residual machining>
+14	Tool number	+44	●Pass point 1 X
+15	T code	+45	●Pass point 1 Z
+16	Unused	+46	●Pass point 2 X
+17	Unused	+47	●Pass point 2 Z
+18	Cutting speed	+48	Run hour
+19	Feed amount	+49	System utilization area (*3)
+20	Direction of rotation (1=CW, 2=CCW)	+50	Surface speed/speed selection (*9)
+21	Cut depth	+51	Speed
+22	Finishing allowance X	+52	* First variable number for roughing
+23	Finishing allowance Z	+53	* First variable number for finishing
+24	Spindle gear (*8)	+54	* First variable number for chamfering
+25	Coolant (1=ON, 2=OFF)	+55	* First variable number of a figure block
+26	Automatic residual machining (1=Used, 2=Not used)	+56	* Unused
+27	Cutting start point X <residual machining>	+57	* Use status flag (0: Not used, 1: Used)
+28	Cutting start point Z <residual machining>	+58	* First variable number of the preceding process
+29	Surface speed/speed selection (*9) <residual machining>	+59	* First variable number of the next process

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Some item names depend on the version.

* : System management area –

Avoid data writing by a user program.

If there are no processes corresponding to +52 to +59, or if the current process corresponds to any of those processes, the area is set to null or 0.

● Bar (finishing)

+ 0	Process number	+30	Speed <residual machining>
+ 1	Unused	+31	Surface reoughness <residual machining>
+ 2	System utilization area (*3)	+32	●Escape amount <residual machining>
+ 3	Machining type (*4)	+33	Unused
+ 4	Machining area (*5)	+34	Tool number <residual machining>
+ 5	Tool post (Spindle axis selection) (*6)	+35	T code <residual machining>
+ 6	Machining cycle (*7)	+36	Unused
+ 7	Cutting start point X	+37	Unused
+ 8	Cutting start point Z	+38	Cutting speed <residual machining>
+ 9	Unused	+39	Feed amount <residual machining>
+10	Unused	+40	Direction of rotation (1=CW, 2=CCW) <residual machining>
+11	Surface roughness	+41	Unused
+12	●Escape amount	+42	Spindle gear (*8) <residual machining>
+13	Unused	+43	Coolant (1=ON, 2=OFF)<residual machining>
+14	Tool number	+44	●Pass point 1 X
+15	T code	+45	●Pass point 1 Z
+16	Unused	+46	●Pass point 2 X
+17	Unused	+47	●Pass point 2 Z
+18	Cutting speed	+48	Run hour
+19	Feed amount	+49	System utilization area (*3)
+20	Direction of rotation (1=CW, 2=CCW)	+50	Surface speed/speed selection (*9)
+21	Unused	+51	Speed
+22	Finishing allowance X	+52	* First variable number for roughing
+23	Finishing allowance Z	+53	* First variable number for finishing
+24	Spindle gear (*8)	+54	* First variable number for chamfering
+25	Coolant (1=ON, 2=OFF)	+55	* First variable number of a figure block
+26	Automatic residual machining (1=Used, 2=Unused)	+56	* Unused
+27	Cutting start point X <residual machining>	+57	* Use status flag (0: Not used, 1: Used)
+28	Cutting start point Z <residual machining>	+58	* First variable number of the preceding process
+29	Surface speed/speed selection (*9) <residual machining>	+59	* First variable number of the next process

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Some item names depend on the version.

* : System management area –

Avoid data writing by a user program.

If there are no processes corresponding to +52 to +59, or if the current process corresponds to any of those processes, the area is set to null or 0

● Pattern Repeating (rough machining)

+ 0	Process number	+30	Unused
+ 1	Unused	+31	Unused
+ 2	System utilization area (*3)	+32	Unused
+ 3	Machining type (*4)	+33	Unused
+ 4	Machining area (*5)	+34	Unused
+ 5	Tool post (Spindle axis selection) (*6)	+35	Unused
+ 6	Machining cycle (*7)	+36	●Program override
+ 7	Cutting start point X	+37	Unused
+ 8	Cutting start point Z	+38	Unused
+ 9	Unused	+39	Unused
+10	Unused	+40	Unused
+11	Surface roughness	+41	Unused
+12	Cutting allowance X	+42	Unused
+13	Cutting allowance Z	+43	Unused
+14	Tool number	+44	●Pass point 1 X
+15	T code	+45	●Pass point 1 Z
+16	Unused	+46	●Pass point 2 X
+17	Unused	+47	●Pass point 2 Z
+18	Cutting speed	+48	Run hour
+19	Feed amount	+49	System utilization area (*3)
+20	Direction of rotation (1=CW, 2=CCW)	+50	Surface speed/speed selection (*9)
+21	Cut depth	+51	Speed
+22	Finishing allowance X	+52	* First variable number for roughing
+23	Finishing allowance Z	+53	* First variable number for finishing
+24	Spindle gear (*8)	+54	* First variable number for chamfering
+25	Coolant (1=ON, 2=OFF)	+55	* First variable number of a figure block
+26	Unused	+56	* Unused
+27	Unused	+57	* Use status flag (0: Not used, 1: Used)
+28	Unused	+58	* First variable number of the preceding process
+29	Unused	+59	* First variable number of the next process

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Some item names depend on the version.

* : System management area –

Avoid data writing by a user program.

If there are no processes corresponding to +52 to +59, or if the current process corresponds to any of those processes, the area is set to null or 0.

● Pattern Repeating (finish machining)

+ 0	Process number	+30	Unused
+ 1	Unused	+31	Unused
+ 2	System utilization area (*3)	+32	Unused
+ 3	Machining type (*4)	+33	Unused
+ 4	Machining area (*5)	+34	Unused
+ 5	Tool post (Spindle axis selection) (*6)	+35	Unused
+ 6	Machining cycle (*7)	+36	Unused
+ 7	Cutting start point X	+37	Unused
+ 8	Cutting start point Z	+38	Unused
+ 9	Unused	+39	Unused
+10	Unused	+40	Unused
+11	Surface roughness	+41	Unused
+12	Unused	+42	Unused
+13	Unused	+43	Unused
+14	Tool number	+44	●Pass point 1 X
+15	T code	+45	●Pass point 1 Z
+16	Unused	+46	●Pass point 2 X
+17	Unused	+47	●Pass point 2 Z
+18	Cutting speed	+48	Run hour
+19	Feed amount	+49	System utilization area (*3)
+20	Direction of rotation (1=CW, 2=CCW)	+50	Surface speed/speed selection (*9)
+21	Unused	+51	Speed
+22	Finishing allowance X	+52	* First variable number for roughing
+23	Finishing allowance Z	+53	* First variable number for finishing
+24	Spindle gear (*8)	+54	* First variable number for chamfering
+25	Coolant (1=ON, 2=OFF)	+55	* First variable number of a figure block
+26	Unused	+56	* Unused
+27	Unused	+57	* Use status flag (0: Not used, 1: Used)
+28	Unused	+58	* First variable number of the preceding process
+29	Unused	+59	* First variable number of the next process

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Some item names depend on the version.

* : System management area –

Avoid data writing by a user program.

If there are no processes corresponding to +52 to +59, or if the current process corresponds to any of those processes, the area is set to null or 0.

● Residual Machining (rough machining)

+ 0	Process number	+30	Unused
+ 1	Unused	+31	Unused
+ 2	System utilization area (*3)	+32	Unused
+ 3	Machining type (*4)	+33	Unused
+ 4	Machining area (*5)	+34	Unused
+ 5	Tool post (Spindle axis selection) (*6)	+35	Unused
+ 6	Machining cycle (*7)	+36	●Program override
+ 7	Machining start point X	+37	Unused
+ 8	Machining start point Z	+38	Unused
+ 9	Unused	+39	Unused
+10	Unused	+40	Unused
+11	Surface roughness	+41	Unused
+12	Unused	+42	Unused
+13	●Process movement (1=Standard, 2=High speed)	+43	Unused
+14	Tool number	+44	●Pass point 1 X
+15	T code	+45	●Pass point 1 Z
+16	Unused	+46	●Pass point 2 X
+17	Unused	+47	●Pass point 2 Z
+18	Cutting speed	+48	Run hour
+19	Feed amount	+49	Unused
+20	Direction of rotation (1=CW, 2=CCW)	+50	Surface speed/speed selection (*9)
+21	Cut depth	+51	Speed
+22	Finishing allowance X	+52	* First variable number for roughing
+23	Finishing allowance Z	+53	* First variable number for finishing
+24	Spindle gear (*8)	+54	* First variable number for chamfering
+25	Coolant (1=ON, 2=OFF)	+55	* First variable number of a figure block
+26	Unused	+56	* Unused
+27	Unused	+57	* Use status flag (0: Not used, 1: Used)
+28	Unused	+58	* First variable number of the preceding process
+29	Unused	+59	* First variable number of the next process

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Some item names depend on the version.

* : System management area –

Avoid data writing by a user program.

If there are no processes corresponding to +52 to +59, or if the current process corresponds to any of those processes, the area is set to null or 0.

● Residual Machining (finish machining)

+ 0	Process number	+30	Unused
+ 1	Unused	+31	Unused
+ 2	System utilization area (*3)	+32	Unused
+ 3	Machining type (*4)	+33	Unused
+ 4	Machining area (*5)	+34	Unused
+ 5	Tool post (Spindle axis selection) (*6)	+35	Unused
+ 6	Machining cycle (*7)	+36	●Program override
+ 7	Machining start point X	+37	Unused
+ 8	Machining start point Z	+38	Unused
+ 9	Unused	+39	Unused
+10	Unused	+40	Unused
+11	Surface roughness	+41	Unused
+12	Unused	+42	Unused
+13	Unused	+43	Unused
+14	Tool number	+44	●Pass point 1 X
+15	T code	+45	●Pass point 1 Z
+16	Unused	+46	●Pass point 2 X
+17	Unused	+47	●Pass point 2 Z
+18	Cutting feed	+48	Run hour
+19	Feed amount	+49	Unused
+20	Direction of rotation (1=CW, 2=CCW)	+50	Surface speed/speed selection (*9)
+21	Unused	+51	Speed
+22	Finishing allowance X	+52	* First variable number for roughing
+23	Finishing allowance Z	+53	* First variable number for finishing
+24	Spindle gear (*8)	+54	* First variable number for chamfering
+25	Coolant (1=ON, 2=OFF)	+55	* First variable number of a figure block
+26	Unused	+56	* Unused
+27	Unused	+57	* Use status flag (0: Not used, 1: Used)
+28	Unused	+58	* First variable number of the preceding process
+29	Unused	+59	* First variable number of the next process

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Some item names depend on the version.

* : System management area –
Avoid data writing by a user program. If there are no processes corresponding to +52 to +59, or if the current process corresponds to any of those processes, the area is set to null or 0.

● End Facing (rough machining)

+ 0	Tool number	+30	Unused
+ 1	Unused	+31	Unused
+ 2	System utilization area (*3)	+32	Unused
+ 3	Machining type (*4)	+33	Unused
+ 4	Unused	+34	Unused
+ 5	Tool post (Spindle axis selection) (*6)	+35	Unused
+ 6	Machining cycle (*7)	+36	●Program override
+ 7	Machining start point X	+37	Unused
+ 8	Machining start point Z	+38	Unused
+ 9	End point	+39	Unused
+10	Unused	+40	Unused
+11	Surface roughness	+41	Unused
+12	Unused	+42	Unused
+13	Unused	+43	Unused
+14	Tool number	+44	●Pass point 1 X
+15	T code	+45	●Pass point 1 Z
+16	Unused	+46	●Pass point 2 X
+17	Unused	+47	●Pass point 2 Z
+18	Cutting speed	+48	Run hour
+19	Feed amount	+49	Unused
+20	Direction of rotation (1=CW, 2=CCW)	+50	Surface speed/speed selection (*9)
+21	Cut depth	+51	Speed
+22	Unused	+52	* First variable number for roughing
+23	Finishing allowance Z	+53	* First variable number for finishing
+24	Spindle gear (*8)	+54	* First variable number for chamfering
+25	Coolant (1=ON, 2=OFF)	+55	* First variable number of a figure block
+26	Unused	+56	* Unused
+27	Unused	+57	* Use status flag (0: Not used, 1: Used)
+28	Unused	+58	* First variable number of the preceding process
+29	Unused	+59	* First variable number of the next process

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Some item names depend on the version.

* : System management area –

Avoid data writing by a user program.

If there are no processes corresponding to +52 to +59, or if the current process corresponds to any of those processes, the area is set to null or 0.

● End Facing (finish machining)

+ 0	Process number	+30	Unused
+ 1	Unused	+31	Unused
+ 2	System utilization area (*3)	+32	Unused
+ 3	Machining type (*4)	+33	Unused
+ 4	Unused	+34	Unused
+ 5	Tool post (*6)	+35	Unused
+ 6	Machining cycle (*7)	+36	●Program override
+ 7	Machining start point X	+37	Unused
+ 8	Machining start point Z	+38	Unused
+ 9	End point	+39	Unused
+10	Unused	+40	Unused
+11	Surface roughness	+41	Unused
+12	Unused	+42	Unused
+13	Unused	+43	Unused
+14	Tool number	+44	●Pass point 1 X
+15	T code	+45	●Pass point 1 Z
+16	Unused	+46	●Pass point 2 X
+17	Unused	+47	●Pass point 2 Z
+18	Cutting speed	+48	Run hour
+19	Feed amount	+49	Unused
+20	Direction of rotation (1=CW, 2=CCW)	+50	Surface speed/speed selection (*9)
+21	Unused	+51	Speed
+22	Unused	+52	* First variable number for roughing
+23	Finishing allowance X	+53	* First variable number for finishing
+24	Spindle gear (*8)	+54	* First variable number for chamfering
+25	Coolant (1=ON, 2=OFF)	+55	* First variable number of a figure block
+26	Unused	+56	* Unused
+27	Unused	+57	* Use status flag (0: Not used, 1: Used)
+28	Unused	+58	* First variable number of the preceding process
+29	Unused	+59	* First variable number of the next process

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Some item names depend on the version.

* : System management area –

Avoid data writing by a user program.

If there are no processes corresponding to +52 to +59, or if the current process corresponds to any of those processes, the area is set to null or 0.

● Threading

+ 0	Process number	+30	Cut type (2) <Ver. 1> (*20)
+ 1	Unused	+31	Number of threads
+ 2	System utilization area (*3)	+32	Spark out
+ 3	Machining type (*4)	+33	Height of threads
+ 4	Machining area (*5)	+34	● Chamfering (1=ON, 2=OFF)
+ 5	Tool post (Spindle axis selection) (*6)	+35	● Cutting number/Cutting depth (*24)
+ 6	Machining cycle (*7)	+36	● Cutting number
+ 7	Machining start point X	+37	● Thread type (*25)
+ 8	Machining start point Z	+38	● Thread number
+ 9	Unused	+39	Unused
+10	Unused	+40	Unused
+11	Unused	+41	Unused
+12	Unused	+42	Unused
+13	Unused	+43	Unused
+14	Tool number	+44	● Pass point 1 X
+15	T code	+45	● Pass point 1 Z
+16	Unused	+46	● Pass point 2 X
+17	Unused	+47	● Pass point 2 Z
+18	Cutting speed	+48	Run hour
+19	Unused	+49	Unused
+20	Direction of rotation (1=CW, 2=CCW)	+50	Surface speed/speed selection (*9)
+21	Cut depth	+51	Speed
+22	Unused	+52	* First variable number for roughing
+23	Unused	+53	* First variable number for finishing
+24	Spindle gear (*8)	+54	* First variable number for chamfering
+25	Coolant (1=ON, 2=OFF)	+55	* First variable number of a figure block
+26	Unused	+56	* Unused
+27	Thread angle	+57	* Use status flag (0: Not used, 1: Used)
+28	Screw lead	+58	* First variable number of the preceding process
+29	Cut type (1) (*19)	+59	* First variable number of the next process

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Some item names depend on the version.

* : System management area –

Avoid data writing by a user program.

If there are no processes corresponding to +52 to +59, or if the current process corresponds to any of those processes, the area is set to null or 0.

● Grooving (rough machining)

+ 0	Process number	+30	Groove angle <slanted>
+ 1	Unused	+31	Unused
+ 2	System utilization area (*3)	+32	Start point X <ordinary, slanted, thread>
+ 3	Machining type (*4)	+33	Start point Z <ordinary, slanted, thread>
+ 4	Machining area (*5)	+34	Groove width <ordinary, slanted, thread>
+ 5	Tool post (Spindle axis selection) (*6)	+35	Groove diameter/depth <ordinary, slanted, thread>
+ 6	Execution cycle (*7)	+36	Pitch
+ 7	Machining start point X	+37	Number of grooves
+ 8	Machining start point Z	+38	Chamfer <ordinary, thread>
+ 9	●Program override	+39	End point X or Z <ordinary, thread>
+10	Unused	+40	Selection of groove diameter or groove depth <ordinary, slanted> (*17)
+11	Surface roughness <trapezoid>	+41	●Dwell time
+12	Unused	+42	Unused
+13	Unused	+43	Unused
+14	Tool number	+44	●Pass point 1 X
+15	T code	+45	●Pass point 1 Z
+16	Unused	+46	●Pass point 2 X
+17	Unused	+47	●Pass point 2 Z
+18	Cutting speed	+48	Run hour
+19	Feed amount	+49	Unused
+20	Direction of rotation (1=CW, 2=CCW)	+50	Surface speed/speed selection (*9)
+21	Cut depth	+51	Speed
+22	Finishing allowance X <trapezoid>	+52	* First variable number for roughing
+23	Finishing allowance Z <trapezoid>	+53	* First variable number for finishing
+24	Spindle gear (*8)	+54	* First variable number for chamfering
+25	Coolant (1=ON, 2=OFF)	+55	* First variable number of a figure block
+26	Unused	+56	* First variable number of data block used to input a trapezoidal groove
+27	Grooving tool program point (*18)	+57	* Use status flag (0: Not used, 1: Used)
+28	Grooving pattern (*10)	+58	* First variable number of the preceding process
+29	Minimum groove width	+59	* First variable number of the next process

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Thread groove can be used Ver.2 or later. Some item names depend on the version.

* : System management area –

Avoid data writing by a user program.

If there are no processes corresponding to +52 to +59, or if the current process corresponds to any of those processes, the area is set to null or 0.

● Grooving (finishing-trapezoid only)

+ 0	Process number	+30	Unused
+ 1	Unused	+31	Unused
+ 2	System utilization area (*3)	+32	Unused
+ 3	Machining type (*4)	+33	Unused
+ 4	Machining area (*5)	+34	Unused
+ 5	Tool post (Spindle axis selection) (*6)	+35	Unused
+ 6	Execution cycle (*7)	+36	Pitch
+ 7	Machining start point X	+37	Number of grooves
+ 8	Machining start point Z	+38	Unused
+ 9	Unused	+39	Unused
+10	Unused	+40	Unused
+11	Surface roughness	+41	Unused
+12	Unused	+42	Unused
+13	Unused	+43	Unused
+14	Tool number	+44	●Pass point 1 X
+15	T code	+45	●Pass point 1 Z
+16	Unused	+46	●Pass point 2 X
+17	Unused	+47	●Pass point 2 Z
+18	Cutting speed	+48	Run hour
+19	Feed amount	+49	Unused
+20	Direction of rotation (1=CW, 2=CCW)	+50	Surface speed/speed selection (*9)
+21	Unused	+51	Speed
+22	Finishing allowance X	+52	* First variable number for roughing
+23	Finishing allowance Z	+53	* First variable number for finishing
+24	Spindle gear (*8)	+54	* First variable number for chamfering
+25	Coolant (1=ON, 2=OFF)	+55	* First variable number of a figure block
+26	Unused	+56	* First variable number of data block used to input a trapezoidal groove
+27	Grooving tool program point (*18)	+57	* Use status flag (0: Not used, 1: Used)
+28	Grooving pattern (*10)	+58	* First variable number of the preceding process
+29	Minimum groove width	+59	* First variable number of the next process

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Some item names depend on the version.

*: System management area –

Avoid data writing by a user program.

If there are no processes corresponding to +52 to +59, or if the current process corresponds to any of those processes, the area is set to null or 0.

● Grooving (input data-trapezoid and thread groove)

+ 0	Start point X	+30	Unused
+ 1	Start point Z	+31	Unused
+ 2	Point 1 X	+32	Unused
+ 3	Point 1 Z	+33	Unused
+ 4	Round	+34	Unused
+ 5	Chamfer	+35	Unused
+ 6	Point 2 X	+36	Unused
+ 7	Point 2 Z	+37	Unused
+ 8	Round	+38	Unused
+ 9	Chamfer	+39	Unused
+10	Point 3 X	+40	Unused
+11	Point 3 Z	+41	Unused
+12	Round	+42	Unused
+13	Chamfer	+43	Unused
+14	Point 4 X	+44	●Pass point 1 X
+15	Point 4 Z	+45	●Pass point 1 Z
+16	Round	+46	●Pass point 2 X
+17	Chamfer	+47	●Pass point 2 Z
+18	End point X	+48	Run hour
+19	End point Z	+49	Unused
+20	Unused	+50	Surface speed/speed selection (*9)
+21	Unused	+51	Speed
+22	Unused	+52	* First variable number for roughing
+23	Unused	+53	* First variable number for finishing
+24	Unused	+54	* First variable number for chamfering
+25	Unused	+55	* First variable number of a figure block
+26	Unused	+56	* First variable number of data block used to input a trapezoidal groove
+27	Unused	+57	* Use status flag (0: Not used, 1: Used)
+28	Unused	+58	* First variable number of the preceding process
+29	Unused	+59	* First variable number of the next process

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Thread groove can be used Ver.2 or later. Some item names depend on the version.

*: System management area –

Avoid data writing by a user program.

If there are no processes corresponding to +52 to +59, or if the current process corresponds to any of those processes, the area is set to null or 0.

● Necking

+ 0	Process number	+30	Necking dimension D (radius)
+ 1	Unused	+31	Tool angle of the tool used (*27)
+ 2	System utilization area (*3)	+32	Cutting edge angle of the tool used (*27)
+ 3	Machining type (*4)	+33	Necking figure (*11)
+ 4	Machining area (*5)	+34	Standard diameter (diameter)
+ 5	Tool post (Spindle axis selection) (*6)	+35	Width (radius)
+ 6	Machining cycle (*7)	+36	Depth (radius)
+ 7	Machining start point X	+37	Corner radius
+ 8	Machining start point Z	+38	Approach angle
+ 9	●Program override	+39	Relief amount (radius)
+10	Unused	+40	Relief angle (radius)
+11	Surface roughness	+41	Unused
+12	Unused	+42	Unused
+13	Unused	+43	Unused
+14	Tool number	+44	●Pass point 1 X
+15	T code	+45	●Pass point 1 Z
+16	Unused	+46	●Pass point 2 X
+17	Unused	+47	●Pass point 2 Z
+18	Cutting speed	+48	Run hour
+19	Feed amount	+49	Unused
+20	Direction of rotation (1=CW, 2=CCW)	+50	Surface speed/speed selection (*9)
+21	Unused	+51	Speed
+22	Unused	+52	* First variable number for roughing
+23	Unused	+53	* First variable number for finishing
+24	Spindle gear (*8)	+54	* First variable number for chamfering
+25	Coolant (1=ON, 2=OFF)	+55	* First variable number of a figure block
+26	Unused	+56	* Unused
+27	Necking dimension A (radius)	+57	* Use status flag (0: Not used, 1: Used)
+28	Necking dimension B (radius)	+58	* First variable number of the preceding process
+29	Necking dimension C (radius)	+59	* First variable number of the next process

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Some item names depend on the version.

* : System management area –

Avoid data writing by a user program.

If there are no processes corresponding to +52 to +59, or if the current process corresponds to any of those processes, the area is set to null or 0.

● Center Drilling

+ 0	Process number	+30	Unused
+ 1	Unused	+31	Unused
+ 2	System utilization area (*3)	+32	Unused
+ 3	Machining type (*4)	+33	Unused
+ 4	Unused	+34	Unused
+ 5	Tool post (Spindle axis selection) (*6)	+35	Unused
+ 6	Machining cycle (*7)	+36	●Program override
+ 7	Cutting start point X	+37	Unused
+ 8	Cutting start point Z	+38	Unused
+ 9	■Start point Z	+39	Unused
+10	Unused	+40	Unused
+11	Unused	+41	Unused
+12	Unused	+42	Unused
+13	Unused	+43	Automatic preceding process determination flag (*12)
+14	Tool number	+44	●Pass point 1 X
+15	T code	+45	●Pass point 1 Z
+16	Unused	+46	●Pass point 2 X
+17	Unused	+47	●Pass point 2 Z
+18	Cutting speed	+48	Run hour
+19	Feed amount	+49	Unused
+20	Direction of rotation (1=CW, 2=CCW)	+50	Surface speed/speed selection (*9)
+21	Unused	+51	Speed
+22	Unused	+52	* First variable number for roughing
+23	Unused	+53	* First variable number for finishing
+24	Spindle gear (*8)	+54	* First variable number for chamfering
+25	Coolant (1=ON, 2=OFF)	+55	* First variable number of a figure block
+26	■End point Z/Hole depth (*28)	+56	* Unused
+27	Hole bottom point	+57	* Use status flag (0: Not used, 1: Used)
+28	Hole diameter/Chamfer diameter (Nominal diameter)	+58	* First variable number of the preceding process
+29	Dwell time at hole bottom point	+59	* First variable number of the next process

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Some item names depend on the version.

* : System management area –

Avoid data writing by a user program.

If there are no processes corresponding to +52 to +59, or if the current process corresponds to any of those processes, the area is set to null or 0.

● Drilling

+ 0	Process number	+30	Machining pattern (*14)
+ 1	Machining type (2) (*13)	+31	Decrement in depth of cut
+ 2	System utilization area (*3)	+32	Relief return amount
+ 3	Machining type (*4)	+33	Minimum value for the depth of cut
+ 4	Unused	+34	Residual point Z/Chamfer length/Shift amount
+ 5	Tool post (Spindle axis selection) (*6)	+35	■FEED/Rev 2/Return speed
+ 6	Machining cycle (*7)	+36	■Start feedrate
+ 7	Cutting start point X	+37	■Start clearance
+ 8	Cutting start point Z	+38	■End feedrate
+ 9	■Start point Z	+39	■End clearance
+10	Override amount	+40	Unused
+11	Unused	+41	Unused
+12	Unused	+42	Unused
+13	Unused	+43	Automatic preceding process determination flag (*12)
+14	Tool number	+44	●Pass point 1 X
+15	T code	+45	●Pass point 1 Z
+16	Unused	+46	●Pass point 2 X
+17	Unused	+47	●Pass point 2 Z
+18	Cutting speed	+48	Run hour
+19	Feed amount	+49	Unused
+20	Direction of rotation (1=CW, 2=CCW)	+50	Surface speed/speed selection (*9)
+21	Cut depth	+51	Speed
+22	Unused	+52	* First variable number for roughing
+23	Unused	+53	* First variable number for finishing
+24	Spindle gear (*8)	+54	* First variable number for chamfering
+25	Coolant (1=ON, 2=OFF)	+55	* First variable number of a figure block
+26	■End point Z/Hole depth (*28)	+56	* Unused
+27	Hole bottom point	+57	* Use status flag (0: Not used, 1: Used)
+28	Hole diameter	+58	* First variable number of the preceding process
+29	Dwell time at hole bottom point	+59	* First variable number of the next process

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Some item names depend on the version.

*: System management area –

Avoid data writing by a user program.

If there are no processes corresponding to +52 to +59, or if the current process corresponds to any of those processes, the area is set to null or 0.

● Tapping

+ 0	Process number	+30	Pitch
+ 1	Unused	+31	Unused
+ 2	System utilization area (*3)	+32	Unused
+ 3	Machining type (*4)	+33	Unused
+ 4	Unused	+34	Unused
+ 5	Tool post (Spindle axis selection) (*6)	+35	Unused
+ 6	Machining cycle (*7)	+36	Unused
+ 7	Cutting start point X	+37	Unused
+ 8	Cutting start point Z	+38	Unused
+ 9	■ Start point Z	+39	Unused
+10	Unused	+40	Unused
+11	Unused	+41	Unused
+12	Unused	+42	Unused
+13	Unused	+43	Automatic preceding process determination flag (*12)
+14	Tool number	+44	● Pass point 1 X
+15	T code	+45	● Pass point 1 Z
+16	Unused	+46	● Pass point 2 X
+17	Unused	+47	● Pass point 2 Z
+18	Cutting speed	+48	Run hour
+19	Feed amount	+49	Unused
+20	Direction of rotation (1=CW, 2=CCW)	+50	Surface speed/speed selection (*9)
+21	Unused	+51	Speed
+22	Unused	+52	* First variable number for roughing
+23	Unused	+53	* First variable number for finishing
+24	Spindle gear (*8)	+54	* First variable number for chamfering
+25	Coolant (1=ON, 2=OFF)	+55	* First variable number of a figure block
+26	■ End point Z/Hole depth (*28)	+56	* Unused
+27	Hole bottom point	+57	* Use status flag (0: Not used, 1: Used)
+28	Nominal diameter	+58	* First variable number of the preceding process
+29	Dwell time at hole bottom point	+59	* First variable number of the next process

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Some item names depend on the version.

* : System management area –
Avoid data writing by a user program.
If there are no processes corresponding to +52 to +59, or if the current process corresponds to any of those processes, the area is set to null or 0.

● Single Action (when bit 0 of parameter No.9766 is 0)

+ 0	Process number	+30	Unused
+ 1	Unused	+31	Unused
+ 2	System utilization area (*3)	+32	Unused
+ 3	Machining type (*4)	+33	Unused
+ 4	Unused	+34	Unused
+ 5	Tool post (Spindle axis selection) (*6)	+35	Unused
+ 6	Execution cycle (*7)	+36	Unused
+ 7	Cutting start point X	+37	Unused
+ 8	Cutting start point Z	+38	Unused
+ 9	Unused	+39	Unused
+10	Unused	+40	Unused
+11	Unused	+41	Unused
+12	Unused	+42	Unused
+13	Unused	+43	Unused
+14	Tool number	+44	●Pass point 1 X
+15	T code	+45	●Pass point 1 Z
+16	Unused	+46	●Pass point 2 X
+17	Unused	+47	●Pass point 2 Z
+18	Cutting speed	+48	Run hour
+19	Unused	+49	Unused
+20	Unused	+50	Surface speed/speed selection (*9)
+21	Unused	+51	Speed
+22	Unused	+52	* First variable number for roughing
+23	Unused	+53	* First variable number for finishing
+24	Unused	+54	* First variable number for chamfering
+25	Unused	+55	* First variable number of a figure block
+26	Unused	+56	* Unused
+27	Feedrate (1=mm/rev., 2=mm/min.)	+57	* Use status flag (0: Not used, 1: Used)
+28	Unused	+58	* First variable number of the preceding process
+29	Unused	+59	* First variable number of the next process

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Some item names depend on the version.

* : System management area –
Avoid data writing by a user program.
 If there are no processes corresponding to +52 to +59, or if the current process corresponds to any of those processes, the area is set to null or 0.

- Single Action II (when bit 0 of parameter No.9766 is 0) <available on Ver.3>

+ 0	Process number	+30	Unused
+ 1	Unused	+31	Unused
+ 2	System utilization area (*3)	+32	Unused
+ 3	Machining type (*4)	+33	Unused
+ 4	Type (*29)	+34	Unused
+ 5	Tool post (Spindle axis selection) (*6)	+35	Unused
+ 6	Execution cycle (*7)	+36	Unused
+ 7	Unused	+37	Unused
+ 8	Unused	+38	Unused
+ 9	Unused	+39	Unused
+10	Unused	+40	Unused
+11	Unused	+41	Unused
+12	Unused	+42	Unused
+13	Unused	+43	Unused
+14	Tool number	+44	Unused
+15	T code	+45	Unused
+16	Unused	+46	Unused
+17	Unused	+47	Unused
+18	Unused	+48	Run hour
+19	Unused	+49	Unused
+20	Unused	+50	Unused
+21	Unused	+51	Unused
+22	Unused	+52	* First variable number for roughing
+23	Unused	+53	* First variable number for finishing
+24	Unused	+54	* First variable number for chamfering
+25	Unused	+55	* First variable number of a figure block
+26	Unused	+56	* Unused
+27	Unused	+57	* Use status flag (0: Not used, 1: Used)
+28	Unused	+58	* First variable number of the preceding process
+29	Unused	+59	* First variable number of the next process

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Some item names depend on the version.

* : System management area –
Avoid data writing by a user program.
 If there are no processes corresponding to +52 to +59, or if the current process corresponds to any of those processes, the area is set to null or 0.

● Calling Subprograms (when bit 3 of parameter No.9771 is 0)

+ 0	Process number	+30	Data 3
+ 1	Unused	+31	Data 4
+ 2	System utilization area (*3)	+32	Unused
+ 3	Machining type (*4)	+33	Unused
+ 4	Unused	+34	Unused
+ 5	Tool post (*6)	+35	Unused
+ 6	Execution cycle (*7)	+36	Unused
+ 7	Unused	+37	Unused
+ 8	Unused	+38	Unused
+ 9	Unused	+39	Unused
+10	Unused	+40	Unused
+11	Unused	+41	Unused
+12	Unused	+42	Unused
+13	Unused	+43	Unused
+14	Unused	+44	Unused
+15	Unused	+45	Unused
+16	Unused	+46	Unused
+17	Unused	+47	Unused
+18	Unused	+48	Run hour
+19	Unused	+49	Unused
+20	Unused	+50	Unused
+21	Unused	+51	Unused
+22	Unused	+52	* First variable number for roughing
+23	Unused	+53	* First variable number for finishing
+24	Unused	+54	* First variable number for chamfering
+25	Unused	+55	* First variable number of a figure block
+26	Unused	+56	* Unused
+27	Sub program	+57	* Use status flag (0: Not used, 1: Used)
+28	Data 1	+58	* First variable number of the preceding process
+29	Data 2	+59	* First variable number of the next process

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Some item names depend on the version.

* : System management area –
Avoid data writing by a user program.
 If there are no processes corresponding to +52 to +59, or if the current process corresponds to any of those processes, the area is set to null or 0.

- Calling Subprograms II (when bit 3 of parameter No.9771 is 1) <available on Ver.2 or later>

+ 0	Process number	+30	Unused
+ 1	Unused	+31	Unused
+ 2	System utilization area (*3)	+32	Data Z
+ 3	Machining type (*4)	+33	Sub program No.
+ 4	Unused	+34	Unused
+ 5	Tool post (*6)	+35	Unused
+ 6	Execution cycle (*7)	+36	Unused
+ 7	Data A	+37	Unused
+ 8	Data B	+38	Unused
+ 9	Data C	+39	Unused
+10	Data I	+40	Unused
+11	Data J	+41	Unused
+12	Data K	+42	Unused
+13	Data D	+43	Unused
+14	Data E	+44	Unused
+15	Data F	+45	Unused
+16	Data H	+46	Unused
+17	Data M	+47	Unused
+18	Data Q	+48	Run hour
+19	Data R	+49	Unused
+20	Data S	+50	Unused
+21	Data T	+51	Unused
+22	Data U	+52	* First variable number for roughing
+23	Data V	+53	* First variable number for finishing
+24	Data W	+54	* First variable number for chamfering
+25	Data X	+55	* First variable number of a figure block
+26	Data Y	+56	* Unused
+27	Unused	+57	* Use status flag (0: Not used, 1: Used)
+28	Unused	+58	* First variable number of the preceding process
+29	Unused	+59	* First variable number of the next process

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Some item names depend on the version.

* : System management area –
Avoid data writing by a user program.
 If there are no processes corresponding to +52 to +59, or if the current process corresponds to any of those processes, the area is set to null or 0.

● C-axis Center Drilling

+ 0	Process number	+30	Unused
+ 1	Unused	+31	Unused
+ 2	System utilization area (*3)	+32	Unused
+ 3	Machining type (*4)	+33	Unused
+ 4	Machining area (*5)	+34	Unused
+ 5	Tool post (Spindle axis selection) (*6)	+35	Unused
+ 6	Machining cycle (*7)	+36	●Program override
+ 7	Machining start point X	+37	Unused
+ 8	Machining start point Z	+38	Unused
+ 9	Unused	+39	Unused
+10	Unused	+40	Unused
+11	Unused	+41	Unused
+12	Unused	+42	Unused
+13	Unused	+43	Automatic preceding process determination flag (*12)
+14	Tool number	+44	■Pass point 1 X
+15	T code	+45	■Pass point 1 Z
+16	Unused	+46	■Pass point 2 X
+17	Unused	+47	■Pass point 2 Z
+18	Tool speed (rpm)	+48	Run hour
+19	Feedrate	+49	Unused
+20	Direction of rotation (1=CW, 2=CCW)	+50	Unused
+21	Unused	+51	Unused
+22	Unused	+52	* First variable number for roughing
+23	Unused	+53	* First variable number for finishing
+24	Milling gear	+54	* First variable number for chamfering
+25	Coolant (1=ON, 2=OFF)	+55	* First variable number of a figure block
+26	Unused	+56	* Unused
+27	Hole pattern (1=equal, 2=unequal)	+57	* Use status flag (0: Not used, 1: Used)
+28	Hole diameter/chamfer diameterer	+58	* First variable number of the preceding process
+29	Dwell time at hole bottom point	+59	* First variable number of the next process

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Some item names depend on the version.

* : System management area –

Avoid data writing by a user program.

If there are no processes corresponding to +52 to +59, or if the current process corresponds to any of those processes, the area is set to null or 0.

● C-axis Drilling

+ 0	Process number	+30	Machining pattern (*14)
+ 1	Machining type (2) (*13)	+31	Decrement in depth of cut
+ 2	System utilization area (*3)	+32	Relief return amount
+ 3	Machining type (*4)	+33	Minimum value for the depth of cut
+ 4	Machining area (*5)	+34	■ Chamfer length/shift amount
+ 5	Tool post (Spindle axis selection) (*6)	+35	■ FEED/Rev 2/return speed/shift direction (*26)
+ 6	Machining cycle (*7)	+36	■ Start feedrate
+ 7	Machining start point X	+37	■ Start clearance
+ 8	Machining start point Z	+38	■ End feedrate
+ 9	● Program override	+39	■ End clearance
+10	Unused	+40	Unused
+11	Unused	+41	Unused
+12	Unused	+42	Unused
+13	Unused	+43	Automatic preceding process determination flag (*12)
+14	Tool number	+44	● Pass point 1 X
+15	T code	+45	● Pass point 1 Z
+16	Unused	+46	● Pass point 2 X
+17	Unused	+47	● Pass point 2 Z
+18	Tool speed	+48	Run hour
+19	Feedrate	+49	Unused
+20	■ Direction of rotation (1=CW, 2=CCW)	+50	Surface speed/speed selection (*9)
+21	Cutting depth	+51	Speed
+22	■ Orientation M	+52	* First variable number for roughing
+23	Unused	+53	* First variable number for finishing
+24	Milling gear	+54	* First variable number for chamfering
+25	Coolant (1=ON, 2=OFF)	+55	* First variable number of a figure block
+26	Unused	+56	* Unused
+27	Hole pattern (1=equal, 2=unequal)	+57	* Use status flag (0: Not used, 1: Used)
+28	Hole diameter	+58	* First variable number of the preceding process
+29	Dwell time at hole bottom point	+59	* First variable number of the next process

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Some item names depend on the version.

*: System management area –

Avoid data writing by a user program.

If there are no processes corresponding to +52 to +59, or if the current process corresponds to any of those processes, the area is set to null or 0.

● C-axis Tapping

+ 0	Process number	+30	Pitch
+ 1	Unused	+31	Unused
+ 2	System utilization area (*3)	+32	Unused
+ 3	Machining type (*4)	+33	Unused
+ 4	Machining area (*5)	+34	Unused
+ 5	Tool post (Spindle axis selection) (*6)	+35	Unused
+ 6	Machining cycle (*7)	+36	Unused
+ 7	Machining start point X	+37	Unused
+ 8	Machining start point Z	+38	Unused
+ 9	Unused	+39	Unused
+10	Unused	+40	Unused
+11	Unused	+41	Unused
+12	Unused	+42	Unused
+13	Unused	+43	Automatic preceding process determination flag (*12)
+14	Tool number	+44	● Pass point 1 X
+15	T code	+45	● Pass point 1 Z
+16	Unused	+46	● Pass point 2 X
+17	Unused	+47	● Pass point 2 Z
+18	Tool speed (rpm)	+48	Run hour
+19	Feedrate	+49	Unused
+20	■ Direction of rotation (1=CW, 2=CCW)	+50	Unused
+21	Unused	+51	Unused
+22	Unused	+52	* First variable number for roughing
+23	Unused	+53	* First variable number for finishing
+24	Milling gear	+54	* First variable number for chamfering
+25	Coolant (1=ON, 2=OFF)	+55	* First variable number of a figure block
+26	Unused	+56	* Unused
+27	Hole pattern (1=equal, 2=unequal)	+57	* Use status flag (0: Not used, 1: Used)
+28	Nominal diameter	+58	* First variable number of the preceding process
+29	Dwell time at hole bottom point	+59	* First variable number of the next process

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Some item names depend on the version.

*: System management area –

Avoid data writing by a user program.

If there are no processes corresponding to +52 to +59, or if the current process corresponds to any of those processes, the area is set to null or 0.

● C-axis Grooving (rough machining)

+ 0	Process number	+30	Unused
+ 1	Unused	+31	Unused
+ 2	System utilization area (*3)	+32	Unused
+ 3	Machining type (*4)	+33	Unused
+ 4	Machining area (*5)	+34	Unused
+ 5	Tool post (Spindle axis selection) (*6)	+35	Unused
+ 6	Machining cycle (*7)	+36	●Program override
+ 7	Machining start point X	+37	Unused
+ 8	Machining start point Z	+38	Unused
+ 9	Unused	+39	Unused
+10	Unused	+40	Unused
+11	Unused	+41	Unused
+12	Unused	+42	Unused
+13	Chamfer amount (*15)	+43	Unused
+14	Tool number	+44	●Pass point 1 X
+15	T code	+45	●Pass point 1 Z
+16	Unused	+46	●Pass point 2 X
+17	Unused	+47	●Pass point 2 Z
+18	Tool speed (rpm)	+48	Run hour
+19	Feedrate-1	+49	Unused
+20	Milling gear	+50	Unused
+21	Feedrate-2	+51	Unused
+22	Unused	+52	* First variable number for roughing
+23	Unused	+53	* First variable number for finishing
+24	Unused	+54	* First variable number for chamfering
+25	Coolant (1=ON, 2=OFF)	+55	* First variable number of a figure block
+26	Unused	+56	* Unused
+27	Groove shape (1=regular, 2=irregular)	+57	* Use status flag (0: Not used, 1: Used)
+28	Groove diameter	+58	* First variable number of the preceding process
+29	Unused	+59	* First variable number of the next process

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Some item names depend on the version.

* : System management area –

Avoid data writing by a user program.

If there are no processes corresponding to +52 to +59, or if the current process corresponds to any of those processes, the area is set to null or 0.

● C-axis Grooving (chamfering)

+ 0	Process number	+30	Unused
+ 1	Unused	+31	Unused
+ 2	System utilization area (*3)	+32	Unused
+ 3	Machining type (*4)	+33	Unused
+ 4	Machining area (*5)	+34	Unused
+ 5	Tool post (Spindle axis selection) (*6)	+35	Unused
+ 6	Machining cycle (*7)	+36	●Program override
+ 7	Machining start point X	+37	Unused
+ 8	Machining start point Z	+38	Unused
+ 9	Unused	+39	Unused
+10	Unused	+40	Unused
+11	Unused	+41	Unused
+12	Unused	+42	Unused
+13	Chamfer (*15)	+43	Unused
+14	Tool number	+44	●Pass point 1 X
+15	T code	+45	●Pass point 1 Z
+16	Unused	+46	●Pass point 2 X
+17	Unused	+47	●Pass point 2 Z
+18	Tool speed (rpm)	+48	Run hour
+19	Feedrate	+49	Unused
+20	Milling gear	+50	Unused
+21	Unused	+51	Unused
+22	Unused	+52	* First variable number for roughing
+23	Unused	+53	* First variable number for finishing
+24	Unused	+54	* First variable number for chamfering
+25	Coolant (1=ON, 2=OFF)	+55	* First variable number of a figure block
+26	Unused	+56	* Unused
+27	Groove shape (1=regular, 2=irregular)	+57	* Use status flag (0: Not used, 1: Used)
+28	Groove diameter	+58	* First variable number of the preceding process
+29	Unused	+59	* First variable number of the next process

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Some item names depend on the version.

* : System management area –

Avoid data writing by a user program.

If there are no processes corresponding to +52 to +59, or if the current process corresponds to any of those processes, the area is set to null or 0.

● C-axis Notching (rough machining)

+ 0	Process number	+30	Unused
+ 1	Unused	+31	Unused
+ 2	System utilization area (*3)	+32	Unused
+ 3	Machining type (*4)	+33	Unused
+ 4	Machining area (*5)	+34	Unused
+ 5	Tool post (Spindle axis selection) (*6)	+35	Unused
+ 6	Machining cycle (*7)	+36	●Program override
+ 7	Unused	+37	Unused
+ 8	Start point Z	+38	Unused
+ 9	End point Z	+39	Unused
+10	Unused	+40	Unused
+11	Unused	+41	Unused
+12	Cutting allowance X	+42	Unused
+13	Chamfer (*15)	+43	Unused
+14	Tool number	+44	●Pass point 1 X
+15	T code	+45	●Pass point 1 Z
+16	Unused	+46	●Pass point 2 X
+17	Unused	+47	●Pass point 2 Z
+18	Tool speed	+48	Run hour
+19	Feedrate	+49	System utilization area (*3)
+20	Milling gear	+50	Unused
+21	Depth of cut	+51	Unused
+22	Finishing allowance X	+52	* First variable number for roughing
+23	Finishing allowance Z	+53	* First variable number for finishing
+24	Unused	+54	* First variable number for chamfering
+25	Coolant (1=ON, 2=OFF)	+55	* First variable number of a figure block
+26	Unused	+56	* Unused
+27	Unused	+57	* Use status flag (0: Not used, 1: Used)
+28	Unused	+58	* First variable number of the preceding process
+29	Unused	+59	* First variable number of the next process

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Some item names depend on the version.

* : System management area –

Avoid data writing by a user program.

If there are no processes corresponding to +52 to +59, or if the current process corresponds to any of those processes, the area is set to null or 0.

● C-axis Notching (finish machining)

+ 0	Process number	+30	Unused
+ 1	Unused	+31	Unused
+ 2	System utilization area (*3)	+32	Unused
+ 3	Machining type (*4)	+33	Unused
+ 4	Machining area (*5)	+34	Unused
+ 5	Tool post (Spindle axis selection) (*6)	+35	Unused
+ 6	Machining cycle (*7)	+36	●Program override
+ 7	Unused	+37	Unused
+ 8	Start point Z	+38	Unused
+ 9	End point Z	+39	Unused
+10	Unused	+40	Unused
+11	Unused	+41	Unused
+12	Cutting allowance X	+42	Unused
+13	Chamfer (*15)	+43	Unused
+14	Tool number	+44	●Pass point 1 X
+15	T code	+45	●Pass point 1 Z
+16	Unused	+46	●Pass point 2 X
+17	Unused	+47	●Pass point 2 Z
+18	Tool speed	+48	Run hour
+19	Feedrate	+49	System utilization area (*3)
+20	Milling gear	+50	Unused
+21	Unused	+51	Unused
+22	Finishing allowance X	+52	* First variable number for roughing
+23	Finishing allowance Z	+53	* First variable number for finishing
+24	Unused	+54	* First variable number for chamfering
+25	Coolant (1=ON, 2=OFF)	+55	* First variable number of a figure block
+26	Unused	+56	* Unused
+27	Unused	+57	* Use status flag (0: Not used, 1: Used)
+28	Unused	+58	* First variable number of the preceding process
+29	Unused	+59	* First variable number of the next process

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Some item names depend on the version.

* : System management area –

Avoid data writing by a user program.

If there are no processes corresponding to +52 to +59, or if the current process corresponds to any of those processes, the area is set to null or 0.

● C-axis Notching (chamfering)

+ 0	Process number	+30	Unused
+ 1	Unused	+31	Unused
+ 2	System utilization area (*3)	+32	Unused
+ 3	Machining type (*4)	+33	Unused
+ 4	Machining area (*5)	+34	Unused
+ 5	Tool post (Spindle axis selection) (*6)	+35	Unused
+ 6	Machining cycle (*7)	+36	●Program override
+ 7	Unused	+37	Unused
+ 8	Start point Z	+38	Unused
+ 9	End point Z	+39	Unused
+10	Unused	+40	Unused
+11	Unused	+41	Unused
+12	Unused	+42	Unused
+13	Chamfer amount (*15)	+43	Unused
+14	Tool number	+44	●Pass point 1 X
+15	T code	+45	●Pass point 1 Z
+16	Unused	+46	●Pass point 2 X
+17	Unused	+47	●Pass point 2 Z
+18	Tool speed (rpm)	+48	Run hour
+19	Feedrate	+49	System utilization area (*3)
+20	Milling gear	+50	Unused
+21	Unused	+51	Unused
+22	Unused	+52	* First variable number for roughing
+23	Unused	+53	* First variable number for finishing
+24	Unused	+54	* First variable number for chamfering
+25	Coolant (1=ON, 2=OFF)	+55	* First variable number of a figure block
+26	Unused	+56	* Unused
+27	Unused	+57	* Use status flag (0: Not used, 1: Used)
+28	Unused	+58	* First variable number of the preceding process
+29	Unused	+59	* First variable number of the next process

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Some item names depend on the version.

* : System management area –
Avoid data writing by a user program.
If there are no processes corresponding to +52 to +59, or if the current process corresponds to any of those processes, the area is set to null or 0.

● C-axis Cylindrical Machining (rough machining)

+ 0	Process number	+30	Development drawing : Z-axis end coordinate (*16)
+ 1	Unused	+31	Development drawing : C-axis diameter (*16)
+ 2	System utilization area (*3)	+32	Unused
+ 3	Machining type (*4)	+33	Unused
+ 4	Unused	+34	Unused
+ 5	Tool post (Spindle axis selection) (*6)	+35	Unused
+ 6	Machining cycle (*7)	+36	● Program override
+ 7	Grooving start point X	+37	Unused
+ 8	Unused	+38	Unused
+ 9	Unused	+39	Unused
+10	Unused	+40	Unused
+11	Unused	+41	Unused
+12	Unused	+42	Unused
+13	Chamfer amount (*15)	+43	Unused
+14	Tool number	+44	● Pass point 1 X
+15	T code	+45	● Pass point 1 Z
+16	Unused	+46	● Pass point 2 X
+17	Unused	+47	● Pass point 2 Z
+18	Tool speed (rpm)	+48	Run hour
+19	Feedrate-1	+49	System utilization area (*3)
+20	Milling gear	+50	Unused
+21	Feedrate-2	+51	Unused
+22	Unused	+52	* First variable number for roughing
+23	Unused	+53	* First variable number for finishing
+24	Unused	+54	* First variable number for chamfering
+25	Coolant (1=ON, 2=OFF)	+55	* First variable number of a figure block
+26	Unused	+56	* Unused
+27	Depth of the groove	+57	* Use status flag (0: Not used, 1: Used)
+28	Groove diameter	+58	* First variable number of the preceding process
+29	Development drawing : Z-axis start coordinate (*16)	+59	* First variable number of the next process

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Some item names depend on the version.

* : System management area –

Avoid data writing by a user program.

If there are no processes corresponding to +52 to +59, or if the current process corresponds to any of those processes, the area is set to null or 0.

● C-axis Cylindrical Machining (chamfering)

+ 0	Process number	+30	Development drawing : Z-axis end coordinate (*16)
+ 1	Unused	+31	Development drawing : C-axis diameter (*16)
+ 2	System utilization area (*3)	+32	Unused
+ 3	Machining type (*4)	+33	Unused
+ 4	Unused	+34	Unused
+ 5	Tool post (*6)	+35	Unused
+ 6	Machining cycle (*7)	+36	● Program override
+ 7	Grooving start coordinate X	+37	Unused
+ 8	Unused	+38	Unused
+ 9	Unused	+39	Unused
+10	Unused	+40	Unused
+11	Unused	+41	Unused
+12	Unused	+42	Unused
+13	Chamfer amount (*15)	+43	Unused
+14	Tool number	+44	● Pass point 1 X
+15	T code	+45	● Pass point 1 Z
+16	Unused	+46	● Pass point 2 X
+17	Unused	+47	● Pass point 2 Z
+18	Tool speed (rpm)	+48	Run hour
+19	Feedrate	+49	System utilization area (*3)
+20	Milling gear	+50	Unused
+21	Unused	+51	Unused
+22	Unused	+52	* First variable number for roughing
+23	Unused	+53	* First variable number for finishing
+24	Unused	+54	* First variable number for chamfering
+25	Coolant (1=ON, 2=OFF)	+55	* First variable number of a figure block
+26	Unused	+56	* Unused
+27	Depth of the groove	+57	* Use status flag (0: Not used, 1: Used)
+28	Groove diameter	+58	* First variable number of the preceding process
+29	Development drawing : Z-axis start coordinate (*16)	+59	* First variable number of the next process

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Some item names depend on the version.

* : System management area –

Avoid data writing by a user program.

If there are no processes corresponding to +52 to +59, or if the current process corresponds to any of those processes, the area is set to null or 0.

● Transfer, Auxiliary Process

+ 0	Process number	+30	Display data 10 (Data format)
+ 1	Unused	+31	Display data 11
+ 2	System utilization area (*3)	+32	Display data 11 (Data format)
+ 3	Machining type (*4)	+33	Display data 12
+ 4	Unused	+34	Display data 12 (Data format)
+ 5	Tool post (Spindle axis selection) (*6, *21)	+35	
+ 6	Machining cycle (*7, *21)	+36	
+ 7	Type	+37	
+ 8	Type (Data format)	+38	
+ 9	Head	+39	
+10	Head (Data format)	+40	
+11	Display data 1	+41	Data area for user programs used with the macro executor
+12	Display data 1 (Data format)	+42	
+13	Display data 2	+43	
+14	Display data 2 (Data format)	+44	
+15	Display data 3	+45	
+16	Display data 3 (Data format)	+46	
+17	Display data 4	+47	
+18	Display data 4 (Data format)	+48	
+19	Display data 5	+49	
+20	Display data 5 (Data format)	+50	
+21	Display data 6	+51	Surface speed/speed selection (*9)
+22	Display data 6 (Data format)	+52	Speed
+23	Display data 7	+53	* First variable number for roughing
+24	Display data 7 (Data format)	+54	* First variable number for finishing
+25	Display data 8	+55	* First variable number for chamfering
+26	Display data 8 (Data format)	+56	* First variable number of a figure block
+27	Display data 9	+57	* Unused
+28	Display data 9 (Data format)	+58	* Use status flag (0: Not used, 1: Used)
+29	Display data 10	+59	* First variable number of the preceding process
			* First variable number of the next process

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Some item names depend on the version.

* : System management area –

Avoid data writing by a user program.

If there are no processes corresponding to +52 to +59, or if the current process corresponds to any of those processes, the area is set to null or 0.

● M-code Process

+ 0	Process number	+30	Unused
+ 1	Unused	+31	Unused
+ 2	System utilization area (*3)	+32	Unused
+ 3	Machining type (*4)	+33	Unused
+ 4	Unused	+34	Unused
+ 5	Tool post (Spindle axis selection) (*6)	+35	Unused
+ 6	Machining cycle (*7)	+36	Unused
+ 7	Unused	+37	Unused
+ 8	Unused	+38	Unused
+ 9	M-code (1)	+39	Unused
+10	M-code (2)	+40	Unused
+11	M-code (3)	+41	Unused
+12	M-code (4)	+42	Unused
+13	M-code (5)	+43	Unused
+14	Unused	+44	Unused
+15	Unused	+45	Unused
+16	Unused	+46	Unused
+17	Unused	+47	Unused
+18	Unused	+48	Run hour
+19	Unused	+49	Unused
+20	Unused	+50	Unused
+21	Unused	+51	Unused
+22	Unused	+52	* First variable number for roughing
+23	Unused	+53	* First variable number for finishing
+24	Unused	+54	* First variable number for chamfering
+25	Unused	+55	* First variable number of a figure block
+26	Unused	+56	* Unused
+27	Unused	+57	* Use status flag (0: Not used, 1: Used)
+28	Unused	+58	* First variable number of the preceding process
+29	Unused	+59	* First variable number of the next process

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Some item names depend on the version.

* : System management area –

Avoid data writing by a user program.

If there are no processes corresponding to +52 to +59, or if the current process corresponds to any of those processes, the area is set to null or 0.

● Program End Process

+ 0	Process number	+30	Unused
+ 1	Unused	+31	Unused
+ 2	System utilization area (*3)	+32	Unused
+ 3	Machining type (*4)	+33	Unused
+ 4	Unused	+34	Unused
+ 5	Tool post (Spindle axis selection) (*6)	+35	Unused
+ 6	Machining cycle (*7)	+36	Unused
+ 7	Unused	+37	Unused
+ 8	Unused	+38	Unused
+ 9	Return code	+39	Unused
+10	Return point X	+40	Unused
+11	Return point Z	+41	Unused
+12	Return point C	+42	Unused
+13	Unused	+43	Unused
+14	End M code	+44	Unused
+15	Loop count	+45	Unused
+16	Unused	+46	Unused
+17	Unused	+47	Unused
+18	Unused	+48	Run hour
+19	Unused	+49	Unused
+20	Unused	+50	Unused
+21	Unused	+51	Unused
+22	Unused	+52	* First variable number for roughing
+23	Unused	+53	* First variable number for finishing
+24	Unused	+54	* First variable number for chamfering
+25	Unused	+55	* First variable number of a figure block
+26	Unused	+56	* Unused
+27	Unused	+57	* Use status flag (0: Not used, 1: Used)
+28	Unused	+58	* First variable number of the preceding process
+29	Unused	+59	* First variable number of the next process

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Some item names depend on the version.

* : System management area –

Avoid data writing by a user program.

If there are no processes corresponding to +52 to +59, or if the current process corresponds to any of those processes, the area is set to null or 0.

● Y-axis Center Drilling <abailabel on Ver.2 or later>

+ 0	Process number	+30	Unused
+ 1	Unused	+31	Unused
+ 2	System utilization area (*3)	+32	Unused
+ 3	Machining type (*4)	+33	Unused
+ 4	Machining area (*5)	+34	Unused
+ 5	Tool post (Spindle axis selection) (*6)	+35	Unused
+ 6	Machining cycle (*7)	+36	Program override
+ 7	Machining start point X	+37	Unused
+ 8	Machining start point Z	+38	Unused
+ 9	Unused	+39	Unused
+10	Unused	+40	Skip point 1
+11	Unused	+41	Skip point 2
+12	Unused	+42	Skip point 3
+13	Unused	+43	Automatic preceding process determination flag (*12)
+14	Tool number	+44	Pass point 1 X
+15	T code	+45	Pass point 1 Z
+16	Unused	+46	Pass point 2 X
+17	Unused	+47	Pass point 2 Z
+18	Tool speed (rpm)	+48	Run hour
+19	Feedrate	+49	Unused
+20	Unused	+50	Unused
+21	Unused	+51	Unused
+22	Unused	+52	* First variable number for roughing
+23	Unused	+53	* First variable number for finishing
+24	Milling gear	+54	* First variable number for chamfering
+25	Coolant (1=ON, 2=OFF)	+55	* First variable number of a figure block
+26	Unused	+56	* Unused
+27	Hole pattern (*23)	+57	* Use status flag (0: Not used, 1: Used)
+28	Nominal diameterer	+58	* First variable number of the preceding process
+29	Dwell time at hole bottom point	+59	* First variable number of the next process

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Some item names depend on the version.

* : System management area –
Avoid data writing by a user program
If there are no processes corresponding to +52 to +59, or if the current process corresponds to any of those processes, the area is set to null or 0.

● Y-axis Drilling <available on Ver.2 or later>

+ 0	Process number	+30	Machining pattern (*14)
+ 1	Machining type (2) (*13)	+31	Decrement in depth of cut
+ 2	System utilization area (*3)	+32	Relief return amount
+ 3	Machining type (*4)	+33	Minimum value for the depth of cut
+ 4	Machining area (*5)	+34	Unused
+ 5	Tool post (Spindle axis selection) (*6)	+35	Unused
+ 6	Machining cycle (*7)	+36	Program override
+ 7	Machining start point X	+37	Unused
+ 8	Machining start point Z	+38	Unused
+ 9	Unused	+39	Unused
+10	Unused	+40	Skip point 1
+11	Unused	+41	Skip point 2
+12	Unused	+42	Skip point 3
+13	Unused	+43	Automatic preceding process determination flag (*12)
+14	Tool number	+44	Pass point 1 X
+15	T code	+45	Pass point 1 Z
+16	Unused	+46	Pass point 2 X
+17	Unused	+47	Pass point 2 Z
+18	Tool speed (rpm)	+48	Run hour
+19	Feedrate	+49	Unused
+20	Unused	+50	Unused
+21	Cutting depth	+51	Unused
+22	Unused	+52	* First variable number for roughing
+23	Unused	+53	* First variable number for finishing
+24	Milling gear	+54	* First variable number for chamfering
+25	Coolant (1=ON, 2=OFF)	+55	* First variable number of a figure block
+26	Unused	+56	* Unused
+27	Hole pattern (*23)	+57	* Use status flag (0: Not used, 1: Used)
+28	Hole diameterer	+58	* First variable number of the preceding process
+29	Dwell time at hole bottom point	+59	* First variable number of the next process

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Some item names depend on the version.

* : System management area –

Avoid data writing by a user program.

If there are no processes corresponding to +52 to +59, or if the current process corresponds to any of those processes, the area is set to null or 0.

● Y-axis Tapping <available on Ver.2 or later>

+ 0	Process number	+30	Pitch
+ 1	Unused	+31	Unused
+ 2	System utilization area (*3)	+32	Unused
+ 3	Machining type (*4)	+33	Unused
+ 4	Machining area (*5)	+34	Unused
+ 5	Tool post (Spindle axis selection) (*6)	+35	Unused
+ 6	Machining cycle (*7)	+36	Unused
+ 7	Machining start point X	+37	Unused
+ 8	Machining start point Z	+38	Unused
+ 9	Unused	+39	Unused
+10	Unused	+40	Skip point 1
+11	Unused	+41	Skip point 2
+12	Unused	+42	Skip point 3
+13	Unused	+43	Automatic preceding process determination flag (*12)
+14	Tool number	+44	Pass point 1 X
+15	T code	+45	Pass point 1 Z
+16	Unused	+46	Pass point 2 X
+17	Unused	+47	Pass point 2 Z
+18	Tool speed (rpm)	+48	Run hour
+19	Feedrate	+49	Unused
+20	Unused	+50	Unused
+21	Unused	+51	Unused
+22	Unused	+52	* First variable number for roughing
+23	Unused	+53	* First variable number for finishing
+24	Milling gear	+54	* First variable number for chamfering
+25	Coolant (1=ON, 2=OFF)	+55	* First variable number of a figure block
+26	Unused	+56	* Unused
+27	Hole pattern (*23)	+57	* Use status flag (0: Not used, 1: Used)
+28	Nominal diameterer	+58	* First variable number of the preceding process
+29	Dwell time at hole bottom point	+59	* First variable number of the next process

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Some item names depend on the version.

* : System management area –

Avoid data writing by a user program

If there are no processes corresponding to +52 to +59, or if the current process corresponds to any of those processes, the area is set to null or 0.

● Y-axis Milling (rough machining) <available on Ver.2 or later>

+ 0	Process number	+30	Unused
+ 1	Unused	+31	Unused
+ 2	System utilization area (*3)	+32	Shift direction (*26)
+ 3	Machining type (*4)	+33	Unused
+ 4	Machining area (*5)	+34	Unused
+ 5	Tool post (Spindle axis selection) (*6)	+35	Unused
+ 6	Machining cycle (*7)	+36	Program override
+ 7	Machining start point X	+37	Unused
+ 8	Machining start point Z	+38	Unused
+ 9	Unused	+39	Unused
+10	Unused	+40	Unused
+11	Unused	+41	Unused
+12	Unused	+42	Unused
+13	Chamfer amount (*15)	+43	Unused
+14	Tool number	+44	Pass point 1 X
+15	T code	+45	Pass point 1 Z
+16	Unused	+46	Pass point 2 X
+17	Unused	+47	Pass point 2 Z
+18	Tool speed (rpm)	+48	Run hour
+19	Feedrate X, Y (end face)/Y, Z (side face)	+49	System utilization area (*3)
+20	Milling gear	+50	Unused
+21	Feedrate Z (end face)/X (side face)	+51	Unused
+22	Unused	+52	* First variable number for roughing
+23	Unused	+53	* First variable number for finishing
+24	Unused	+54	* First variable number for chamfering
+25	Coolant (1=ON, 2=OFF)	+55	* First variable number of a figure block
+26	Escape speed Z (end face)/X(side face)	+56	* Unused
+27	Cut depth	+57	* Use status flag (0: Not used, 1: Used)
+28	Endmill diameter	+58	* First variable number of the preceding process
+29	Unused	+59	* First variable number of the next process

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Some item names depend on the version.

* : System management area –

Avoid data writing by a user program.

If there are no processes corresponding to +52 to +59, or if the current process corresponds to any of those processes, the area is set to null or 0.

● Y-axis Milling (chamfering) <available on Ver.2 or later>

+ 0	Process number	+30	Unused
+ 1	Unused	+31	Unused
+ 2	System utilization area (*3)	+32	Shift direction (*26)
+ 3	Machining type (*4)	+33	Unused
+ 4	Machining area (*5)	+34	Unused
+ 5	Tool post (Spindle axis selection) (*6)	+35	Unused
+ 6	Machining cycle (*7)	+36	Program override
+ 7	Machining start point X	+37	Unused
+ 8	Machining start point Z	+38	Unused
+ 9	Unused	+39	Unused
+10	Unused	+40	Unused
+11	Unused	+41	Unused
+12	Unused	+42	Unused
+13	Chamfer amount (*15)	+43	Unused
+14	Tool number	+44	Pass point 1 X
+15	T code	+45	Pass point 1 Z
+16	Unused	+46	Pass point 2 X
+17	Unused	+47	Pass point 2 Z
+18	Tool speed (rpm)	+48	Run hour
+19	Feedrate	+49	System utilization area (*3)
+20	Milling gear	+50	Unused
+21	Unused	+51	Unused
+22	Unused	+52	* First variable number for roughing
+23	Unused	+53	* First variable number for finishing
+24	Unused	+54	* First variable number for chamfering
+25	Coolant (1=ON, 2=OFF)	+55	* First variable number of a figure block
+26	Unused	+56	* Unused
+27	Cut depth	+57	* Use status flag (0: Not used, 1: Used)
+28	Endmil diameter	+58	ϕ* First variable number of the preceding process
+29	Unused	+59	* First variable number of the next process

●: Ver.2 or later, ■: Ver.3 or later, (*?): See the note below.

NOTE

Some item names depend on the version.

* : System management area –

Avoid data writing by a user program.

If there are no processes corresponding to +52 to +59, or if the current process corresponds to any of those processes, the area is set to null or 0.

NOTE

- *1 : Coolant (initial setting data)
 In new process generation, the data set here is automatically set as an initial value in the item of coolant for each process. If the initial setting of the item of coolant is modified during editing, the new value is reflected in all processes of the program being edited.
- *2 : Finishing allowances X and Z (initial setting data)
 In new process generation, the data set here is automatically set as initial values in the items of finishing allowances for each process. If the initial setting of an item of allowance is modified during editing, the new value is reflected in all processes (except C-axis notching) of the program being edited.
- *3 : System area
 This area is used by the system. Macro programs cannot understand any data contained in this area.
- *4 : Type of machining

1 : Bar machining	2 : Tracing	3 : Residual machining
4 : End facing	5 : Threading	6 : Grooving
7 : Necking	8 : Center drilling	9 : Drilling
10 : Tapping	11 : Single action	
13 : Subprogram calling	14 : C-axis center drilling	15 : C-axis drilling
16 : C-axis tapping	17 : C-axis grooving	18 : C-axis notching
19 : C-axis cylindrical machining	20 : Transfer	21 : Auxiliary
22 : M process	23 : End process	24 : Y-axis center drilling
25 : Y-axis drilling	26 : Y-axis tapping	27 : Y-axis milling
- *5 : Machining area (depending on the type of machining)
 - <Bar machining/tracing>

1 : Outer surface edge	2 : Outer non-edge surface
3 : Inner surface edge	4 : Inner MID
2 : End face edge	6 : End face non-edge surface
7 : OUT-ENDBK	8 : OUT-MIDBK
9 : INN-ENDBK	10 : INN-MIDBK
11 : FACE-BACK	12 : FACE-MDBK (No.7 to No.12 are available only for bar machining)
 - <Residual machining>

1 : Outer surface	2 : Inner surface	3 : End face
4 : BOTTOM UED		
 - <Threading>

1 : Outer surface	2 : Inner surface
-------------------	-------------------
 - <Grooving>

1 : Outer surface	2 : Inner surface	3 : End face
-------------------	-------------------	--------------
 - <Necking>

1 : Outer surface right side	2 : Outer surface left side
3 : Inner surface right side	4 : Inner surface left side
5 : End face upper side	6 : End face lower side
 - <C-axis center drilling/C-axis drilling/C-axis tapping/C-axis grooving/C-axis notching/
 Y-axis center drilling/Y-axis drilling/Y-axis tapping/Y-axis milling>

1 : End face	2 : Side face
--------------	---------------
- *6 : Tool post selection (Spindle-axis selection)

1 : Tool post 1	2 : Tool post 2
3 : Both turret, both spindle	

NOTE

- *7 : Process cycle, execution cycle

1 : Rough machining	2 : Finish machining	3 : Chamfering
---------------------	----------------------	----------------

[Usually, this process cycle is automatically set at new process generation to divide processes into rough machining, finish machining, and chamfering, and to arrange the order of these operation so that rough machining is performed first. However, in grooving (excluding trapezoid grooving), single action, measurement, and subprogram call, this cycle is displayed as an execution cycle on the screen to allow modifications to be made on the screen. Thus, the order can be arranged so that rough machining is performed first.]
- *8 : Spindle gear

1 : Automatic	2 : Low speed	3 : Intermediate speed
1	4 : Intermediate speed 2	5 : High speed
- *9 : Surface speed/speed selection

0 (or null) : Surface speed	1 : Speed
-----------------------------	-----------
- *10 : Process pattern (grooving)

1 : Ordinary	2 : Slant	3 : Trapezoid
4 : Thread groove (available on and after Ver. 2)		
- *11 : Necking figure

1 : General-purpose	2 : Necking 1 for abrasion
3 : Necking 2 for abrasion	4 : Necking for threading
- *12 : Automatic preceding process determination flag

1	: Process generated by automatic preceding process determination
0 or (null)	: Process generated by ordinary editing (MDI key input). (However, if the automatic preceding process determination function is activated, this flag is set to 1 even for the last process.)
- *13 : Type of machining (2)
 - <Center drill/C-axis center drill> (available on Ver. 3)

1 : Center	2 : Center+Chamfer	3 : Starting
4 : Starting+Chamfer		
 - <Drilling>

1 : Drilling	2 : Reamer	3 : Boring
4 : Endmill (available on Ver.3)		
5 : Throw-away drill (available on Ver.3)		
 - <C-axis drilling>

1 : Drilling	2 : Reamer	3 : Boring
4 : Endmill (available on Ver.3)		
- *14 : Machining pattern
 - In case of the Ver.1 and Ver.2

1 : Drilling	2 : Pecking	3 : Hi-spd. pecking
--------------	-------------	---------------------
 - In case of the Ver.3
 - <Drilling/C-axis drilling>

1 : Hole drilling	2 : Hole pecking	3 : Hole hi-spd. pecking
4 : Penetrate drilling	5 : Penetrate pecking	
6 : Penetrate hi-spd. pecking		
 - <Endmill/C-axis endmill>

1 : Residual cutting	2 : Spot-facing	
----------------------	-----------------	--
 - <Reaming/C-axis reaming>

1 : Hole	2 : Penetrate	
----------	---------------	--
- *15 : Chamfering amount

When a value other than 0 is entered here, a chamfering process is generated. However, this does not apply if a chamfering processing already exists. In this case, such a process can be deleted only by pressing the [process deletion] key.
- *16 : Development

These areas are used only for development display.

NOTE

- *17 : Groove diameter/groove depth selection (Groove depth selected always when an end face is machined)

0 (or null) : Groove depth	1 : Groove diameter
----------------------------	---------------------
- *18 : Reference direction (depending on the machining area)
 - <Outer surface>

1 : Left-reference	2 : Right-reference
--------------------	---------------------
 - <Inner surface>

1 : Left-reference (fixed)	
----------------------------	--
 - <End face>

1 : Down-reference	2 : Up-reference
--------------------	------------------
- *19 : Cutting method (1)
 - In case of Ver.2 and Ver.3

1 : Constant depth, half side cutting	2 : Constant depth, zigzag cutting
3 : Constant depth, both side cutting	4 : Constant depth, half side cutting
5 : Constant depth, zigzag cutting	6 : Constant depth, both side cutting
 - In case of Ver.1

1 : Constant depth	2 : Constant depth
--------------------	--------------------
- *20 : Cutting method (2)
 - Ver.1 only

1 : Half side cutting	2 : Zigzag cutting
-----------------------	--------------------
- *21 : Tool post selection, process cycle
 The items of tool post selection (auxiliary) and process cycle (auxiliary) are to be set with a user program.
- *22 : Trapezoidal groove, thread groove - figure editing flag (initial setting)

0 : Edit end	1 : Trapezoidal groove editing
2 : Thread groove editing (available on and after Ver.2)	
<Null>: No trapezoidal grooving or no thread grooving	
- *23: Hole pattern

1 : Circle	2 : Lattice	3 : Optional
------------	-------------	--------------
- *24: Cut number/cut depth

0 (or null) : Cut number	1 : Cut depth
--------------------------	---------------
- *25: Thread type

1 : General	2 : Metric thread	3 : Unified thread
4 : PT thread	5 : PF thread	
- *26: Shift direction
 - <C-axis drilling (boring)> <Ver.3 only>

1 : +	2 : -
-------	-------
 - <Y-axis milling>

1 : Center	2 : Right	3 : Left
------------	-----------	----------
- *27: Tool angle and cutting edge angle of tool to be used (necking)
 The data is copied from the tool file immediately before the process is executed.
- *28: End point Z/hole depth <Ver.3 only>
 - <Center drill/drill/tap>

0 (or null) : End point Z	1 : Hole depth
---------------------------	----------------
 - <C-axis center drill/C-axis drill/C-axis tap>

0 (or null) : Hole depth	1 : End point Z/X
--------------------------	-------------------
- *29: Type (Single action II) <Ver.3 only>

1 : Side	2 : Front drill	3 : C-open drill
4 : C-front mill	5 : C-open mill	6 : Y-open drill
7 : Y-front mill	8 : Y-open mill	

(The data is used for plane selection or animated simulation in single action II.)

(c) Data structure of an auxiliary process and transfer process

The input formats and display formats of data items such as type, head, and display data depend on the data format values specified in pairs for such data items.

(Data format) = -1 : The data item is not displayed. The cursor cannot be moved to the item. The field for a data item not displayed is front-justified, that is, the field displays the next data item without leaving space.

(Data format) < 10000 : The data is numeric data, and numeric keys are used for data input. A data format value represents the number of decimal places.

(Data format) \geq 10000 : The data provides a string indication. A soft key is used for data input.

(Data format) \geq 20000 : The data is numeric data, and soft keys and numeric keys can be used for data input.

(Data format) = *AB** : When A= 0, the data is normally displayed.
When A=1, the data is displayed in reverse video.
When B=1, the data is displayed in red.
When B=2, the data is displayed in green.
When B=3, the data is displayed in yellow.
When B=4, the data is displayed in blue.
When B=5, the data is displayed in purple.
When B=6, the data is displayed in light blue.
When B=0, 7, or 9, the data is displayed in white.

(Data format) = 100000 : The data represents a surface speed/speed. Its display and data input processing are performed exactly in the same way as for other processes.

(Data format) = 100001 : The data provides a coolant ON/OFF indication (1=ON, 2=OFF). Soft keys and numeric keys can be used for data input.

(Data format) = 200000 : The data provides a string indication. Soft keys and numeric keys can be used for data input.

(Data format) = 300001 : The data represents a tool ID number.
Soft keys and numeric keys can be used
for data input.

(Data format) = 300002 : The data represents a T code. Soft keys
and numeric keys can be used for data
input.

(d) Examples of command format

(i) When a process is to be searched for using the process data and
offset

#9895 = (search mode) ; -1.

#9892 = (process data) ; -2.

#9893 = (offset number) ; -3.

#9892 = (process data) ; -4.

#9893 = (offset number) ; -5.

#9899 = -1 ; -6.

#???? = #9898 ; -7.

1. Sets #9895=0 when an editing program is searched for, or
sets #9895 = 1 when an executable program is searched for.

2., 4. Sets reference data used for process search operation in
#9892.

3., 5. Sets the offset number in #9893.

6. Enters the completion code.

7. Reads the first macro variable number, set in #9898, of a
found process.

NOTE

1 Be sure to specify #9892 first, then specify #9893. A pair
of these two variables makes up a command. Up to five
pairs can be specified until -1 is set in #9899. If more than
five pairs are specified, those pairs beyond the first five are
ignored. If the number of specified #9892 variables does
not match the number of specified #9893 variables, the
error code (99) is set in #9898.

2 Process search operation starts with the process
immediately after the process set in #9898. So, in order to
perform process search operation starting with the first
process, once perform a search operation that causes an
error intentionally to set #9898=99.

(ii) When the process data of the process currently displayed is to be
read

#???? = # [#9890 + (offset number)] -1.

1. Reads the offset added to #9890 containing the first macro
variable number of the process currently displayed.

(iii) When the initial setting data of the program currently displayed is to be read

$\#???? = \# [\#9891 + (\text{offset number})] - 1.$

1. Reads the offset added to #9891 containing the first macro variable number of the initial setting data of the program currently displayed.

(iv) Examples of execution

- When a process being edited is to be searched for using the process data and its offset

[A process of bar outer surface rough machining is searched for which uses a tool with the tool ID number 101.]

$\#9895 = 0$; Search mode (editing program)

$\#9899 = -1$; Completion code (to set $\#9898 = 99$)

$\#9892 = 1$; Bar machining

$\#9893 = 3$; Type of machining

$\#9892 = 1$; Rough machining

$\#9893 = 6$; Machining cycle

$\#9892 = 101$; Tool ID number 101

$\#9893 = 14$; Tool ID number

$\#9899 = -1$; Completion code

$\#10500 = \#9898$; Loads the first macro variable number of a found process into #10500

- When the process data of the process currently displayed is to be read

[The machining type of the process currently displayed is read.]

$\#12345 = \# [\#9890 + 3]$

The internal code representing the machining type of the process currently displayed is read into #12345.

E.6.3 Software Package Associated with the Interface Between User Programs and the System

E.6.3.1 Overview

With the FANUC Super CAP T Ver. 1, 2, 3, a user program for use with the macro executor can create a dedicated screen as part of the conversational programming menu. In addition, the status of the system can be obtained with a user program.

E.6.3.2 Interface Between the Conversational Programming Menu and User Programs

- (1) System variables for specifying multi-window display
- #9111 = X coordinate of the top-left corner of a window
 - #9112 = Y coordinate of the top-left corner of a window
 - #9113 = Number of characters in the X direction
(horizontal direction on the screen)
 - #9114 = Number of characters in the Y direction
(vertical direction on the screen)
 - #9115 = Line type of the frame (0: thin, 1: heavy)
 - #9116 = Color of the frame (0: black, 1: red, 2: green, 3: yellow,
4: blue, 5: purple, 6: light blue, 7: white)
 - #9120 = Display request to the system
 - When 1 is entered, the system opens the window specified by the information of #9111 to #9116. When 2 is entered, the system closes the window. Upon completion of processing, the system initializes #9120 to 0.
To return from the detail screen to the process screen, set 99. Then the system displays the process screen.

NOTE

When any of the variables above assumes a null or a value beyond a specifiable range, the window is not displayed.

- #9119 = Redisplay request to the user program
 - When there is no request from the user program to close the window, the system may close the window, for example, to switch to another screen. If the system closes the window for its reason, the user program is expected to make another request to open the window. In such a case, the system sets 1. In response to this, the user program is to set the variable in the system variable to direct window display, then the user program is to output the display request to the system. When the user program is read, the system initializes #9119 to 0.
The system sets #9119 to 1 when the cursor is moved.

- (2) Program numbers of user programs for screen display
- O1000 = User program for detail data screen display
 - When the [DETAIL DATA] soft key is pressed (to display the detail data screen) in a transfer process, the program is called in each cycle in task processing internal to the CNC.
 - O1001 = User program for process data screen display
 - When a window is to be displayed on the process data screen in a transfer process, the program is called in each cycle in task processing internal to the CNC.
 - O1002 = Program for process data initialization
 - When a transfer process is newly generated, the program is called just once before the screen for the process is displayed.
 - O1003 = Program for termination processing of process data, and so forth
 - When a transfer process is terminated, the program is called just once.
 - O1004 = User program for detail data screen display
 - When the [DETAIL DATA] soft key is pressed (to display the detail data screen) in an auxiliary process, the program is called in each cycle in task processing internal to the CNC.
 - O1005 = User program for process data screen display
 - When a window is to be displayed on the process data screen in an auxiliary process, the program is called in each cycle in task processing internal to the CNC.
 - O1006 = Program for process data and cursor position initialization
 - When an auxiliary process is newly generated, the program is called just once before the screen for the process is displayed.
 - O1007 = Program for termination processing of process data, and so forth
 - When an auxiliary process is terminated, the program is called just once.

- Machining type identification

The first variable number of the process block currently edited is set in #9890. So the type of machining can be checked by making a reference as follows:

$$\#???? = \# [\#9890 + 3]$$

(3) Input key monitoring and echo back display

When a screen is displayed with a user program as described in (2) above, key input can be read using system variables #8501 and #8503. The code and specification of each key is the same as in the case of a standard macro executor, with some exceptions described below.

Note, however, that the echo back display of key input need not be performed by the user program, but is performed by the conversational system as with other conversational process data screens.

Since the detail data screens for a transfer process and auxiliary process as well as the data structure are made open to user programs, the system variables listed below are added for key-in buffer display.

- #9124 : In key-in buffer display on a detail data screen, this variable indicates whether the input is numeric key input or soft key input. In the latter case, this variable also indicates the number of decimal places of numeric data.
 0 - 7 : Number of decimal places in the case of numeric key input
 99 : Soft key input
 When a value other than the above is entered, 3 is set in the case of mm input, or 4 is set in the case of inch input.
- #9125 : 1 - Warning being displayed
 0 - Normal state
 The system may display a warning (associated with numeric calculation input, etc.) on line 20. In such a case, #9125=1 is set. When a user program provides a string indication on line 20 and below, #9125=1 is to be set in the user program. When the value of #9125 changes from 1 to 0 on a process data screen, the system rewrites line 20 and below. On a detail data screen, the key-in buffer frame only is rewritten.
- #9126 : 1 - Cancel state
 0 - Normal state
 If the key-in buffer contains no data, #9126=1 is set if the [CAN] key is pressed followed by the [INPUT] key. #9126=0 is set when #8501 ≠ 0 is read, that is, when a key other than the numeric keys is pressed, and the key input is read by the user program.

Exceptions:

1. With a standard macro executor, input key monitoring is performed using #8501 to #8504. On the other hand, #8501 and #8503 only are used in this case. Any other variables including #8502 are invalid.
 2. Numeric data set in #8503 is valid only in the case of [INPUT] key input (#8501=8).
 3. With an addition of the numeric calculation input function, the results of calculation only are output to a user program. For this reason, [INPUT] key input for intermediate calculation and intermediate results are not output to a user program.
- (4) System variables for cursor position teaching
- (a) System variables for cursor position teaching

#9110 = Cursor position on process data

- #9110 = 1 : Offset + 7 (type)
 #9110 = 2 : Offset + 9 (head)
 #9110 = 3 : Offset + 11 (display data 1)
 #9110 = 4 : Offset + 13 (display data 2)
 #9110 = 5 : Offset + 15 (display data 3)
 #9110 = 6 : Offset + 17 (display data 4)
 #9110 = 7 : Offset + 19 (display data 5)
 #9110 = 8 : Offset + 21 (display data 6)
 #9110 = 9 : Offset + 23 (display data 7)
 #9110 = 10 : Offset + 25 (display data 8)
 #9110 = 11 : Offset + 27 (display data 9)
 #9110 = 12 : Offset + 29 (display data 10)
 #9110 = 13 : Offset + 31 (display data 11)
 #9110 = 14 : Offset + 33 (display data 12)

NOTE

- 1 Only the cursor position for a transfer process or auxiliary process is readable/writable.
- 2 The cursor position is not related to the position on the screen, but corresponds to the position (offset) of internal data.
- 3 The cursor must be entirely controlled by a user program. The system monitors #9110 at all times, and places the cursor at the screen position corresponding to the data position of the process.
- 4 When #9110 has been changed, the sequence must always exit from the user program. The system changes display after user program termination.
 - #9108 = X coordinate of the cursor position on a process data screen (read only)
 - #9109 = Y coordinate of the cursor position on a process data screen (read only)


On a process data screen, the current cursor position (reverse display position) is indicated using character coordinates. This can be used for window display position control.

NOTE

The cursor cannot be controlled using #9108 and #9109. Use #9110 to control the cursor.


- (b) Communication associated with the position of the cursor between a user program and the system
1. Cursor movement in a transfer or auxiliary process must be controlled by setting a value in #9110 with a user program. Depending on the value in #9110, the system displays the cursor at the corresponding position on the screen.
 2. Any cursor movement operation in a process other than transfer and auxiliary processes is controlled by the system. Currently, the user program is not activated at that time.
 3. Set, in #9110, 100 added to the current cursor position when the cursor moves outward from within a transfer or auxiliary process because the cursor key [\downarrow] is pressed. Set, in #9110, 200 added to the current cursor position when the cursor moves outward from within a transfer or auxiliary process because the cursor key [\uparrow] is pressed. Depending on the value in #9110, the system displays the cursor at the corresponding position.
 4. Set 199 in #9110 when the cursor moves to the outside of a transfer or auxiliary process from the first item (type) of the process because the cursor key [\leftarrow] is pressed. Set 299 in #9110 when the cursor moves to the outside of a transfer or auxiliary process from the last item (of the process because the cursor key [\rightarrow] is pressed. Depending on the value of #9110, the system displays the cursor at the corresponding position.

Example:



- Set, in #9110, 300 added to the current cursor position when the cursor moves outward from within a transfer or auxiliary process because the page key [↑] is pressed. Set, in #9110, 400 added to the current cursor position when the cursor moves outward from within a transfer or auxiliary process because the page key [↓] is pressed. Depending on the value in #9110, the system displays the cursor at the corresponding position.

Example:



- When the cursor moves into a transfer or auxiliary process from the outside because a page key or cursor key is pressed, the system sets the cursor position in #9110, and calls a user program.

NOTE

- If an item is not displayed according to the data format in the examples above, the system front-justifies the items that follow. (That is, no space is left for an item not displayed.)
- According to the data format of internal data, the system calculates the position of the cursor taking into any front-justification processing performed.


E.6.3.3 Display Character Specification

(1) Transfer or auxiliary process display

In a transfer or or auxiliary process, an arbitrary character string can be displayed by registering display items and soft key indications in a user program.

(a) Transfer or auxiliary process details

The data items of a transfer or auxiliary process have the following structure:



With a transfer or auxiliary process, one head name and up to 12 data item names can be displayed for each of up to 20 operation types. For each data item, up to five soft keys can be displayed. These head names, data item names, and soft key names are to be registered in a user program beforehand.

NOTE

Up to 12 characters are potentially usable for soft key display. However, the display of only nine characters is allowed to display the same character string in a data display area.

(b) Registration of display character strings in a transfer or auxiliary process

Display character strings are registered as a user program for each display language in the following formats:

(i) Registration of type/data item display character strings

N1101 (H12345678)	;	Head 1 character string
N1111 (D12345678)	;	} Data item character string group 1 (12 blocks)
:		
N1122 (D23456789)	;	
N1201 (H23456789)	;	Head 2 character string
N1211 (D34567890)	;	} Data item character string group 2 (12 blocks)
:		
N1222 (D45678901)	;	
	}	
N1501 (H34567890)	;	Head 5 character string
N1511 (D56789010)	;	} Data item character string group 5 (12 blocks)
:		
N1522 (D67890123)	;	
	}	
N3001 (H45678901)	:	Head 20 character string
N3011 (D78901234)	;	} Data item character string group 20 (12 blocks)
:		
N3022 (D89012345)	;	

NOTE

One head and 12 data items are displayed as a set for each type. This means that no arbitrary character string can be selected for each data item. (For details, see Section (c) (i).)

O11*1 = English	O11*5 = Italian
O11*2 = Japanese	O11*6 = Spanish
O11*3 = German	O11*7 = Chinese (*1)
O11*4 = French	O11*8 = Korean (*1)

* = 0 : Auxiliary process
1 : Transfer process

NOTE

The system displays the character string of a specified sequence number, according to the language selection parameter. English is used if no character string program specifying a language is registered.

*1 : The Chinese and Korean languages will be supported in the future.

(ii) Registration of soft key display character strings

```
O11** ;
N0001 (S12345678) ;
N0002 (S23456789) ;
N0003 (S34567890) ;
}
N5000 (S98765432) ;

O11*1 = English      O11*5 = Italian
O11*2 = Japanese    O11*6 = Spanish
O11*3 = German      O11*7 = Chinese (*1)
O11*4 = French      O11*8 = Korean (*1)
```

* = 2 : Auxiliary process
 3 : Transfer process

NOTE

- 1 The system displays the character string of a specified sequence number, according to the language selection parameter. English is used if no character string program specifying a language is registered.
 *1 : The Chinese and Korean languages will be supported in the future.
- 2 Up to five arbitrary soft key character strings can be selected for display. (For details, see Section (c) (ii).)

(c) Method of displaying transfer or auxiliary process display character strings

(i) Display of the display character strings of head/data item names

Display of head/data item names for a type has a tree structure. This means that when a type is selected, the character strings of one head and 12 data items are uniquely determined.

- Head/data item name display
 Set a type number (1 to 20) in the data variable for type (offset + 7). The system displays the corresponding head and data item character strings.

NOTE

The type name as an item is always "type".

- Display of type/head/data item data
 Usually, numeric values are displayed as the data of each data item. In the case of data input using soft keys (data format ≥ 10000), however, soft key display character strings are displayed as type/head/data item data. At that time, set the sequence number of a soft key display character string in the data variable. The system displays the corresponding soft key display character string on the process screen.

NOTE

A value ranging from 1 to 20 can be set to specify a type. Each value corresponds to a display character string group on a one-to-one basis. So when a character string is displayed type data, the character string must be registered with a sequence number from N1 to N20 in a program for soft key display character string registration.

- Front-justified display

If a data item is not displayed (data format=–1), the next data item is front-justified for display.

To disable front-justification, register character strings or control the cursor as follows:

1. Register a data item display character string consisting of blanks only beforehand.
2. Register a soft key display character string consisting of blanks only.
3. Set the data format of data input by soft key (data format \cong 10000) for an item not to be displayed.
4. Set a sequence number in the data variable of an item of (iii).
5. Prevent the cursor from moving to an item of (iii), by using a user program.

(ii) Display of soft key display character strings

- System variables for soft key display

#9131 : System variable representing a soft key 1 display character string

#9132: System variable representing a soft key 2 display character string

#9133: System variable representing a soft key 3 display character string

#9134: System variable representing a soft key 4 display character string

#9135: System variable representing a soft key 5 display character string

Set the sequence number of a soft key to be displayed in a variable from #9131 to 9135. The system displays the character string in the corresponding soft key position.

NOTE

When a variable from #9131 to #9135 has been changed, the sequence must always exit from the user program. The system changes display after user program termination.

- System variable for soft key page display

#9136 : 1 – The system displays soft keys specified by a user program according to #9131 to #9135.

0 – The system displays the default soft keys.

(2) Specification of display characters used with the system

(a) Use by a user program of characters used with the system

When characters are to be displayed using the macro executor, the display characters are usually specified using a display command, or a character string already registered by a user program is usually specified.

However, a very complicated user program may be required, for example, to handle many different languages.

To solve this problem, a command is added which allows character strings available in each language with the conversational system to be specified for display.

Note, however, only those characters that have preassigned codes can be specified.

G243 X (X coordinate of display start position) Y (Y coordinate of display start position) P9**** ;
 O1191 to O1198 ;

P90001: “Machining program creation”	...	N1001
P90002: “Number”	...	N1002
P90003: “Name”	...	N1003
P90004: “Process”	...	N1004
P90005: “Transfer”	...	N1005
P90006: “Head”	...	N1006
P90007: “Tool”	...	N1007
P90008: “Cutting”	(Soft key - 1)	...
P90009: “Condition”	(Soft key - 2)	...
P90010: “Tool”	(Soft key - 1)	...
P90011: “Data”	(Soft key - 2)	...
P90012: “Detail”	(Soft key - 1)	...
P90013: “Data”	(Soft key - 2)	...
P90014: “Product”	(Soft key - 1)	...
P00015: “Draw”	(Soft key - 2)	...
P90016: “Explanation”	(Soft key - 1)	...
P90017: “ ”		...

Each string is registered in O1191 to O1198 (eight languages). P9**** corresponds to each sequence number as indicated above.

(b) Title display

On the main menu screen, a title desired by each machine tool builder can be displayed. In each language (O1191 to O1198), up to 50 half-size characters can be registered in N9999(*1).

*1 : The Chinese and Korean languages will be supported in the future.

E.6.3.4 Executable Macro Program Numbers

To execute a transfer or auxiliary process, the following dedicated program numbers are added:

O9018 = Program number of the transfer process executable macro

O9019 = Program number of the auxiliary process executable macro

NOTE

A program number called with G code from a user program (NC format program) is used for a transfer or auxiliary process.

E.6.3.5 System Variable for Conversational Programming Menu Indication

#9122 = 1 : Conversational programming menu being displayed

#9122 = 0 : Different screen being displayed

NOTE

#9122 can be read also with an executable macro.

E.6.3.6 System Variable for Window ON/OFF State Indication

#9123 = 1 : Window OFF

#9123 = 0 : Window ON

In a user program, control whether to provide window according to the value of #9123.

NOTE

Be sure to exercise cursor control at all times, regardless of the value of the system variable above.

E.6.3.7 System Variable for Conversational Mode/NC Mode Indication

#9121 = 1 : Conversational mode

#9121 = 0 : NC mode

From the value of #9121, a user program can check whether the conversational mode or NC mode is currently selected.

NOTE

At the time of activation (including animatedsimulation), the conversational mode or NC mode is started.

#9121 can be read also with an executable macro.

E.6.3.8
System Variable for
Execution Mode
Indication

#9127 = 0 : Normal state
 #9127 = 1 : Simulation being executed
 #9127 = 2 : NC statement being output

NOTE

#9127 can be read also with an executable macro.

E.6.3.9
Conversational Macro
Program Executed
Immediately Before
Execution

O1008 : Program activated when a program to be executed is selected, that is, when a soft key such as the [EXEC] and [ANIMATION] soft keys is pressed

NOTE

Only the program of the head currently selected is activated.

E.6.3.10
Parameters and System
Variables

The parameters usable for user macro programs are listed below. Each parameter corresponds to a system variable.

Bit parameter			Double-word parameter		
9646	—	#9140	9656	—	#9150
9647	—	#9141	9657	—	#9151
9648	—	#9142	9658	—	#9152
9649	—	#9143	9659	—	#9153
9650	—	#9144	9660	—	#9154
9651	—	#9145	9661	—	#9155
9652	—	#9146	9662	—	#9156
9653	—	#9147	9663	—	#9157
9654	—	#9148	9664	—	#9158
9655	—	#9149	9665	—	#9159

E.6.3.11
Program Numbers
Usable with User
Programs

Program numbers 2500 to 2599, 3500 to 3599, and 4500 to 4599 can be used by user programs only. Program numbers 1000 to 1199 and 9000 to 9999 are, or may be, used for the interface between the system and user macro program. User macro programs can use these program numbers provided no problem results.(*)

Other program numbers are, or will be, used by the execution macro programs of the system. User macro programs cannot, therefore, use these numbers.

NOTE

* If an interface between the system and user macro program is added in the future, user program numbers 1000 to 1199 and 9000 to 9999 may have to be changed.

E.6.4 Data Which Can Be Referred to by Macro Programs

E.6.4.1 Outline

In the FANUC Super CAP T/CAP II T system, macro programs corresponding to processes, such as the auxiliary and transfer processes, can refer to various data.

E.6.4.2 Description

Program data is stored in extended P-code variables from variable No. 20000 in the Super CAP T/CAP II T system. Macro programs cannot directly refer to the program data. However, data items can be referred to indirectly. Such data items are data used in the process being executed, parameters used for conversational programming, and initial settings, which are stored in the specified areas.

(1) Program data (process data) area

Program data used in a certain process is copied to sixty macro variables, from No. 20800 to No. 20859. For details of variables used in each process, see Section 6.2.

NOTE

The same variable numbers are used for heads 1 and 2.

(2) Macro parameter area

Parameters, tool data, initial settings, and data derived from these three data items are stored in this area. These items are used in macro programs.

Initial settings 1 used in the program for head 2 are stored in sixty variables, from No. 22000 to No. 22059, immediately after the program starts. Initial settings 2 are stored in sixty variables, from No. 22060 to No. 22119, also immediately after the program starts.

NOTE

The same variable numbers are used for heads 1 and 2.

Macro variable	Description	Processes in which the variable can be referred to	Corresponding data
#20799	[Width of a cutter used for grooving]*2 Note) Only when a cutter for grooving is registered	Grooving, transfer, and auxiliary processes	Tool data
#20798 <Ver.1>			
<Ver.2 or later>	G code for calling a subprogram to rewrite an offset value in ROM when NC statements for C-axis notching are output	C-axis notching	PRM No.9779#7 Compile PRM No.9013
#20797	Cutting angle of a cutter Tools other than round-nose tools : 180-([cutting edge angle]+[tools angle]) Round-nose tools : 90+[parameter setting] [Angle of a tool used for threading]	Bar machining and threading	Tool data PRM No. 9801
#20796			
#20795	Flag for rough machining 0 : Rough machining is performed. 1 : Rough machining is not performed.	All processes	PRM No.9772#5
#20794	The position of the program origin is on the end face of the : 0 : Workpiece 1 : Chuck	All processes	PRM No.9786
#20793	Diameter or radius programming for the X-axis 0 : Radius programming is used. 1 : Diameter programming is used.	All processes	PRM No.1006#3
#20792	When the spindle gear is changed or the direction of the spindle rotation changes, 0 : code M05 is not output. 1 : code M05 is output.	All processes	PRM No.9772#1
#20791	The M code used for the end of a program is: 0 : M02 1 : M30 Note) When a program is repeated, M99 is used.	All processes	PRM No.9772#2
#20790	The machine moves from the common safety point to the point where the tool is changed along : 0 : One axis 1 : Two axes at the same time	All processes	PRM No.9772#3
#20789	Amount of return in grooving [Parameter setting]*2 Note) When a tool is specified	Grooving, transfer, and auxiliary processes	PRM No.9824
#20788	Limit for the depth of cut [Parameter setting]*2 Note) When a tool is specified	Bar machining, tracing residual machining, grooving transfer, and auxiliary processes	PRM No.9796 PRM No.9823
#20787	Rate of changing the depth of cut [Parameter setting]/100 Note) If the parameter is set to 0 or 201 or more, the variable become 1.0. Note) When a tool is specified	Bar machining, tracing residual machining, grooving transfer, and auxiliary processes	PRM No.9795 PRM No.9822
#20786	Clearance along the X-axis at the start point in grooving [Parameter setting] Note) When a tool is specified	Grooving, transfer, and auxiliary processes	PRM No.9820

Macro variable	Description	Processes in which the variable can be referred to	Corresponding data
#20785	Clearance along the Z-axis at the start point in grooving [Parameter setting]*2 Note) When a tool is specified	Grooving, transfer, and auxiliary processes	PRM No.9821
#20784	Overlap between adjacent cuts in grooving [Parameter setting]*[width of a tool]*2/100 Note) When a tool is specified	Grooving, transfer, and auxiliary processes	PRM No.9825
#20783	Dwell time at the bottom of a groove in grooving (ms) Millimeter system : [Parameter setting] $*(1000*60*3.1416*diameter) / (1000*surface\ speed)$ Inch system : [Parameter setting] $*(1000*60*3.1416*diameter) / (12*surface\ speed)$	Grooving	PRM No.9826
<Ver.2 or later>			
#20782	Angle used for cutting with a margin from the back of a tool in intermediate bar machining [Parameter setting]	Bar machining, tracing residual machining, and end facing	PRM No.9801
#20781	Clearance along the X-axis from the workpiece to the start point for cutting [Parameter setting]	All processes	PRM No.9784
#20780	Clearance along the Z-axis from the workpiece to the start point for cutting [Parameter setting]*2	All processes	PRM No.9785
#20779	Clearance along the X-axis from the cut surface in machining in bites [Parameter setting]	Bar machining, tracing residual machining, and end facing	PRM No.9797
#20778	Clearance along the Z-axis from the cut surface in machining in bites [Parameter setting]*2	Bar machining, tracing residual machining, and end facing	PRM No.9798
#20777 <Ver.1>			
<Ver.2 or later>	M code for turning off Y-axis mode	Y-axis processes	PRM No.9840
#20776 <Ver.1>			
<Ver.2 or later>	M code for turning on Y-axis mode	Y-axis processes	PRM No.9840
#20775	Cutting angle in necking [Parameter setting]	Necking	PRM No.9815
#20774	Clearance along the X-axis from the line connecting the start and end points in residual machining [Parameter setting]	Bar machining and residual machining	PRM No.9799
#20773	Clearance along the Z-axis from the line connecting the start and end points in residual machining [Parameter setting]*2	Bar machining and residual machining	PRM No.9800
#20772			

Macro variable	Description	Processes in which the variable can be referred to	Corresponding data
#20771			
#20770	Clearance along the X-axis in threading [Parameter setting]	Threading	PRM No.9830
#20769	Clearance along the Z-axis in threading [Parameter setting]*2	Threading	PRM No.9831
#20768	Minimum depth of cut in threading [Parameter setting]*2	Threading	PRM No.9833
#20767	Maximum spindle speed with gear 1 (low speed) [Parameter setting]	All processes	PRM No.3741
#20766	Maximum spindle speed with gear 2 (medium speed 1) [Parameter setting]	All processes	PRM No.3742
#20765	Maximum spindle speed with gear 3 (medium speed 2) [Parameter setting]	All processes	PRM No.3743
#20764	Maximum spindle speed with gear 4 (high speed) [Parameter setting]	All processes	PRM No.3744
#20763	M code specifying gear 1 (low speed) [Parameter setting]	All processes	PRM No.9870
#20762	M code specifying gear 2 (medium speed 1) [Parameter setting]	All processes	PRM No.9871
#20761	M code specifying gear 3 (medium speed 2) [Parameter setting]	All processes	PRM No.9872
#20760	M code specifying gear 4 (high speed) [Parameter setting]	All processes	PRM No.9873
#20759 <Ver.1>	Common safety point along the X-axis for machining the outer surface [Farthest point on the outer surface (farthest point X)]+[Parameter setting]	All processes	PRM No.9780
<Ver.2 or later>	Set above amount only for transfer process and for auxiliary process.	Transfer and auxiliary processes	PRM No.9780
#20758 <Ver.1>	Common safety point along the Z-axis for machining the outer surface – End face of a workpiece [Cutting allowance for the end face (head 1/head 2)]+[Parameter setting] – End face of the chuck Head 1: [Length (farthest point Z)]+ [Parameter setting] Head 2: [Length (farthest point Z)]– [cutting allowance for the end face (head 1)]+[Parameter setting]	All processes	PRM No.9781
<Ver.2 or later>	Set above amount only for transfer process and for auxiliary process.	Transfer and auxiliary processes	PRM No.9780
#20757 <Ver.1>	Common safety point along the X-axis for machining the inner surface =[Start point along the X-axis for cutting]	All processes (except for sub-calling, measuring, transfer for the C-axis, and auxiliary processes for the C-axis)	Process data
<Ver.2 or later>	Set above amount only for transfer process and for auxiliary process.	Transfer and auxiliary processes	PRM No.9780

Macro variable	Description	Processes in which the variable can be referred to	Corresponding data
#20756 <Ver.1>	Common safety point along the Z-axis for machining the inner surface – End face of a workpiece [Cutting allowance for the end face (head 1/head 2)]+[Parameter setting] – End face of the chuck Head 1: [Length (farthest point Z)]+ [Parameter setting] Head 2: [Length (farthest point Z)]– [cutting allowance for the end face (head 1)]+[Parameter setting]	All processes	PRM No.9783
<Ver.2 or later>	Set above amount only for transfer process and for auxiliary process.	Transfer and auxiliary processes	PRM No.9780
#20754	Provisional offset number	All processes	
#20755			
#20753	Reference position of the chuck barrier along the X-axis : X1	All processes	Data set previously
#20752	Reference position of the chuck barrier along the Z-axis : Z1	All processes	Data set previously
#20751	Reference position of the chuck barrier along the X-axis : X2	All processes	Data set previously
#20750	Reference position of the chuck barrier along the Z-axis : Z2	All processes	Data set previously
#20749	Geometry offset for the reference tool along the X-axis	All processes	
#20748	Geometry offset for the reference tool along the Z-axis	All processes	
#20747	Wear offset for the reference tool along the X-axis	All processes	
#20746	Wear offset for the reference tool along the Z-axis	All processes	
#20745			
#20744	Feedrate when the tool changes the direction of cutting from the normal to reverse direction in tracing 0 : Rapid traverse 1 : Cutting feed	Tracing	PRM No.9773#3
#20743	Finishing allowance in threading [Parameter setting]	Threading	PRM No.9834
#20742			
#20741	Tool orientation in pattern repeating 1: Right-handed, 2: Left-handed, 3: Positive direction, 4: Negative direction	Tracing	Tooling data
#20740	Calling T codes are : 0 : Not provided 1 : Provided	All processes	PRM No.9773#4
#20739	Diameter or radius programming for offset 0 : Diameter programming is used. (Only effective for axes for which diameter programming is specified.) 1 : Radius programming is used.	All processes	PRM No.5004#1
#20738	Upper limit of cutting feedrate	All processes	PRM No.1422
#20737	The unit used in entering data is : 0 : mm 1 : Inches	All processes	PRM No.0000#2 (setting)
#20736	M code for preparing the tailstock	All processes	PRM No.9874
#20735	M code for storing the tailstock	All processes	PRM No.9875

Macro variable	Description	Processes in which the variable can be referred to	Corresponding data
#20734	On the graphics screen, the tailstock at the initial condition is : 0 : Displayed 1 : Not displayed	All processes	PRM No.9773#5
#20733			
#20732			
#20731			
#20730	Blank drawing 0 : The side view is an: 1 : End-face view 2 : Exploded view	All processes	Process data
#20729	Clearance at the tip of a chamfering tool [Setting in the tool data]*2	C-axis grooving, notching, and cylindrical machining	Tool data
#20728	Diameter of the chamfering tool to be used [Setting in the tool data]	C-axis grooving, notching, and cylindrical machining	Tool data
#20727	Tool angle of the chamfering tool to be used [Setting in the tool data]	C-axis grooving, notching, and cylindrical machining	Tool data
#20726	Overlap at adjacent cuts in side-face notching [Parameter setting]*[width of the tool] /100	Notching (side face)	PRM No.9865 Tool data
#20725	Width of the tool used for side cutting	Notching (side face)	Tool data
#20724	M code which changes the turning mode to the milling mode	All processes	PRM No.9880
#20723	M code which changes the milling mode to the turning mode	All processes	PRM No.9881
#20722	Clearance at the start point for C-axis drilling, C-axis grooving, and C-axis cylindrical machining [Parameter setting]*2	C-axis drilling, C-axis grooving, and C-axis cylindrical machining	PRM No.9855
#20721	Maximum number registered on the graphic screen for tools used in turning Setting : 1 to 16 (0 when turning tools are not registered)	All processes	Tooling data
#20720	Maximum number registered on the graphic screen for tools used which rotate Setting : 17 to 32 (16 when rotating tools are not registered)	All processes	Tooling data
#20719	M code for stopping the rotation about the milling axis [Parameter setting] (5 when a setting is 0)	All C-axis processes	PRM No.9876

Macro variable	Description	Processes in which the variable can be referred to	Corresponding data
#20718	M code for specifying the direction of rotation about the milling axis – When bit 2 of parameter No. 9774 is 0, the tools to be used rotate in the : [3] : Normal direction [4] : Reverse direction – When bit 2 of parameter No. 9774 is 1, the tools to be used rotate in the : [Setting in parameter No.9877] : Normal direction [Setting in parameter No.9878] : Reverse direction If the settings in parameters No.9877 and No.9878 are zero or 100 or more, no value is specified.	All C-axis processes	Tool data PRM No.9774#2 PRM No.9877 PRM No.9878
#20717 <Ver.1>			
<Ver.2 or later>	Limit on finishing feed amount	Bar machining, Tracing, End face, and Trapezoid groove	Cutting condition data
#20716 <Ver.1>			
<Ver.2 or later>	Limit on finishing feed amount	Automatic residual machining of bars	Cutting condition data
#20715	When a program is completed, codes T0; and G28; are : 0 : Output 1 : Not output	All processes	PRM No.9774#4
#20714	When a process is completed, code M01 is : 0 : Not output 1 : Output	All processes	PRM No.9774#3
#20713			
#20712	The optional C-axis conversational programming function is 0 : Provided 1 : Not provided	All processes	
#20711			
#20710	Geometric compensation number for the tool to be used	All processes	Process data
#20709	Geometric compensation number for the tool to be used for automatic residual machining	Bar machining	Process data
#20708 <Ver.1>			
<Ver.2 or later>	For the chuck/tailstock barrier function, 0: The second stored stroke limit is used. 1: The NC's chuck/tailstock barrier function is used.	All processes	Option parameter
#20707 <Ver.1>			
<Ver.2 or later>	Chuck number	All processes	Initial setting
#20706 <Ver.1>			
<Ver.2 or later>	Tail stock number	All processes	Initial setting

Macro variable	Description	Processes in which the variable can be referred to	Corresponding data
#20705	Number registered in the graphic screen for the tool to be used Note) Specify this value after address Q in the graphic command for selecting a tool.	All processes	
#20704	Number registered in the graphic screen for the tool to be used for automatic residual machining. Note) Specify this value after address Q in the graphic command for selecting a tool.	Bar machining	
#20703			
#20702			
#20701			
#20700	Point where deceleration starts in end-face machining along the X-axis [Parameter setting]	Bar machining and end facing	PRM No.9807
#20699	Deceleration rate in end-face machining [Parameter setting]	Bar machining and end facing	PRM No.9808
#20698	Tool geometry compensation number When bit 1 of parameter No.5002 is 0, the value is the same as the wear compensation number. When bit 1 of parameter No.5002 is 1, the value is the same as the tool selection number.	All C-axis processes	PRM No.5002#1
#20697	Wear compensation number of the tool to be used	All processes	Process data
#20696	Wear compensation number of the tool to be used for automatic residual machining	Bar machining	Process data
#20695			
#20694			
#20693			
#20692	Finishing allowance in end-face machining along the Z-axis [Parameter setting]*2	All processes	Process data
#20691	Selection number of the tool to be used	All processes	Process data
#20690	Selection number of the tool to be used for automatic residual machining	Bar machining	Process data
#20689			
#20688			
#20687			
#20686	The optional interpolation function for the polar coordinate is : 0 : Not provided. 1 : Provided.	All processes	
#20685	The optional cylindrical interpolation function is : 0 : Not provided. 1 : Provided.	All processes	
#20684	Flag indicating NC statements are being output 0 : NC statements are not being output. 1 : NC statements are being output.	All processes	
#20683	Number of the turret corresponding to the tool used in the process being performed	All processes	Process data

Macro variable	Description	Processes in which the variable can be referred to	Corresponding data
#20682	Number of the turret corresponding to the tool used in the next process, or number of the turret corresponding to the tool used for automatic residual machining	All processes Only in bar machining	Process data
#20681	Number of the turret corresponding to the tool used in the next process	Only in bar machining	Process data
#20680	Feed amount when a tool returns in reaming or boring [Feed amount]*[parameter No.9860]/10	Reaming and boring	PRM No.9860
#20679	Surface speed of the tool at the first cut in bar machining, tracing, or end facing. [Surface speed]*[parameter No.9806]/10	Reaming and boring	PRM No.9806
#20678	Flag indicating the change in feed amount due to the change in the cutting angle of a tool 0 : The feed amount is not changed. 1 : The feed amount is changed.	Bar machining and tracing	
#20677	Feed amount for the tool with a cutting angle of 90° to 135° [Feed amount]*[Parameter setting]/100	Bar machining and tracing	Process data PRM No.9802
#20676	Feed amount for the tool with a cutting angle of 136° to 180° [Feed amount]*[Parameter setting]/100	Bar machining and tracing	Process data PRM No.9803
#20675	Feed amount for the tool with a cutting angle of 181° to 225° [Feed amount]*[Parameter setting]/100	Bar machining and tracing	Process data PRM No.9804
#20674	Feed amount for the tool with a cutting angle of 226° to 270° [Feed amount]*[Parameter setting]/100	Bar machining and tracing	Process data PRM No.9805
#20673	Clearance at the start point in boring [Parameter setting]	Boring	PRM No.9859
#20672	M code for clamping the movement about the C-axis [Parameter setting] Note) M code for unclamping the movement about the C-axis [Parameter setting]+1	All C-axis processes	PRM No.5110
#20671	Dwell time when unclamping the C-axis is specified [Parameter setting]	All C-axis processes	PRM No.5111
#20670	Clearance at the start point in C-axis tapping [Parameter setting]*2	C-axis tapping	PRM No.9856
#20669	Switching from the turning mode to the milling mode is performed by : 0 : The M code 1 : Calling the sub-program	All processes	PRM No.9776#1
#20668	Switching from the milling mode to the turning mode is performed by : 0 : The M code 1 : Calling the sub-program	All processes	PRM No.9776#2
#20667	Outermost diameter	All processes	Initial setting
#20666	Length	All processes	Initial setting
#20665	Cutting allowance in end facing	All processes	Initial setting
#20664			
#20663			
#20662			

Macro variable	Description	Processes in which the variable can be referred to	Corresponding data
#20661	Length of a workpiece Head 1 : [Length]-[cutting allowance in end facing] Head 2 : [Length of the product]	All processes	Initial setting
#20660	Maximum spindle speed	All processes	Initial setting
#20659	Figure of a workpiece 1 : Bar 2 : Formed material	All processes	Initial setting
#20658	Position on the formed material-1 : X Diameter programming : [Setting] Radius programming : [Setting]*2 Note) A value is set only when bit 7 of parameter No. 9777 is 1.	All processes	PRM No.9777#7 Initial setting
#20657	Position on the formed material-1 : Z [Setting] Note) A value is set only when bit 7 of parameter No. 9777 is 1.	All processes	PRM No.9777#7 Initial setting
#20656	Position on the formed material-2 : X Diameter programming : [Setting] Radius programming : [Setting]*2 Note) A value is set only when bit 7 of parameter No. 9777 is 1.	All processes	PRM No.9777#7 Initial setting
#20655	Position on the formed material-2 : Z [Setting] Note) A value is set only when bit 7 of parameter No. 9777 is 1.	All processes	PRM No.9777#7 Initial setting
#20654	Position on the formed material-3 : X Diameter programming : [Setting] Radius programming : [Setting]*2 Note) A value is set only when bit 7 of parameter No. 9777 is 1.	All processes	PRM No.9777#7 Initial setting
#20653	Position on the formed material-3 : Z [Setting] Note) A value is set only when bit 7 of parameter No. 9777 is 1.	All processes	PRM No.9777#7 Initial setting
#20652	Position on the formed material-4 : X Diameter programming : [Setting] Radius programming : [Setting]*2 Note) A value is set only when bit 7 of parameter No. 9777 is 1.	All processes	PRM No.9777#7 Initial setting
#20651	Position on the formed material-4 : Z [Setting] Note) A value is set only when bit 7 of parameter No. 9777 is 1.	All processes	PRM No.9777#7 Initial setting

Macro variable	Description	Processes in which the variable can be referred to	Corresponding data
#20650	Position on the formed material-5 : X Diameter programming : [Setting] Radius programming : [Setting]*2 Note) A value is set only when bit 7 of parameter No. 9777 is 1.	All processes	PRM No.9777#7 Initial setting
#20649	Position on the formed material-5 : Z [Setting] Note) A value is set only when bit 7 of parameter No. 9777 is 1.	All processes	PRM No.9777#7 Initial setting
#20648	Position on the formed material-6 : X Diameter programming : [Setting] Radius programming : [Setting]*2 Note) A value is set only when bit 7 of parameter No. 9777 is 1.	All processes	PRM No.9777#7 Initial setting
#20647	Position on the formed material-6 : Z [Setting] Note) A value is set only when bit 7 of parameter No. 9777 is 1.	All processes	PRM No.9777#7 Initial setting
#20646	Position on the formed material-7 : X Diameter programming : [Setting] Radius programming : [Setting]*2 Note) A value is set only when bit 7 of parameter No. 9777 is 1.	All processes	PRM No.9777#7 Initial setting
#20645	Position on the formed material-7 : Z [Setting] Note) A value is set only when bit 7 of parameter No. 9777 is 1.	All processes	PRM No.9777#7 Initial setting
#20644	Position on the formed material-8 : X Diameter programming : [Setting] Radius programming : [Setting]*2 Note) A value is set only when bit 7 of parameter No. 9777 is 1.	All processes	PRM No.9777#7 Initial setting
#20643	Position on the formed material-8 : Z [Setting] Note) A value is set only when bit 7 of parameter No. 9777 is 1.	All processes	PRM No.9777#7 Initial setting
#20642	Position on the formed material-9 : X Diameter programming : [Setting] Radius programming : [Setting]*2 Note) A value is set only when bit 7 of parameter No. 9777 is 1.	All processes	PRM No.9777#7 Initial setting
#20641	Position on the formed material-9 : Z [Setting] Note) A value is set only when bit 7 of parameter No. 9777 is 1.	All processes	PRM No.9777#7 Initial setting

Macro variable	Description	Processes in which the variable can be referred to	Corresponding data
#20640	Position on the formed material-10 : X Diameter programming : [Setting] Radius programming : [Setting]*2 Note) A value is set only when bit 7 of parameter No. 9777 is 1.	All processes	PRM No.9777#7 Initial setting
#20639	Position on the formed material-10 : Z [Setting] Note) A value is set only when bit 7 of parameter No. 9777 is 1.	All processes	PRM No.9777#7 Initial setting
#20638	Position on the formed material-11 : X Diameter programming : [Setting] Radius programming : [Setting]*2 Note) A value is set only when bit 7 of parameter No. 9777 is 1.	All processes	PRM No.9777#7 Initial setting
#20637	Position on the formed material-11 : Z [Setting] Note) A value is set only when bit 7 of parameter No. 9777 is 1.	All processes	PRM No.9777#7 Initial setting
#20636	Position on the formed material-12 : X Diameter programming : [Setting] Radius programming : [Setting]*2 Note) A value is set only when bit 7 of parameter No. 9777 is 1.	All processes	PRM No.9777#7 Initial setting
#20635	Position on the formed material-12 : Z [Setting] Note) A value is set only when bit 7 of parameter No. 9777 is 1.	All processes	PRM No.9777#7 Initial setting
#20634 <Ver.1>	Common safety point X for turning and drilling [Parameter setting]	Turning and drilling	PRM No.9787
<Ver.2 or later>			
#20633 <Ver.1>	Common safety point Z for turning and drilling [Parameter setting]*2 – When the program origin is positioned on the end face of the workpiece [Cutting allowance on the end face]+ [Parameter setting] – When the program origin is positioned on the end face of the chuck Head 1: [Length (outermost point Z)] + [Parameter setting] Head 2: [Length (outermost point Z)] – [cutting allowance on the end face for head 1]+ [Parameter setting]	Turning and drilling	PRM No.9788 Initial setting
<Ver.2 or later>			
#20632	Flag indicating spindle positioning 0 : Related to C-axis contour control 1 : Not related to C-axis contour control	All processes	PRM No.9930#1

Macro variable	Description	Processes in which the variable can be referred to	Corresponding data
#20631	The program to be called is a : 0 : User program stored in the NC program area 1 : P-code program	Sub-calling, transfer, and auxiliary processes	PRM No.9777 #1-#5 PRM No.9778 #0, #1
#20630	The tool post to be selected is : 0 : Head 1 1 : Head 2	All processes	
#20629			
#20628			
#20627			
#20626			
#20625			
#20624	Cutting allowance on the end face at head 2 [Length]-(cutting allowance on the end face)+ [length of the product] If the result is negative, set this to 0.	All processes	Initial setting
#20623	Compensation along the Z-axis for copying blanks When the program origin is positioned on the end face of a workpiece : A+B+C When the program origin is positioned on the end face of a chuck : A+B-C Where, A : Z coordinate of the center of the screen at head 1 B : Z coordinate of the center of the screen at head 2 C : Length of the product		
#20622			
#20621			
#20620			
#20619	Flag related to cutting on the end faces 0 : End facing is not performed in bar machining. 1 : End facing is also performed in bar machining.	Bar machining	
#20618	The program to be called for switching turning to milling is a : 0 : User program stored in the NC program area 1 : P-code program	All processes	PRM No.9778#3
#20617	The program to be called for switching milling to turning is a : 0 : User program stored in the NC program area 1 : P-code program	All processes	PRM No.9778#4
#20616	Innermost diameter	All processes	Initial setting
#20615	M code for calling a sub-program	All processes	Compile PRM No. 9033
#20614	Destination for calling a T code 0 : NC program in the RAM 1 : P-code program in the ROM	All processes	PRM No.9778#7
#20613	Sub-program calling by the end M code (P code) 0 : The end M code is output. 1 : The sub-program is called by the end M code.	All processes	PRM No.9779#2

Macro variable	Description	Processes in which the variable can be referred to	Corresponding data
#20612	When the direction of rotation about the milling axis is changed or the spindle gear is changed, the M code for stopping the movement about the axis is : 0 : Not output. 1 : Output.	All C-axis processes	PRM No.9774#1
#20611	M code for rotation about the milling axis in the opposite direction to that specified	C-axis drilling	PRM No.9779#0 1 PRM No.9861
#20610 <Ver.1>			
<Ver.2 or later>	Subspindle classification 0: Without T-series subspindle 1: With T-series subspindle	All processes	PRM No.9779#0 1 PRM No.9861
#20609 <Ver.1>			
<Ver.2 or later>	Initial setting data [PRODUCT LENGTH], [SETTING VALUE]	All processes	Initial setting
#20608 <Ver.1>			
<Ver.2 or later>	Amount of Z coordinate shift for animated simulation of head 2 of T-series subspindle <Programmed zero point> – Workpiece end face: [PRODUCT LENGTH](*2) – Chuck end face: [LENGTH - END REMOVAL](*2)	All processes	Initial setting
#20607	Code to be used to specify turning tapping 0: G84, 1: G32	Drilling	PRM No.9779#6
#20606 <Ver.1>			
<Ver.2 or later>	M code for turning on chamfering during threading	Threading	PRM No.9836
#20605 <Ver.1>			
<Ver.2 or later>	M code for turning off chamfering during threading	Threading	PRM No.9837
#20604 <Ver.1>			
<Ver.2 or later>	Specification in 96 subdivisions: 0: Disabled, 1: Enabled (Note)1 can be set only for a system having a T-series subspindle.	C-axis drilling and grooving	PRM No.9771#4 5
#20603 <Ver.1>			
<Ver.2 or later>	M code for releasing specification in 96 subdivisions. (Note)1 can be set only for a system having a T-series subspindle.	C-axis drilling and grooving	PRM No.9862

Macro variable	Description	Processes in which the variable can be referred to	Corresponding data
#20602 <Ver.1>			
<Ver.2 or later>	M code for calling O9029: Set value	C-axis drilling and grooving	Compile parameter No.9032
#20601 <Ver.1>			
<Ver.2 or later>	M code for calling O9028: Set value	All processes	Compile parameter No.9031
#20600 <Ver.1>			
<Ver.2 or later>	M code for calling O9027: Set value	All processes	Compile parameter No.9030

E.6.5 Displaying the Basic Menu Screen by a User Program (Not Supported by Ver.1.)

E.6.5.1 Overview

FANUC Super CAP T/CAP II T allow a user-created program to display the user's own basic menu screen instead of the standard FANUC basic menu screen.

E.6.5.2 Setting a parameter

Parameter	#7	#6	#5	#4	#3	#2	#1	#0
9779			USRMNU					

bit5 (USRMNU) 0 : Standard FANUC basic menu screen is displayed.
 1 : The user program for displaying the user's own basic menu screen is called.


E.6.5.3 Details

When the USRMNU bit (bit 5 of parameter 9779) is set to 1, the user-created program for displaying the user's own basic menu screen is called.

(1) Number of the program for displaying the user's own basic menu screen, and starting that program

O1020 is assigned to the program to display basic menu screen 1, while O1021 is assigned to that to display basic menu screen 2. Each program is called only once when the screen is displayed.

(2) Screen configuration and notes



The system displays the soft keys, time, and mode as shown in the figure above. The remainder of the screen can be used freely by the user as the display area. The soft keys are controlled by the system. The user program can manage the display only. For details of the menu displayed during background editing, refer to the description of the following variable:

#8526 1 : Background editing is in progress.
 0 : Background editing has stopped.

E.6.6 Display of a Window by a User Program, Depending on the Cursor Position (Not Supported by Ver.1.)

E.6.6.1 Overview

FANUC Super CAP T/CAP II T allow a user-created program to display the user's own window on the program process data screen. The user program determines the current position of the cursor by reading a system variable.

E.6.6.2 Details

- (1) Displaying a window, depending on the cursor position
 - (a) Number of the user program which displays a window
Number O1022 is assigned which the program which displays a window, depending on the cursor position.
 - (b) Starting the user program
User program O1022 is called:
 - When the cursor is positioned to an item
 - If the system issues a warning as data is being entered
 - When the  soft key is pressed
 - When the screen is switched to the program editing screen
 - When the product figure drawing window, M-detail window, or any other window opened by the system is closed
 - When the [LIST ↓] soft key is pressed while the cursor is positioned to the program number or name

NOTE

- 1 Even in the window off state, that is, when system variable #9123 is set to 1, user program O1022 is called. In such a case, however, this program is not used to display a window. Should this be attempted in the window off state, the window may not be erased and will remain on the screen.
- 2 Even if the cursor is positioned to an item other than MACHINING in an auxiliary or transfer process, O1022 is called. In this case, however, O1022 must not be used to display a window. The O1022 must be used only to set system variable #9029 for displaying a window by pressing a soft key. Should O1022 be used to display a window in this state, the window may not be erased and will remain on the screen.
To display a window associated with an auxiliary or transfer process, use any of user programs O1000 to O1007.
- 3 If the cursor is positioned to an item other than MACHINING in an auxiliary or transfer process, the system variable associated with this function becomes undefined.

(2) System variables indicating the position of the cursor

System variables #9200 to #9203, #9108, and #9109 indicate the position of the cursor for the function for displaying a window.

(a) System variable indicating an item: #9200

In system variable #9200, a value indicating the item to which the cursor is positioned is set. The set value varies with the item, as shown below. If the cursor is positioned to the line of contour data for bar machining, pattern repeating, C-axis notching, or C-axis cylindrical machining, or to the line of single action figure data, the values of items start from 0 on each line.

<<Values of items set in system variable #9200 (italicized)>>

● Program number or name

Number=0	Name=1
----------	--------

● Initial setting (two-spindle type)

INITAL SET	MATERIAL	SHAPE	OUT-DIA	IN-DIA	WORK-LNG	MAX-S	COOLANT
	0	1	2	3	4	5	6
	FINISHX	FINISHZ	E-REMOVAL	PROD-LNG			
	7	8	9	10			

● Initial setting (one-spindle type)

INITAL SET	MATERIAL	SHAPE	OUT-DIA	IN-DIA	WORK-LNG	MAX-S	COOLANT
	0	1	2	3	4	5	6
	FINISHX	FINISHZ	E-REMOVAL				
	7	8	9				

● Workpiece point data (point on outer surface)

OUT-P X1	Z1	X2	Z2	X3	Z3
0	1	2	3	4	5
X4	Z4	X5	Z5	X6	Z6
6	7	8	9	10	11
X7	Z7	X8	Z8	X9	Z9
12	13	14	15	16	17
X10	Z10	X11	Z11	X12	Z12
18	19	20	21	22	23

● Workpiece point data (point on inner surface)

IN-P X1	Z1	X2	Z2	X3	Z3
0	1	2	3	4	5
X4	Z4	X5	Z5	X6	Z6
6	7	8	9	10	11
X7	Z7	X8	Z8	X9	Z9
12	13	14	15	16	17
X10	Z10	X11	Z11	X12	Z12
18	19	20	21	22	23

- PROCESS DATA : the value at every items are defined.

Data value	Name of item	Data value	Name of item
0	MACHINING	50	FEEDRATE1 <C-Axis Cylinder>
1	MACHIN-2	51	FEEDRATE2 <C-Axis Grooving, Y-Axis Mill>
2	AREA	52	FEEDRATE2 <C-Axis Cylinder>
3	HEAD or SPINDLE	53	BEVEL-AM
4	PATTERN	54	STAT-PZ
5	BASIS	55	END-PTZ
6	SHAPE <Necking >	56	FINISHX
7	FEEDRATE	57	FINISHZ
8	PROGRAM	58	STAT-PX
9	INTRVAL	59	DEPTH
10	SHAPE	60	M
11	RETURN	61	RETURN-X
12	END-M	62	RETURN-Z
13	ROUGHNES	63	RETURN-C
14	TOOL-NO	64	LOOP
15	CUT-SPD or REV/MIN	65	CUT-METHD <Threading>
16	FEED/REV	66	THRD-TYPE
17	CUT DEPTH/CUT NUMBER <Threading>	67	THRD ANGL
18	T-CODE	68	THRD CNT
19	ROUGHNES <BAR: Auto Res. Cut>	69	HOLE-PTN
20	TOOL-NO <BAR: Auto Res. Cut>	70	SHIFT-DR
21	CUT-SPD or REV/MIN <BAR: Auto Res. Cut>	71	STAT-PX
22	FEED/REV <BAR: Auto Res. Cut>	72	STAT-PZ
23	CUT DEPTH <BAR: Auto Res. Cut>	73	FEEDRATE1 <Y-Axis Milling: Face>
24	T-CODE <BAR: Auto Res. Cut>	74	FEEDRATE1 <Y-Axis Milling: Side>
25	REMOVALX	75	ESCAPE-SZ
26	REMOVALZ	76	ESCAPE-SX
27	LEAD	77	RESID-PZ
28	CHAMFER	78	CHAMF-LNG
29	WIDTH	79	STAT-PZ
30	CUT-DPTH	80	CHAMF-DIA
31	DWELL	81	TYPE <Single Action II>
32	ANGLE	82	DATA A <Call Sub II. >
33	AMNT A	83	DATA B <Call Sub II. >
34	AMNT B	84	DATA C <Call Sub II. >
35	AMNT C	85	DATA I <Call Sub II. >
36	AMNT D	86	DATA J <Call Sub II. >
37	STNDRD-D	87	DATA K <Call Sub II. >
38	END-PT <Ver. 2> END-PTZ/DEPTH <Ver. 3>	88	DATA D <Call Sub II. >
39	NOMINL-D	89	DATA E <Call Sub II. >
40	DWELL	90	DATA F <Call Sub II. >
41	HOLE-DIA	91	DATA H <Call Sub II. >
42	SHIFT	92	DATA M <Call Sub II. >
43	PITCH	93	
44	DATA1	94	
45	DATA2	95	
46	DATA3	96	
47	DATA4	97	
48	GRV-DIA	98	
49	FEEDRATE1 <C-Axis Grooving>	99	

- When a new process is created

PROC(01)	0
----------	---

- Bar machining (TT, T two-spindle type)

Bar machining (rough)	PROC(01)	AREA	HEAD	TOOL-NO	CUT-SPD	FEED/REV	CUT-DPTH	T-CODE
	0	2	3	14	15	16	17	18
		AREA		TOOL-NO	CUT-SPD	FEED/REV	CUT-DPTH	T-CODE
Bar machining (finish)	PROC(01)	RESIDUAL		20	21	22	23	24
	0	2	3	13	14	15	16	18
		AREA		ROUGHNES	TOOL-NO	CUT-SPD	FEED/REV	T-CODE
		RESIDUAL		19	20	21	22	24

● Bar machining (T one-spindle type)

Bar machining (rough)	PROC(01) 0	AREA 2		TOOL-NO 14	CUT-SPD 15	FEED/REV 16	CUT-DPTH 17	T-CODE 18
		AREA RESIDUAL		TOOL-NO 20	CUT-SPD 21	FEED/REV 22	CUT-DPTH 23	T-CODE 24
Bar machining (finish)	PROC(01) 0	AREA 2		ROUGHNES 13	TOOL-NO 14	CUT-SPD 15	FEED/REV 16	T-CODE 18
		AREA RESIDUAL		ROUGHNES 19	TOOL-NO 20	CUT-SPD 21	FEED/REV 22	T-CODE 24

● Pattern repeating (TT, T two-spindle type)

Pattern repeating (rough)	PROC(01) 0	AREA 2	HEAD 3	REMOVALX 25	REMOVALZ 26	TOOL-NO 14	CUT-SPD 15	T-CODE 18
		FEED/REV 16	CUT-DPTH 17					
Pattern reaping (finish)	PROC(01) 0	AREA 2	HEAD 3	ROUGHNES 13	TOOL-NO 14	CUT-SPD 15	FEED/REV 16	T-CODE 18

● Pattern repeating (T one-spindle type)

Pattern repeating (rough)	PROC(01) 0	AREA 2		REMOVALX 25	REMOVALZ 26	TOOL-NO 14	CUT-SPD 15	T-CODE 18
		FEED/REV 16	CUT-DPTH 17					
Pattern reaping (finish)	PROC(01) 0	AREA 2		ROUGHNES 13	TOOL-NO 14	CUT-SPD 15	FEED/REV 16	T-CODE 18

● Residual machining (TT, T two-spindle type)

Residual machining (rough)	PROC(01) 0	AREA 2	HEAD 3	TOOL-NO 14	CUT-SPD 15	FEED/REV 16	CUT-DPTH 17	T-CODE 18
Residual machining (finish)	PROC(01) 0	AREA 2	HEAD 3	ROUGHNES 13	TOOL-NO 14	CUT-SPD 15	FEED/REV 16	T-CODE 18

● Residual machining (T one-spindle type)

Residual machining (rough)	PROC(01) 0	AREA 2		TOOL-NO 14	CUT-SPD 15	FEED/REV 16	CUT-DPTH 17	T-CODE 18
Residual machining (finish)	PROC(01) 0	AREA 2		ROUGHNES 13	TOOL-NO 14	CUT-SPD 15	FEED/REV 16	T-CODE 18

● End facing (TT, T two-spindle type)

End facing (rough)	PROC(01) 0		HEAD 3	TOOL-NO 14	CUT-SPD 15	FEED/REV 16	CUT-DPTH 17	T-CODE 18
End facing (finish)	PROC(01) 0		HEAD 3	ROUGHNES 13	TOOL-NO 14	CUT-SPD 15	FEED/REV 16	T-CODE 18

● End facing (T one-spindle type)

End facing (rough)	PROC(01) 0			TOOL-NO 14	CUT-SPD 15	FEED/REV 16	CUT-DPTH 17	T-CODE 18
End facing (finish)	PROC(01) 0			ROUGHNES 13	TOOL-NO 14	CUT-SPD 15	FEED/REV 16	T-CODE 18

* For the T two-spindle type, UNIT is replaced with SPINDLE.

● Threading (TT, T two-spindle type)

Threading (general-purpose)	PROC(01)	AREA	HEAD	THRD TYPE	THRD ANGL	CUT-METHD	LEAD	
	0	2	3	66	67	65	27	
Threading (metric)	PROC(01)	AREA	HEAD	THRD TYPE	CUT-METHD	LEAD		
	0	2	3	66	65	27		
Threading (unified PT, PF)	PROC(01)	AREA	HEAD	THRD TYPE	CUT-METHD	THRD CNT		
	0	2	3	66	65	68		
		TOOL-NO	CUT-SPD	CUT-NMBR	CHAMFER			T-CODE
		14	15	17	28			18

● Threading (T one-spindle type)

Threading (general-purpose)	PROC(01)	AREA		THRD TYPE	THRD ANGL	CUT-METHD	LEAD	
	0	2		66	67	65	27	
Threading(metric)	PROC(01)	AREA		THRD TYPE	CUT-METHD	LEAD		
	0	2		66	65	27		
Threading (unified PT, PF)	PROC(01)	AREA		THRD TYPE	CUT-METHD	THRD CNT		
	0	2		66	65	68		
		TOOL-NO	CUT-SPD	CUT-NMBR	CHAMFER			T-CODE
		14	15	17	28			18

● Grooving (TT, T two-spindle type)

Grooving <standard>	PROC(01)	AREA	HEAD	BASIS	PATTERN	WIDTH	TOOL-NO	T-CODE
	0	2	3	5	4	29	14	18
Grooving <slanted>	PROC(01)	AREA	HEAD	BASIS	PATTERN	WIDTH	ANGLE	
	0	2	3	5	4	29	32	
Grooving (rough) <trapezoidal>	PROC(01)	AREA	HEAD	BASIS	PATTERN	WIDTH	TOOL-NO	T-CODE
	0	2	3	5	4	29	14	18
Grooving (finish) <trapezoidal>	PROC(01)	AREA	HEAD	BASIS	PATTERN	WIDTH	ROUGHNES	
	0	2	3	5	4	29	13	
Grooving <thread>	PROC(01)	AREA	HEAD	BASIS	PATTERN	WIDTH	ANGLE	
	0	2	3	5	4	29	32	
		TOOL-NO	CUT-SPD	FEED/REV	CUT-DPTH	DWELL		T-CODE
		14	15	16	30	31		18

● Grooving (T one-spindle type)

Grooving <standard>	PROC(01)	AREA		BASIS	PATTERN	WIDTH	TOOL-NO	T-CODE
	0	2		5	4	29	14	18
		CUT-SPD	FEED/REV	CUT-DPTH	DWELL			
		15	16	30	31			
Grooving <slanted>	PROC(01)	AREA		BASIS	PATTERN	WIDTH	ANGLE	
	0	2		5	4	29	32	
		TOOL-NO	CUT-SPD	FEED/REV	CUT-DPTH	DWELL		T-CODE
		14	15	16	30	31		18
Grooving (rough) <trapezoidal>	PROC(01)	AREA		BASIS	PATTERN	WIDTH	TOOL-NO	T-CODE
	0	2		5	4	29	14	18
		CUT-SPD	FEED/REV	CUT-DPTH	DWELL			
		15	16	30	31			
Grooving (finish) <trapezoidal>	PROC(01)	AREA		BASIS	PATTERN	WIDTH	ROUGHNES	
	0	2		5	4	29	13	
		TOOL-NO	CUT-SPD	FEED/REV				T-CODE
		14	15	16				18
Grooving <thread>	PROC(01)	AREA		BASIS	PATTERN	WIDTH	ANGLE	
	0	2		5	4	29	32	
		TOOL-NO	CUT-SPD	FEED/REV	CUT-DPTH	DWELL		T-CODE
		14	15	16	30	31		18

● Necking (TT, T two-spindle type)

Necking <general-purpose>	PROC(01)		HEAD	AREA	SHAPE	ROUGHNES	TOOL-NO	T-CODE
	0		3	2	6	13	14	18
		CUT-SPD	FEED/REV	AMNT A	AMNT B	AMNT C	AMNT D	
		15	16	33	34	35	36	
Necking <DIN>	PROC(01)		HEAD	AREA	SHAPE	STNDRD-D	ROUGHNES	
	0		3	2	6	37	13	
		TOOL-NO	CUT-SPD	FEED/REV				T-CODE
		14	15	16				18

● Necking (T one-spindle type)

Necking <general-purpose>	PROC(01)			AREA	SHAPE	ROUGHNES	TOOL-NO	T-CODE
	0			2	6	13	14	18
		CUT-SPD	FEED/REV	AMNT A	AMNT B	AMNT C	AMNT D	
		15	16	33	34	35	36	
Necking <DIN>	PROC(01)			AREA	SHAPE	STNDRD-D	ROUGHNES	
	0			2	6	37	13	
		TOOL-NO	CUT-SPD	FEED/REV				T-CODE
		14	15	16				18

● Center drilling (TT, T two-spindle type)

<Ver.2>

Center drilling	PROC(01)		HEAD	END-PT	NOMINL-D	TOOL-NO	CUT-SPD	T-CODE
	0		3	38	39	14	15	18
		FEED/REV	DWELL					
		16	40					

* For the T two-spindle type, UNIT is replaced with SPINDLE.

● Center drilling (TT, T two-spindle type) <Ver.3>								
[Center drilling, starting]								
Center drilling	PROC(01)	MACHN-2	HEAD	HOLE-DIA	STAT-PZ	END-PTZ	TOOL-NO	T-CODE
	0	1	3	39	79	38	14	18
		CUT-SPD	FEED/REV	DWELL				
		15	16	40				
[Center drilling + chamfering, starting + chamfering]								
Center drilling	PROC(01)	MACHN-2	HEAD	CHAMF-DIA	STAT-PZ	END-PTZ	TOOL-NO	T-CODE
	0	1	3	80	79	38	14	18
		CUT-SPD	FEED/REV	DWELL				
		15	16	40				
● Center drilling (T one-spindle type) <Ver.2>								
Center drilling	PROC(01)			END-PT	NOMINL-D	TOOL-NO	CUT-SPD	T-CODE
	0			38	39	14	15	18
		FEED/REV	DWELL					
		16	40					
● Center drilling (T one-spindle type) <Ver.3>								
[Center drilling, starting]								
Center drilling	PROC(01)	MACHN-2		HOLE-DIA	STAT-PZ	END-PTZ	TOOL-NO	T-CODE
	0	1		39	79	38	14	18
		CUT-SPD	FEED/REV	DWELL				
		15	16	40				
[Center drilling + chamfering, starting + chamfering]								
Center drilling	PROC(01)	MACHN-2		CHAMF-DIA	STAT-PZ	END-PTZ	TOOL-NO	T-CODE
	0	1		80	79	38	14	18
		CUT-SPD	FEED/REV	DWELL				
		15	16	40				
● Drilling (TT, T two-spindle type) <Ver.2>								
[Up to 40 tools registered]								
Drilling	PROC(01)		HEAD	END-PT	HOLE-DIA	TOOL-NO	CUT-SPD	T-CODE
	0		3	38	41	14	15	18
		FEED/REV	DWELL	PATTERN	CUT-DPTH			
		16	40	4	30			
[Up to 99 tools registered: drilling]								
Drilling	PROC(01)	MACHN-2	HEAD	END-PT	HOLE-DIA	TOOL-NO	CUT-SPD	T-CODE
	0	1	3	38	41	14	15	18
		FEED/REV	DWELL	PATTERN	CUT-DPTH			
		16	40	4	30			
[Up to 99 tools registered: reaming]								
Drilling	PROC(01)	MACHN-2	HEAD	END-PT	HOLE-DIA	TOOL-NO	CUT-SPD	T-CODE
	0	1	3	38	41	14	15	18
		FEED/REV	DWELL					
		16	40					
[Up to 99 tools registered: boring]								
Drilling	PROC(01)	MACHN-2	HEAD	END-PT	HOLE-DIA	TOOL-NO	CUT-SPD	T-CODE
	0	1	3	38	41	14	15	18
		FEED/REV	DWELL	SHIFT				
		16	40	42				

* For the T two-spindle type, UNIT is replaced with SPINDLE.

● Drilling (TT, T two-spindle type)
 [Drilling]

<Ver.3>

Drilling	PROC(01) 0	MACHIN-2 1	HEAD 3	PATTERN 4	PROC-DIA 41	STAT-PZ 79	END-PTZ 38	
		TOOL-NO 14	CUT-SPD 15	FEED/REV 16	DWELL 40	CUT-DEPT H 30		T-CODE 18

[Reaming]

Drilling	PROC(01) 0	MACHIN-2 1	HEAD 3	PATTERN 4	PROC-DIA 41	CHAMF-LNG 78		
		STAT-PZ 79	END-PTZ 38	TOOL-NO 14	CUT-SPD 15	FEED-REV 16	DWELL 40	T-CODE 18

[Boring]

Drilling	PROC(01) 0	MACHIN-2 1	HEAD 3	PROC-DIA 41	STAT-PZ 79	END-PTZ 38	TOOL-NO 14	T-CODE 18
		CUT-SPD 15	FEED/REV 16	DWELL 40	SHIFT 42			

[End milling]

Drilling	PROC(01) 0	MACHIN-2 1	HEAD 3	PATTERN 4	PROC-DIA 41	STAT-PZ 79	RESID-PZ 77	
		END-PTZ 38	TOOL-NO 14	CUT-SPD 15	FEED/REV1 16	DWELL 40		T-CODE 18

[Throw-away drilling]

Drilling	PROC(01) 0	MACHIN-2 1	HEAD 3	PATTERN 4	PROC-DIA 41	STAT-PZ 79	END-PTZ 38	
		TOOL-NO 14	CUT-SPD 15	FEED/REV 16	DWELL 40	CUT-DEPTH 30		T-CODE 18

● Drilling (T one-spindle type)
 [Up to 40 tools registered]

<Ver.2>

Drilling	PROC(01) 0			END-PT 38	HOLE-DIA 41	TOOL-NO 14	CUT-SPD 15	T-CODE 18
		FEED/REV 16	DWELL 40	PATTERN 4	CUT-DPTH 30			

[Up to 99 tools registered: drilling]

Drilling	PROC(01) 0	MACHN-2 1		END-PT 38	HOLE-DIA 41	TOOL-NO 14	CUT-SPD 15	T-CODE 18
		FEED/REV 16	DWELL 40	PATTERN 4	CUT-DPTH 30			

[Up to 99 tools registered: reaming]

Drilling	PROC(01) 0	MACHN-2 1		END-PT 38	HOLE-DIA 41	TOOL-NO 14	CUT-SPD 15	T-CODE 18
		FEED/REV 16	DWELL 40					

[Up to 99 tools registered: boring]

Drilling	PROC(01) 0	MACHN-2 1		END-PT 38	HOLE-DIA 41	TOOL-NO 14	CUT-SPD 15	T-CODE 18
		FEED/REV 16	DWELL 40	SHIFT 42				

* For the T two-spindle type, UNIT is replaced with SPINDLE.

● Drilling (T one-spindle type) <Ver.3>								
[Drilling]								
Drilling	PROC(01) 0	MACHIN-2 1		PATTERN 4	PROC-DIA 41	STAT-PZ 79	END-PTZ 38	
		TOOL-NO 14	CUT-SPD 15	FEED/REV 16	DWELL 40	CUT-DEPTH 30		T-CODE 18
[Reaming]								
Drilling	PROC(01) 0	MACHIN-2 1		PATTERN 4	PROC-DIA 41	CHAMF-LNG 78		
		STAT-PZ 79	END-PTZ 38	TOOL-NO 14	CUT-SPD 15	FEED-REV 16	DWELL 40	T-CODE 18
[Boring]								
Drilling	PROC(01) 0	MACHIN-2 1		PROC-DIA 41	STAT-PZ 79	END-PTZ 38	TOOL-NO 14	T-CODE 18
		CUT-SPD 15	FEED/REV 16	DWELL 40	SHIFT 42			
[End milling]								
Drilling	PROC(01) 0	MACHIN-2 1		PATTERN 4	PROC-DIA 41	STAT-PZ 79	RESID-PZ 77	
		END-PTZ 38	TOOL-NO 14	CUT-SPD 15	FEED/REV1 16	DWELL 40		T-CODE 18
[Throw-away drilling]								
Drilling	PROC(01) 0	MACHIN-2 1		PATTERN 4	PROC-DIA 41	STAT-PZ 79	END-PTZ 38	
		TOOL-NO 14	CUT-SPD 15	FEED/REV 16	DWELL 40	CUT-DEPTH 30		T-CODE 18
● Tapping (TT, T two-spindle type) <Ver. 2>								
Tapping	PROC(01) 0		HEAD 3	END-PT 38	NOMINL-D 39	PITCH 43	TOOL-NO 14	T-CODE 18
		CUT-SPD 15	DWELL 40					
● Tapping (TT, T two-spindle type) <Ver. 3>								
Tapping	PROC(01) 0		HEAD 3	STAT-PZ 79	END-PTZ 38	NOMINL-D 39	PITCH 43	
		TOOL-NO 14	CUT-SPD 15	DWELL 40				T-CODE 18
● Tapping (T one-spindle type) <Ver. 2>								
Tapping	PROC(01) 0			END-PT 38	NOMINL-D 39	PITCH 43	TOOL-NO 14	T-CODE 18
		CUT-SPD 15	DWELL 40					
● Tapping (T one-spindle type) <Ver. 3>								
Tapping	PROC(01) 0			STAT-PZ 79	END-PTZ 38	NOMINL-D 39	PITCH 43	
		TOOL-NO 14	CUT-SPD 15	DWELL 40				T-CODE 18
● Single action (TT, T two-spindle type)								
Single action	PROC(01) 0		HEAD 3	TOOL-NO 14	CUT-SPD 15	FEEDRATE 7		T-CODE 18

* For the T two-spindle type, UNIT is replaced with SPINDLE.

● Single action (T one-spindle type)

Single action	PROC(01)		TOOL-NO	CUT-SPD	FEEDRATE		T-CODE
	0		14	15	7		18

● Single action II (TT, T two-spindle type)

<Ver. 3>

[With animated simulation]

Single action	PROC(01)	HEAD	TOOL-NO		TYPE	T-CODE
	0	3	14		81	18

[Without animated simulation]

Single action	PROC(01)	HEAD	TOOL-NO			T-CODE
	0	3	14			18

● Single action II (T one-spindle type)

<Ver. 3>

[With animated simulation]

Single action	PROC(01)		TOOL-NO		TYPE	T-CODE
	0		14		81	18

[Without animated simulation]

Single action	PROC(01)		TOOL-NO			T-CODE
	0		14			18

● Subprogram call (TT, T two-spindle type)

[Use of custom macro disabled]

Subprogram call	PROC(01)	HEAD	PROGRAM				
	0	3	8				

[Use of custom macro enabled]

Subprogram call	PROC(01)	HEAD	PROGRAM	DATA1	DATA2	DATA3	DATA4
	0	3	8	44	45	46	47

● Subprogram call (T one-spindle type)

[Use of custom macro disabled]

Subprogram call	PROC(01)		PROGRAM				
	0		8				

[Use of custom macro enabled]

Subprogram call	PROC(01)		PROGRAM	DATA1	DATA2	DATA3	DATA4
	0		8	44	45	46	47

● Subprogram call II (TT, T two-spindle type)

Subprogram call	PROC(01)	HEAD	PROGRAM	DATA A	DATA B	DATA C	DATA I
	0	3	8	82	83	84	85
		DATA J	DATA K	DATA D	DATA E	DATA F	DATA M
		86	87	88	89	90	92

● Subprogram call II (T one-spindle type)

Subprogram call	PROC(01)		PROGRAM	DATA A	DATA B	DATA C	DATA I
	0		8	82	83	84	85
		DATA J	DATA K	DATA D	DATA E	DATA F	DATA M
		86	87	88	89	90	92

● C-axis center drilling (TT, T two-spindle type)

<Ver. 2>

C-axis center drilling	PROC(01)	AREA	HEAD	NOMINL-D	TOOL-NO	REV/MIN	FEED/MIN	T-CODE
	0	2	3	39	14	15	16	18
		DWELL	INTRVAL					
		40	9					

* For the T two-spindle type, UNIT is replaced with SPINDLE.

● C-axis center drilling (TT, T two-spindle type) <Ver. 3>
[Center drilling, starting]

C-axis center drilling	PROC(01)	AREA	HEAD	MACHN-2	HOLE-DIA	TOOL-NO	REV/MIN	T-CODE
	0	2	3	1	39	14	15	18
		FEED/MIN	DWELL	INTERVAL				
		16	40	9				

[Center drilling + chamfering, starting + chamfering]

C-axis center drilling	PROC(01)	AREA	HEAD	MACHN-2	CHAMF-DIA	TOOL-NO	REV/MIN	T-CODE
	0	2	3	1	80	14	15	18
		FEED/MIN	DWELL	INTERVAL				
		16	40	9				

● C-axis center drilling (T one-spindle type) <Ver. 2>

C-axis center drilling	PROC(01)	AREA		NOMINL-D	TOOL-NO	REV/MIN	FEED/MIN	T-CODE
	0	2		39	14	15	16	18
		DWELL	INTRVAL					
		40	9					

● C-axis center drilling (T one-spindle type) <Ver. 3>
[Center drilling, starting]

C-axis center drilling	PROC(01)	AREA		MACHN-2	HOLE-DIA	TOOL-NO	REV/MIN	T-CODE
	0	2		1	39	14	15	18
		FEED/MIN	DWELL	INTERVAL				
		16	40	9				

[Center drilling + chamfering, starting + chamfering]

C-axis center drilling	PROC(01)	AREA		MACHN-2	CHAMF-DIA	TOOL-NO	REV/MIN	T-CODE
	0	2		1	80	14	15	18
		FEED/MIN	DWELL	INTERVAL				
		16	40	9				

● C-axis Drilling (TT, T two-spindle type) <Ver.2>
[Up to 40 tools registered]

C-axis Drilling	PROC(01)	AREA	HEAD		HOLE-DIA	TOOL-NO	REV/MIN	T-CODE
	0	2	3		41	14	15	18
		FEED/MIN	DWELL	PATTERN	CUT-DPTH	INTERVAL		
		16	40	4	30	0		

[Up to 99 tools registered: drilling]

C-axis Drilling	PROC(01)	AREA	HEAD	MACHIN-2	HOLE-DIA	TOOL-NO	REV/MIN	T-CODE
	0	2	3	1	41	14	15	18
		FEED/MIN	DWELL	PATTERN	CUT-DPTH	INTERVAL		
		16	40	4	30	9		

[Up to 99 tools registered: reaming]

C-axis Drilling	PROC(01)	AREA	HEAD	MACHIN-2	HOLE-DIA	TOOL-NO	REV/MIN	T-CODE
	0	2	3	1	41	14	15	18
		FEED/MIN	DWELL	INTERVAL				
		16	40	9				

* For the T two-spindle type, UNIT is replaced with SPINDLE.

● C-axis Drilling (TT, T two-spindle type)
 [Drilling]

<Ver.3>

C-axis Drilling	PROC(01)	AREA	HEAD	MACHIN-2	PATTERN	PROC-DIA	TOOL-NO	T-CODE
	0	2	3	1	4	41	34	18
		REV/MIN	FEED/MIN	DWELL	CUT-DPTH	INTERVAL		
		15	16	40	30	9		

[Reaming]

C-axis Drilling	PROC(01)	AREA	HEAD	MACHIN-2	PATTERN	PROC-DIA	CHAMFLNG	T-CODE
	0	2	3	1	4	41	78	18
		TOOL-NO	REV/MIN	FEED/MIN	DWELL	INTERVAL		
		14	15	16	40	9		

[End milling]

C-axis Drilling	PROC(01)	AREA	HEAD	MACHIN-2	PATTERN	PROC-DIA	TOOL-NO	T-CODE
	0	2	3	1	4	41	14	18
		REV/MIN	FEED/MIN	DWELL	INTERVAL			
		15	16	40	9			

[Boring]

C-axis Drilling	PROC(01)	AREA	HEAD	MACHIN-2	PROC-DIA	TOOL-NO	REV/MIN	T-CODE
	0	2	3	1	4	14	15	18
		FEED/MIN	DWELL	SHIFT	INTERVAL			
		16	40	42	9			

● Drilling (T one-spindle type)
 [Up to 40 tools registered]

<Ver.2>

C-axis Drilling	PROC(01)	AREA			HOLE-DIA	TOOL-NO	REV/MIN	T-CODE
	0	2			41	14	15	18
		FEED/MIN	DWELL	PATTERN	CUT-DPTH	INTERVAL		
		16	40	4	30	9		

[Up to 99 tools registered: drilling]

C-axis Drilling	PROC(01)	AREA		MACHIN-2	HOLE-DIA	TOOL-NO	REV/MIN	T-CODE
	0	2		1	41	14	15	18
		FEED/MIN	DWELL	PATTERN	CUT-DPTH	INTERVAL		
		16	40	4	30	9		

[Up to 99 tools registered: reaming]

C-axis Drilling	PROC(01)	AREA		MACHIN-2	HOLE-DIA	TOOL-NO	REV/MIN	T-CODE
	0	2		1	41	14	15	18
		FEED/MIN	DWELL	INTERVAL				
		16	40	9				

* For the T two-spindle type, UNIT is replaced with SPINDLE.

● Drilling (T one-spindle type)

<Ver.3>

[Drilling]

C-axis Drilling	PROC(01)	AREA		MACHIN-2	PATTERN	PROC-DIA	TOOL-NO	T-CODE
	0	2		1	4	41	14	18
		REV/MIN	FEED/MIN	DWELL	CUT-DPTH	INTERVAL		
		15	16	40	30	9		

[Reaming]

C-axis Drilling	PROC(01)	AREA		MACHIN-2	PATTERN	PROC-DIA	CHAMFLNG	
	0	2		1	4	41	78	
		TOOL-NO	REV/MIN	FEED/MIN	DWELL	INTERVAL		T-CODE
		14	15	16	40	9		18

[End milling]

C-axis Drilling	PROC(01)	AREA		MACHIN-2	PATTERN	PROC-DIA	TOOL-NO	T-CODE
	0	2		1	4	41	14	18
		REV/MIN	FEED/MIN	DWELL	INTERVAL			
		15	16	40	9			

[Boring]

C-axis Drilling	PROC(01)	AREA		MACHIN-2	PROC-DIA	TOOL-NO	REV/MIN	T-CODE
	0	2		1	4	14	15	18
		FEED/MIN	DWELL	SHIFT	INTERVAL			
		16	40	42	9			

● C-axis tapping (TT, T two-spindle type)

C-axis tapping	PROC(01)	AREA	HEAD	NOMINL-D	PITCH	TOOL-D	REV/MIN	T-CODE
	0	2	3	39	43	14	15	18
		FEED/MIN	DWELL	INTRVAL				
		16	40	9				

● C-axis tapping (T one-spindle type)

C-axis tapping	PROC(01)	AREA		NOMINL-D	PITCH	TOOL-D	REV/MIN	T-CODE
	0	2		39	43	14	15	18
		FEED/MIN	DWELL	INTRVAL				
		16	40	9				

● C-axis grooving (TT, T two-spindle type)

[Spindle positioning type : Only standard grooving on the side face enabled]

C-axis grooving (rough)	PROC(01)		HEAD	GRV-DIA	TOOL-NO	REV/MIN	FEEDRATE1	T-CODE
	0		3	48	14	15	49	18
		FEEDRATE2	BEVEL-AM					
		51	53					
C-axis grooving (chamfer)	PROC(01)		HEAD	GRV-DIA	TOOL-NO	REV/MIN	FEED/MIN	T-CODE
	0		3	48	14	15	16	18
		BEVEL-AM						
		53						

[Contour control type - machining area: End face]

C-axis grooving (rough)	PROC(01)	AREA	HEAD	GRV-DIA	TOOL-NO	REV/MIN	FEEDRATE1	T-CODE
	0	2	3	48	14	15	49	18
		FEEDRATE2	SHAPE	BEVEL-AM				
		51	10	53				
C-axis grooving (chamfer)	PROC(01)	AREA	HEAD	GRV-DIA	TOOL-NO	REV/MIN	FEED/MIN	T-CODE
	0	2	3	48	14	15	16	18
		SHAPE	BEVEL-AM					
		10	53					

* For the T two-spindle type, UNIT is replaced with SPINDLE.

[Contour control type - machining area: Side face]

C-axis grooving (rough)	PROC(01) 0	AREA 2	HEAD 3	GRV-DIA 48	TOOL-NO 14	REV/MIN 15	FEEDRATE1 49	T-CODE 18
		FEEDRATE2 51	SHAPE 10	BEVEL-AM 53				
C-axis grooving (chamfer)	PROC(01) 0	AREA 2	HEAD 3	GRV-DIA 48	TOOL-NO 14	REV/MIN 15	FEED/MIN 16	T-CODE 18
		SHAPE 10	BEVEL-AM 53					

● C-axis grooving (T one-spindle type)

[Spindle positioning type : Only standard grooving on the side face enabled]

C-axis grooving (rough)	PROC(01) 0			GRV-DIA 48	TOOL-NO 14	REV/MIN 15	FEEDRATE1 49	T-CODE 18
		FEEDRATE2 51	BEVEL-AM 53					
C-axis grooving (chamfer)	PROC(01) 0			GRV-DIA 48	TOOL-NO 14	REV/MIN 15	FEED/MIN 16	T-CODE 18
		BEVEL-AM 53						

[Contour control type - machining area : End face]

C-axis grooving (rough)	PROC(01) 0	AREA 2		GRV-DIA 48	TOOL-NO 14	REV/MIN 15	FEEDRATE1 49	T-CODE 18
		FEEDRATE2 51	SHAPE 10	BEVEL-AM 53				
C-axis grooving (chamfer)	PROC(01) 0	AREA 2		GRV-DIA 48	TOOL-NO 14	REV/MIN 15	FEED/MIN 16	T-CODE 18
		SHAPE 10	BEVEL-AM 53					

[Contour control type - machining area : Side face]

C-axis grooving (rough)	PROC(01) 0	AREA 2		GRV-DIA 48	TOOL-NO 14	REV/MIN 15	FEEDRATE1 49	T-CODE 18
		FEEDRATE2 51	SHAPE 10	BEVEL-AM 53				
C-axis grooving (chamfer)	PROC(01) 0	AREA 2		GRV-DIA 48	TOOL-NO 14	REV/MIN 15	FEED/MIN 16	T-CODE 18
		SHAPE 10	BEVEL-AM 53					

● C-axis notching (TT, T two-spindle type)

[Machining area: End face]

C-axis notching (rough)	PROC(01) 0	AREA 2	HEAD 3	STAT-PZ 54	END-PTZ 55	REMOVALX 25	TOOL-NO 14	T-CODE 18
		REV/MIN 15	FEED/MIN 16	FINISHX 56	FINISHZ 57			
C-axis notching (finish)	PROC(01) 0	AREA 2	HEAD 3	STAT-PZ 54	END-PTZ 55	TOOL-NO 14	REV/MIN 15	T-CODE 18
		FEED/MIN 16	BEVEL-AM 53					
C-axis notching (chamfer)	PROC(01) 0	AREA 2	HEAD 3	STAT-PZ 54	TOOL-NO 14	REV/MIN 15	FEED/MIN 16	T-CODE 18
		BEVEL-AM 53						

* For the T two-spindle type, UNIT is replaced with SPINDLE.

[Machining area: Side face]

C-axis notching (rough)	PROC(01)	AREA	HEAD	STAT-PZ	END-PTZ	REMOVALX	TOOL-NO	T-CODE
	0	2	3	54	55	25	14	18
		REV/MIN	FEED/MIN	FINISHX	FINISHZ			
		15	16	56	57			
C-axis notching (finish)	PROC(01)	AREA	HEAD	STAT-PZ	END-PTZ	TOOL-NO	REV/MIN	T-CODE
	0	2	3	54	55	14	15	18
		FEED/MIN						
		16						

● C-axis notching (T one-spindle type)

[Machining area: End face]

C-axis notching (rough)	PROC(01)	AREA		STAT-PZ	END-PTZ	REMOVALX	TOOL-NO	T-CODE
	0	2		54	55	25	14	18
		REV/MIN	FEED/MIN	FINISHX	FINISHZ			
		15	16	56	57			
C-axis notching (finish)	PROC(01)	AREA		STAT-PZ	END-PTZ	TOOL-NO	REV/MIN	T-CODE
	0	2		54	55	14	15	18
		FEED/MIN	BEVEL-AM					
		16	53					
C-axis notching (chamfer)	PROC(01)	AREA		STAT-PZ	TOOL-NO	REV/MIN	FEED/MIN	T-CODE
	0	2		54	14	15	16	18
		BEVEL-AM						
		53						

[Machining area: Side face]

C-axis notching (rough)	PROC(01)	AREA		STAT-PZ	END-PTZ	REMOVALX	TOOL-NO	T-CODE
	0	2		54	55	25	14	18
		REV/MIN	FEED/MIN	FINISHX	FINISHZ			
		15	16	56	57			
C-axis notching (finish)	PROC(01)	AREA		STAT-PZ	END-PTZ	TOOL-NO	REV/MIN	T-CODE
	0	2		54	55	14	15	18
		FEED/MIN						
		16						

● C-axis cylindrical machining (TT, T two-spindle type)

C-axis cylindrical machining (rough)	PROC(01)		HEAD	STAT-PX	DEPTH	GRV-DIA	TOOL-NO	T-CODE
	0		3	58	59	48	14	18
		REV/MIN	FEEDRATE1	FEEDRATE2	BEVEL-AM			
		15	50	52	53			
C-axis cylindrical machining (chamfer)	PROC(01)		HEAD	STAT-PX	DEPTH	GRV-DIA	TOOL-NO	T-CODE
	0		3	58	59	48	14	18
		REV/MIN	FEED/MIN	BEVEL-AM				
		15	16	53				

● C-axis cylindrical machining (T one-spindle type)

C-axis cylindrical machining (rough)	PROC(01)			STAT-PX	DEPTH	GRV-DIA	TOOL-NO	T-CODE
	0			58	59	48	14	18
		REV/MIN	FEEDRATE1	FEEDRATE2	BEVEL-AM			
		15	50	52	53			
C-axis cylindrical machining (chamfer)	PROC(01)			STAT-PX	DEPTH	GRV-DIA	TOOL-NO	T-CODE
	0			58	59	48	14	18
		REV/MIN	FEED/MIN	BEVEL-AM				
		15	16	53				

* For the T two-spindle type, UNIT is replaced with SPINDLE.

● Transfer

Transfer	PROC(01) 0	User Program
----------	---------------	--------------

● Auxiliary

Auxiliary	PROC(01) 0	User Program
-----------	---------------	--------------

● M (TT, T two-spindle type)

M	PROC(01) 0	HEAD 3	M 60	M 60	M 60	M 60	M 60
---	---------------	-----------	---------	---------	---------	---------	---------

● M (T one-spindle type)

M	PROC(01) 0	M 60	M 60	M 60	M 60	M 60
---	---------------	---------	---------	---------	---------	---------

● End

End	PROC(01) 0	RETURN 11	RETURN-X 61	RETURN-Z 62	RETURN-C 63	END-M 12	LOOP 64
-----	---------------	--------------	----------------	----------------	----------------	-------------	------------

● Y-axis center drilling (TT, T two-spindle type)

Y-axis center drilling	PROC(01) 0	AREA 2	HEAD 3	NOMINL-D 39	TOOL-NO 14	REV/MIN 15	FEED/MIN 16	T-CODE 18
		DWELL 40	HOLE-PTN 69					

● Y-axis center drilling (T one-spindle type)

Y-axis center drilling	PROC(01) 0	AREA 2	NOMINL-D 39	TOOL-NO 14	REV/MIN 15	FEED/MIN 16	T-CODE 18
		DWELL 40	HOLE-PTN 69				

● Y-axis drilling (TT, T two-spindle type)

[Up to 40 tools registered]

Y-axis drilling	PROC(01) 0	AREA 2	HEAD 3	HOLE-DIA 41	TOOL-NO 14	REV/MIN 15	T-CODE 18
		FEED/MIN 16	DWELL 40	PATTERN 4	CUT-DPTH 30	HOLE-PTN 69	

[Up to 99 tools registered: drilling]

Y-axis drilling	PROC(01) 0	AREA 2	HEAD 3	MACHN-2 1	HOLE-DIA 41	TOOL-NO 14	REV/MIN 15	T-CODE 18
		FEED/MIN 16	DWELL 40	PATTERN 4	CUT-DPTH 30	HOLE-PTN 69		

[Up to 99 tools registered: reaming]

Y-axis drilling	PROC(01) 0	AREA 2	HEAD 3	MACHN-2 1	HOLE-DIA 41	TOOL-NO 14	REV/MIN 15	T-CODE 18
		FEED/MIN 16	DWELL 40	HOLE-PTN 69				

● Y-axis drilling (T one-spindle type)

[Up to 40 tools registered]

Y-axis drilling	PROC(01) 0	AREA 2	HOLE-DIA 41	TOOL-NO 14	REV/MIN 15	T-CODE 18
		FEED/MIN 16	DWELL 40	PATTERN 4	CUT-DPTH 30	HOLE-PTN 69

* For the T two-spindle type, UNIT is replaced with SPINDLE.

[Up to 99 tools registered: drilling]

Y-axis drilling	PROC(01)	AREA		MACHN-2	HOLE-DIA	TOOL-NO	REV/MIN	T-CODE
	0	2		1	41	14	15	18
		FEED/MIN	DWELL	PATTERN	CUT-DPTH	HOLE-PTN		
		16	40	4	30	69		

[Up to 99 tools registered: reaming]

Y-axis drilling	PROC(01)	AREA		MACHN-2	HOLE-DIA	TOOL-NO	REV/MIN	T-CODE
	0	2		1	41	14	15	18
		FEED/MIN	DWELL	HOLE-PTN				
		16	40	69				

● Y-axis tapping (TT, T two-spindle type)

Y-axis tapping	PROC(01)	AREA	HEAD	NOMINL-D	PITCH	TOOL-NO	REV/MIN	T-CODE
	0	2	3	39	43	14	15	18
		FEED/MIN	DWELL	HOLE-PTN				
		16	40	69				

● Y-axis tapping (T one-spindle type)

Y-axis tapping	PROC(01)	AREA		NOMINL-D	PITCH	TOOL-NO	REV/MIN	T-CODE
	0	2		39	43	14	15	18
		FEED/MIN	DWELL	HOLE-PTN				
		16	40	69				

● Y milling (TT, T two-spindle type)

[Machining area: End face]

Y milling	PROC(01)	AREA	HEAD	DEPTH	GRV-DIA	TOOL-NO	REV/MIN	T-CODE
	0	2	3	59	48	14	15	18
		FEEDRATE1	FEEDRATE2	ESCAPE-SZ	SHIFT-DR			
		73	51	75	70			

[Machining area: Side face]

Ymilling	PROC(01)	AREA	HEAD	DEPTH	GRV-DIA	TOOL-NO	REV/MIN	T-CODE
	0	2	3	59	48	14	15	18
		FEEDRATE1	FEEDRATE2	ESCAPE-SX	SHIFT-DR			
		74	51	76	70			

● Y milling (T one-spindle type)

[Machining area: End face]

Y milling	PROC(01)	AREA		DEPTH	GRV-DIA	TOOL-NO	REV/MIN	T-CODE
	0	2		59	48	14	15	18
		FEEDRATE1	FEEDRATE2	ESCAPE-SZ	SHIFT-DR			
		73	51	75	70			

[Machining area: Side face]

Ymilling	PROC(01)	AREA		DEPTH	GRV-DIA	TOOL-NO	REV/MIN	T-CODE
	0	2		59	48	14	15	18
		FEEDRATE1	FEEDRATE2	ESCAPE-SX	SHIFT-DR			
		74	51	76	70			

* For the T two-spindle type, UNIT is replaced with SPINDLE.

● Figure data

<Residual machining>

STAT-PX 10	STAT-PZ 11	END-PTX 12	END-PTZ 13	ROUND 14	CHAMFER 15
STAT-PX 20	STAT-PZ 21	END-PTX 22	END-PTZ 23	ROUND 24	CHAMFER 25
STAT-PX 30	STAT-PZ 31	END-PTX 32	END-PTZ 33	ROUND 34	CHAMFER 35
STAT-PX 40	STAT-PZ 41	END-PTX 42	END-PTZ 43	ROUND 44	CHAMFER 45
STAT-PX 50	STAT-PZ 51	END-PTX 52	END-PTZ 53	ROUND 54	CHAMFER 55

<Threading-general-purpose>

STAT-PX 10	STAT-PZ 11	END-PTX 12	END-PTZ 13
STAT-PX 20	STAT-PZ 21	END-PTX 22	END-PTZ 23
STAT-PX 30	STAT-PZ 31	END-PTX 32	END-PTZ 33
STAT-PX 40	STAT-PZ 41	END-PTX 42	END-PTZ 43
STAT-PX 50	STAT-PZ 51	END-PTX 52	END-PTZ 53

<Threading-metric>

THRD DIA 14	STAT-PZ 11	END-PTZ 13
THRD DIA 24	STAT-PZ 21	END-PTZ 23
THRD DIA 34	STAT-PZ 31	END-PTZ 33
THRD DIA 44	STAT-PZ 41	END-PTZ 43
THRD DIA 54	STAT-PZ 51	END-PTZ 53

<Threading-PT>

END-PTX 10	STAT-PZ 11	END-PTZ 12
---------------	---------------	---------------

<Threading-unified, PF>

THRD DIA 14	STAT-PZ 11	END-PTZ 12
----------------	---------------	---------------

<Grooving-standard>

STAT-PX 0	STAT-PZ 1	END-PTX 2	WIDTH 4	DEPTH 5	PITCH 6	NUMBER 7
CHAMFER 8						

<Grooving-slanted>

STAT-PX 0	STAT-PZ 1	WIDTH 4	GRV-DIA 5	PITCH 6	NUMBER 7
--------------	--------------	------------	--------------	------------	-------------

<Grooving-trapezoidal>

	PITCH	NUMBER		
	6	7		
	STAT-PX	STAT-PZ		
	0	1		
	POINT 1X	POINT 1Z	ROUND	CHAMFER
	10	11	12	13
	POINT 2X	POINT 2Z	ROUND	CHAMFER
	20	21	22	23
	POINT 3X	POINT 3Z	ROUND	CHAMFER
	30	31	32	33
	POINT 4X	POINT 4Z	ROUND	CHAMFER
	40	41	42	43
	END-PTX	END-PTZ		
	2	3		

<Grooving-thread>

	STAT-PX	STAT-PZ	END-PTX	WIDTH	GRV-DIA	CHAMFER
	0	1	2	4	5	8

<Grooving-thread> (when a subspindle of T one-spindle type is selected)

	STAT-PX	STAT-PZ	END-PTX	WIDTH	GRV-DIA	CHAMFER
	0	1	2	4	5	8

<Necking>

	BSC PTX1	BSC PTZ1	BSC PTX2	BSC PTZ2	BSC PTX3	BSC PTZ3
	0	1	2	3	4	5
	BSC PTX4	BSC PTZ4	BSC PTX5	BSC PTZ5		
	6	7	8	9		

<C-axis center drilling, C-axis drilling, C-axis tapping-[constant interval]>

	STAT-PX	STAT-PZ	STAT-PC	DEPTH	ANGLE	ITEMS	FIN-ANGL
	0	1	2	3	4	5	6

<C-axis center drilling, C-axis drilling, C-axis tapping-[variable interval-end face]>

	POINT 1X	POINT 1C	STAT-PZ	DEPTH
	10	11	12	13
	POINT 2X	POINT 2C	STAT-PZ	DEPTH
	20	21	22	23
	POINT 3X	POINT 3C	STAT-PZ	DEPTH
	30	31	32	33
	POINT 4X	POINT 4C	STAT-PZ	DEPTH
	40	41	42	43
	POINT 5X	POINT 5C	STAT-PZ	DEPTH
	50	51	52	53
	POINT 6X	POINT 6C	STAT-PZ	DEPTH
	60	61	62	63

<C-axis center drilling, C-axis drilling, C-axis tapping-[variable interval-side face]>

POINT 1Z	POINT 1C	STAT-PX	DEPTH
10	11	12	13
POINT 2Z	POINT 2C	STAT-PX	DEPTH
20	21	22	23
POINT 3Z	POINT 3C	STAT-PX	DEPTH
30	31	32	33
POINT 4Z	POINT 4C	STAT-PX	DEPTH
40	41	42	43
POINT 5Z	POINT 5C	STAT-PX	DEPTH
50	51	52	53
POINT 6Z	POINT 6C	STAT-PX	DEPTH
60	61	62	63

<C-axis grooving-[constant interval]>

STAT-PX	STAT-PZ	STAT-PC	DEPTH	GRV-LENG	ANGLE	ITEMS
0	1	2	3	4	5	6
FIN-ANGL						
7						

<C-axis grooving-[variable interval-end face]>

STAT-PX	STAT-PZ	STAT-PC	END-PTX	END-PTC	DEPTH
10	11	12	13	14	15
STAT-PX	STAT-PZ	STAT-PC	END-PTX	END-PTC	DEPTH
20	21	22	23	24	25
STAT-PX	STAT-PZ	STAT-PC	END-PTX	END-PTC	DEPTH
30	31	32	33	34	35
STAT-PX	STAT-PZ	STAT-PC	END-PTX	END-PTC	DEPTH
40	41	42	43	44	45
STAT-PX	STAT-PZ	STAT-PC	END-PTX	END-PTC	DEPTH
50	51	52	53	54	55
STAT-PX	STAT-PZ	STAT-PC	END-PTX	END-PTC	DEPTH
60	61	62	63	64	65

<C-axis grooving-[variable interval-side face]>

STAT-PX	STAT-PZ	STAT-PC	END-PTZ	END-PTC	DEPTH
10	11	12	13	14	15
STAT-PX	STAT-PZ	STAT-PC	END-PTZ	END-PTC	DEPTH
20	21	22	23	24	25
STAT-PX	STAT-PZ	STAT-PC	END-PTZ	END-PTC	DEPTH
30	31	32	33	34	35
STAT-PX	STAT-PZ	STAT-PC	END-PTZ	END-PTC	DEPTH
40	41	42	43	44	45
STAT-PX	STAT-PZ	STAT-PC	END-PTZ	END-PTC	DEPTH
50	51	52	53	54	55
STAT-PX	STAT-PZ	STAT-PC	END-PTZ	END-PTC	DEPTH
60	61	62	63	64	65

<Y-axis center drilling, Y-axis drilling, Y-axis tapping-[circle-end face]>

CENTR-PX	CENTR-PY	STAT-PZ	STAT-ANGL	DEPTH	REVOLVE-A
0	1	2	3	4	5
RADIUS	ANGLE	ITEMS	FIN-ANGL		
6	7	8	9		

<Y-axis center drilling, Y-axis drilling, Y-axis tapping-[circle-side face]>

CENTR-PY	CENTR-PZ	STAT-PX	STAT-ANGL	DEPTH	REVOLVE-A
0	1	2	3	4	5
RADIUS	ANGLE	ITEMS	FIN-ANGL		
6	7	8	9		

<Y-axis center drilling, Y-axis drilling, Y-axis tapping-[grid-end face]>

CENTR-PX	CENTR-PY	STAT-PZ	DEPTH	REVOLVE-A	PITCH-WID
0	1	2	3	4	5
COUNT/LIN	REMOV-WID	LIN-COUNT			
6	7	8			

<Y-axis center drilling, Y-axis drilling, Y-axis tapping-[grid-side face]>

CENTR-PY	CENTR-PZ	STAT-PX	DEPTH	REVOLVE-A	PITCH-WID
0	1	2	3	4	5
COUNT/LIN	REMOV-WID	LIN-COUNT			
6	7	8			

<Y-axis center drilling, Y-axis drilling, Y-axis tapping-[desired-end face]>

POINT 1X	POINT 1Y	POINT 1C	POINT 1Z	DEPTH
10	11	12	13	14
POINT 2X	POINT 2Y	POINT 2C	POINT 2Z	DEPTH
20	21	22	23	24
POINT 3X	POINT 3Y	POINT 3C	POINT 3Z	DEPTH
30	31	32	33	34
POINT 4X	POINT 4Y	POINT 4C	POINT 4Z	DEPTH
40	41	42	43	44
POINT 5X	POINT 5Y	POINT 5C	POINT 5Z	DEPTH
50	51	52	53	54
POINT 6X	POINT 6Y	POINT 6C	POINT 6Z	DEPTH
60	61	62	63	64

<Y-axis center drilling, Y-axis drilling, Y-axis tapping-[desired-side face]>

POINT 1Y	POINT 1Z	POINT 1C	POINT 1X	DEPTH
10	11	12	13	14
POINT 2Y	POINT 2Z	POINT 2C	POINT 2X	DEPTH
20	21	22	23	24
POINT 3Y	POINT 3Z	POINT 3C	POINT 3X	DEPTH
30	31	32	33	34
POINT 4Y	POINT 4Z	POINT 4C	POINT 4X	DEPTH
40	41	42	43	44
POINT 5Y	POINT 5Z	POINT 5C	POINT 5X	DEPTH
50	51	52	53	54
POINT 6Y	POINT 6Z	POINT 6C	POINT 6X	DEPTH
60	61	62	63	64

● Contour data

<Bar machining, pattern repeating>

0	START	X=	Z=		
0	←	X=	Z=	SR=	
0	→	X=	Z=	SR=	
0	↑	X=	Z=	SR=	
0	↓	X=	Z=	SR=	
0	↗	X=	Z=	SR=	
0	↖	X=	Z=	SR=	
0	↘	X=	Z=	SR=	
0	↙	X=	Z=	SR=	
0	⊚	X=	Z=	R=	SR=
0	⊙	X=	Z=	R=	SR=
0	CHAMFR	X=	Z=	SR=	
0	ROUND	X=	Z=	R=	SR=

<C-axis notching>

0	START	X=	Z=		
0	APROCH	X=	Z=	R=	
0	←	X=	Z=		
0	→	X=	Z=		
0	↑	X=	Z=		
0	↓	X=	Z=		
0	↗	X=	Z=		
0	↖	X=	Z=		
0	↘	X=	Z=		
0	↙	X=	Z=		
0	⊚	X=	Z=	R=	
0	⊙	X=	Z=	R=	
0	CHAMFR	X=	Z=		
0	ROUND	X=	Z=	R=	
0	ESCAPE	X=	Z=	R=	

<C-axis cylindrical machining>

0	START	C=	Z=		
0	←	C=	Z=		
0	→	C=	Z=		
0	↑	C=	Z=		
0	↓	C=	Z=		
0	↗	C=	Z=		
0	↖	C=	Z=		
0	↘	C=	Z=		
0	↙	C=	Z=		
0	⊚	C=	Z=	R=	
0	⊙	C=	Z=	R=	
0	CHAMFR	C=	Z=		
0	ROUND	C=	Z=	R=	
0	SHIFT	C=	Z=	R=	

<Y-axis milling-end face>

0	START	X=	Y=	C=	
0	←	X=	Y=		
0	→	X=	Y=		
0	↑	X=	Y=		
0	↓	X=	Y=		
0	↗	X=	Y=		
0	↖	X=	Y=		
0	↙	X=	Y=		
0	↘	X=	Y=		
0	Ⓚ	X=	Z=	R=	
0	Ⓛ	X=	Z=	R=	
0	CHAMFR	X=	Y=		
0	ROUND	X=	Y=	R=	
0	SHIFT	X=	Y=	C=	Z=

<Y-axis milling-side face>

0	START	Y=	Z=		
0	←	Y=	Z=		
0	→	Y=	Z=		
0	↑	Y=	Z=		
0	↓	Y=	Z=		
0	↗	Y=	Z=		
0	↖	Y=	Z=		
0	↙	Y=	Z=		
0	↘	Y=	Z=		
0	Ⓚ	X=	Z=	R=	
0	Ⓛ	X=	Z=	R=	
0	CHAMFR	Y=	Z=		
0	ROUND	Y=	Z=	R=	
0	SHIFT	Y=	Z=	C=	X=

● Action figure data

<Single action>

0	AUX-F	M=1	S=2	T=3	
0	POSITN	X=1	Z=2		
0	LINE	X=1	Z=2	F=3	
0	ARC Ⓚ	X=1	Z=2	R=3	F=4
0	ARC Ⓛ	X=1	Z=2	R=3	F=4
0	DWELL	P=1			
0	THREAD	X=1	Z=2	F=3	

<Single action II>

0	1	2	3	4	<Ver. 3>
---	---	---	---	---	----------

(b) System variable indicating a data line : #9201

In system variable #9201, a value indicating the data line to which the cursor is positioned is set.

- #9201 0 : Process data
- 1 : Figure data
- 2 : Contour data or single action figure data
- 3 : Initial setting data
- 4 : Workpiece point data (point on outer surface)
- 5 : Workpiece point data (point on inner surface)
- 6 : Program number or name

(c) System variable indicating contour data : #9202

In system variable #9202, a value indicating the line of contour data to which the cursor is positioned is set.

- #9202 0 : START
(Bar, Pattern repeating, C-axis notching, C-axis cylinder)
- 1 : →, ←
(Bar, Pattern repeating, C-axis notching, C-axis cylinder)
- 2 : ↑, ↓
(Bar, Pattern repeating, C-axis notching, C-axis cylinder)
- 3 : ↖, ↙, ↘, ↗
(Bar, Pattern repeating, C-axis notching, C-axis cylinder)
- 4 : Ⓞ, Ⓢ
(Bar, Pattern repeating, C-axis notching, C-axis cylinder)
- 5 : CHAMFER
(Bar, Pattern repeating, C-axis notching, C-axis cylinder)
- 6 : ROUND
(Bar, Pattern repeating, C-axis notching, C-axis cylinder)
- 7 : ESCAPE (C-axis nothcing)
- 8 : SHIFT (C-axis cylinder)
- 9 : APROACH (C-axis nothcing)
- 10: at inputting new figuredata in Single Action
- 11: AUX (Single action)
- 12: POSITION (Single action)
- 13: LINE (Single action)
- 14: ARC Ⓞ (Single action)
- 15: ARC Ⓢ (Single action)
- 16: DWELL (Single action)
- 17: THREAD (Single action)

(d) System variable indicating the number of lines of contour data : #9203

In system variable #9203, a value indicating the position of the line of the contour data or single action figure data, to which the cursor is positioned, is set. The line position is counted from the first line.

0	START	X=	Z=		
1	↑	X=	Z=	SR=	
2	ROUND	X=	Z=	R=	SR=
3	←	X=	Z=	SR=	
4	↖	X=	Z=	SR=	
5	←	X=	Z=	SR=	
6	CHAMFER	X=	Z=	SR=	
7	↑	X=	Z=	SR=	
			}		
20	ROUND	X=	Z=	R=	SR=
			}		
30	↑	X=	Z=	SR=	

- (e) System variables indicating the position of the cursor on the screen : #9108, #9109

In system variables #9108 and #9109, values indicating the position of the cursor on the screen are set as character coordinates.

#9108 : X coordinate of the cursor position
#9109 : Y coordinate of the cursor position

- (3) System variable indicating a soft key page : #9204

In system variable #9204, a value indicating the currently displayed soft key page is set.

#9204 0 : The first page is displayed.
1 : The second page is displayed.
2 : The third page is displayed.
3 : The fourth page is displayed.

- (4) System variable indicating the window page displayed by pressing the [+] soft key : #9205

The value of system variable #9205 is incremented each time the [+] soft key is pressed while the cursor is positioned to PROGRAM NO. or PROGRAM NAME. When the cursor is positioned for the first time, 0 is set. The user program can display a window according to this value.

If the window for the last page is displayed, the user program must set -1 in system variable #9205.

#9205 0 : The window for the first page is displayed.
1 : The window for the second page is displayed.
2 : The window for the third page is displayed.
3 : The window for the fourth page is displayed.
4 : The window for the fifth page is displayed.
5 : The window for the sixth page is displayed.
6 : The window for the seventh page is displayed.
7 : The window for the eighth page is displayed.
8 : The window for the ninth page is displayed.
9 : The window for the tenth page is displayed.
10: The window for the eleventh page is displayed.
-1: This value must be set to notify the system that the last page is currently displayed.

- (5) System variable to notify the system whether a window is being displayed by a user program : #9206

System variable #9206 is used to notify the system that a window is being displayed by a user program. The user can display the standard system window by setting an appropriate value in this variable.

#9206 0 : No window is displayed by a user program. Nor is the standard system window displayed, either.
1 : No window is displayed by a user program. The standard system window is displayed.
2 : A window is displayed by a user program.

E.6.7 Using a User Program to Display Guidance on the Detailed Program Data Screen (Not Supported by Ver.1.)

E.6.7.1 Overview

FANUC Super CAP T/CAP II T enable a user-created program to display the user's own guidance on part of the detailed program data screen.

E.6.7.2 Details

(1) Number of the program used to display guidance on the detailed program data screen

O1023 is assigned to the program used to display guidance on the detailed program data screen. This program is called only once when a screen is changed to the detailed program data screen or when the cursor is moved.

(2) System variable indicating the position of the cursor

#9207 : Number of the item to which the cursor is positioned

Classification	Item name	Item No.	Classification	Item name	Item No.	
Common	PASSPOINT 1	X1	Drilling C-axis nothcing	DEPTH DECRS.	DC	901
		Z1		RETURN AMNT.	RU	902
	PASSPOINT 2	X2		MIN DEPTH	MI	903
		Z2	Subprogram call (Enabled only when bit 3 of parameter 9771 is set to 1)	DATA A		1301
	START PNT.	CX		DATA B		1302
	(MACHINING START POINT)	CZ		DATA C		1303
	S-DRCT.	RS		DATA I		1304
	FINISHING	FX		DATA J		1305
		FZ		DATA K		1306
	PROC MOVE.	MP		DATA D		1307
	SPINDLGEAR	GM		DATA E		1308
	COOLANT	CM		DATA F		1309
	MILLNGGEAR	GM		DATA H		1310
	PRG.OVERRIDE	OV		DATA M		1311
Bar amchining	RESIDUAL CUT	AU		DATA Q		1312
End facing	END POINT	EX		DATA R		1313
Threading	THREAD ANGLE	TA		DATA S		1314
	CUT METHOD (1)	P1	DATA T		1315	
	CUT METHOD (2)	P2	DATA U		1316	
	NO. OF THREAD	NT	DATA V		1317	
	SPARK OUT	SO	DATA W		1318	
	THRD HEIGHT	SH	DATA X		1319	
Grooving	EXEC. CYCLE	EX	DATA Y		1320	
			DATA Z		1321	
Necking	WIDTH	WT	C-axis nothcing	CUT WID (%)	Q	1801
	DEPTH	DT		Y-axis drilling	SKIP POINT 1	
	ROUND	R	SKIP POINT 2			2402
	APPROACH ANG	AA	SKIP POINT 3			2403
	RELIEF AMONT	W1				
	RELIEF ANGLE	WA				


(3) System variable indicating whether the program detail data screen is that for automatic residual cutting data for bar machining.

#9208 1 : Program detail data screen for automatic residual cutting data

0 : Program detail data screen for other than automatic residual cutting data

(4) Screen control


Use the right-hand area in the figure below to display guidance. When the guidance is displayed upon cursor movement, the FANUC system program clears the area and calls the user program. The user program need not clear the area.



E.6.8 Displaying a Window by Using a User Program and Pressing a Soft Key on the Program Process Data Screen (Not Supported by Ver.1.)

E.6.8.1 Overview

FANUC Super CAP T/CAP II T allow a user-created program to draw a user's own window while a machining program is being edited. The window is drawn when [SOFT KEY 10] is pressed on the program process data screen.



E.6.8.2 Details

- (1) Displaying a window by pressing a soft key
 - (a) Number of the program used to display a window, and starting that program

O1025 is assigned to the program used to display a window upon pressing a soft key. User program O1025 is called in each cycle of a system task if [SOFT KEY 10] is pressed while a machining program is being edited on the program process data screen.

To close the window, set a value of 99 in system variable #9120 of user program O1025. The system closes the window and does not call the user program in the subsequent cycles.
 - (b) Displaying the window and monitoring keys

The system erases the soft key section, while leaving the remainder of the screen as is. The user program shall open a window and create a drawing in that window. Enter the character string for each soft key to be used with the user program, in the corresponding frame, using G243 or another suitable means.

Input by soft keys, page/cursor keys, numeric keys, and other keys can be monitored using system variables #8501 and #8503.
- (2) Displaying the character string for the soft key used to display a window
 - (a) Registering soft key character strings

To display a window, press [SOFT KEY 10]. Register the character string for the soft key in the selected display language, using the following format. Up to six half-size characters can be registered for each row. Up to 49 character strings can be registered.

E.6.9.3


Details

(1) Displaying a window on the tooling data screen

- (a) Number of the program used to display a window, and starting that program

O1018 and O1019 are assigned to the programs that display a desired window upon a soft key being pressed. User programs O1018 and O1019 are called in each cycle of a system task when [SOFT KEY 7] and [SOFT KEY 6] are pressed, respectively.

To close the window, set a value of 99 in system variable #9120. The system closes the window and does not call the user program in subsequent cycles.



- (b) Displaying the window and monitoring keys

The system erases the soft key section while leaving the remainder of the screen as is. The user program shall open a window and create a drawing in that window. Enter the character string for each soft key to be used with the user program, in the corresponding frame, using G243 or another suitable means.

Input by soft keys, page/cursor keys, numeric keys, and other keys can be monitored using system variables #8501 and #8503.

- (c) System variables

- i) System variables indicating the position of the cursor on the screen: #9108, #9109

In system variables #9108 and #9109, values indicating the position of the cursor on the screen are set in character coordinates.

#9108 : X coordinate of the cursor position
 #9109 : Y coordinate of the cursor position

- ii) System variable indicating the ID number of the tool used in the process indicated by the cursor: #9182

The variable is set to the tool ID number of the process indicated by the cursor.

- iii) System variable indicating the tool post having the tool to be used in the process, and indicated by the cursor : #9942

#9942 0 or 1 : Tool of head 1 of TT or T (two-spindle type),
 tool of T (one-spindle type)
 2: Tool of head 2 of TT or T (two-spindle type)

- (2) Displaying the character string for the soft key used to display a window on the tooling data screen

- (a) Registering a soft key character string

To display a window on the tooling data screen, press [SOFT KEY 6] or [SOFT KEY 7]. Register the soft key character string in the selected display language, using the following format. Up to 12 half-size characters can be registered.

O119*

N9995 ('123456123456') ; (Soft key7)

N9996 ('123456123456') ; (Soft key6)

* : Selected language

=1 : English

=2 : Japanese

=3 : German

=4 : French

=5 : Italian

=6 : Spanish

=7 : Chinese

=8 : Korean

E.6.10

Starting the Chuck/Tailstock Barrier Setting Screen (Not Supported by Ver.1.)

E.6.10.1 Overview

FANUC Super CAP T/CAP II T support parameter setting that enables a user-created program to use the chuck/tailstock barrier function of the NC. This is done by pressing a soft key on the presetting menu. This function uses the optional chuck/tailstock barrier function of the NC.


E.6.10.2 Details

(1) Chuck/tailstock barrier setting screen

- (a) Number of the program used to display the chuck/tailstock barrier setting screen, and starting that program

O1026 and O1027 are assigned to the programs that display the chuck/tailstock barrier setting screen. If the cursor is positioned to CHUCK NO. or CHUCK BARRIER of the presetting menu, user program O1026 is called. If the cursor is positioned to TAILSTOCK NO. or TAILSTOCK BARRIER on the same screen, user program O1027 is called. The program is called in each cycle of a system task when [SOFT KEY 9] is pressed.

To close the window, set a value of 99 in system parameter #9120. The system closes the window and does not call the user program in subsequent cycles.



- (b) Displaying the screen and monitoring keys

The system erases the soft key section while leaving the remainder of the screen as is. The user program shall open the window and create a drawing in that window. Enter the character string for each soft key to be used with the user program, in the corresponding frame, using G243 or another suitable means.

Input by soft keys, page/cursor keys, numeric keys, and other keys can be monitored using system variables #8501 and #8503.

- (2) Displaying the character string for the soft key used to display the chuck/tailstock barrier setting screen

- (a) Registering a soft key character string

To display the chuck/tailstock barrier setting screen, press [SOFT KEY 9]. Register the soft key character string in the selected display language, using the following format. Up to twelve half-size characters can be registered.

O119* * : Selected language

N9993 ('123456123456') ;

Soft key string for the chuck =1 : English
barrier setting screen =2 : Japanese

N9994 ('123456123456') ;

Soft key string for the =3 : German
tailstock setting screen =4 : French
=5 : Italian
=6 : Spanish
=7 : Chinese
=8 : Korean

E.7 SETTING PARAMETERS USED FOR COMPILER

E.7.1 Overview

FANUC Super CAP T/CAP II T allows the machine tool builder to create his own unique system. Programs coded by the machine tool builder and software offered by FANUC can be combined and stored in the ROM module.

The procedure for combining and storing the programs in the ROM module is the same as that for compiling macro-executor programs and P-code programs in the standard format and storing them in the ROM module. However, some restrictions apply to some parameters used for compiling programs with the special macro-executor.

The restrictions that apply to parameters used for compiling are described below.

E.7.2 Setting Parameters Used for Compiling

Compile parameter	#7	#6	#5	#4	#3	#2	#1	#0
9000	LD6	M3MB	M2MB					

#7 (LD6) 1: Be sure to set this bit to 1.

Compile parameter	#7	#6	#5	#4	#3	#2	#1	#0
9001							LOC4	SEQN

#0 (SEQN) 0: The sequence number is not output to a P-code program.
1: The sequence number is output to a P-code program.

★ Be sure to set this bit to 1.

#1 (LOC4) 0: Be sure to set this bit to 0.

Compile parameter	#7	#6	#5	#4	#3	#2	#1	#0
9002	EXIT1	PWSR			EVF			

#3 (EVF) 0: Extended special P-code variables No. 20000 and after are of the floating point type.

1: Extended special P-code variables No. 20000 and after are of the integer type.

★ Be sure to set this bit to 0.

#6 (PWSR) 0: The function for searching for a P-code workpiece number is disabled.

1: The function for searching for a P-code workpiece number is enabled.

★ Be sure to set this bit to 1.

#7 (EXT1) 0: The extended function is not used.

1: The extended function is used.

★ Be sure to set this bit to 1.

Compile parameter	#7	#6	#5	#4	#3	#2	#1	#0
9003	TCF							

#7 (TCF) 0: The special function for entering conversational programs is not used.

1: The function for entering conversational programs is used.

★ Be sure to set this bit to 1.

Compile parameter	#7	#6	#5	#4	#3	#2	#1	#0
9007	MFOPT	TFOPT				TTVR2		

- #2 (TTVR2) 0: Extended special P-code variables No. 20000 and after are separated for head 1 and head 2.
 1: Extended special P-code variables No. 20000 and after are shared by head 1 and head 2.
 ★ Be sure to set this bit to 0 when Super CAP T Ver. 1 is used for the Series 16-TTA.
- #6 (TFOPT) 0: The conversational programming function for the Series 16-T/TTA is not used.
 1: The conversational programming function for the Series 16-T/TTA is used.
 ★ Be sure to set this bit to 1.
- #7 (MFOPT) 0: The conversational programming function for the Series 16-MA is not used.
 1: The conversational programming function for the Series 16-MA is used.
 ★ Be sure to set this bit to 0.

Compile parameter	
9021	G code (1 to 999) which calls the P-code program No. O9018

The macro program used in the auxiliary process is assigned P-code program No. O9018 in FANUC Super CAP.

Compile parameter	
9022	G code (1 to 999) which calls the P-code program No. O9019

The macro program used in the auxiliary process is assigned P-code program No. O9010 in FANUC Super CAP.

Compile parameter	
9037	Number of special P-code variables No. 10000 and after to be used

★ Be sure to set this bit to 7.

NOTE
 The special P-CODE variables of FANUC Super CAP T are usually set in system variables #10000 to #10699. They can be extended to #10000 to #13999 if desired.

Compile parameter	
9044	Number of special P-code variables No. 20000 and after to be used

★ Be sure to set this parameter to 2044.

NOTE
 The extended special P-CODE variables of FANUC Super CAP T are used by the system. The user program cannot use these variables.

E.8 COMMAND USED IN THE DYNAMIC GRAPHIC FUNCTION

E.8.1 Outline

To perform animated simulation in the dynamic graphic function (A02B-0121-J973), data such as the figures of blanks, the chuck, tailstock, and tools are required to be sent using commands [G10 P90???...] in advance from the NC unit to the graphic section. A program consisting of the commands [G10 P90??? ...] needs to be operated before a machining program coded in the NC format operates to display its animated simulation.

When the conversational programming function is used, the necessary data is automatically sent to the graphic section.

When either the menu or the tool is changed, execute the program consisting of the commands [G10 P90???...] to send the data to the graphic section.

E.8.2 Description

- (1) Start point for animated simulation

Command format G10 P90000 X_Z_ ;

Specifies the coordinates of the start point.

NOTE

When commands are issued in the following order animated simulation does not start, but the data is registered in the graphic section: A registration command, G10 P90051, G10 P90052, G10 P90053, G10 P90054, or G10 P90055, this command, and the registration end command G10 P90050

- (2) Drawing a straight line

Command format G10 P90001 X_Z_ ;

Draws a straight line from the current position to the specified end point.

NOTE

When commands are issued in the following order, animated simulation does not start, but the data is registered in the graphic section: A registration command, G10 P90051, G10 P90052, G10 P90053, G10 P90054, or G10 P90055, this command, and the registration end command G10 P90050.

(3) Drawing an arc

Command format

G10 P90002 X_Z_I_K_ ; for drawing clockwise

G10 P90003 X_Z_I_K_ ; for drawing counterclockwise

Draws an arc around the specified center of the arc from the current position to the specified end point.

X: X coordinate of the end point

Z: Z coordinate of the end point

I : X coordinate of the center of the arc

K: Z coordinate of the center of the arc

NOTE

When commands are issued in the following order, animated simulation does not start, but the data is registered in the graphic section: A registration command, G10 P90051, G10 P90052, G10 P90053, G10 P90054, or G10 P90055, this command, and the registration end command G10 P90050.

(4) Filling

Command format G10 P90004 ;

Fills an area.

NOTE

The color command G10 P90006 specifies a color used for filling an area and the start point command G10 P90001 for animated simulation specifies the center of the area.

(5) Type of line

Command format G10 P90005 Q_ ;

Specifies the type of line.

Q=0 : Solid line

1 : Dotted line

2 : Line with alternate dots and long segments

3 : Line with alternate long segments and sets of two dots

4 : Deletion

NOTE

The length of each line is specified.

(6) Color

Command format G10 P90006 Q_ ;

Specifies the color.

Q=0 : Black 4 : Blue

1 : Red 5 : Pink

2 : Green 6 : Light blue

3 : Yellow 7 : White

(7) End of registration of the figures of tools, workpieces, the chuck, and tailstock

Command format G10 P90050 ;

Be sure to specify this command when the figure data of tools, workpieces, the chuck, and tailstock have been registered.

(8) Start of tool-figure registration

Command format G10 P90051 X_Z_Q_;

Specifies the start of tool-figure registration as well as the position of the tip of the tool and the tool registration number on the graphic screen.

X: X coordinate of the tip of the tool

Z: Z coordinate of the tip of the tool

Q: Tool registration number on the graphic section (1 to 16)

NOTE

The start point command G10 P90000 for animated simulation, command G10 P90001 for drawing a straight line, and command G10 P90002 or G10 P90003 for drawing an arc specify the figure of a tool. The figure of the tip of a tool must be closed.

(9) Start of registering the chuck profile

Command format G10 P90052 X_Z_;

Specifies the start of registering the chuck figure as well as the start point of the figure.

X: X coordinate of the start point for the chuck profile

Z: Z coordinate of the start point for the chuck profile

NOTE

The start point command G10 P90000 for animated simulation, command G10 P90001 for drawing a straight line, and command G10 P90002 or G10 P90003 for drawing an arc specify the figure of the chuck. The figure must be closed.

(10) Start of tailstock-figure registration

Command format G10 P90053 X_Z_;

Specifies the start of registering the tailstock figure as well as the start point of the figure.

X: X coordinate of the start point for the tailstock profile

Z: Z coordinate of the start point for the tailstock profile

NOTE

The start point command G10 P90000 for animated simulation, command G10 P90001 for drawing a straight line, and command G10 P90002 or G10 P90003 for drawing an arc specify the tailstock figure. The figure must be closed.

(11) Start of registering a blank profile

Command format G10 P90054 X_Z_;

Specifies the start of registering the blank profile as well as the start point of the figure.

X: X coordinate of the start point for the blank profile

Z: Z coordinate of the start point for the blank profile

NOTE

The start point command G10 P90000 for animated simulation, command G10 P90001 for drawing a straight line, and command G10 P90002 or G10 P90003 for drawing an arc specify the blank figure. The figure must be closed.

- (12) Start of the registration of a blank profile viewed from the end face

Command format G10 P90055 X_Z0 ;

Specifies the start of the registration of a blank figure viewed from the end face as well as the diameter.

X: Diameter of the blank

- (13) Registering the profile of the tool used for C-axis machining

Command format G10 P90056 X_Z_Q_R_ ;

Specifies the diameter, length, and tool type, as well as the registration number in the graphic section.

X: Diameter of the tool

Z: Length of the tool

Q: Registration number of the tool in the graphic section
(17 to 32)

R = 0 : For a tool which cuts end faces

1 : For a tool which cuts side faces

- (14) Size of an exploded view

Command format G10 P90057 X_Z_C_ ;

Specifies the area (X, Z) for which an exploded view is drawn and the diameter (C) of a workpiece.

X: Z coordinate of the start point

Z: Z coordinate of the end point

C: Diameter of a workpiece

- (15) Selecting the tool used in tool post 1

Command format G10 P90060 Q_R_ ;

Selects the tool to be used in tool post 1 and specifies the registration number of the tool in the graphic section.

Q : Registration number of the tool (1 to 16) in the graphic section

R : Axes to which the mirror function is applied to generate the figure of the tool

= 0 : X-axis off, Z-axis off

= 1 : X-axis on, Z-axis off

= 2 : X-axis off, Z-axis on

= 3 : X-axis on, Z-axis on

NOTE

When the conversational programming function is used in FANUC Super CAP, the registration number of the tool in the graphic section can be read from macro variable No. 20705 or 20704 (variable No. 20704 is used for the tool used for residual machining in bar machining).

(16) Selecting the tool used in tool post 2

Command format G10 P90061 Q_R_ ;

Selects the tool to be used in tool post 2 and specifies the registration number of the tool in the graphic section.

Q : Registration number (1 to 16) of the tool in the graphic section

R : Axes to which the mirror function is applied to generate the figure of the tool

= 0 : X-axis off, Z-axis off

= 1 : X-axis on, Z-axis off

= 2 : X-axis off, Z-axis on

= 3 : X-axis on, Z-axis on

NOTE

When the conversational programming function is used in FANUC Super CAP, the registration number of the tool in the graphic section can be read from macro variable No. 20705 or 20704 (variable No. 20704 is used for the tool used for residual machining in bar machining).

This command is effective only for a lathe with one spindle and two turrets.

(17) Selecting the tool used for C-axis machining

Command format G10 P90062 Q_R_ ;

Selects the tool to be used for C-axis machining and specifies the registration number of the tool in the graphic section.

Q : Registration number (17 to 32) of the tool in the graphic section

R : Color used for drawing the tool

Q= 0 : Black

16 : Red

32 : Green

48 : Yellow

64 : Blue

80 : Pink

96 : Light blue

112 : White

NOTE

When the conversational programming function is used in FANUC Super CAP, the registration number of the tool in the graphic section can be read from macro variable No. 20705.

(18) Animation screen

Command format G10 P90070 Q_ ;

Specifies the type of drawing used for animated simulation.

Q= 0 : Drawing used for turning

1 : End-face drawing used for C-axis machining

2 : Exploded view used for C-axis machining

(19) Deleting figures on the screen

Command format G10 P90099 ;

Deletes the figures on the screen.

(20) Start point for drawing the chuck figure

Command format G10 P90100 X_Z_ ;

Specifies the start point for drawing the profile of the chuck.

X : X coordinate of the start point for drawing the profile of the chuck in the current workpiece coordinate system

Z : Z coordinate of the start point for drawing the profile of the chuck in the current workpiece coordinate system

(21) Start point for drawing the profile of the tailstock

Command format G10 P90101 X_Z_ ;

Specifies the start point for drawing the profile of the tailstock.

X : X coordinate of the start point for drawing the profile of the tailstock in the current workpiece coordinate system

Z : Z coordinate of the start point for drawing the profile of the tailstock in the current workpiece coordinate system

(22) Start point for drawing the profile of a blank

Command format G10 P90102 X_Z_ ;

Specifies the start point for drawing the profile of a blank.

X : X coordinate of the start point for drawing the profile of a blank in the current workpiece coordinate system

Z : Z coordinate of the start point for drawing the profile of a blank in the current workpiece coordinate system

(23) Drawing the end-face view used for C-axis machining

Command format G10 P90103 ;

Draws the end-face view used for C-axis machining.

(24) Drawing the exploded view used for C-axis machining

Command format G10 P90104 ;

Draws the exploded view used for C-axis machining.

(25) Copying the profile of a workpiece

Command format G10 P90200 X_Z_I_K_ ;

Copies the profile of a workpiece drawn in the specified area from the first graphic screen to the second graphic screen or vice versa.

X : X coordinate of the upper right point of the area to be copied

Z : Z coordinate of the upper right point of the area to be copied

I : X coordinate of the lower left point of the area to be copied

K : Z coordinate of the lower left point of the area to be copied

NOTE

The command copies the profile of a workpiece to the screen on which the command is issued. When the command is specified in head 2, for example, the profile is copied from head 1 to head 2. The coordinates must be those on the source screen. When the profile is copied from head 1 to head 2, for example, the coordinates must be those in the workpiece coordinate system of head 1. The coordinates cannot be omitted.

This command is effective only for a lathe with two spindles and two turrets.

(26)Coordinate conversion to those in the copy destination


Command format G10 P90201 X_Z_;

X, Z : Differences between coordinates used in two heads with reference to those in the source area


NOTE

1 If the command G10 P90201 is not specified before the command G10 P90200 is specified, the differences between the coordinates used in two heads are assumed to be 0. Command G10 P90201 is a continuous-state command. The differences between coordinates specified by this command is not reset until this command is specified next.

When the directions of two axes are the same between two coordinate systems as shown below, to copy the rectangular area specified by the two points (x, z) and (i, k) in head α to that specified by the two points (x', z') and (i', K') in head β , specify the following:



Coordinates of the center point of the screen: (x₀, z₀)




Coordinates of the center point of the screen: (x₀', z₀')

```
G10 P90201 X((x' - x) + (-x0' + x0) Z((z' - z) + (-z0' + z0); (can be omitted)
G10 P90200 Xx Zz li Kk;
```


Specify these commands in head β .

2 When the Z-axes in the two coordinate systems have the same directions as shown above, the command cannot be used in FANUC Super CAP.

When the horizontal Z-axes in the two coordinate systems have opposite directions as shown below, to copy the rectangular area specified by the two points (x, z) and (i, k) in head α to that specified by the two points (x', z') and (i', K') in head β , specify the following:



Coordinates of the center point of the screen: (x₀, z₀)



Coordinates of the center point of the screen: (x₀', z₀')

```
G10 P90201 X((x' - x) + (x0' + x0) Z((-z' - z) + (z0' + z0); (can be omitted)
G10 P90200 Xx Zz li Kk;
```

Specify these commands in head β .

NOTE

3 When the Z-axes in the two coordinate systems have opposite directions as shown above, the command can be used in FANUC Super CAP.

The signs of coordinates used in the command G10 P90201 are as follows:

For the Z coordinates:

Z (+/-A -/+B -/+C +/-D) when the direction of the Z-axis is right/left
where,

A : Z coordinate of the rightmost point in the destination

B : Z coordinate of the rightmost point in the source

C : Z coordinate of the center point of the screen in the destination

D : Z coordinate of the center point of the screen in the source

The upper right point is not affected by the direction of the coordinate system.

For the X coordinates:

X (+/-A -/+B -/+C +/-D) when the direction of the X-axis is up/down
where,

A : X coordinate of the uppermost point in the destination

B : X coordinate of the uppermost point in the source

C : X coordinate of the center point of the screen in the destination

D : X coordinate of the center point of the screen in the source

When the X-axis is a horizontal axis and the Z-axis is a vertical axis, the same signs can be used by interchanging the X- and Z-axes.

4 A user program cannot refer to the coordinates of the center point of the screen in FANUC Super CAP.

(27)Switching the display mode


Command format G10 P90210 Q_ ;

Switches between the two-spindle and one-spindle display modes.

NOTE

Issuing this command changes the mode and initializes the screen. This command is effective only for a lathe with two spindles and two turrets.

E.8.3 Example




The following program registers the profiles of a workpiece, the chuck, and tailstock in the graphic section.

```

G10 P90099 ;          ---- Screen erase
G10 P90055 X100. Z0. ;
G10 P90050 ;
G10 P90054 X0. Z-100. ;
G10 P90001 X100. Z-100. ;
G10 P90001 X100. Z0. ;
G10 P90001 X0. Z0. ;
G10 P90001 X0. Z-100. ;
G10 P90050 ;          ---- End of registration
G10 P90102 X0. Z0. ;  ---- Blank standard position
G10 P90052 X50. Z-100. ;
G10 P90001 X110. Z-110. ;
G10 P90001 X110. Z-90. ;
G10 P90001 X100. Z-90. ;
G10 P90001 X100. Z-100. ;
G10 P90001 X50. Z-100. ;
G10 P90001 X50. Z-100. ;
G10 P90050 ;          ---- End of registration
G10 P90100 X0. Z0. ;  ---- Chuck standard position
G10 P90053 X0. Z10000. ;
G10 P90001 X40. Z10020. ;
G10 P90001 X40. Z10030. ;
G10 P90001 X70. Z10030. ;
G10 P90001 X70. Z10050. ;
G10 P90001 X100. Z10050. ;
G10 P90001 X100. Z10070. ;
G10 P90001 X0. Z10070. ;
G10 P90001 X0. Z10000. ;
G10 P90050 ;          ---- End of registration
G10 P90101 X0. Z-10000. ;  Tail stock standard position
(G10 P90101 X0. Z10000. ;)

```



The following program registers the above tools.

```

G10 P90099 ;          ---- Screen erase
G10 P90051 X0. Z0. Q1 ;
G10 P90001 X5. Z1. ;
G10 P90001 X5. Z6. ;
G10 P90001 X1. Z6. ;
G10 P90001 X0. Z0. ;
G10 P90000 X15. Z1. ;
G10 P90001 X5. Z1. ;
G10 P90001 X0. Z0. ;
G10 P90001 X1. Z6. ;
G10 P90001 X5. Z12. ;
G10 P90001 X15. Z12. ;
G10 P90050 ;          ---- End of registration
    
```

} Chip figure } Tool figure

} Chunk profile }

```
G10 P90056 X10. Z40. Q17 R0. ; Registering milling tool shape
```

E.8.4 Transferring a Workpiece in Animated Simulation

In a lathe with two spindles, it is necessary to copy the profile of a workpiece between heads using the following commands to display the transfer process in animated simulation.

```
G10 P90201 X_Z_ ;
G10 P90200 X_Z_I_K_ ;
```

However, command G10 P90201 cannot be specified without the coordinates of the center point of the screen. The following data is assigned to P-code variable No. 20623 when the conversational programming function is used in FANUC Super CAP.


- When the program origin is positioned on the end face of a workpiece
 $\#20623 = A + B + C$
- When the program origin is positioned on the end face of the chuck
 $\#20623 = A + B - C$

where,

- A: Z coordinate of the center point of the screen in head 1
- B: Z coordinate of the center point of the screen in head 2
- C: Length of the product

(1) Example

When the parameter No. 6510 for head 1 is 14 and that for head 2 is 34 :



In this example, the X coordinates of the center points are the same in both screens. Specify as follows in head β :

```
G10 P90201 X0. Z(-(-95) -5 +Z0' +Z0). ;
```

```
G10 P90200 X100. Z5. I-100. K-95. ;
```

(when diameter programming is used for the X-axis)

NOTE

In FANUC Super CAP T/CAP II T, parameter No. 6510 for head 1 is set to 1, 4, 11, or 14 and that for head 2 is set to the value set in parameter No. 6510 for head 1 plus 20. So the X coordinates of the center points are the same in both screens.

E.9 COMMANDS FOR READING/WRITING VARIABLES STORED IN THE REMOTE HEAD

E.9.1 Outline

In FANUC Super CAP T/CAP II T, all programs are stored in head 1. Extended P-code variables No. 20000 and after must be separated for head 1 and head 2. When head 2 is selected, user programs in head 2 are required to read/write extended P-code variables for head 1. These commands have been added for reading/writing variables stored in the remote head.

E.9.2 Description

G316 Pp Dd ; (1)

G316 Dd Qq ; (2)

- (1) This command reads the value of parameter No. d stored in the remote head and stores it in parameter No. p in the local head.

(Example) G316 P10000 D20000 ;

The value of parameter No. 20000 in the remote head is transferred to parameter No. 10000 in the local head.

- (2) This command writes the value of parameter No. q stored in the local head in parameter No. d stored in the remote head.

(Example) G316 D10001 Q20001 ;

The value of parameter No. 20001 in the local head is transferred to parameter No. 10001 in the remote head.

(Restrictions)

- This command cannot be used in an execution macro.
- System variables #9000 to #9999 cannot be specified.
- In a conversational macro program, variable d of the remote head must be a special P-CODE variable (#10000 or later), extended special P-CODE variable (#20000 or later), or common variable.
- In an auxiliary macro program, variable d of the remote head must be a special P-CODE variable (#10000 or later) or extended special P-CODE variable (#20000 or later).

E.10 FUNCTION FOR CONVERTING PROGRAMS USED FOR THE AUXILIARY AND TRANSFER PROCESSES TO NC STATEMENTS

E.10.1 Outline

When programs used for the auxiliary and transfer processes are converted to NC statements, the machine conditions strongly affect the NC statements even if the same data is used. Super CAP T/CAP II T provides two types of NC statements to be converted from programs used for the auxiliary and transfer processes. They are NC statements which represent the programs to be executed and those only for calling sub-programs.

It is also possible to select whether programs are called either from the ROM or from the RAM.

E.10.2 Setting Parameters

Parameter	#7	#6	#5	#4	#3	#2	#1	#0
9777		NCSNTF						

Bit 6 (NCSNTF) 0 : NC statements which represent programs to be executed are output for the auxiliary and transfer processes.

1 : NC statements only for calling sub-programs are output for the auxiliary and transfer processes. (For details, see 6.8.3.)

Parameter	#7	#6	#5	#4	#3	#2	#1	#0
9778							AUX	TRANS

Bit 0 (TRANS) 0 : Sub-programs are called from the ROM in the transfer process.

1 : Sub-programs are called from the RAM in the transfer process.

Bit 1 (AUX) 0 : Sub-programs are called from the ROM in the auxiliary process.

1 : Sub-programs are called from the RAM in the auxiliary process.

E.10.3 Format Used for NC Statements Only for Calling Sub-programs

When bit 6 of parameter 9777 is 1, programs for calling sub-programs in the auxiliary and transfer processes are converted to NC statements in the following format.

- (1) When sub-programs are called from the ROM (when bit 0 of parameter No. 9778 is set to 0 for the transfer process, and/or when bit 1 of parameter No. 9778 is set to 0 for the auxiliary process)

```
G (1)  A (+7)  B (+9)  C (+11) I (+13) J (+15) K (+17)
      I (+19)  J (+21) K (+23) I (+25) J (+27) K (+29)
      I (+31)  J (+33) K (+35) I (+36) J (+37) K (+38)
      I (+39)  J (+40) K (+41) I (+42) J (+43) K (+44)
      I (+45)  J (+46) K (+47) I (+48) J (+50) K (+51)
      I (#20500)      J (#20501)      K (#20502)
```

(1) : For the transfer process, the value of compile parameter No. 9021 is output. For the auxiliary process, the value of compile parameter No. 9022 is output.

(+?) : +? indicates the offset from the start of the process data. The values corresponding to offset +? are output. For details of the process offset data, see 6.2.2 (b) (i).

(#?) : #? indicates the number of a macro variable. The values of the corresponding macro variables are output.

- (2) When sub-programs are called from the RAM

- When bit 0 of parameter No. 9778 is set to 1 for the transfer process, M98 P9018;
- When bit 1 of parameter 9778 is set to 1 for the auxiliary process, M98 P9019;

E.10.4 Note

- If no value is specified for a certain data item shown in 6.8.3.(1), the value 0 is output for the item.
- Version 3 enables NC statement conversion to another format. For details, refer to the FANUC Super CAP T Operator's Manual (Series 16-TB).

E.11 IMPROVEMENTS FEATURED BY VERSION 4

- (1) The system capacity has been expanded.
Super CAP T Version 3 : 2M bytes
Super CAP T Version 4 : 3M bytes
- (2) The macro capacity has been expanded.
Super CAP T Version 3 : 512K bytes
Super CAP T Version 4 : 768K bytes
- (3) The link file has been partially modified to reflect the above expansions and to ensure compatibility with the VGA graphics capability.
See the next page.

E.11.1 Modifications Made to the Link File

To reflect the conversational system capacity and macro capacity expansions and to ensure compatibility with the VGA graphics capability, the link file has been partially changed.

```

/*
/* Conversation MACRO Sample LINK control file.
/*
/*
/* executor file 'FS16TC for VGA'
/*
CNC =c:\mcomp\USR\BH5G_4A.EX1
CNC2 =c:\mcomp\USR\BH5G_4A.EX2
CNC3 =c:\mcomp\USR\BH5G_4A.EX3
PCODE=REAR ← Must not be omitted.
/*
/* compile parameter P9000 - P9009 and P9010 - P9059
/*
    ↓ Set 3M (by setting bit 6 to 1).
P9000=11000000
P9001=10000001
P9002=11000000
P9003=10001001
P9007=01000000
P9009=00000100
/*
    ↑↑ Number of screen lines used
    The higher of these two bits must always be set to 0.
    The lower of these two bits can be set arbitrarily by the
    machine tool builder.
P9013=200
/*
P9023=320
P9024=321
/*
    9009
    CM30 LM30
P9030=27
P9031=28
P9032=29
/*
P9033=97
P9037=7
P9044=2044
/*
P9038=4999
/*
/* Link file's
/*
FILE=CAPS_4A
FILE=BH5G_4A
  
```

9000	LD6	R3M	R2M	R1M	R512	R256	R128	VRFY
------	-----	-----	-----	-----	------	------	------	------

R3M = 1: Output to a 3M-byte ROM cassette or ROM module.

NOTE
 The modifications made to the link file described above are just an example. Set those items other than those indicated by an arrow and comment, as required, as described in this manual.

E.12 IMPROVEMENTS FEATURED BY FANUC SUPER CAP II T

- (1) The system capacity has been expanded.
Super CAP T Version 3 : 2M bytes
Super CAP II T : 3M bytes
- (2) The macro capacity has been expanded.
Super CAP T Version 3 : 512K bytes
Super CAP II T : 768K bytes
- (3) The software package related to the process data and user program of the macro compiler/executor has been partially modified.
See Section E.12.1.
- (4) The software package related to the interface between the system and user programs of the macro compiler/executor has been partially modified.
See Section E.12.2.
- (5) The graphics interface of the macro compiler/executor for Super CAP II T has been partially modified for screen display based on VGA graphics.
See Appendix M.
- (6) The link file has been partially modified to reflect the expansions above ((1) and (2)) and to ensure compatibility with the VGA graphics capability.
See Section E.12.3.

E.12.1 Software Package Related to Process Data

E.12.1.1 Specifications

- (a) Data structure of the auxiliary and passing processes
The input format and display format of a data item such as type, head, and display data depends on the data format specified for the data item.
(Data format) = -1:
The data item is not displayed. The cursor cannot be positioned to the item. In the field of the data item, the data for the next data item is moved up and displayed.
(Data format) < 10000:
The data item represents numeric data. The data is entered using the numeric keypad. A value indicated with the data format represents the number of decimal places.
(Data format) \geq 10000:
The data item is displayed as a string. The data is entered using the soft keys.
(Data format) \geq 20000:
The data item represents numeric data. The data is entered using the soft keys and numeric keypad.
(Data format) = *ABC*:
When A = 0, the data is displayed in the standard character color.

When A = 1, the data is displayed in reverse video.

When A = 2, an extended palette is used for the character color of B.

When A = 4, an extended palette is used for the background color of C.

(Data format) = *ABC*:

When B = 0, the data is displayed in black
(or in the 8th color when color extension is specified with A).

When B = 1, the data is displayed in color palette 1
(or in the 9th color when color extension is specified with A).

When B = 2, the data is displayed in color palette 2
(or in the 10th color when color extension is specified with A).

When B = 3, the data is displayed in color palette 3
(or in the 11th color when color extension is specified with A).

When B = 4, the data is displayed in color palette 4
(or in the 12th color when color extension is specified with A).

When B = 5, the data is displayed in color palette 5
(or in the 13th color when color extension is specified with A).

When B = 6, the data is displayed in color palette 6
(or in the 14th color when color extension is specified with A).

When B = 7, the data is displayed in color palette 7
(or in the 15th color when color extension is specified with A).

(Data format) = *ABC*:

When C = 0, the background is displayed in color palette 14
(or in the 8th color when color extension is specified with A).

When C = 1, the background is displayed in color palette 1
(or in the 9th color when color extension is specified with A).

When C = 2, the background is displayed in color palette 2
(or in the 10th color when color extension is specified with A).

When C = 3, the background is displayed in color palette 3
(or in the 11th color when color extension is specified with A).

When C = 4, the background is displayed in color palette 4
(or in the 12th color when color extension is specified with A).

When C = 5, the background is displayed in color palette 5
(or in the 13th color when color extension is specified with A).

When C = 6, the background is displayed in color palette 6
(or in the 14th color when color extension is specified with A).

When C = 7, the background is displayed in color palette 7
(or in the 15th color when color extension is specified with A).

(Supplement)

To use extended colors for both characters and their background, or to use reverse video, set the sum of all the states in A:

Example: [12th extended color for characters] + [15th extended color for the background]
A = 2 (character extension) + 4 (background extension)
= 6

Examples of *ABC* specification

Example: [Standard character in black] + [palette 14 for the background] (same as the system data background color)
ABC = *000*

Example: [Standard character in extended character palette 12] +
[extended palette 15 for the background]
ABC = *647*

(Data format) = 100000:

The data item represents a surface speed or rotational speed, and its display and data input are handled in the same way as other processes.

(Data format) = 100001:

The data item represents coolant ON or OFF (1 = ON, 2 = OFF). The data item is displayed as a string. Data can be entered using the soft keys and numeric keypad.

(Data format) = 200000:

The data item is displayed as a string. Data can be entered using the soft keys and numeric keypad.

(Data format) = 300001:

The data item represents a tool ID number. Data can be entered using the soft keys and numeric keypad.

(Data format) = 300002:

The data item represents a T code. Data can be entered using the soft keys and numeric keypad.

E.12.2 Software Package Related to the Interface Between the System and User Programs

E.12.2.1 Interface Between the Conversational Program Screen and User Programs

- (1) System variables for multi-window display specification
- #9111 = X coordinate of the upper-left point of the multi-window
 - #9112 = Y coordinate of the upper-left point of the multi-window
 - #9113 = Number of characters in the X direction (horizontal direction of the screen) of the multi-window
 - #9114 = Number of characters in the Y direction (vertical direction of the screen) of the multi-window
 - #9115 = Type of frame of the multi-window
0: Thin line, 1: Heavy line, 2: Three-dimensional window
 - #9116 = Color of the frame of the multi-window (color of the title bar when the multi-window is a three-dimensional window)
0: Black, 1: Red, 2: Green, 3: Yellow, 4: Blue, 5: Purple, 6: Light blue, 7: White, 8 to 15: Extended colors
 - #9120 = Request for display to the system
 - When 1 is entered, the system opens a window based on the information of #9111 through #9116. When 2 is entered, the system closes the window. Upon the completion of processing, the system initializes #9120 to 0. Set 99 to return from the detail screen to the process screen. Then, the system displays the process screen.

NOTE

1. The multi-window is not displayed when any of the above variables assumes a null value or a value outside the specifiable range.
2. When a window is converted to a three-dimensional window, the color of the characters within the window must be changed to a color that is easily legible against the background color of the window.
3. When a window is displayed on the macro debugger screen, the color palettes for the conversational screen cannot be used. So, the window may not be displayed in the specified colors in some cases.

#9119 = Request for redisplay to the user program

The system may close a window (for example, for switching to another screen) when no request is issued from a user program. If the system closes a window for the system's reason, the user program must issue another request to display the window. When the user program must reopen a window, the system sets 1. Then, to output a display request to the system, the user program must set the system variable for window display specification. The system initializes #9119 to 0 when the user program performs a read.

Modifications made to the basic menu screen

E.12.2.2

Specification of Display Characters

(1) Specification of characters to be displayed by the system

(a) Title display

On the basic menu screen, a title specific to each machine tool builder can be displayed.

In N9999 of O1191 to O1198 (for each language), register a title of no more than 50 half-size characters.

Moreover, Super CAP II T allows a title to be displayed using O1030.

When parameter 9975 (MNU) = 0

When O1020 is not linked, only the basic menu screen, which is standard for conversation, is displayed. No title is displayed.

When O1030 is linked, the basic menu screen, which is standard for conversation, is displayed, and the program coded in O1030 is displayed. As with a sample program, a yellow frame, graphic display, characters, and so forth can be displayed as required.

When parameter 9975 (MNU) = 1

When O1020 (O1021) is not linked

The basic menu screen, which is standard for conversation, is not displayed. Because O1020 (O1021) is not linked, no menu is displayed.

When O1020 (O1021) is linked


The basic menu screen, which is standard for conversation, is not displayed. The program coded in O1020 (O1021) is displayed.

Multi-window and basic menu screen display areas

With Super CAP II T, the multi-window cannot be displayed in the system display area (upper three lines) and the two lines below the system display area. Moreover, a basic menu screen created by each machine tool builder cannot be displayed in the system display area (upper three lines).

In connection with the above, set the macro executor compile parameter (bit 1 (LM30) of parameter No. 9009) to 0 (so that the full 30-line screen is not used for VGA display).

The method of screen address specification for character and graphics display is compatible with the conventional method for Super CAP T, so that a program can be transported without making major modifications to the program.



E.12.3 Modifications Made to the Link File

To reflect the conversational system capacity and macro capacity expansions and to ensure compatibility with the VGA graphics capability, the link file has been partially changed.

```

/*
/* Conversation MACRO Sample LINK control file.
/*
/*
/* executor file 'FS16TC for VGA'
/*
CNC =c:\mcomp\BH18_Z0.EX1
CNC2 =c:\mcomp\BH18_Z0.EX2
CNC3 =c:\mcomp\BH18_Z0.EX3
PCODE=REAR ← Must not be omitted.
/*
/* compile parameter P9000 - P9009 and P9010 - P9059
/*
    ↓ Set 3M (by setting bit 6 to 1).
P9000=11000000 9000 LD6 R3M R2M R1M R512 R256 R128 VRFY
P9001=10000001
P9002=11000000
P9003=10001001
P9007=01000000
P9009=00000100
/*
    ↑↑ Number of screen lines used
    The higher of these two bits must always be set to 0.
    The lower of these two bits can be set arbitrarily by the
    machine tool builder.
P9013=200
/*
P9023=320
P9024=321
/*
    9009
P9030=27
P9031=28
P9032=29
/*
P9033=97
P9031=28
P9032=29
/*
P9033=97
P9037=7
P9044=2044
/*
P9038=4999
/*
/* Link file's
/*
FILE=CPS2T_Z0
FILE=BH18_Z0
FILE=TRANS
    
```

R3M = 1: Output to a 3M-byte ROM cassette or ROM module.

LM30 = 1: The full 30-line screen is used for VGA display. (Super CAP II T)
 LM30 = 0: The full 30-line screen is not used for VGA display. (Super CAP II T)
 CM30 = 1: The full 30-line screen is used for VGA display. (CUSTOM)
 CM30 = 0: The full 30-line screen is not used for VGA display. (CUSTOM)

NOTE

The modifications made to the link file described above are just an example. Set those items other than those indicated by an arrow and comments, as required, as described in this manual.

F

MACRO VARIABLES USED IN THE MACRO EXECUTOR FUNCTIONS

Variable No.	Function	R/W	Conversa- tional	Auxiliary	Execut- able
Macro variables					
#1 - #33	Local variables	R/W	×	×	○
#1 - #99	Array-type variables	R/W	○	○	×
#100 - #149	Common variables (non-hold type)	R/W	○	○	○
#500 - #531	Common variables (hold type)	R/W	○	○	○
#10000 -	P-CODE variables	R/W	○	○	○
#20000 -	Extended P-CODE variables	R/W	○	○	○
Reading the remaing traveling distance					
#5181 to #5188	Variables for reading the remaining traveling distance	R/	○	○	×
Execution control variables					
#8500	Variable 1 for controlling the execution of conversational macros (CUSTOM screen 1)	R/W	○	○	×
#8550	Variable 2 for controlling the execution of conversational macros (CUSTOM screen 2)	R/W	○	○	×
#8551	Variable 3 for controlling the execution of conversational macros (CUSTOM screen 3)	R/W	○	○	×
Key/data input control					
#8501	Key input control variable	R/	○	×	×
#8502	Data input control variable	R/W	○	×	×
#8503	Numeric data variable	R/	○	×	×
#8504	Address data variable	R/	○	×	×
#8552	Variable for controlling extended data input for conversational macros	R/W	○	×	×
Cursor control					
#8505	Cursor control variable	R/W	○	○	×
#8506	Cursor X position control variable	R/W	○	○	×
#8507	Cursor Y position control variable	R/W	○	○	×
Screen control					
#8509	Variable for controlling the character string cataloging program	R/W	○	○	×
#8510	Variable for controlling conversational macro function screens	R/W	○	○	×
Processing of P-CODE variables of array type					
#8511	Transfer source data	R/W	○	○	×
#8512	Two-dimensional array number (transfer source)	R/W	○	○	×
#8513	Three-dimensional array number (transfer source)	R/W	○	○	×
#8514	Two-dimensional array number (transfer destination)	R/W	○	○	×
#8515	Three-dimensional array number (transfer destination)	R/W	○	○	×
#8516	Maximum number of one-dimensional array elements	R/W	○	○	×
#8517	Maximum number of two-dimensional array elements	R/W	○	○	×

R : Readable W : Writable ○ : Usable × : Unusable

Variable No.	Function	R/W	Conversa- tional	Auxiliary	Execut- able
#8519	Number of the first variable in the array	R/W	○	○	×
Reading and writing an NC program					
#8520	Program number specification	R/W	○	○	×
#8521	Block number specification	R/W	○	○	×
#8522	Stored variable number specification	R/W	○	○	×
#8523	Variable for specifying the number of decimal places	R/W	○	○	×
#8529	Completion code for reading or writing an NC program	R/	○	○	×
Reading data stored in the tape					
#8526	Variable for reading the background editing status	R/	○	○	×
#8527	Variable for reading the number of cataloged programs	R/	○	○	×
#8528	Variable for reading the size of the free space in the CNC program memory	R/	○	○	×
Reader/punch interface					
#8539	Completion code for reader/punch interface	R/	○	○	×
MDI key image read function					
#8549	MDI key image storing variable	R/	○	×	×
Reading and resetting the cutting time and cutting distance					
#8553	Reading and presetting the cutting time	R/W	○	○	×
#8554	Reading and presetting the cutting distance	R/W	○	○	×
Key-in line control					
#8561	X coordinate of the point where the key-in line is displayed	R/W	○	×	×
#8562	Y coordinate of the point where the key-in line is displayed	R/W	○	×	×
#8563	Number of input keys	R/W	○	×	×
#8564	Display of the prompt	R/W	○	×	×
#8565	Display of the key-in line	R/W	○	×	×
Interlock control for a signal axis direction					
#8600	Interlock control variable for a single axis direction	R/W	○	○	×
#8601	Variable indicating the axis and direction of movement when the SKIP signal is turned on	R/	○	○	×
PMC axis control					
#8602	PMC control axis selection variable (with G codes)	R/W	○	○	×
#8700	PMC control axis selection variable (with macro variables)	R/W	○	○	×
#8710	PMC command signal variable (Area A)	R/W	○	○	×
#8711	PMC control command variable (Area A)	R/W	○	○	×
#8712	PMC cutting feedrate variable (Area A)	R/W	○	○	×
#8713	Variable for traveling distance controlled by PMC (Area A)	R/W	○	○	×
#8715	Read variable for PMC status signal (Area A)	R/	○	○	×
#8720	PMC command signal variable (Area B)	R/W	○	○	×
#8721	PMC control command variable (Area B)	R/W	○	○	×
#8722	PMC cutting feedrate variable (Area B)	R/W	○	○	×
#8723	Variable for traveling distance controlled by PMC (Area B)	R/W	○	○	×
#8725	Read variable for PMC status signal (Area B)	R/	○	○	×
#8730	PMC command signal variable (Area C)	R/W	○	○	×
#8731	PMC control command variable (Area C)	R/W	○	○	×


R : Readable W : Writable ○ : Usable × : Unusable

Variable No.	Function	R/W	Conversa- tional	Auxiliary	Execut- able
#8732	PMC cutting feedrate variable (Area C)	R/W	○	○	×
#8733	Variable for traveling distance controlled by PMC (Area C)	R/W	○	○	×
#8735	Read variable for PMC status signal (Area C)	R/	○	○	×
#8740	PMC command signal variable (Area D)	R/W	○	○	×
#8741	PMC control command variable (Area D)	R/W	○	○	×
#8742	PMC cutting feedrate variable (Area D)	R/W	○	○	×
#8743	Variable for traveling distance controlled by PMC (Area D)	R/W	○	○	×
#8745	Read variable for PMC status signal (Area D)	R/	○	○	×
Torque limit control					
#8621	Override value of the torque limit for the 1st servo axis	R/W	○	○	○
#8622	Override value of the torque limit for the 2nd servo axis	R/W	○	○	○
#8623	Override value of the torque limit for the 3rd servo axis	R/W	○	○	○
#8624	Override value of the torque limit for the 4th servo axis	R/W	○	○	○
#8625	Override value of the torque limit for the 5th servo axis	R/W	○	○	○
#8626	Override value of the torque limit for the 6th servo axis	R/W	○	○	○
#8627	Override value of the torque limit for the 7th servo axis	R/W	○	○	○
#8628	Override value of the torque limit for the 8th servo axis	R/W	○	○	○
Reading A/D converter data (Series 16/18)					
#8631	A/D converter data for channel 1	R/W	○	○	×
#8632	A/D converter data for channel 2	R/W	○	○	×
#8633	A/D converter data for channel 3	R/W	○	○	×
#8634	A/D converter data for channel 4	R/W	○	○	×
Window function					
#8998	System information ID	R/W	○	○	×
#8999	System information	R/	○	○	×
Reading custom macro variables					
#99000 – #99999	#99000 + Custom macro variable number	R/W	○	○	○
Offset memory and work piece coordinate system (Series 16/18)					
#100000 –	Extended system variable for the offset memory and workpiece coordinate system	R/W	○	○	○

R : Readable W : Writable ○ : Usable × : Unusable

G


DIFFERENCES BETWEEN Series 0 AND Series 16/18 (CONVERSION FROM FS0 TO FS16/18)



G.1 CHARACTER DISPLAY (G243)

Double size can be specified for character size specification A (only for alphanumeric characters).

⇒ An alphanumeric character is displayed having the same size as a kanji character.



G.2 DISPLAY COLOR SPECIFICATION (G240)

(1) Setting a negative value for the display color reverses the display.

G240 Pp;

P : 0=Black

1=Red 2=Green 3=Yellow 4=Blue 5=Purple 6=Blue-green 7=White
1=Red 2=Green 3=Yellow 4=Blue 5=Purple 6=Blue-green 7=White


(2) Blinking display can be specified in address L.

G240 Pp Ll; L : 0 = Does not blink 1 = Blinks

⇒ The display blinks under the control of the hardware. The program does not have to contain a loop. Once blinking is specified for the display, it keeps blinking.

G.3 KEY INPUT VARIABLE (#8501)

(1) Key numbers are added for the cursor keys.



(2) Key number 9 cannot be used because there is not a START key on the MDI.

G.4 CONTROLLING CONVERSATIONAL MACRO FUNCTION SCREENS (#8510)

Screen numbers and corresponding screens are changed.

For standard MDI		For small MDI	
0	POS	0	POS
1	PROG	1	PROG
2	OFFSET/SETTING	2	OFFSET/SETTING
3	SYSTEM	3	SYSTEM
4	MESSAGE	4	MESSAGE
5	GRAPHIC	5	CUSTOM/GRAPHIC
6	CUSTOM	6	CUSTOM
7	FAPT		

⇒When the graphic screen is provided, the graphic screen is selected.)

G.5 PMC WRITE CONTROL CODE

Signed values consisting of 1 to 4 bytes can be written.

G310 Dd Ll Qq ;

G310 Rr Ll Qq ;

G310 Cc Ll Qq ;

G310 Kk Ll Qq ;

D: Data table number of the PMC

R: Internal relay number of the PMC

C: Counter

K: Keep relay

L: Data length (1 or blank: 1 byte, 2: 2 bytes, 4: 4 bytes)

⇒ Unsigned when L is not specified. Signed when L is 1.

Q: Write data (Converted to binary when transferred)

G.6 PMC READ CONTROL CODE

Signed values consisting of 1 to 4 bytes can be read.

G310 Dd Pp Ll ;

G310 Rr Pp Ll ;

G310 Cc Pp Ll ;

G310 Kk Pp Ll ;

D: Data table number of the PMC

R: Internal relay number of the PMC

C: Counter

K: Keep relay

P: Number of the variable in which the read data is stored.

L: Data length (1 or blank: 1 byte, 2: 2 bytes, 4: 4 bytes)

⇒ Unsigned when L is not specified. Signed when L is 1.

⇒ The value is handled using two's complement.

G.7 CALLING A SUBPROGRAM WITH AN AXIS ADDRESS

Compile parameter	#7	#6	#5	#4	#3	#2	#1	#0
9005	TMACC			AXCLS	AX4CL	AX3CL	AX2CL	AX1CL


- AX1CL 0 : Subprogram call by the 1st address is invalid
1 : Subprogram call by the 1st address is valid
- AX2CL 0 : Subprogram call by the 2nd address is invalid
1 : Subprogram call by the 2nd address is valid
- AX3CL 0 : Subprogram call by the 3rd address is invalid
1 : Subprogram call by the 3rd address is valid
- AX4CL 0 : Subprogram call by the 4th address is invalid
1 : Subprogram call by the 4th address is valid
- AXCLS 0 : Always program O9009 is called irrespective of specified axes.
1 : The program number to be called depends on a specified axis:
Program O9031 is called when 1st axis is specified.
Program O9032 is called when 2nd axis is specified.
:
:
Program O9038 is called when 8th axis is specified.
- TMACC 0 : Macro call by T code is invalid
1 : Macro call by T code is valid

Compile parameter	#7	#6	#5	#4	#3	#2	#1	#0
9008	HRGCC				AX8CL	AX7CL	AX6CL	AX5CL

- AX5CL 0 : Subprogram call by the 5th axis address is made invalid.
1 : Subprogram call by the 5th axis address is made valid.
- AX6CL 0 : Subprogram call by the 6th axis address is made invalid.
1 : Subprogram call by the 6th axis address is made valid.
- AX7CL 0 : Subprogram call by the 7th axis address is made invalid.
1 : Subprogram call by the 7th axis address is made valid.
- AX8CL 0 : Subprogram call by the 8th axis address is made invalid.
1 : Subprogram call by the 8th axis address is made valid.
- HRGCC 0 : Character display screen is not set to the intensity modulation mode.
1 : Character display screen is set to the intensity modulation mode.

G.8 CALLING A MACRO WITH A T CODE

P-CODE program O9008 can be called from the user program using a T code.



Compilation parameter	#7	#6	#5	#4	#3	#2	#1	#0
9007	TMAC							

#7(TMAC) 0 : Does not call a macro with a T code.

1 : Calls a macro with a T code.

⇒ The specified T code is assigned to #27.

⇒ Addresses P (#16) and L (#12) can also be used as arguments.

⇒ Up to five G codes (including one code for a group) are assigned to #28 to #32.

General argument	#1 to #26
T code	#27
G code	#28 to #32

(Example)

G91 G28 X123.45678 T5678;⇒

Local variable	
#24	123.45678
#27	5678
#28	28
#29	91

G.9 A BIT CANNOT BE SPECIFIED TO READ A PARAMETER.

In FS0, a command such as #100=P100.2; can be specified. In FS16, however, use a command such as #100=[P100 AND 4]/4; instead.

G.10 THE ROM SIZE IS SPECIFIED DIFFERENTLY.

Compile parameter	#7	#6	#5	#4	#3	#2	#1	#0
9000				R1MB	R512	R256		

#4 (R1MB) Writes data in a 1M-byte ROM module.

#3 (R512) Writes data in a 512K-byte ROM module.

#2 (R256) Writes data in a 256K-byte ROM module.

G.11 THE USE OF P-CODE DEDICATED VARIABLES HAS BEEN EXTENDED.

Compile parameter	#7	#6	#5	#4	#3	#2	#1	#0
9002					EVF			

#3 (EVF) 0 : Extended P-CODE variables (#20000 or larger) are floating-point type.

1 : Extended P-CODE variables (#20000 or larger) are integer type.
(Numeric values -32768 to +32767 can be handled.)

NOTE

When extended P-CODE variables are integer type, note the following:

- 1 When an extended P-CODE variable is specified on the left side of an expression, the result of calculation is rounded off and assigned.
- 2 When an extended P-CODE variable is referenced in an expression, it is converted to floating-point type.

Compile parameter	9037	Number of P-CODE dedicated variables to be used (0 to 60)
-------------------	------	---

Sets the number of P-CODE dedicated variables to be used in units of 100. Each 100 variables use 1.63m of tape storage.

9037 = 12 or less for 20m tape storage

9037 = 25 or less for 40m tape storage

9037 = 51 or less for 80m tape storage

9037 = 60 or less for 160m to 1280m tape storage

Compile parameter	9044	Number of extended P-CODE dedicated variables to be used
-------------------	------	--

Sets the number of extended P-CODE dedicated variables to be used. Twelve floating-point variables or 30 integer variables make a set. Each set uses 0.21m of tape storage.

9044 = 819 or less for 160m tape storage

9044 = 1638 or less for 320m tape storage

9044 = 3276 or less for 640m tape storage (9002#3 = 0)

9044 = 2184 or less for 640m tape storage (9002#3 = 1)

9044 = 5461 or less for 1280m tape storage (9002#3 = 0)

9044 = 2184 or less for 1280m tape storage (9002#3 = 1)

G.12 THE METHOD FOR DISPLAYING P-CODE VARIABLES #10000 OR LARGER HAS BEEN CHANGED.

Executor parameter	#7	#6	#5	#4	#3	#2	#1	#0
9000							NDP	

#1 (NDP) 0 : Local and common variables for a P-CODE program are not displayed.

1 : Local and common variables for a P-CODE program are displayed.

(Press the OFFSET key several times.)

P-CODE VARIABLE			
No.	DATA	No.	DATA
100	0.000	110	0.000
101	9.000	111	9.000
102	10.000	112	10.000
103		113	
104		114	
105		115	
106		116	
107		117	
108		118	
109		119	

NUM. _____
[] [] [] [] [NO-SEL]

Enter the variable number and press soft key [NO-SEL] to select the number of the variable to be displayed.

- ⇒ The values of the variables just before the screen is displayed are displayed. Note that even if the value of a variable is changed after the screen is displayed, the displayed value does not change.
- ⇒ In FS16, variables of numbers #10000 or larger can be displayed using soft key [NO-SEL]. To display P-CODE dedicated variables of numbers #10000 or larger in FS0, set the number of the first variable to be displayed in parameter 9001. Twenty variables after and including the set variable are displayed.

H G CODES THAT CAN BE USED BY THE CONVERSATIONAL AND AUXILIARY MACROS

NOTE

- 1 The conversational macro can issue all G codes. The auxiliary macro cannot issue commands relating to screen display (●). The execution macro cannot issue G codes. (G01, G02, and G03 are commands for linear interpolation and cylindrical interpolation of the NC unit.)
- 2 A single-shot G code is marked with "1S". A continuous-state G code is marked with "M". Each continuous-state G code is shared by the conversational and auxiliary macros and belongs to one G-code group.

G code	Function	Standard command format	M/1S	Conversa- tional	Auxiliary
G01	Graphics: Displays a straight line.	G01 X_ Y_ ;	M	○	●
G02	Graphics: Displays an arc (clockwise).	G02 X_ Y_ I_ J_ Q_ ;	M	○	●
G03	Graphics: Displays an arc (counterclockwise).	G03 X_ Y_ I_ J_ Q_ ;	M	○	●
G202	Erases the screen.	G206 P_ ;	1S	○	●
G206	Graphics: Fills in an area.	G206 P_ X_ Y_ ;	1S	○	●
G240	Screen/graphics: Specifies a display color.	G240 P_ L_ ;	1S	○	●
G242	Graphics: Specifies a start point.	G242 X_ Y_ ;	M	○	●
G243	Displays characters.	G243 [String Form] ;	M	○	●
G244	Graphics: Specifies a line type.	G244 P_ ;	1S	○	●
G310	Reads or writes the PMC data.	G310 [R/D/C/K]_ [Q/P]_ L_ ;	M	○	○
G315	Processes the array-type data.	G315 P_ K_ ;	1S	○	○
G319	Registration of external character	G319 P_ Q_ ;	1S	○	○
G320	Reference to the NC program: Catalogs a program.	G320 ;	1S	○	○
G321	Reference to the NC program: Deletes a program.	G321 ;	1S	○	○
G325	Reference to the NC program: Reads a block.	G325 ;	1S	○	○
G326	Reference to the NC program: Writes a block.	G326 P_ ;	1S	○	○
G327	Reference to the NC program: Deletes a block.	G327 ;	1S	○	○
G328	Reference to the NC program: Reads a block (characters).	G328 ;	1S	○	○
G329	Reference to the NC program: Writes a block (characters).	G329 P_ ;	1S	○	○

G code	Function	Standard command format	M/1S	Conversa- tional	Auxiliary
G330	RS232c: Opens a line.	G330 P_ B_ S_ C_ (F_/L_);	1S	○	○
G331	RS232c: Closes a line.	G331 ;	1S	○	○
G335	RS232c: Reads a single character. (Reception)	G335 P_ ;	1S	○	○
G336	RS232c: Writes data. (Transmission)	G336 [String Form] ;	M	○	○
G337	RS232c: Reads variable data. (Reception)	G337 P_ Q_ R_ ;	1S	○	○
G338	RS232c: Writes variable data. (Transmission)	G338 P_ Q_ F_ Z_ R_ ;	1S	○	○
G339	RS232c: Controls the FANUC cassette.	G339 P_ F_ L_ S_ ;	1S	○	○
G340	PMC axis control: Issues a rapid traverse command.	G340 X_ ;	1S	○	○
G341	PMC axis control: Issues a cutting feed command.	G341 X_ F_ ;	1S	○	○
G344	PMC axis control: Issues a dwell command.	G344 X_ ;	1S	○	○
G345	PMC axis control: Issues a reference position return command.	G345 ;	1S	○	○
G346	PMC axis control: Issues a miscellaneous function command.	G346 M_ ;	1S	○	○
G348	PMC axis control: Issues a status signal read command.	G348 P_ ;	1S	○	○
G349	PMC axis control: Issues a command signal write command.	G349 P_ ;	1S	○	○

NOTE

- 1 G codes (G340 to G349) for PMC axis control cannot be used for Series 20-TA.
- 2 External character registration (G319) cannot be used for Series 16/18.
- 3 G codes for graphic display (G01, G02, G03, G204, G206, G242, G244, G249, etc.) cannot be used with the Series 21 or 20-MA.

INTERNAL CODE

0020	0021	0022	0023	0024
	!	"	#	\$
0025	0026	0027	0028	0029
%	&	'	()
002A	002B	002C	002D	002E
*	+	,	-	.
002F	0030	0031	0032	0033
/	0	1	2	3
0034	0035	0036	0037	0038
4	5	6	7	8
0039	003A	003B	003C	003D
9	:	;	<	=
003E	003F	0040	0041	0042
>	?	@	A	B
0043	0044	0045	0046	0047
C	D	E	F	G
0048	0049	004A	004B	004C
H	I	J	K	L
004D	004E	004F	0050	0051
M	N	O	P	Q
0052	0053	0054	0055	0056
R	S	T	U	V
0057	0058	0059	005A	005B
W	X	Y	Z	[
005C	005D	005E	005F	0061
¥]	^	_	a
0062	0063	0064	0065	0066
b	c	d	e	f
0067	0068	0069	006A	006B
g	h	i	j	k
006C	006D	006E	006F	0070
l	m	n	o	p
0071	0072	0073	0074	0076
q	r	s	t	u

0076	0077	0078	0079	007A
v	w	x	y	z
00A0	00A1	00A2	00A3	00A4
~	。	「	」	、
00A5	00A6	00A7	00A8	00A9
·	ヲ	ァ	ィ	ゥ
00AA	00AB	00AC	00AD	00AE
エ	オ	ヤ	ユ	ヨ
00AF	00B0	00B1	00B2	00B3
ッ	ー	ァ	ィ	ゥ
00B4	00B5	00B6	00B7	00B8
エ	オ	カ	キ	ク
00B9	00BA	00BB	00BC	00BD
ケ	コ	サ	シ	ス
00BE	00BF	00C0	00C1	00C2
セ	ソ	タ	チ	ツ
00C3	00C4	00C5	00C6	00C7
テ	ト	ナ	ニ	ヌ
00C8	00C9	00CA	00CB	00CC
ネ	ノ	ハ	ヒ	フ
00CD	00CE	00CF	00D0	00D1
へ	ホ	マ	ミ	ム
00D2	00D3	00D4	00D5	00D6
メ	モ	ヤ	ユ	ヨ
00D7	00D8	00D9	00DA	00DB
ラ	リ	ル	レ	ロ
00DC	00DD	00DE	00DF	2137
ワ	ン	・	°	〃
2421	2422	2423	2424	2425
ぁ	ぁ	ぃ	ぃ	ぅ
2426	2427	2428	2429	242A
う	え	え	お	お
242B	242C	242D	242E	242F
か	が	き	ぎ	く

2430	2431	2432	2433	2434
ぐ	け	げ	こ	ご
2435	2436	2437	2438	2439
さ	ざ	し	じ	す
243A	243B	243C	243D	243E
ず	せ	ぜ	そ	ぞ
243F	2440	2441	2442	2443
た	だ	ち	ぢ	っ
2444	2445	2446	2447	2448
つ	づ	て	で	と
2449	244A	244B	244C	244D
ど	な	に	ぬ	ね
244E	244F	2450	2451	2452
の	は	ば	ぱ	ひ
2453	2454	2455	2456	2457
び	び	ふ	ぶ	ぶ
2458	2459	245A	245B	245C
へ	べ	ぺ	ほ	ぼ
245D	245E	245F	2460	2461
ぼ	ま	み	む	め
2462	2463	2464	2465	2466
も	ゃ	や	ゅ	ゆ
2467	2468	2469	246A	246B
よ	よ	ら	り	る
246C	246D	246E	246F	2472
れ	ろ	わ	わ	を
2473	2641	2642	2F40	2F41
ん	α	β	→	↗
2F42	2F43	2F44	2F45	2F46
↑	↖	←	↙	↓
2F47	2F48	2F49	2F4A	2F4B
↘	⊖	⊕	⌒	⊙
2F4C	2F50	2F51	2F52	2F53
■	▽	∇	∇∇	∇∇∇
2F60	2F61	2F62	2F63	2F64
○	⊥	⌋	⌈	┘
2F65	2F66	2F67	2F68	2F69
⊥	└	┌	┌	┐
2F6A	2F6B	2F6C	2F6D	2F6E
┆	+	-	┆	ノ

2F6F	2F70	2F71	2F72	2F73
ノ	()	[]
2F74	2F75	2F76	2F77	2F78
⌋	⌈	┐	┌	↑
2F79	2F7A	2F7B		
↑	↑	—		
	302E	3035	3037	3042
	握	庄	扱	安
3045	304A	304C	304F	3055
暗	以	位	罍	意
305B	305C	3063	3068	306C
異	移	違	域	一
3075	307A	3122	3123	3126
印	引	陰	隱	右
313F	3146	3154	315B	315F
運	影	銳	越	円
3168	316F	3173	317A	317B
沿	縁	遠	凹	央
317C	317D	317E	3221	3223
奥	往	応	押	横
323D	322F	3230	3239	323C
化	億	屋	温	下
323D	323E	323F	3241	3243
化	仮	何	価	加
3244	3248	324A	324C	3254
可	家	科	果	稼
3255	3259	325D	3261	3268
箇	荷	課	過	画
3271	3272	3273	327E	3323
会	解	回	改	械
3326	3328	332B	332C	3330
界	絵	開	階	外
3335	333A	3346	3348	334A
概	該	各	拈	格
334B	334E	3351	3354	3356
核	確	角	郭	隔
3358	335B	335D	3364	3368
学	額	掛	割	活
342C	3430	3439	3441	3446
卷	完	換	漢	監

3449	344A	3451	3453	3456
管	簡	觀	貫	間
3458	345D	345E	346A	346F
閑	丸	含	願	器
3470	3471	3473	3474	347B
基	奇	寄	岐	既
347C	3521	3522	3524	352C
期	機	帰	気	規
352D	352F	3530	353B	353F
記	起	軌	技	疑
3541	3551	3552	3555	3559
義	却	客	逆	休
355E	3561	3565	3566	3569
急	求	球	究	級
356B	356C	356E	3576	3577
給	旧	去	許	距
3621	3626	362D	362F	3635
供	共	境	強	教
3648	364A	3651	3652	3658
業	曲	均	巾	禁
365A	3661	3662	3668	366B
筋	近	金	区	矩
366E	3671	3675	3676	3679
馭	具	空	偶	隅
3721	372B	3732	3738	3739
掘	繰	群	係	傾
373F	3741	3742	374F	3750
型	形	径	系	經
3751	3757	375A	3765	3767
繼	計	輕	桁	欠
3768	376A	376B	376F	3821
決	穴	結	件	檢
3822	3826	382A	382B	3833
權	研	肩	見	驗
3835	3836	3839	383A	383B
元	原	弦	減	源
383D	3840	3842	3844	3846
現	言	限	個	呼
3847	384A	384C	385F	3865
固	己	弧	互	後

3866	386C	386D	386E	3872
御	語	誤	護	交
387A	387C	387D	387E	3926
効	厚	口	向	孔
3929	392A	392D	3933	3935
工	巧	広	抗	控
3939	393B	393D	3942	3945
更	校	構	溝	硬
3953	3954	395D	395F	3960
荒	行	鋼	降	項
3962	3966	3967	396F	3970
高	号	合	刻	告
3975	397E	3A2C	3A2E	3A38
黒	込	根	混	左
3A39	3A3F	3A42	3A46	3A47
差	鎖	座	再	最
3A4E	3A51	3A59	3A5F	3A60
採	濟	細	在	材
3A62	3A6E	3A6F	3A76	3B28
財	作	削	策	雜
3B32	3B33	3B36	3B3A	3B3B
参	山	散	産	算
3B44	3B45	3B48	3B4D	3B4F
残	仕	使	四	始
3B51	3B52	3B57	3B58	3B5F
姿	子	思	指	止
3B65	3B67	3B69	3B6B	3B6E
糸	紫	脂	視	試
3B71	3B75	3B76	3B77	3B7D
資	齒	事	似	持
3B7E	3C21	3C23	3C28	3C2A
時	次	治	示	耳
3C2B	3C30	3C34	3C3A	3C3C
自	式	軸	失	室
3C41	3C42	3C4C	3C4D	3C50
質	実	写	射	斜
3C54	3C56	3C5A	3C61	3C65
者	車	借	釈	弱
3C67	3C68	3C69	3C6A	3C6C
主	取	守	手	殊

3C6F	3C75	3C77	3C79	3C7D
種	受	壽	樹	收
3C7E	3D24	3D2A	3D38	3D3D
周	修	終	集	十
3D3E	3D44	3D45	3D50	3D51
從	縱	重	出	術
3D52	3D60	3D63	3D67	3D68
述	準	純	順	処
3D69	3D6A	3D71	3D75	3D78
初	所	書	助	序
3D7C	3E21	3E26	3E2E	3E2F
除	勝	商	小	少
3E30	3E3A	3E43	3E44	3E48
尚	昇	消	涉	照
3E4A	3E4E	3E4F	3E5A	3E5C
省	称	章	証	詳
3E5D	3E65	3E6A	3E6C	3E6F
象	上	剩	場	常
3E72	3E75	3E7E	3F22	3F27
条	状	飾	植	色
3F28	3F29	3F2D	3F2E	3F2F
触	食	伸	信	侵
3F34	3F36	3F37	3F3B	3F3C
心	振	新	浸	深
3F3F	3F47	3F48	3F4A	3F4D
真	診	身	進	人
3F4F	3F5E	3F62	3F64	3F65
刃	囟	垂	推	水
3F6D	3F74	3F78	4023	4029
錐	数	据	寸	制
402D	402E	4030	4035	4038
性	成	整	正	生
403A	403D	4044	404A	4050
精	製	青	席	石
4051	4053	4056	405A	405C
積	績	赤	切	接
405E	405F	4061	4062	4064
折	設	節	說	絶
4068	4069	406C	4075	407B
先	千	專	淺	旋

407E	412A	4130	4133	4134
線	選	前	然	全
4146	4147	414F	4150	415B
粗	素	創	双	想
415C	415E	4160	4161	416A
搜	插	操	早	相
416D	4175	4176	4177	417D
總	裝	走	送	增
4226	4227	4228	422C	422D
側	則	即	測	足
422E	4230	4233	4238	423B
速	属	続	存	損
423E	423F	4240	4247	424E
他	多	太	打	体
4250	4254	4256	4258	4260
对	待	態	替	退
4265	4266	4267	4268	426A
代	台	大	第	題
426E	4272	4323	432B	4331
卓	扱	達	谷	单
4335	433A	433B	433C	4347
探	炭	短	端	断
434A	434D	434E	434F	4356
段	值	知	地	置
4357	4359	4365	4366	436C
致	遲	着	中	柱
436D	4372	437A	4425	4427
注	鑄	丁	張	徵
4434	4436	4439	443A	443B
調	超	長	頂	鳥
443E	4449	444C	4463	4464
直	追	通	低	停
446A	446C	4478	4479	447B
定	底	程	締	訂
452A	452C	4534	453A	453E
的	適	鉄	添	転
4540	4541	4545	4550	4553
点	伝	電	登	途
4559	456A	4576	4579	4628
度	投	当	等	逃

462C	4630	4631	4633	463B
頭	動	同	導	道
4640	4643	4648	4649	464C
得	特	独	読	凸
464D	465F	4662	4679	467C
突	鈍	内	肉	日
467E	4724	4727	472E	472F
入	任	認	熱	年
473B	473C	473D	474B	474F
濃	納	能	破	馬
4753	4754	4755	4758	475B
排	敗	杯	背	配
475C	4772	4776	4822	482F
倍	白	薄	箱	発
4834	483C	483D	483E	483F
抜	伴	判	半	反
4842	4844	4846	484C	484F
搬	板	汎	般	範
4856	4866	4869	486F	4873
番	比	皮	被	非
4877	4879	487E	492C	4934
備	微	美	必	百
4938	493D	4941	4943	494A
標	表	描	秒	品
4954	4955	495B	4961	4969
不	付	布	普	負
4974	497A	497B	497C	497D
部	伏	副	復	幅
4A23	4A2A	4A2C	4A34	4A38
複	物	分	粉	文
4A39	4A3B	4A3F	4A42	4A44
聞	併	平	並	閉
4A47	4A4C	4A51	4A52	4A54
頁	別	変	片	編
4A55	4A56	4A59	4A5B	4A5D
辺	返	勉	弁	保
4A62	4A64	4A6F	4A71	4A73
步	補	倣	包	報
4A7C	4A7D	4B21	4B3A	4B40
放	方	法	忘	棒

4B5C	4B60	4B67	4B68	4B76
本	摩	枚	毎	末
4B7C	4C24	4C29	4C35	4C3E
万	未	密	無	名
4C3F	4C40	4C47	4C4C	4C57
命	明	滅	面	耗
4C5A	4C5C	4C61	4C64	4C67
木	目	戻	問	門
4C73	4C75	4C7D	4D2D	4D33
約	訳	油	有	由
4D3D	4D3E	4D3F	4D46	4D49
予	余	与	容	揺
4D4D	4D4F	4D51	4D57	4D5E
様	溶	用	要	抑
4D6D	4D6E	4D70	4D77	4D78
絡	落	乱	覧	利
4D7D	4E22	4E25	4E28	4E29
理	裏	離	率	立
4E2C	4E3B	4E3E	4E41	4E49
略	了	両	料	良
4E4C	4E4E	4E4F	4E50	4E58
量	領	力	緑	輪
4E60	4E61	4E63	4E64	4E69
類	令	例	冷	礼
4E73	4E74	4E7D	4F22	4F29
列	劣	練	連	路
4F3F	4F40	4F42	4F43	4F44
録	論	和	話	歪
4F48				
榨				

J

PARAMETERS



J.1 COMPILE PARAMETERS

	#7	#6	#5	#4	#3	#2	#1	#0
8000	ROMM	16BT		BAUD		M30	M02	M99

(Exclusive for FANUC SYSTEM P-MODEL G)

- M99 0 : M99 does not terminate compilation of a single program.
1 : M99 terminates compilation of a single program.
- M02 0 : M02 does not terminate compilation of a single program.
1 : M02 terminates compilation of a single program.
- M30 0 : M30 does not terminate compilation of a single program.
1 : M30 terminates compilation of a single program.
- BAUD 0 : Data is transferred to the FA-WRITER at a baud rate of 4800 bps.
1 : Data is transferred to the FA-WRITER at a baud rate of 9600 bps.
- 16BT 0 : Data is written into the ROM module in units of 32 bits.
(For Series 16)
1 : Data is written into the ROM module in units of 16 bits.
(For Series 18)
- ROMM 0 : The ROM cassette is used. (For Series 0)
1 : The ROM module is used. (For Series 16 or 18)

	#7	#6	#5	#4	#3	#2	#1	#0
8010								CAP

(Exclusive for FANUC SYSTEM P-MODEL G)

- CAP 0 : The macro executor has one file.
1 : The macro executor has two files. (Conversational type)

	#7	#6	#5	#4	#3	#2	#1	#0
9000	LD6			R1M	R512	R256	R128	VERFY

(Exclusive for FANUC SYSTEM P-MODEL G)

- VERFY 0 : The ROM is not checked when the data is output to it.
1 : The ROM is checked when the data is output to it.
- R128 0 : Data is output to the 64K-byte ROM cassette. (Only for FS0)
1 : Data is output to the 128K-byte ROM cassette or module.
(Only for FS18/20-MA/21-TB)
- R256 0 : R128 is referenced.
1 : Data is output to the 256K-byte ROM cassette or module.
- R512 0 : R256 is referenced.
1 : Data is output to the 512K-byte ROM cassette or module.
- R1M 0 : R512 is referenced.
1 : Data is output to the 1M-byte ROM cassette or module.
- LD6 1 : Always specify 1.

NOTE

If both R512 and R256 are set to 1, the data is output to the 768K-byte ROM module.

Compile parameter	9000	#7	#6	#5	#4	#3	#2	#1	#0
			M3MB	M2MB	M1MB	M512	M256	M128	
(Only for personal computer)									
Compile parameter	9001	#7	#6	#5	#4	#3	#2	#1	#0
							M4MB		SEQN
(Only for personal computer)									

	M4MB	M3MB	M2MB	M1MB	M512	M256	M128
4.0 MB	1	0	0	0	0	0	0
3.0 MB	0	1	0	0	0	0	0
2.0 MB	0	0	1	0	0	0	0
1.0 MB	0	0	0	1	0	0	0
512 KB	0	0	0	0	1	0	0
256 KB	0	0	0	0	0	1	0
128 KB	0	0	0	0	0	0	1

NOTE

- 1 For the 21-TB, always specify 128 KB.
- 2 For the Series 16, a 128-KB ROM-format file cannot be specified.
- 3 For the 21-MB, no more than 1.0 MB can be specified.

SEQN 0 : When data is output to the ROM, sequence numbers are not output to the P-CODE program.

1 : When data is output to the ROM, sequence numbers are output to the P-CODE program.

NOTE

When SEQN is set to 0, the P-CODE program requires a small amount of space and can be executed at high speed. However, this cannot be specified in the following cases: When GOTO is specified by a variable in the P-CODE program and when a program contains M99 and the number of the sequence (P) to which it is to be returned. (If an attempt is made to set SEQN to 0 in either of these cases, a compilation error occurs.)

Examples) GOTO #101;
M99 P100;

	#7	#6	#5	#4	#3	#2	#1	#0
9002	EXT1	PWSR	DAUX	XDIL	EVF	ACL2	ACL1	TCAL
TCAL	0 : Makes invalid the sub-program call with T code 1 : Makes effective the sub-program call with T code							
ACL1	0 : Makes invalid call by the specific code 1 : Makes effective call by the specific code (O9004/#146)							
ACL2	0 : Makes invalid call by the specific code 1 : Makes effective call by the specific code (O9005/#147)							
EVF	0 : Extension P-CODE variable #20000 is the floating decimal point format 1 : Extension P-CODE variable #20000 is the fixed decimal format							
XDIL	0 : Axis interlock function invalid 1 : Axis interlock function valid							
DAUX	0 : Does not make the CUSTOM screen appear at power on 1 : Makes CUSTOM screen appear at power on							
PWSR	0 : P CODE work number search function invalid 1 : P CODE work number search valid							
EXT1	0: Extension functions invalid 1: Extension functions valid (RS-232-C control, NC program access)							

NOTE

When EXT1 = 1, part program memory reduces by 1.63 m (In case of 21-TB or when part program memory capacity is 80 m or less).

	#7	#6	#5	#4	#3	#2	#1	#0
9003		PTCR	KY20			HRGR		ONMSK
ONMSK	0 : The O and N numbers are displayed on the CUSTOM screen. 1 : The O and N numbers are not displayed on the CUSTOM screen.							
HRGR	0 : Standard mode graphic display 1 : High resolution graphic mode display (set to "1" usually)							
KY20	0 : Not +20 to #8501 with decimal point input by key input variables 1 : +20 to #8501 with decimal input by key input variables							
PTCR	0 : Does not output "CR" code twice in P-CODE variable outputting 1 : Output "CR" code twice in P-CODE variable outputting							
SP_G_B, SP_G_C	00: Standard G code system 01:G code system B 10:G code system C 11:G code system C							

	#7	#6	#5	#4	#3	#2	#1	#0
9004	CUTLG	NOP_B		HRGC		IMG	SP_G_C	SP_G_B

- IMG 0 : FS16-T type (Special G code)
1 : FS16-G type (Special G code)
- NOP_B 0 : When no other address is specified in a block that calls a subprogram by a T or M code, the block is executed.
1 : The block is not executed.
- HRGC 0 : 9" high resolution monochrome CRT, standard
1 : 9" high resolution monochrome CRT, brightness modulation mode setting (paint)
- CUTLG 0 : Does not count cutting distance
1 : Count cutting distance

	#7	#6	#5	#4	#3	#2	#1	#0
9005	TMACC			AXCLS	AX4CL	AX3CL	AX2CL	AX1CL

- AX1CL 0 : Subprogram call by the 1st address is invalid
1 : Subprogram call by the 1st address is valid
- AX2CL 0 : Subprogram call by the 2nd address is invalid
1 : Subprogram call by the 2nd address is valid
- AX3CL 0 : Subprogram call by the 3rd address is invalid
1 : Subprogram call by the 3rd address is valid
- AX4CL 0 : Subprogram call by the 4th address is invalid
1 : Subprogram call by the 4th address is valid
- AXCLS 0 : Always program O9009 is called irrespective of specified axes.
1 : The program number to be called depends on a specified axis:
Program O9031 is called when 1st axis is specified.
Program O9032 is called when 2nd axis is specified.
:
:
Program O9038 is called when 8th axis is specified.
- TMACC 0 : Macro call by T code is invalid
1 : Macro call by T code is valid

	#7	#6	#5	#4	#3	#2	#1	#0
9006			US19W	CNCHG	DAUXR	STDM	KEYC	DIOC

- DIOC 0 : Standard UI:G54/G55 and UO:F54/F55 are used for UI/UO(#1000-#1132) of execution macro/ conversational macro.
1 : UI:G82/G83 and UO:F84/F85 are used for UI/UO (#1000-#1132) of execution macro/ conversational macro.
- KEYC 0 : When KEY switch =0, completion code #8529=254 in an access to NC program
1 : KEY switch is not checked in an access to NC program
- STDM 0 : The mode and status display is changed on the USER-1, USER-2, and USER-3 screens on which the conversational macro screen is displayed.
1 : The mode and status display is left unchanged on the USER-1, USER-2, and USER-3 screens on which the conversational macro screen is displayed.

- DAUXR : The conversational macro screen is displayed when power is turned on while the system is in the emergency stop state or external reset state.
(Parameter DAUX (No. 9002, #5) must also be set to 1.)
- CNCHG : Execution of the conversational macro is continued when the CUSTM key is pressed while the conversational macro screen is displayed.
- US19W : The screen for the 9" CRT is displayed on the 14" CRT.
(USER-1 screen)

	#7	#6	#5	#4	#3	#2	#1	#0
9007						TIVR2	TIVR1	TTDSP

- TTDSP : The common conversational macro screen for the F16-TTA is specified.
(This setting is validated only for the HEAD-2 cassette.)
(Both TTDSP and CNCHG (No. 9006, #4) cannot be set to 1 at the same time.)
- TTVR1 : Common conversational macro variables (#10000 to #19999) are specified.
(1: For variables #10000 to #19999, areas #10000 to #19999 of the other head are used.)
- TTVR2 : Common conversational macro variables (#20000 to #29999) are specified.
(1: For variables #20000 to #29999, areas #20000 to #29999 of the other head are used.)

	#7	#6	#5	#4	#3	#2	#1	#0
9008	HRGCC		MCARG		AX8CL	AX7CL	AX6CL	AX5CL

- AX5CL 0 : Subprogram call by the 5th axis address is made invalid.
1 : Subprogram call by the 5th axis address is made valid.
- AX6CL 0 : Subprogram call by the 6th axis address is made invalid.
1 : Subprogram call by the 6th axis address is made valid.
- AX7CL 0 : Subprogram call by the 7th axis address is made invalid.
1 : Subprogram call by the 7th axis address is made valid.
- AX8CL 0 : Subprogram call by the 8th axis address is made invalid.
1 : Subprogram call by the 8th axis address is made valid.
- MCARG 0 : In macro calling of G/M codes, P/L/N/G is not argument.
1 : In macro calling of G/M codes, P/L/N/G is argument.
- HRGCC 0 : Does not set the character display screen to brightness modulation mode.
1 : Sets the character display screen to brightness modulation mode.

9010	M code calls sub-program O9001
9011	M code calls sub-program O9002
9012	M code that calls sub-program O9003
9013	G code that calls custom macro O9010
⋮	⋮
9022	G code that calls custom macro O9019
9023	M code that calls sub-program O9020
⋮	⋮
9032	M code that calls sub-program O9029
9033	M code that calls user program
9034	G code that to cancel the modal call
9035	M code calls sub-program O9001
9036	M code calls sub-program O9002

Parameters 9035 and 9036 specify the bit signal of the internal PMC relay (R area) that determines the control mode of the interlock function for a single axis direction.

Signal number (0 to 999): Specifies the number of the internal PMC relay (R area).

Signal position (0 to 7): Specifies the bit position of the signal.

Example) When parameters 9035 and 9036 are set to 900 and 7 respectively

The interlock function for a single axial direction is validated when the internal PMC relay (R900, #7) is set to 1 in the JOG or HNDL mode.

9037	Used number of (1/100) of conversational macro exclusive variable
9038	Conversational macro exclusion program at the time of power supply input (CUSTOM screen)
9039	Auxiliary macro execution program number
9040	Conversational macro execution program number at the time of power on (MENU screen)
9041	Conversational macro execution program number at the time of power on (MACRO screen)
9042	M code call by area specification, lower limit M code

9043	M code call by area specification, upper limit M code
9044	Used number of extension conversational macro variables
9045	Starting G code in G code calls of ,range specification
9046	Number of G codes in G code calls of ,range specification
9047	Starting O number in G code calls of ,range specification
9048	Distance by which the graphics coordinate system is shifted on the conversational macro screen (in the X direction)
9049	Distance by which the graphics coordinate system is shifted on the conversational macro screen (in the Y direction)

These parameters specify the distance by which the graphics coordinate system is shifted on the conversational macro screen in units of dots.

J.2 EXECUTOR PARAMETER

	#7	#6	#5	#4	#3	#2	#1	#0
9000	L2R		MKG	RSC	EXS	STP	NDP	SQN
SQN	0 : Displays program number and sequence number of called user program during execution of a recorded program. 1 : Displays program number of recorded program and sequence number during execution of a recorded program.							
NDP	0 : Does not display variables for P-CODE program. 1 : Displays variables for P-CODE program.							
STP	0 : Execute the conversational macro program. 1 : Stops execution of conversational macro program. ("1" is set by break function automatically)							
EXS	0 : Stop if feed hold acts, during macro statement execution at execution level. 1 : Execute macro statement till the next NC statement has come with feed hold, during macro statement execution at execution level.							
RSC	0 : Common variables #100-#149 do not clear to <vacant> if NC is reset. 1 : Common variables #100-#149 are cleared to <vacant> if NC is reset.							
MKG	: Be sure to set to 0.							
L2R	0 : Display conversational / auxiliary macro and screen during execution macro operation. 1 : Does not display conversational / auxiliary macro and screen during execution macro operation.							

9002	Conversational macro break program number
------	---


9003	Conversational macro break sequence number
------	--

	#7	#6	#5	#4	#3	#2	#1	#0
9010	MA8	MA7	MA6	MA5	MA4	MA3	MA2	MA1

- MA1 0 : Does not mask a first axis address macro call.
1 : Masks a first axis address macro call.
- MA2 0 : Does not mask a second axis address macro call.
1 : Masks a second axis address macro call.
- MA3 0 : Does not mask a third axis address macro call.
1 : Masks a third axis address macro call.
- MA4 0 : Does not mask a fourth axis address macro call.
1 : Masks a fourth axis address macro call.
- MA5 0 : Does not mask a fifth axis address macro call.
1 : Masks a fifth axis address macro call.
- MA6 0 : Does not mask a sixth axis address macro call.
1 : Masks a sixth axis address macro call.
- MA7 0 : Does not mask a seventh axis address macro call.
1 : Masks a seventh axis address macro call.
- MA8 0 : Does not mask an eighth axis address macro call.
1 : Masks an eighth axis address macro call.

NOTE

When compilation parameter bit 4 of No. 9005 (AXCLS) is set to 1, MA1 masks O9031, MA2 masks O9032, MA3 masks O9033, and so on.




MTC 0 : Does not mask a T code execution macro call.
 1 : Masks a T code execution macro call.

K ERROR CODES



K.1 COMPILER ERROR CODES (SYSTEM P)

- (1) Display of error codes
The error codes are displayed as follows when an error occurs.



If the program does not contain any sequence number, the program number is not shown in the error message.

The program number, sequence number and block number are not displayed in error messages with numbers greater than 100.

- (2) Table of error codes and their meaning

No.	Explanation
001	The program number exceeds the maximum registered number. Up to 400 pieces loaded.
002	No program available.
011	The block delete address includes a decimal point.
012	The block delete address is out of the 1 to 9 range
013	The program has a program number other than the head of program.
014	The block has a sequence number other than the head of program.
015	The NC statement contains an error.
016	The macro statement ends with an other code than EOB.
017	The equal sign of the macro statement cannot be found.
018	The nesting of DO exceeds 3 levels
019	The relational operator in the conditional expression is not found.
020	No GOTO after IF.
021	The ']' of the IF [<conditional expression>] is not found.
022	There is a code other than EOB after GOTO n.
023	There is a code than EOB after DO m.
024	There is a code than EOB after END m.
025	The END identification number does not correspond to that of DO.
030	No END found for DO.
031	No DO found after WHILE.
032	The ']' of the WHILE [<conditional expression>] is not found.
033	It is unclear whether the block is a NC statement or a macro statement.
034	No DO found for END.
035	The program number in the directory and actual number used in the program do not correspond.
036	No program number in the program heading.
041	Nesting of brackets exceeds 5 levels.
042	The ']' of the # [<expression>] is not found.

No.	Explanation
043	The ']' of the [<expression>] is not found.
044	The second ']' of the ATAN [<expression>]/[<expression>] is not found.
045	The ']' of the ATAN [<expression>]/[<expression>] is not found.
046	The first ']' of the ATAN [<expression>]/[<expression>] is not found.
047	The ']' of the function [<expression>] is not found.
048	The <expression> format contains an error.
049	The left part of <expression> of the substitution statement contains an error.
050	The <expression> of the <address>[<expression>], <address> - [<expression>] or GOTO [<expression>] format contains an error.
051	The numeral contains more than 8 figures.
052	Other codes than numeric codes follow the decimal point.
053	The variable address of the macro variable consists of more than 6 digits.
054	No figure or '[' following #.
055	The program number consists of more than 4 figures.
056	The sequence number contains more than 4 figures.
057	The '[' of function [<expression>] is not found.
058	The '[' of IF [<expression>] or WHILE [<expression>] is not found.
059	m of D0m or ENDm consists of more than 1 digit.
060	D0m or ENDm is out of the 1 to 3 range.
061	Other codes than numeric codes follow DO or END.
062	Other alphabetical string than control directive or function found.
063	Alphabetical string of more than 5 characters found.
064	No EOR at the end of the program.
065	Inappropriate code found in the program.
070	Character string exceeds 255 characters.
071	Inner code consists of more than 4 figures.
072	Inner code is not in hexadecimal format.
073	Non-displayable system code is specified.
074	Not end with '*' for character string starting with '('.
075	'(' and ')' hold characters that are not allowed.
081	The transient variable area used by the macro executor is not available. Too many addresses in the <expression> of 1 block of a NC statement.
082	The branch point for the GOTO statement is too large. Add a parameter to set the branch point as 4 bytes or reduce the program size.
083	The number of addresses contained in 1 block of the NC statement exceeds 50.
084	The variable No. of the macro variable has more than 6 digits.
085	The variable No. of the macro variable is negative.
086	The variable No. of the macro variable contains a decimal point.
087	More than 4 digits following the GOTO statement.
088	The figures following the GOTO statement contain a decimal point.
091	The number of GOTO statements in one block directly pointing to a sequence number, exceeds the limit (200).
092	The sequence number indicated as the branch point of the GOTO statement is not found.
093	The number of WHILE statements in one program exceeds the limit (200).
094	There are several sequence numbers for the branch point of the GOTO statement.
100	The macro executor is not read into memory.

No.	Explanation
101	The ROM module has caused a memory overflow.
102	256 KByte ROM module cannot be used with this macro executor.
111	A time error occurred while waiting for answer from the FA writer.
112	A parity error occurred while waiting for answer from the FA writer.
113	An overflow error occurred while waiting for answer from the FA writer.
114	Framing error occurred while waiting for answer from the FA writer.
115	FA writer is not READY or cable is not connected.
116	Error occurred during transmission to the FA writer.
117	Parity error occurred while sending to the FA writer.
118	ROM is not erased.
119	ROM write error occurred.
120	ROM verify error occurred.
121	ROM module is not installed.
122	Other than order made macro ROM module is installed.
123	Wrong FA writer version number.
124	Error occurred in FA writer.
125	The address or length instruction for the FA writer is uneven.
126	The written data exceeds the capacity of the installed ROM module.
127	The FA writer is not set up properly.
128	Address setting error of the FA writer.
129	Inverse installment of ROM.
131	Memory write error.
132	Memory read error.
140	File open parameter error.
141	Floppy disk hard error.
142	File not found.
143	Wrong file format.
144	Floppy disk already in use.
145	File is protected.
146	File name already in use.
147	Password error.
148	File size overflow.
149	File number overflow.
150	File closed error.


K.2 EXECUTOR ERROR CODE

The following is an explanation of the supplementary P/S error codes that may occur at the time of execution of P-CODE program.


Code	Explanation
110	The absolute value of the data of the fixed decimal point display exceeds the allowable range.
111	The index of the data of the floating decimal point exceeds the allowable range.
112	The divisor is 0.
115	Pointing to the value of an undefined variable address.
116	The left part of the substitution statement consists of an illegal variable.
119	The SQRT parameter is a negative value, the BCD parameter is a negative value or the BIN parameter contains values others than 0 to 9.




CHARACTER COORDINATE SYSTEM



(1) For 12 soft keys display



(2) For 7soft keys display



M SCREEN DISPLAY ON A VGA GRAPHICS DISPLAY UNIT (SUPPORTED BY Super CAP EXECUTOR ONLY)



M.1 DISPLAY COLOR SPECIFICATION EXTENSION

M.1.1 Overview

When using a VGA graphics display unit, the user can choose any of sixteen colors for character display and graphics display.

Moreover, the user can choose from sixteen colors for the character display background.

The initial color settings on the CUSTOM screen are as follows: color palette 7 for character display/graphics display, color palette 0 for the background, and non-blinking.

G240 P_C_L_;

P: Character display/graphics display color specification
 When one of the following values is specified with a minus sign (-) prefixed, characters are displayed in reverse video.

=0	.. Color of color palette 0	Default :	Black
=1	.. Color of color palette 1		Red
=2	.. Color of color palette 2		Green
=3	.. Color of color palette 3		Yellow
=4	.. Color of color palette 4		Blue
=5	.. Color of color palette 5		Purple
=6	.. Color of color palette 6		Peacock blue
=7	.. Color of color palette 7		White
=8	.. Color of color palette 8		Light black
=9	.. Color of color palette 9		Light red
=10	.. Color of color palette 10		Light green
=11	.. Color of color palette 11		Light yellow
=12	.. Color of color palette 12		Light blue
=13	.. Color of color palette 13		Light purple
=14	.. Color of color palette 14		Light peacock blue
=15	.. Color of color palette 15		Light white

C: Specification of the background color


=0	.. Color of color palette 0	Default :	(Same as above)
=1	.. Color of color palette 1		
=2	.. Color of color palette 2		
=3	.. Color of color palette 3		
=4	.. Color of color palette 4		
=5	.. Color of color palette 5		
=6	.. Color of color palette 6		
=7	.. Color of color palette 7		
=8	.. Color of color palette 8		

- =9 .. Color of color palette 9
- =10 .. Color of color palette 10
- =11 .. Color of color palette 11
- =12 .. Color of color palette 12
- =13 .. Color of color palette 13
- =14 .. Color of color palette 14
- =15 .. Color of color palette 15

L: Specification of blinking

- =0 .. Non-blinking
- =1 .. Blinking

The following specification displays the colors shown below:



When only addresses P and C are specified, the specification of 0 at address L is assumed.

G240 P1 ; Character color: Color of color palette 1
Background color: (No change)
Blinking: Non-blinking

G240 C1 ; Character color: (No change)
Background color: Color of color palette 1
Blinking: Non-blinking

NOTE


Color palettes cannot be set using the executor. Those set using the CNC are used.

M.2 SCREEN ERASURE EXTENSION

M.2.1 Overview

When a VGA graphics display unit is used, the screen is erased using color palette 7 for character display and a selected color for the background.

If no of background color has been specified on the CUSTOM screen, color palette 0 is used.



NOTE

For display units other than a VGA graphics display, white is used for screen erasure. This corresponds to color palette 7, so that color palette 7 is used for erasure on a VGA graphics display unit.

M.3 EXTENSION OF NUMBER OF DISPLAY LINES

M.3.1 Overview


When a VGA graphics display unit having twelve soft keys is used, and bit 2 (CM30) of compile parameter No. 9009 is set to 1, up to 30 lines including the upper three lines and lower two lines, which are not usually used, can be used to display characters.

When a VGA graphics display unit having seven soft keys is used, up to 19 lines including the upper two lines and lower one line which are not usually used, can be used to display characters.


When the following command is issued with a VGA graphics display unit, the usable lines can be increased as shown below:

```
G243 X0 Y0 (123) ;  
G243 X4 Y24 (980) ;
```

When bit 2 of compile parameter No. 9009 = 0



When bit 2 of compile parameter No. 9009 = 1



M.3.2 Compile Parameters

	#7	#6	#5	#4	#3	#2	#1	#0
9009						CM30	LM30	

- LM30 0 : The full 30-line screen is not used for VGA display. (Super CAP)
 1 : The full 30-line screen is used for VGA display. (Super CAP)
- CM30 0 : The full 30-line screen is not used for VGA display. (CUSTOM)
 1 : The full 30-line screen is used for VGA display. (CUSTOM)

NOTE


LM30 is enabled when a command related to executor screen display is used on a screen other than the CUSTOM screen.

M.4 GRAPHICS COORDINATE SYSTEM

M.4.1 Overview


When a VGA graphics display unit having twelve soft keys is used, the X coordinate of the graphics coordinate system ranges from -320 to 319 (from left to right), while the Y coordinate ranges from -232 to 247 (from bottom to top). When a VGA graphics display unit having seven soft keys is used, the X coordinate ranges from -160 (-320) to 159 (319) (from left to right), while the Y coordinate ranges from -129 (-232) to 140 (247) (from bottom to top).

Display unit having seven soft keys



High-resolution mode in parentheses

Display unit having twelve soft keys



NOTE

For a display unit having twelve soft keys, the standard (low-resolution) display mode is not supported.

N DISPLAY WITH A BACKGROUND COLOR ON THE CUSTOM SCREEN




N.1 OVERVIEW

When a VGA graphics display unit is used with the Series 16i/18i/21i, display with a background color can be provided on the conversational macro (CUSTOM) screen by setting bit 0 (VGAR) of compile parameter No. 9100 to 1.

Display with a background color can be provided in the following areas:

Display with twelve soft keys: 30 lines (vertically), 80 characters (horizontally)

Display with seven soft keys: 19 lines (vertically), 40 characters (horizontally)



2 (1) lines for the menu display area

23 (15) lines for the data display area


5 (3) lines for the soft key display area

Each number in parentheses represents the number of lines for a display unit having seven soft keys.

Display with a background color is provided using the graphics display. When graphics is specified in the same position, display with a background color is overwritten. Similarly, display with a background color can overwrite the specified graphics display.

When a screen erase command (G202) is specified, graphics display is erased using color palette 15.

When a dot coordinate system is used, the number of dots is 640 x 480, regardless of whether a display unit having twelve or seven soft keys is used. The coordinate system is as follows:



N.2 COMMAND FOR DISPLAY WITH A BACKGROUND COLOR

G250 P_<parameter>

P_: Specifies an item number.

<parameter>: Specifies a parameter for each item.

N.3 ITEMS OF THE COMMAND FOR DISPLAY WITH A BACKGROUND COLOR (P_)

Item (P_)	Description	Parameter
000	Clears the screen with a background color.	None
001	Clears the data display area only.	None
002	Clears the screen background with a background color	None
003	Clears only the background of the data display area.	None
010	Displays a convex group frame.	X_ Y_ I_ J_
011	Displays a concave group frame.	X_ Y_ I_ J_
015	Displays a key-in line frame.	X_ Y_
018	Displays a frame for 9 selected window(*).	X_ Y_
019	Displays a frame for an unselected window(*).	X_ Y_
020	A window for window frame mode(*).	X_ Y_ R_
021	Selects a window for window frame mode(*).	R_
022	Displays a frame for a selected window in window frame mode(*).	R_
023	Displays a frame for an unselected window in window frame mode(*).	R_
024	Displays a frame background for a selected window in window frame mode(*).	R_
025	Displays a frame background for an unselected window in window frame mode(*).	R_
030	Displays soft key nonselection state.	None
031	Displays the state of soft key pressing.	R_ (B_)
040	Sets a graphics palette (1 palette).	R_ A_ B_ C_
041	Sets a character palette (1 palette).	R_ A_ B_ C_
042	Sets graphics/character palettes.	R_
043	Sets graphics palettes (all palettes).	R_
044	Sets character palettes (all palettes).	R_

The items marked with an asterisk (*) can be specified only for the display unit having twelve soft keys.

A screen background with a background color corresponds to a graphics display plane. On the screen, a graphics display plane and character display plane are overlaid on each other. For display with a background color, a graphics display plane is used.

In window frame mode, display coordinates are based on the frame of a selected/unselected window. This means that, for character display, the upper-left point of each window frame serves as the coordinates (0,0). However, this does not affect the graphics display coordinates.

**N.4
DETAILS OF ITEMS
OF THE COMMAND
FOR DISPLAY WITH
A BACKGROUND
COLOR (P_)**

Items (000, 001, 002, 003)

The items (000 and 002) clear the display with a background color and character display.

The items (001 and 003) clear only the display with a background color.

Items (010 and 011)


X_: Frame upper-left point (X-axis)

Y_: Frame upper-left point (Y-axis)

I_: Frame lower-right point (X-axis)

J_: Frame lower-right point (Y-axis)

The X, Y, I, and J points represent coordinates for character display.



The above parameters specify a rectangular frame.

When a specified frame is too large to be displayed within the screen, the command is ignored.

Only display with a background color is supported.





Item (015)

X_: Frame start point (X-axis)

Y_: Frame start point (Y-axis)

The X and Y points represent the coordinates for character display.

A fixed frame size is used: 40 characters along the X-axis, and one line along the Y-axis. When a frame of this size cannot be displayed within the display area of the screen, the command is ignored. Only display with a background color is supported.

Items (018, 019) (Usable with a display unit having twelve soft keys)


X_: Frame start point (X-axis)

Y_: Frame start point (Y-axis)

The X and Y points represent the coordinates for character display.

A fixed frame size is used: 41 characters along the X-axis, and 14 lines along the Y-axis. When a frame of this size cannot be displayed within the display area of the screen, the command is ignored.





Item (020) (Usable with a display unit having twelve soft keys)

R_: Frame number (1 to 3)

X_: Frame start point (X-axis)

Y_: Frame start point (Y-axis)

The X and Y points represent the coordinates for character display.

A fixed frame size is used: 41 characters along the X-axis, and 14 lines along the Y-axis. When a frame of this size cannot be displayed within the display area of the screen, the command is ignored.

Item (021) (Usable with a display unit having twelve soft keys)

R_: Selection number of a frame registered with Item (020)

A frame registered with Item (020) is selected, but is not displayed.

Item (022, 024) (Usable with a display unit having twelve soft keys)

R_: Selection number of a frame registered with Item (020)

A frame registered with Item (020) is displayed for a selected window.

Item (020) clears the character display from within the area.

Items (023 and 025) (Usable with a display unit having twelve soft keys)

R_: Selection number of a frame registered with Item (020)

A frame registered with Item (020) is displayed for an unselected window frame.

Item (023) clears the character display from within the area.

Item (031)

R_: Soft key number

When a display unit having seven soft keys is used

1 = Selects soft key 1

2 = Selects soft key 2

3 = Selects soft key 3

4 = Selects soft key 4

5 = Selects soft key 5

When a display unit having twelve soft keys is used

- 1 = Selects soft key 1
- 2 = Selects soft key 2
- 3 = Selects soft key 3
- 4 = Selects soft key 4
- 5 = Selects soft key 5
- 6 = Selects soft key 6
- 7 = Selects soft key 7
- 8 = Selects soft key 8
- 9 = Selects soft key 9
- 10 = Selects soft key 10

When a display unit having twelve soft keys is used, one of soft keys 1 through 5, and one of soft keys 6 through 10 can be selected. When two soft keys are selected, address R is used to select one soft key, while address B is used to select the other soft key.

G250 P31 R2 B8 This command selects soft key 2 and soft key 8.

When 0 is specified in R, the command has the effect of Item (030).

Items (040, 041)

R_: Color palette number (0 to 15)

A_: R value (0 to 15)

B_: G value (0 to 15)

C_: B value (0 to 15)

Item (042)

R_: Color palette setting selection number (0 to 1)

R = 0 Standard color for a screen with a background color

	R value	G value	B value
Graphics			
Color palette 0	0	0	0
Color palette 1	15	0	0
Color palette 2	0	15	0
Color palette 3	15	15	0
Color palette 4	0	0	15
Color palette 5	15	0	15
Color palette 6	0	15	15
Color palette 7	15	15	15
Color palette 8	0	0	15
Color palette 9	0	11	11
Color palette 10	15	15	15
Color palette 11	10	9	9
Color palette 12	15	15	15
Color palette 13	12	11	11
Color palette 14	4	4	4
Color palette 15	12	11	11
Character			
Color palette 0	0	0	0
Color palette 1	8	0	0
Color palette 2	0	8	0
Color palette 3	8	8	0
Color palette 4	15	15	0
Color palette 5	15	0	15
Color palette 6	0	8	8
Color palette 7	3	1	1
Color palette 8	15	15	15
Color palette 9	13	13	13
Color palette 10	12	12	12
Color palette 11	11	11	11
Color palette 12	10	10	10
Color palette 13	9	9	9
Color palette 14	8	8	8
Color palette 15	7	7	7

R = 1 Standard color for a screen without a background color

	R value	G value	B value
Graphics			
Color palette 0	0	0	0
Color palette 1	15	0	0
Color palette 2	0	15	0
Color palette 3	15	15	0
Color palette 4	0	0	15
Color palette 5	15	0	15
Color palette 6	0	15	15
Color palette 7	15	15	15
Color palette 8	0	0	15
Color palette 9	0	11	11
Color palette 10	15	15	0
Color palette 11	11	9	9
Color palette 12	15	15	15
Color palette 13	12	11	11
Color palette 14	4	4	4
Color palette 15	12	11	11
Character			
Color palette 0	0	0	0
Color palette 1	15	0	0
Color palette 2	0	15	0
Color palette 3	15	15	0
Color palette 4	0	0	15
Color palette 5	15	0	15
Color palette 6	0	15	15
Color palette 7	15	15	15
Color palette 8	14	14	14
Color palette 9	13	13	13
Color palette 10	12	12	12
Color palette 11	11	11	11
Color palette 12	10	10	10
Color palette 13	9	9	9
Color palette 14	8	8	8
Color palette 15	7	7	7

**N.5
COMPILE
PARAMETERS**

	#7	#6	#5	#4	#3	#2	#1	#0
9100	MSFT	C9WN	DLMT	VKLN			VGCL	VGAR

- VGAR 0 : Does not display the CUSTOM screen with a background color.
1 : Displays the CUSTOM screen with a background color.
- VGCL 0 : Does not display the CUSTOM screen with a background in a background color.
1 : Displays the CUSTOM screen with a background in a background color.
- VKLN 0 : Does not display a key-in line background.
1 : Displays a key-in line background.
- DLMT 0 : Does not confine display with a background color to within the data area.
1 : Confines display with a background color to within the data area.
- C9WN 0 : Does not perform character display coordinate correction in seven-soft-key window display.
1 : Performs character display coordinate correction in seven-soft-key window display.
- MSFT 0 : Displays a soft key frame on the CUSTOM screen.
1 : Does not display a soft key frame on the CUSTOM screen.

N.6 RELATED ITEMS

N.6.1 Related Compile Parameters

Note the following related compile parameters for display.

	#7	#6	#5	#4	#3	#2	#1	#0
9002			DAUX					

DAUX = 0 : The CUSTOM screen is not displayed at power-up.
= 1 : The CUSTOM screen is displayed at power-up.

	#7	#6	#5	#4	#3	#2	#1	#0
9003						HRGR		ONMSK

ONMSK = 0 : The O and N numbers are displayed on the CUSTOM screen.
= 1 : The O and N numbers are not displayed on the CUSTOM screen.

HRGR = 0 : Graphic display is performed in standard mode.
= 1 : Graphic display is performed in high resolution mode (only for a window displayed with seven soft keys).


	#7	#6	#5	#4	#3	#2	#1	#0
9006		NNUM	US19W		DAUXR	STDM		

STDM = 0 : The mode or status is displayed on the CUSTOM screen.
= 1 : The mode or status is not displayed on the CUSTOM screen.

DAUXR = 0 : The CUSTOM screen is not displayed when the system is in emergency stop status at power-up.
= 1 : The CUSTOM screen is displayed when the system is in emergency stop status at power-up. (Set the DAUX bit (bit 5 of parameter 9002) to 1 as well.)

US19W = 0 : When display with 12 soft keys is selected, the CUSTOM screen (USER1) is not displayed as a window with seven soft keys.
= 1 : When display with 12 soft keys is selected, the CUSTOM screen (USER1) is displayed as a window with seven soft keys.

NNUM = 0 : When data input control is valid for the CUSTOM screen, the NUM prompt is displayed.
= 1 : When data input control is valid for the CUSTOM screen, the NUM prompt is not displayed.



US19WK = 0 : When display with 12 soft keys is selected, the position of the key-in line is not changed in a window with seven soft keys.
 = 1 : When display with 12 soft keys is selected, the position of the key-in line is changed in a window with seven soft keys.

**N.6.2
 Conversational/
 Auxiliary Macro Alarms**

For the command for display with a background color, the following conversational/auxiliary macro alarms are added:

Alarm No.	Description
200	The environment does not support the use of the function for display with a background color (G250).
201	Address P is not specified with the function for display with a background color (G250).
202	Address P, specified with the function for display with a background color (G250), is incorrect.
203	A parameter other than address P is specified incorrectly with the function for display with a background color (G250).

**N.6.3
 Graphics Display
 Screen Erasure**

Graphics display is used for display with a background color. When character display or graphics display is erased using the screen erase command (G202), the background of the display with a background color may be erased, or the coordinates may change.

The coordinates change when window frame mode is used.

When the screen erase command (G202) is used, the erase color is as follows:

- Color palette 15 when bit 6 (C9WN) of compile parameter No. 9100 is 1
- Color palette 11 when bit 6 (C9WN) of compile parameter No. 9100 is 0

**N.6.4
 Color Palette
 Difference between
 Character Display and
 Graphics Display**

When display with a background color is specified with the CNC system, the color palette value for character display differs from the color palette value for graphics display in standard color specification. The color specified with the color type specification command (G240) differs between character display and graphics display.

[A]

A Bit Cannot be Specified to Read a Parameter., 435
 Addition of Options, 241
 Address Code Table, 87
 Address Functions, 66
 Alarms, 22
 Area of Variable Used, 200
 Argument Designation, 31
 Argument Transfer, 224
 Auxiliary Macro Function, 38

[B]

Basic Operations, 218
 Block Deletion, 86
 Block Writing, 84

[C]

Call Code and Program No., 25
 Calling a Macro Using a T Code, 28
 Calling a Macro with a T Code, 434
 Calling a Subprogram Using Specified Codes, 26
 Calling a Subprogram with an Axis Address, 433
 Calling Format, 110
 Calling Macros O9010-9019 by G Code, 27
 Calling Macros O9020-9029 by M Code, 27
 Calling Macros with a G Code by Specifying the Range, 29
 Calling Subprogram O9000 by T code, 26
 Calling subprograms O9001-9003 by M code , 26
 Character Coordinate System, 460
 Character Display (G243), 431
 Coding, 195
 Color Palette Difference between Character Display and Graphics Display, 481
 Command for Display with a Background Color, 471
 Command Used in the Dynamic Graphic Function, 405
 Commands for Reading/Writing Variables Stored in the Remote Head, 416
 Common Conversational Macro Screen, 142
 Common Conversational Macro Variable, 143
 Common Variables (#100 to #149 and #500 to #531), 43

Compile Paramertes, 446
 Compile Parameters, 468, 479
 Compiling Procedure (Main Flow), 10
 Compiling Procedure Using System P Series (Details), 10
 Compiling Procedure Using System P-G, 233
 Compiler Error Codes (System P), 456
 Connectiing to FA writer, 218
 Continuous Input by Cursor and Page Key, 89
 Controlling Conversational Macro Function Screens (#8510), 432
 Conversational Macro, 35
 Conversational Macro Execution Control Variable #8500, #8550, #8551, 40
 Conversational Macro Function and Auxiliary Macro Function, 34
 Conversational Macro Program Executed Immediately Before Execution, 354
 Conversational/ Auxiliary Macro Alarms, 481
 Coordinates System of Screen, 51
 Correcting Macro Program (Command edit), 220
 Correcting Macro Program (Screen edit), 219
 Cursor Control, 94

[D]

Data on Macro Compiler, 223
 Data Reading of A/D Converter (Series 16/18), 99
 Data Which Can Be Referred to by Macro Programs, 355
 Deleting a Program, 82
 Description, 405, 416
 Detailed Description of Reference System Information, 122
 Details, 370, 371, 396, 398, 400, 401
 Details of Items of the Command for Display with a Background Color (P_), 473
 Details of New User Programs, 247
 Details of the Software Package Associated with the Cutting Condition Data, 257
 Details of the Software Package Associated with Tool Data, 251
 Differences between Series 0 and Series 16 (Conversion from FS0 to FS16), 430
 Display Character Specification, 348
 Display Color Specification (G240), 431
 Display Color Specification Extension, 464
 Display of a Window by a User Program, Depending on the Cursor Position (Not Supported by Ver.1.), 371

Display with a Background Color on the Custom Screen, 470

Displaying a Window by Using a Soft Key on the Tooling Data Screen (Not Supported by Ver.1.), 399

Displaying a Window by Using a User Program and Pressing a Soft Key on the Program Process Data Screen (Not Supported by Ver.1.), 398

Displaying Seven Soft Keys Data on the Twelve Soft Keys Type, 64

Displaying the Basic Menu Screen by a User Program (Not Supported by Ver.1.), 370

Displaying the Conversational Macro Screen when the Power is Turned On, 108

Displaying Variables, 46

[E]

End Code (#8529), 87

End Code (#8539), 80

Equipment Needed for Compile, 8

Equipment Needed for Compiling, 231

Equipment Required for Development, 244

Error Codes, 455

Equipment Connection, 9

Example, 413

Example-1: circular Cutting Input and Execution, 148

Example-2 Example for Key Input and Cursor Control, 185

Executable Macro Program Numbers, 353

Executer Error Code, 459

Executer Parameter, 453

Execution Control Code, 39

Execution Macro, 24, 161

Execution Macro Call Mask Function, 139

Explanation of Program, 168, 212

Explanation of Variable Area, 200

Extending the Function for Inputting and Outputting a Macro Variable, 75

Extension of Number of Display Lines, 467

External Character Registration/Display Function (Series 20), 136

[F]

FANUC Floppy Cassette Control, 77

Flow Chart, 162, 194

Format Used for NC Statements Only for Calling Subprograms, 418

Function Details, 70

Function for Calling a User Program by an Execution Macro, 110

Function for Calling Macros with an Axis Address, 29

Function for Converting Programs used for the Auxiliary and Transfer Processes to NC Statements, 417

Function for Finding a P-CODE Work Number, 109

Function for Identifying the Pressed MDI Key Using a Conversational Macro, 114

Function for Masking the Status Display on the Conventional Macro Screen, 65

Function for Separating UI from UO of the P-CODE Program, 107

Functions for Stopping a Conversational Macro, 144

Functions of the Macro Executor, 47

[G]

G Codes that can be Used by the Conversational and Auxiliary Macros, 438

Graphic Cursor Function, 61

Graphic Painting Function, 59

Graphics Coordinate System, 469

Graphics Display Screen Erasure, 481

[H]

Handling Floppy Disk , 221

[I]

Improvements Featured by Version 4, 419

Inputting and Outputting Macro Variables, 72

Inputting Files to P-G from Floppy Disk, 221

Inputting Macro Program from Keyboard, 218

Intensity Modulation Mode Display of 9" Monochrome CRT, 63

Interface Between the Conversational Program Screen and User Programs, 423

Interface Between the Conversational Programming Menu and User Programs, 343

Interlock Function for Axis Direction, 106

Internal Code, 440

Items of the Command for Display with a Background Color (P_), 472

[K]

Key Input Variable (#8501), 431
 Key Number List, 114
 Key-In Line Control, 100
 Key-Input and Data-Input Control, 92

[L]

Leaving the Screen Unchanged when the  Key is Pressed, 108
 Limitation for Execution Macro, 32
 Limitation on the User's Program, 241
 List for Source Program, 208
 Local Variables (#1 to #33 or for Referencing the P-CODE Variables of Array Type, #1 to #99), 43

[M]

M Code Subprogram Call with Range Specified, 28
 Macro Compiler, 8
 Macro Compiler and Macro Executor, 7
 Macro Compiler/macro ExecutOr with Cap I (Series 16/18), 229
 Macro Compiler Operation (Series 16-A/18-A), 217
 Macro Executor Controls, 23
 Macro Program Example, 147
 Macro Variables, 42, 43, 140
 Macro Variables Used in the Macro Executor Functions, 427
 Modal Call Using G Code, 27
 Modifications Made to the Link File, 420, 426
 Improvements Featured by Fanuc Super Cap II T, 421

[N]

Notes, 87

[O]

Offset Memory C and Extended System Variable of the Workpiece Coordinate System (Series 16/18), 101
 Operation Functions (Logarithm, Exponent, Arcsine, Arccosine), 113

Operation on P-G, 218
 Outputting Files to Floppy Disk, 220

[P]

P-CODE Loader Function, 13
 P-CODE Variables #10000-, 44
 Parameters, 445
 Parameters and System Variables, 354
 PMC Axis Control, 102
 PMC axis Control by Variables, 104
 PMC Read Control Code, 432
 PMC Write Control Code, 432
 Presetting Relative Coordinates, 91
 Processing Array Type P-CODE Variables, 95
 Program Example for PMC Sequence, 171
 Program Numbers Usable with User Programs, 354
 Program Structure, 193

[R]

Reader Puncher Interface Control by Conversational Macro, 69
 Reading a Specified Block, 82
 Reading and Presetting Cutting Time and Cutting Distance by Conversational Macro, 90
 Reading and Presetting Relative Coordinates by Conversational Macro, 91
 Reading and Writing a PMC Address, 67
 Reading Relative Coordinates, 91
 Reading the Background Editing Status, 101
 Reading the Number of Cataloged Programs, 101
 Reading the Remaining Traveling Distance, 101
 Reading the Size of the Free Space in the CNC Program Memory, 101
 Recording of a New Program, 82
 Rectangular Display Function, 61
 Referencing and Reading NC Program with Conversational Macro, 81
 Referencing Common Variables of Custom Macros, 108
 Related Compile Parameters, 480
 Related Items, 480
 Rom Module, 241

[S]

Screen Display Control Code, 53

Screen Display Function, 51

Screen Display on a VGA Graphics Display Unit (Supported by Super CAP Executor Only), 463

Screen Erasure Extension, 466

Screen Layout, 216

Series 16/18 2-Path Dedicated Control Function, 141

Setting a parameter, 370, 399

Setting Parameters, 417

Setting Parameters Used for Compiler, 403

Setting Parameters Used for Compiling, 403

Shift Function for Adjusting the Graphic Screen, 65

Software Package Associated with Process Data, 295

Software Package Associated with the Interface Between User Programs and the System, 343

Software Package Associated with Tool Data and Cutting Condition Data, 251

Software Package for User Program Development, 251

Software Package Related to Process Data, 421

Software Package Related to the Interface Between the System and User Programs, 423

Source Program for Address Variables, 156

Source Program for Character Display, 152

Source Program for Cursor Control, 151

Source Program for Graphic Display and Circle Cutting, 158

Source Program for Input Control, 150

Source Program for Main Program, 148

Source program List, 185

Special Notes, 218

Specification, 190

Specification of Display Characters, 424

Specifications, 295, 421

Standard Macro Program, 200

Standard Routine, 204

Standard Routine List, 200

Starting the Chuck/Tailstock Barrier Setting Screen (Not Supported by Ver.1.), 401

Summary of System Variables (Refer to Operator's Manual for details), 226

System Variable for Conversational Mode/NC Mode Indication, 353

System Variable for Conversational Programming Menu Indication, 353

System Variable for Execution Mode Indication, 354

System Variable for Window ON/OFF State Indication, 353

[T]

Table for Editing by P-G Mate, 12

The Method for Displaying P-CODE Variables #10000 or Larger has been Changed., 437

The ROM Size is Specified Differently., 435

The Use of P-code Dedicated Variables has been Extended., 436

Torque Limit Control, 98

Transferring a Workpiece in Animated Simulation, 414

Type of Screen, 190

Type of User Programs, 246

[U]

User Program Size, 250

Using a User Program to Display Guidance on the Detailed Program Data Screen (Not Supported by Ver.1.), 396

[V]

Variable Data, 191

Variables of Expanded P-CODE (#20000 -), 45

[W]

Window Function, 117

Revision Record

FANUC Series 16/18/20/21 PROGRAMMING MANUAL (Macro Compiler/Macro Executor) (B-61803E-1)

05	Dec., '94	<ul style="list-style-type: none"> • Series 21 was added. • Execution macro call mask function was added in 6.33. 				
04	Mar., '94	<ul style="list-style-type: none"> • Series 16-MODEL B was added. • Graphic cursor function was added in 6.1.4. • Rectangular display function was added in 6.1.5. • Intensity modulation mode display of 9" monochrome CRT was added in 6.1.6. 				
03	May, '93	<ul style="list-style-type: none"> • Series 20 was added. • Arithmetic function was added in 6.29. • MDI key image read function was added in 6.30. • Window function was added in 6.31. 				
02	Oct., '92	<ul style="list-style-type: none"> • Series 18 was added. • All pages were revised. 	07	Aug., '97		<ul style="list-style-type: none"> • Series 16<i>i</i>/18<i>i</i>/21<i>i</i> was added.
01	May, '91	_____	06	Sep., '95		<ul style="list-style-type: none"> • Series 21-MB was added.
Edition	Date	Contents	Edition	Date	Contents	Contents

- *No part of this manual may be reproduced in any form.*
- *All specifications and designs are subject to change without notice.*